

VEICHI



Manual

SD700 Series servo system

VEICHI

Shenzhen Veichi Electric Co., Ltd.

Address: Third Floor, Building ChunSheng, Lingya Industrial Park, No.1 Road,
Shiyan Tangtou Community, Bao'an District, Shenzhen

Phone: +86-755-3686 1688

Fax: +86-755-2968 5680

Suzhou Veichi Electric Co., Ltd.

Address : No.1000 Songjia road, Wuzhong Economic and Technological Development
Zone, Suzhou

Phone: +86-512-6617 1988

Facebook: <https://www.facebook.com/veichiglobal/>

Whatsapp: +86- 138 2881 8903

E-mail: overseas@veichi.com

Web: <http://www.veichi.org>



Wechat Official Account

Version: 2020 V1.4
Veichi Electric Co., Ltd. all rights
reserved, subject to change without notice.

Contents

Contents.....	I
1 Abstract	1
1.1 Series Introduction	1
1.2 Name of Each Part of the Servo Drive	1
1.3 Basic Information of Servo Unit	2
1.4 System Diagram.....	10
1.5 System Configuration Example.....	11
1.6 Drive Nomenclature	12
1.7 Maintenance and Inspection of Servo Unit	13
1.8 Motor Nomenclature.....	14
1.9 Motor Nomenclature.....	16
2 Panel operation	25
2.1 Basic Operation.....	25
2.2 Auxiliary Functions Operation of Fn group.....	26
2.3 Parameter Pn Group's Operation.....	27
2.4 Operations of Monitoring Display Un Group	27
3 Wiring and Connections	29
3.1 Main Circuit Wiring	29
3.2 Motor Power Line Connection.....	33
3.3 CN2 Encoder Connection	35
3.4 Brake Wire Connection	35
3.5 CN7 USB Communication Terminal.....	37
3.6 Connection of CN6A and CN6B Communication Terminal.....	37
3.7 CN5 Full Closed Loop Port	38
3.8 Definition of CN1 Terminal	39
3.9 Switch-Value Input Signal	40
3.10 Switching Output Signal.....	44
3.11 Connection with the Upper Device.....	45
3.12 Position Control Wiring Diagram.....	51
3.13 Speed Control Wiring Diagram	52
3.14 Torque Control Wiring Diagram.....	53
3.15 Regenerative Resistor Connection	54
3.16 Noise and High Harmonic Countermeasures	55
4 Trial operation.....	56
4.1 Inspections and Notes before Trial Operation	56
4.2 JOG trial operation	56
5 Operation.....	57
5. 1 Basic Functions.....	57
5. 2 Position Mode	66
5. 3 Speed Mode.....	75
5. 4 Torque Mode	82
5. 5 Hybrid Control Mode Selection	86

5. 6 Other Output Signals	88
5. 7 Timing Sequence	90
5. 8 Full closed-loop control	92
6 Adjustment	100
6. 1 Adjustments	100
6. 2 Robust Control	103
6. 3 Inertia Recognition	105
6. 4 Intelligent Setting	106
6. 5 Bandwidth Setting	109
6. 6 Manual Adjustment Function	112
7 Accessibility	121
7. 1 List of Auxiliary Functions	121
7.2 Displaying Alarm Logs (Fn000)	121
7.3 Clear Alarm Record (Fn001)	122
7.4 Software Reset (Fn002)	122
7.5 Restoring Factory Parameters (Fn003).....	123
7.5.1 Overview.....	123
7.6 JOG Operation (Fn005).....	123
7.7 Program JOG Operation (Fn006).....	124
7.8 Automatic Adjustment of Instruction Offset (Fn100)	125
7.9 Speed command Offset Manual Adjustment (Fn101)	125
7.10 Profile Torque command Offset Manual Adjustment (Fn102)	126
7.11 Current Offset Automatic Adjustment (Fn103)	126
7.12 Current Offset Manual Adjustment (Fn104)	127
7.13 Initializing the Detection Value of Vibration Detection (Fn105)	128
7.14 Bandwidth Settings (Fn303).....	129
7.15 EasyFFT (Fn401)	129
7.16 Online Vibration Monitoring (Fn402)	130
8 Function Code Instructions	131
8. 1 The principle of origin return function	131
8. 2 Origin return function code	133
8. 3 Origin return method	134
9 Internal location	170
9. 1 Internal multi-stage position control function code parameter setting	170
9. 2 Internal multi-stage position control related function codes.....	171
9. 3 Multi-speed function operating parameters	182
9. 4 Interrupt function	184
9. 5 Overlap function	188
9. 6 Stop function	189
9. 7 Jump function.....	189
9. 8 Jog function.....	190
10 Function Code Instructions.....	192
10. 1 Basic Control Related Pn0 Group Parameters.....	192
10. 2 Gain Related Pn1 Group	198
10. 3 Position Related Pn2 Group Parameters	203
10. 4 Speed Related Pn3 Group Parameters	210


10. 5 Torque Related Pn4 Group Parameters	212
10. 6 Jogging Related Parameters	215
10. 7 Switch Configuration Related Pn6 Group Parameters	216
10. 8 Pn7 Expansion Related Parameters	219
10. 9 Pn8 group internal position/origin return parameters	221
11 Monitoring Parameters	227
12 Fault Code and Countermeasures	231
12. 1 Fault Code	231
12. 2 Warning Code	238
13 Communication.....	239
13. 1 Communication introduction	239
13. 2 RS485 communication protocol description	239
13. 3 Communication frame structure	239
13. 4 Command code and communication data description	240
13. 5 Communication frame error check mode:	242
13. 6 Error message response	242
14 Host Debugging Instruction	243
14. 1 System Requirements	243
14. 2 Main Interface	244
14. 3 Features.....	245
14. 4 Real-Time Monitoring	249
14. 5 Auxiliary Functions.....	249
14. 6 Digital Oscilloscope	258
14. 7 Others	265

1 Abstract

1.1 Series Introduction


SD700 series servo drives are mainly used for the occasion of high speed, high frequency and high positioning accuracy. The servo unit can maximize the performance of the machine in the shortest time, which can improve the production efficiency. In terms of communication, it supports EtherCAT, MECHATROLINK-II, MECHATROLINK-III, CANopen, RS-485 and other mainstream field buses in the market. At the same time, it also has non-standard application functions such as full closed-loop, electronic cam, flying shear, gantry synchronization and so on. USB can be connected to the host computer for debugging, which is convenient and fast.

1.2 Name of Each Part of the Servo Drive




1.3 Basic Information of Servo Unit

Installation Dimensions (Part of the models)




Structure	Machine model	External size(mm)			Installation size(mm)						Installation aperture
		W	H	D	W1	W2	H1	H2	A	B	
SIZE A	SD700-1R1A-**	45	168	170	\	20	160	\	7.5	5	2-M4
	SD700-1R8A-**										
	SD700-3R3A-**										
SIZE B	SD700-5R5A-**	71	168	180	58	58	160	\	6.5	5	3-M4
	SD700-7R6A-**										
	SD700-9R5A-**										
	SD700-2R5D-**										
	SD700-3R8D-**										
SIZE C	SD700-120A-**	92.5	188	182	82.5	75	180	\	5	5	3-M4
	SD700-160A-**										
	SD700-6R0D-**										
	SD700-8R4D-**										
	SD700-110D-**										
SIZE D	SD700-170D-**	120	260	210	100	84.5	250	236	\	\	4-M5
	SD700-240D-**										
	SD700-300D-**										



Structure	Machine model	External size(mm)			Installation size(mm)				Installation aperture
		W	H	D	W1	W2	H1	H2	
SIZE E	SD700-500D-**	210	471	254	140	140	457	434.5	4-M6
	SD700-600D-**								
SIZE F	SD700-700D-**	240	558	310	176	176	544	520	4-M6
	SD700-800D-**								
	SD700-121D-**								

Installation Method



Single installation

Multiple installation



In order to ensure effective cooling by fans and natural convection, please leave enough space around the drive for heat dissipation during installation. To ensure a good heat dissipation effect, please install a fan above the cabinet where the drive is installed to draw out air. The heat dissipation duct in the body is the air inlet under the cabinet and the air outlet above.

Specifications and Electrical Parameters

VEICHI AC SERVO DRIVE

MODEL	SD700-3R3A-PA	IP20
INPUT	MAIN	1PH 200V-240V 50Hz/60Hz 1PH:5.6A
	CONT	1PH 200V-240V 50Hz/60Hz
OUTPUT	3PH 0V-240V 0Hz-500Hz 3.3A	

SER NO 




危险
DANGER


警告
WARNING


注意
CAUTION

请务必按照使用说明书的指示操作。
Must read the manual before installing.
本产品有内置电机过热保护回路。
Motor overtemperature protection is not provided.

断电10分钟内, 以及CHARGE充电指示灯未熄灭, 请勿触摸电源端子部位. 有触电危险。
Risk of electric shock. Don't touch power terminals for 10 minutes after turning OFF or CHARGE indicator is lit.

为了防止触电, 必须连接好地线。
Never fail to connect protective Earth(⊕) terminal.

请勿触摸散热器, 有烫伤的危险。
Hot surface-risk of burn. Don't touch heatsink.

 400-600-0303

苏州伟创电气科技股份有限公司
Suzhou Veichi Electric Co.,Ltd. **MADE IN CHINA**

Scan to know details

Drive specification	1R1A	1R8A	3R3A	5R5A	7R6A	9R5A	2R5D	3R8D
Cabinet volume	A			B				
Continuous output current Arms	1.1	1.8	3.3	5.5	7.6	9.5	2.5	3.8
Maximum output current Arms	3.9	6.3	11.6	16.5	22.8	23.8	7.5	11.4
Drive specification	2R5D	3R8D	6R0D	8R4D	110D	170D	240D	300D
Cabinet volume	C			D				
Continuous output current Arms	2.5	3.8	6	8.4	11	17	24	30
Maximum output current Arms	7.5	11.4	18	25.2	27.5	42.5	60	70
Drive specification	500D	600D	700D	800D	121D	-	-	-
Cabinet volume	E		F					
Continuous output current Arms	50	60	70	80	120	-	-	-
Maximum output current Arms	115	120	140	160	240	-	-	-

Basic specifications


Project		Specification	
Control mode		IGBT PWM control sine wave current drive mode	
Feedback	Rotary servo motor combination	Serial encoder: 17-bit, 23-bit, 24-bit absolute encoder	
	Linear servo motor combination	Incremental grating scale, parallel signal	
Environmental conditions	Ambient temperature	-5 °C to 55 °C (55 °C to 60 °C, can be used after lowering the rated value)	
	Storage temperature	-20 °C ~ 85 °C	
	Use ambient humidity	95% RH or less (no freezing, condensation)	
	Storage humidity	95% RH or less (no freezing, condensation)	
	Vibration resistance	4.9m/s ²	
	Impact strength	19.6m/s ²	
	Protection level	Level IP20	
	Cleanliness	Non-corrosive gas, flammable gas Water, oil, and chemical splashes. Environments with less dust, dust, salt, and metal powder.	
	Altitude	1000m or less (1000m to 2000m, it is necessary to lower the rated value)	
	Other	No static interference, strong electric field, strong magnetic field, radiation, etc.	
Applicable standard		IEC61800-2/-3/-5、IEC61000-2/-3/-4	
Installation type		Base mounting type	Standard
		Shelf mounting type	Need to add accessories
Performance	Speed control rage		1:5000 (the lower limit of the speed control range is the value under the condition that the rated torque load is not stopped)
	Speed volatility	Load fluctuation	±0.01% of rated speed (load fluctuation: 0% to 100%)
		Voltage fluctuation	±0.01% of rated speed (voltage fluctuation: ±10%)
		Temperature fluctuation	±0.1% of rated speed (temperature fluctuation: 25 °C ± 25 °C)
	Torque control accuracy (reproducibility)		±1%
Soft start time setting		0s to 30s (acceleration and deceleration can be set separately)	
Input and output signal	Encoder divided pulse output		Phase A, Phase B, Phase C: Linear Drive Output Number of divided pulses: can be set arbitrarily
	Sequence input signal	Fixed input	Operating voltage range: DC5 V ± 5% Input points: 1 point Encoder absolute value data requires input (SEN) signal
		Assignable input signal	Operating voltage range: DC24V ± 20% Input points: 9 points

			<p>Input method: common collector input, common emitter input</p> <ul style="list-style-type: none"> • Servo ON (/S-ON) • Positive limit (P-OT), negative limit (N-OT) • Alarm Clear (/ALM-RST) • Manual PI-P Control (/P-CON) • Torque limit switching (/TLC) • Motor rotation direction switching input (/SPD-D) signal • Internal set speed switching (/SPD-A, /SPD-B) • Control mode switching (/C-SEL) • Zero fixed (/ZCLAMP) • Command pulse inhibit (/INHIBIT) • Gain switching (/G-SEL) • Command pulse input override switching (/PSEL) <p>(For the detailed list of assignable input signals, see 3.9 switch input signals The assignable signal can change the positive / negative logic)</p>
	Sequential output signal	Fixed output	<p>Operating voltage range: DC5V ~ DC30V Output points: 1 point Output signal: servo alarm (ALM)</p>
		Assignable output signal	<p>Operating voltage range: DC5V ~ DC30V Output points: 3 points (3 points, output mode: optocoupler output (isolated))</p> <ul style="list-style-type: none"> • Positioning completed (/COIN) • Speed consistent detection (/V-CMP) • Rotate checkout (/TGON) • Servo ready (/S-RDY) • Torque limit detection (/CLT) • Speed limit checkout (/VLT) • Brake (/BK) • Warning (/WARN) • Positioning close (/NEAR) • Command pulse input override switching output (/PSELA) <p>(For the detailed list of assignable output signals, see 3.10 switch output signals The assignable signal can change the positive / negative logic)</p>
Communication function	Bus communication (CN6)	RS-485	Standard
		CANopen	Optional
		M-II	Optional
		M-III	Optional


		EtherCAT	Optional		
	USB communication (CN7)	Connecting device	Computer host computer, standard, micro-USB(android USB port)		
		Communication specification	Compliant with USB2.0 specification (12Mbps)		
Display function			CHARGE, 8-segment LED × 5 digits		
Panel operator function			Button switch × 4		
Dynamic brake (DB)			Main circuit power OFF, servo alarm, servo OFF, overtravel (OT) action		
Regeneration treatment			Function can be built in / external		
Overtravel (OT) prevention			Dynamic brake (DB) stop, deceleration stop or free running stop when P-OT and N-OT input action		
Protective function			Over current, over voltage, under voltage, overload, regenerative fault, encoder disconnection, etc.		
Accessibility			Gain adjustment, alarm recording, JOG operation, origin search, etc.		
Control	Speed control	Soft start time setting		0s to 30s (acceleration and deceleration can be set separately)	
		Input signal	Command voltage		Maximum input voltage: ±10V (motor forward rotation when positive voltage command) • Rated speed at DC6V [factory setting] Input gain setting can be changed
			Input resistance		About 66kΩ
			Loop time parameter		30μs
		Internal set speed control	Direction of rotation		Use /SPD-D signal selection
			Speed selection		Use SPD-A/SPD-B signal input (1st to 3rd speed selection) When both sides are off, the internal speed is 0 and the servo stops
	Position control	Feedforward compensation		0% ~ 100%	
		Output signal positioning complete width setting		0 ~ 1073741824 Command unit	
		Input Signal	Instruction Pulse	Command pulse form	Choose one of the following: Symbol + pulse sequence, CW + CCW pulse sequence, 90° phase difference two-phase pulse
	Input form			Linear drive, open collector	

			Maximum input frequency	<ul style="list-style-type: none"> • Line drive Symbol + pulse sequence, CW+CCW pulse sequence: 4Mpps 90° phase difference two-phase pulse: 1Mpps • Open collector Symbol + pulse sequence, CW+CCW pulse sequence: 200kpps 90° phase difference two-phase pulse: 200kpps 	
				Input magnification switching	1 to 100 times
			Clear signal		Position deviation clear Support linear drive, open collector
			Torque Control	Input Signal	Command voltage
			Input resistance	About 66k Ω	
			Loop time parameter	16 μs	

1.4 System Diagram



1.5 System Configuration Example



1.6 Drive Nomenclature

SD700-3R3A-PA*

 A B C D E F G

Field ID	Field Explanation
A	SD: Servo product code
B	700: Product series
C	Current class:
	1R1: 1.1A 1R8: 1.8A 3R3: 3.3A 5R5: 5.5A 7R6: 7.6A 9R5: 9.5A 2R5: 2.5A 3R8: 3.8A 6R0: 6A 8R4: 8.4A 110: 11A 170: 17A 240: 24A 300: 30A 500: 50A 600: 60A 700: 70A 800: 80A 121: 120A
D	Input voltage class:
	A: 220VAC; D: 400VAC
E	Machine type:
	P: pulse type; S: standard type; C: CAN open bus type; N: Ether CAT bus type; M: MECHATROLINK-II bus type; L: MECHATROLINK-III bus type; F: Multi I / O type
F	Supported encoder types:
	A Absolute type
G	Product management number, standard product default.

Different functions between different types:

Code	model	Input pulse	16-bit analog value	Full closed loop	RS485	CAN open	Ether CAT	MECHATROLINK II	MECHATROLINK III
P	Pulse type	√	x	√	√	x	x	x	x
S	Standard type	√	√	√	√	√	x	x	x
C	CAN type	√	x	√	√	√	x	x	x
N	Ether CAT type	x	x	√	√	x	√	x	x
M	MECHATROLINK II type	x	x	√	√	x	x	√	x
L	MECHATROLINK III type	x	x	√	√	x	x	x	√
F	Multi I / O type	√	x	√	√	x	x	x	x

*1.M-II type refers to the servo unit interface specification for MECHATROLINK-II communication command type

*2.M-III type refers to the servo unit interface specification for MECHATROLINK-III communication command

type

Note: Pulse and CANopen type servo are equipped with 12-bit analog quantity as standard.

1.7 Maintenance and Inspection of Servo Unit

The servo system is made up of many parts. The equipment performs its functions only when all the parts work properly. In mechanical parts and electronic parts, some parts need to be maintained depending on the conditions of use. It must be regularly checked or replaced according to the service-time to ensure that the servo motor and servo drive can operate normally for a long time.

Overhaul of Servo Motor

Since the AC servo motor does not have the electric brush so that only a simple daily maintenance is required. The maintenance period in the table is a rough standard. Please judge and determine the most appropriate time for repair according to the conditions of use and use environment.

Inspect items	Inspect time	The essentials of inspection and maintenance	Notes
Vibration and sound confirmation	every day	Tactile and auditory judgments	No increase compared to usual
Appearance overhaul	According to the insult	Erasing with a cloth or cleaning with an air gun	-
Insulation resistance measurement	At least once a year	Disconnect the servo unit and measure the insulation resistance with a 500V megger. Resistance value exceeding 10MΩ is normal	When it is 10MΩ or less, please contact our maintenance department.
Replacement of oil seals	At least once every 5000 hours	Please contact our agents or technical support.	Only servo motor with oil seal.
Comprehensive maintenance	At least once every 20,000 hours or 5 years		-

Overhaul of Servo Drive

Although the servo drive unit does not require daily inspections, it should be overhauled more than once a year.

Maintenance project	Inspect time	The essentials of inspection and maintenance	Notes
Appearance maintenance	more than once a year	No garbage, dust, oil traces, etc.	Erasing with a cloth or cleaning with an air gun
Loose screws		Wiring board, connector mounting screws and so on must not loosen	Please tighten

Approximate Standards for Changing Internal Parts of Servo Units

Electrical and electronic parts are subject to mechanical wear and aging. To ensure safety, please do regular inspections. In addition, please refer to the following table for the standard number of years of replacement, and contact our agency or sales office. After the inspection, we will judge whether we need to replace the parts. The servo unit serviced by our company has its user parameters adjusted back to the factory settings. Be sure to reset the user parameters before use by yourself.

Parts' name	Standard replacement period	Conditions of use
Cooling fan	4~5 years	Ambient temperature: annual average 30°C Load rate: 80% or less Operating rate: 20 hours or less
Smoothing capacitor	7~8 years	
Relay	According to actual use conditions	
Aluminum electrolytic capacitors on printed circuit boards	5 years	

1.8 Motor Nomenclature

VM7-L06A-1R015-D1*


A B C D E F G H I

Field identification	Detailed description
A	Product series: VM7 VM5
B	Inertia level: L: Low M: Medium H: High
C	Mounting flange: 04:40mm 11:110mm 06:60mm 13:130mm 08:80mm 18:180mm 10:100mm 20:200mm 26:263mm
D	Rated voltage: A: 220VAC; D: 400VAC; F: 110VAC

Field identification	Detailed description
E	Rated power: R05: 50W R10: 100W R20: 200W R40:400W R60:600W R75:750W R85: 850W 1R0: 1.0kW 1R2:1.2kW 1R3:1.3kW 1R5:1.5kW 1R8:1.8kW 2R0: 2.0kW 2R3: 2.3kW 2R6: 2.6kW 2R9:2.9kW 4R4:4.4kW 5R5:5.5kW 7R5:7.5kW 011:11kW 015:15kW 020:20kW 022:22kW 030:30kW 037: 37kW 045:45kW 055:55kW
F	Rated speed (RPM) 15: 1500 20: 2000 25: 2500 30: 3000
G	Encoder type: D: 23-Bit multi-turn absolute value optical coding E:24-Bit multi-turn absolute value optical coding Q: 17-Bit single-turn absolute value magnetic coding R: 17-Bit multi-turn absolute value magnetic coding
H	Shaft type: 1: Key shaft, with threaded hole, with oil seal, without band brake 2: Key shaft, with threaded hole, with oil seal, with band brake
I	Internal management number

1.9 Motor Nomenclature


60 flange motor:



Unit:mm

Motor model	L	LL	LR	S	U	W	T	QK
VM7-L06A-R2030-□1	116	86	30	14	3	5	5	22.5
VM7-L06A-R2030-□2	153	123	30	14	3	5	5	22.5
VM7-L06A-R4030-□1	138	108	30	14	3	5	5	22.5
VM7-L06A-R4030-□2	175	145	30	14	3	5	5	22.5
VM7-L06A-R6030-□1	162	132	30	14	3	5	5	22.5
VM7-L06A-R6030-□2	194	164	30	14	3	5	5	22.5


80 flange motor:



Unit: mm

Motor model	L	LL	LR	S	U	W	T	QK
VM7-L08A-R7530-□1L	151	116	35	19	3.5	6	6	25
VM7-L08A-R7530-□2L	194	159	35	19	3.5	6	6	25
VM7-L08A-R7530-□1	151	116	35	19	3.5	6	6	25
VM7-L08A-R7530-□2	194	159	35	19	3.5	6	6	25
VM7-M08A-R7530-□1L	161	126	35	19	3.5	6	6	25
VM7-M08A-R7530-□2L	205	170	35	19	3.5	6	6	25
VM7-M08A-R7530-□1	161	126	35	19	3.5	6	6	25
VM7-M08A-R7530-□2	205	170	35	19	3.5	6	6	25
VM7-L08A-1R030-□1	174	139	35	19	3.5	6	6	25
VM7-L08A-1R030-□2	207	172	35	19	3.5	6	6	25


110 flange motor:



Unit: mm

Motor model	L	LL	LR	S	U	W	T	QK
VM7-M11A-1R230- $\square 1$	193	137	56	19	3.5	6	6	40
VM7-M11A-1R230- $\square 2$	227	171	56	19	3.5	6	6	40
VM7-M11A-1R530- $\square 1$	213	157	56	19	3.5	6	6	40
VM7-M11A-1R530- $\square 2$	247	191	56	19	3.5	6	6	40
VM7-M11A-1R830- $\square 1$	218	162	56	19	3.5	6	6	40
VM7-M11A-1R830- $\square 2$	252	196	56	19	3.5	6	6	40


130 flange motor:



Unit: mm

Motor model	L	LL	LR	S	U	W	T	QK
VM7-M13□-R8515-□1	192	137	55	22	4	8	7	36
VM7-M13□-R8515-□2	229	174	55	22	4	8	7	36
VM7-M13□-1R020-□1	192	137	55	22	4	8	7	36
VM7-M13□-1R020-□2	229	174	55	22	4	8	7	36
VM7-M13□-1R520-□1	207	152	55	22	4	8	7	36
VM7-M13□-1R520-□2	244	189	55	22	4	8	7	36
VM7-M13□-1R815-□1	222	167	55	22	4	8	7	36
VM7-M13□-1R815-□2	259	204	55	22	4	8	7	36
VM7-M13□-2R020-□1	222	167	55	22	4	8	7	36
VM7-M13□-2R020-□2	259	204	55	22	4	8	7	36
VM7-M13□-2R315-□1L	257	202	55	22	4	8	7	36
VM7-M13□-2R315-□2L	299	244	55	22	4	8	7	36
VM7-M13□-2R625-□1L	222	167	55	22	4	8	7	36
VM7-M13□-2R625-□2L	259	204	55	22	4	8	7	36
VM7-M13□-3R825-□1	272	217	55	22	4	8	7	36
VM7-M13□-3R825-□2	314	259	55	22	4	8	7	36


180 flange motor:



Unit: mm

Motor model	L	LL	LR	S	U	W	T	QK
VM5-M18D-2R915-□1	264	185	79	35	5	10	8	65
VM5-M18D-2R915-□1H	264	185	79	35	5	10	8	65
VM5-M18D-2R915-□2	325	246	79	35	5	10	8	65
VM5-M18D-2R915-□2H	325	246	79	35	5	10	8	65
VM5-M18D-4R415-□1	288	209	79	35	5	10	8	65
VM5-M18D-4R415-□1H	288	209	79	35	5	10	8	65
VM5-M18D-4R415-□2	371	292	79	35	5	10	8	65
VM5-M18D-4R415-□2H	371	292	79	35	5	10	8	65
VM5-M18D-5R515-□1	325	246	79	35	5	10	8	65
VM5-M18D-5R515-□2	371	292	79	35	5	10	8	65
VM5-M18D-7R515-□1	371	292	79	35	5	10	8	65
VM5-M18D-7R515-□2	427	348	79	35	5	10	8	65

263 flange motor:




Unit: m m

Motor model	L	LL	LR	S	U	W	T	QK
VM7-M26D-03015-□1FN	640	530	110	48	4.5	14	9	90
VM7-M26D-03715-□1FN	684	574	110	48	4.5	14	9	90
VM7-M26D-04515-□1FN	727	617	110	48	4.5	14	9	90
VM7-M26D-05515-□1FN	795	685	110	48	4.5	14	9	90

Note 2: 263 flange motor grounding plate set (except vm7-m26d-05515, other models are optional)

Model: S25F Material code: 2800050433


130 flange B shaft motor:



Unit: mm

Motor model	L	LL	LR	S	U	W	T	QK
VM7-M13□-R8515-□B	192	137	55	19	3.5	6	6	25
VM7-M13□-R8515-□B	229	174	55	19	3.5	6	6	25
VM7-M13□-1R815-□B	222	167	55	24	4	8	7	36
VM7-M13□-1R815-□B	259	204	55	24	4	8	7	36

180 flange B shaft motor:



Unit:mm

Motor model	L	LL	LR	S	U	W	T	QK
VM5-M18D-5R515-□1BH	359	246	113	42	5	12	8	96
VM5-M18D-5R515-□2BH	405	292	113	42	5	12	8	96
VM5-M18D-7R515-□1BH	405	292	113	42	5	12	8	96
VM5-M18D-7R515-□2BH	461	348	113	42	5	12	8	96

2 Panel operation


2.1 Basic Operation

2.1.1 Keys' Names and Functions of the Panel Operator

The panel operator consists of panel monitor and keys.

The panel operator could display condition, operate the accessory functions, set parameters and monitor the motions of the drive unit.

The panel operator keys' names and functions are shown as below:




Keys' name	Functions
MODE/SET key	Shift the function modes
	Confirm parameter settings
	Operate the accessory functions
▲ JP key	Select parameters up or increase the value, switch between high, medium, and low segment values in multiple segment display parameters
▼ DOWN key	Select parameters down or decrease the value, switch between high, medium, and low segment values in multiple segment display parameters
DATA/SHIFT key	Press and hold the DATA/SHIFT button for about 1 second to enter or exit
	Short press to move to the left one (when flashing)



Pressing the Up and Down keys at the same time could reset the drive alarm, but remember to exclude causes of the alarm before reset the drive alarm.

2.12 Functions Switch

Press the MODE/SET key, the function will be switched like this shown as below:



2.1.3 Status Display

The method of judging the status display is as follows:


Display	Meaning	Display	Meaning
oFF	Means that the drive is OFF	noT	Means that the input signal(N-OT) is an open circuit
oN	Means that the drive is ON	CS0	Flashing displays fault code, more details on the "fault code"
PoT	Means that the input signal(P-OT) is an open circuit	oN & tSt	No-motor testing function displays the running status alternately, more details in this function

Display	Meaning	Display	Meaning
oB	It lights on when the control power is ON and lights off when OFF	oB	It lights on when the main circuit is ON and lights off when OFF
oB	Speed control: speed outputs(/V-CMP) are absolutely same Position control: it lights on when the positioning is OK(/COIN) Torque control: it lights on all the time	oB	It lights on when the rotation detection outputs(/TGON)
oB	It lights on when the drive is OFF and lights off when ON	oB	Speed control: it lights on when the speed command inputs Position control: it lights on when the position command inputs Torque control: it lights on when the torque command inputs Position control: it lights on when the pulse clear signal outputs

2.2 Auxiliary Functions Operation of Fn group

Auxiliary functions are about performing the settings and adjustment of the drive unit. The panel operator displays the numbers which begin with Fn.


Let's take the JOG function (Fn005) as an example to explain the operating method of the auxiliary functions:



2.3 Parameter Pn Group's Operation


(1) When the setting range is within 5-digit numbers.

Taking the setting method when the setting value of speed loop gain (PN101) is changed from 40.0 to 100.0 as an example to illustrate the operation method of parameter group.



(2) When the setting range is beyond 6-digit numbers:


Since the panel operator can only display 5 digits, the setting value above 6 digits is shown in the figure below.



They appear only when the number is a negative

2.4 Operations of Monitoring Display Un Group


This function could monitor setting command values of the drive unit, the status of input and output signals and internal conditions of the drive unit. The panel operator displays the numbers which begin with Un, then let's take this function as an example to explain the operating method of the monitoring display: when the motor speed (Un000) is 3000rpm:



If you need the digital tube to automatically display relevant information after each power on of the driver, please set the parameter PN003 (default 0xFF) as the relevant value. For example, if the drive needs to display the motor speed automatically after power on, you can set PN003 to 00000 (motor speed). For the setting values corresponding to each monitoring information, see "monitoring display"

3 Wiring and Connections

3.1 Main Circuit Wiring



3.1.1 Terminals Explanation:


Needle code	Signal name	Functions
1	L1 (R/L)	Main circuit power input
2	L2 (S/N)	Main circuit power input
3	L3 (T)	Main circuit power input
4	L1C	Control power input
5	L2C	Control power input
6	B1/+	Internal and external braking resistor pins/ DC power supply positive, after rectification
7	B2(PB)	Energy-consumption braking output
8	B3	Pin of internal brake resistor
9	-	Negative of DC power supply
10	U	Motor power U phase
11	V	Motor power V phase
12	W	Motor power W phase
Casing	Grounding	Safely grounding



The A volume main circuit wiring can only be connected to single phase (provide two terminals), please pay attention to the correct wiring according to the wiring identification when wiring.


3. 1. 2 Wiring Diagram

A-volume single-phase wiring diagram




- Please make this emergency stop protection circuit.
- Electromagnetic contactor package surge absorbing device at both ends.
- 220V system input voltage range: AC 220V(-15%)~240(+10%)
- 400V system input voltage range: AC 380V(-15%)~440(+10%)
- When using an external regenerative braking resistor, connect it by the dotted line in the figure.
- Please connect the U, V, W, and output of the drive correctly according to the motor cable phase sequence of the servo motor. The wrong phase sequence will cause the drive to malfunction.
- Be sure to ground the servo drive to avoid electrical damage.
- The 24V power supply for electromagnetic braking needs to be provided by the user and must be isolated from the 12~24V power supply for the control signal.
- Pay attention to the connection of the freewheeling diode. Reversing the positive and negative poles may damage the driver.

B/C/D-volume three-phase wiring diagram





- Please make this emergency stop protection circuit.
- Electromagnetic contactor package surge absorbing device at both ends.
- 220V system input voltage range: AC 220V(-15%)~240(+10%)
- 400V system input voltage range: AC 380V(-15%)~440(+10%)
- Please connect the U, V, W, and output of the drive correctly according to the motor cable phase sequence of the servo motor. The wrong phase sequence will cause the drive to malfunction.
- Do not disconnect short wires between B2 and B3 unless using an external regenerative braking resistor.
- When using an external regenerative braking resistor, disconnect the short wiring between B2 and B3 and connect them by the dotted line in the figure.
- Be sure to ground the servo drive to avoid electrical damage.
- The 24V power supply for electromagnetic braking needs to be provided by the user and must be isolated from the 12~24V power supply for the control signal.
- Pay attention to the connection of the freewheeling diode. Reversing the positive and negative poles may damage the driver.

E/F-volume three-phase wiring diagram





- Please make this emergency stop protection circuit.
- Electromagnetic contactor package surge absorbing device at both ends.
- 400V system input voltage range: AC 380V(-15%)~440(+10%)
- Please connect the U, V, W, and output of the drive correctly according to the motor cable phase sequence of the servo motor. The wrong phase sequence will cause the drive to malfunction.
- When using external regenerative resistor, connect according to the dotted line in the figure (Pb / +).
- Be sure to ground the servo drive to avoid electrical damage
- The 24V power supply for electromagnetic braking needs to be provided by the user and must be isolated from the 12~24V power supply for the control signal.
- Pay attention to the connection of the freewheeling diode. Reversing the positive and negative poles may damage the driver.

3.2 Motor Power Line Connection




View A


Definition of 40 / 60 / 80 flange motor power line		
Signal definition	A-end pin number	Core color
U	D	Blue
V	E	Brown
W	F	Red
PE	G	Yellow-green




Definition of 100 / 110 / 130 / V5 series 180 flange motor power line		
Signal definition	A-end pin number	Core color
U	D	Blue
V	E	Brown
W	F	Red
PE	G	Yellow-green




Definition of D2M+VM7 series D2 180 flange motor power line		
Signal definition	pin number	Core color
U	D	Blue
V	E	Brown
W	F	Red
PE	G	Yellow-green
BAKE+	A	Red
BAKE-	B	Black



Power line definition of 110 / 130 flange motor with brake		
Signal definition	pin number	Core color
U	F	Blue
V	I	Brown
W	B	Red
PE	E	Yellow-green
BAKE+	G	Red
BAKE-	H	Black



3.3 CN2 Encoder Connection




Note:

1. When welding the encoder, please pay attention to the definition of A-end and B-end pins (as shown in the table above). The encoder wire uses twisted pair shielded wire, and the shielding layers at both ends of the wire should be grounded.

2. When using the multi-turn absolute encoder, please pay attention to the positive and negative electrodes of the battery. It is recommended to use the lithium battery with rated voltage of 3.6V and rated capacity of 2.7AH.


3.4 Brake Wire Connection

Mounting flange	Braking power	Mounting flange	Braking power
40 Flange	7W	110 Flange	15W
60 Flange	10W	130 Flange	20W
80 Flange	15W	180 Flange	30W





Braking cable model: VB-* -B*

Signal definition	Definition of the braking cable of 40 /60 /80 flange motor with brake	
	Pin number	Core color
BAKE+	1	Orange
BAKE-	2	Grey




Braking cable model: VB-+-D*

	Definition of the braking cable of V5 series 180 flange motor with brake(D2)		
	Signal definition	Pin number	Core color
	BAKE+	1	Orange
	BAKE-	2	Grey



Braking cable model: VB-+-C*


	Definition of the braking cable of 180 flange motor with brake(E2M)		
	Signal definition	Pin number	Core color
	BAKE+	1	Orange
	BAKE-	2	Grey



110 flange and 130 flange, as well as VM7 series 180 flange motors with brake hold brake wire and power line together (9 pins), we only need to select the matching power line


3.5 CN7 USB Communication Terminal

Note: ordinary Android cable with data transmission function can also be used



Pin number	Name	Function
1	VBUS	External power supply + 5V
2	D-	Data-
3	D+	Data+
4	-	None
5	GND	Signal ground

3.6 Connection of CN6A and CN6B Communication Terminal



According to different models, the definition of the port is different. When using it, you need to confirm the model before defining the interface. For model identification, please refer to "1.6 driver naming".

The field identification bit E is P: pulse type; S: standard type; C: CANopen bus type.

CN6A/CN6B port definition					
Pin number	Signal name	Function	Pin number	Signal name	Function
1	CANH	CAN Data+	6	-	
2	CANL	CAN Data -	7	GND	485 Signal ground
3	CANG	CAN Signal ground	8	-	-
4	485-	485 Data -	Shell	Shield	Shield
5	485+	485 Data +			

The field identification bit E is M: MECHATROLINK-II bus type.

CN6A/CN6B port definition					
Pin number	Signal name	Function	Pin number	Signal name	Function
1	SRD+	M-II Data +	6	-	-
2	SRD-	M-II Data -	7	-	-

3	-	-	8	-	-
4	-	-	Shell	Shield	Shield
5	-	-			

The field identification bit E is E: EtherCAT bus type; L: MECHATROLINK-III bus type.

CN6A/CN6B port definition					
Pin number	Signal name	Function	Pin number	Signal name	Function
1	TX+	Data transmission+	6	RX-	Data reception -
2	TX-	Data transmission-	7	-	-
3	RX+	Data reception +	8	-	-
4	-	-	Shell	Shield	Shield
5	-	-			

As for using multiple drivers at the same time, the cascade mode is CN6A in and CN6B out. Failure to follow the cascade mode of up in and down out may lead to abnormal communication. Please try to ensure that the length of the cascaded cable is less than 50cm, and the CN6B of the last one should be connected with the terminal resistance (Only CANopen bus/ Mechatrolink-II bus/ RS-485 bus should be considered with terminal resistance).

3.7 CN5 Full Closed Loop Port

2500 line encoder and full closed loop interface (differential input)					
Pin number	Signal name	Function	Pin number	Signal name	Function
1	EA-	Full closed loop signal EA-	9	-	-
2	EB-	Full closed loop signal EB-	10	-	-
3	EZ-	Full closed loop signal EZ-	11	-	-
4	-	-	12	-	-
5	-	-	13	0V	Encoder power supply 0V
6	EA+	Full closed loop signal EA+	14		
7	EB+	Full closed loop signal EB+	15	5V	Encoder power supply 5V
8	EZ+	Full closed loop signal EZ+	Shell	Shield	-

3.8 Definition of CN1 Terminal

			1	SG	Signal ground				26	/SO1-(V-CMP)	General sequence control output 2
2	SG	Signal ground				27	/SO2+(TGON+)	General sequence control output 2			
4	SEN	Requirement input of encoder absolute data (SEN)	3	PL1	OC power output of command pulse	29	/SO3+(S-RDY+)	General sequence control output 3	28	/SO2-(TGON-)	General sequence control output 2
6	SG	Signal ground	5	V-REF	Speed command input	31	ALM+	Servo alarm output	30	/SO3-(S-RDY-)	General sequence control output 3
8	/PULS	Pulse command input	7	PULS	Pulse command input	33	PAO	A phase of encoder pulse division output	32	ALM-	Servo alarm output
10	SG	Signal ground	9	T-REF	Torque command input	35	PBO	B phase of encoder pulse division output	34	/PAO	A phase of encoder pulse division output
12	/SIGN	Sign command input	11	SIGN	Sign command input	37	STO	Safe torque limit	36	/PBO	B phase of encoder pulse division output
14	/CLR	Clearance input of position deviation	13	PL2	OC power output of command pulse	39	/SI9	General sequence control input 9	38	/SI8	General sequence control input 8
16	OC	OC power input of command pulse	15	CLR	Clearance input of position deviation	41	/SI3 (P-CON)	General sequence control input 3	40	/SI0 (/S-ON)	General sequence control input 0
18	PL3	OC power output of command pulse	17	OCS	OC input of pulse direction	43	/SI2 (N-OT)	General sequence control input 2	42	/SI1 (P-OT)	General sequence control input 1
20	/PCO	C phase of encoder pulse division output	19	PCO	C phase of encoder pulse division output	45	/SI5 (/P-CL)	General sequence control input 5	44	/SI4 (/ALM-RTS)	General sequence control input 4
22	BAT-	Battery(-) of absolute encoder	21	BAT+	Battery(+) of absolute encoder	47	+24VIN	Power input of sequence control input signal	46	/SI6 (/N-CL)	General sequence control input 6
24	OCS	OC input of pulse clearance	23	OCZ	OC output of Z phase pulse division	49	/PSO	Position output of absolute encoder	48	PSO	Position output of absolute encoder
			25	/SO1+(V-CMP+)	General sequence control output 1				50	TH	Overheat protection input of linear motor



Caution

When tightening the screw of cN1 terminal, the torque shall not be greater than 0.2N. M, otherwise, the screw will slide

3.9 Switch-Value Input Signal

3.9.1 Input Signal Explanation

Control mode	Signal name	Needle number	Function number and description	
Normal	/S-ON	Allocated signal (38~46)	0x01	Control signal of servo motor ON/OFF (power on/off)
	POT		0x02	Prohibited forward rotation When the mechanical movement exceeds the movable range, stop the servo motor drive (over travel prevention function)
	NOT		0x03	Prohibited reverse rotation When the mechanical movement exceeds the movable range, stop the servo motor drive (over-travel prevention function)
	/ALM-RST		0x04	Alarm clear
	/P-CON		0x05	When the P action command signal is ON, the speed control loop is switched from PI (proportional, integral) control to P (proportional) control.
	/TLC		0x06	Torque limit switching use when changing the torque limit during operation
	/SPD-D		0x08	used to change the direction of motor control in internal speed,
	/SPD-A		0x09	When used as internal speed mode, it is used to select the internal speed command
	/SPD-B		0x0A	
	/C-SEL		0x0B	Control mode switching, it is used as a switching control mode when the control mode is mixed mode
	/ZCLAMP		0x0C	Zero fixed signal speed mode, it is used as a fixed zero.
	/INHIBIT		0x0D	Pulse input inhibit when used in position mode, it is used as disable pulse input count
	/G-SEL		0x0E	Gain switching gain switching to manual gain switching used as a switching gain
	/PSEL		0x10	Command pulse input rate switch, when in position mode, it is used to switch pulse input rate signal
	+24VIN	47	Use when the sequence signal is input with the control power supply. Operating voltage range: +11V to +25V (please provide your own +24V power supply.)	
	BAT+ BAT-	21 22	Spare battery connection pin for absolute encoder. Note: do not connect when using an encoder cable with a battery pack.	
Speed	V-REF	5 (6)	Enter the speed command. Maximum input voltage: ± 10V	
Position	PULS	7	Set any of the speed following input pulse patterns. Symbol + pulse sequence CW+CCW pulse sequence 90° phase difference 2-phase pulse	
	/PULS	8		
	SIGN	11		
	/SIGN	12		
	CLR /CLR	15 14	Clear position deviation during position control	
Torque	T-REF	9 (10)	Enter the torque command and the maximum input voltage: ±10V	

3.9.2 Input Signal Configuration

1. The digital input signal distribution mode is internally fixed (Pn600=0). The function servo unit of each input signal is internally fixed and cannot be changed. When selecting different control modes, the functions of the pins are different as shown in the following table:

Control mode (Pn000)	NO. of CN1 pins							
	40	42	43	41	44	45	46	38/ 39
0- position control	/S-ON servo enable	P-OT forward limit	N-OT reverse limit	/P-CON proportional control	/ALM-RST alarm clear	/TLC torque limit switching	Reserved	Invalid
1- analog speed								
2- torque control								
3- internal speed				/SPD-D internal speed command direction selection		/SPD-A internal speed command selection A	/SPD-B internal speed command selection B	
4- internal speed <-> analog speed								
5- internal speed <-> position								
6- internal speed <-> torque								
7- position <-> analog speed				/C-SEL control mode switching		Reserved		
8- position <-> torque								
9- torque <-> analog speed				/ZCLAMP zero fixed		/TLC torque limit switching		
10- speed <-> speed control with zero fixed function								
11- speed <-> position control with command pulse inhibit function	/INHIBIT command pulse prohibition							

2. The switching input signal distribution mode is the parameter configuration (Pn600=1 default parameter). The function of each input signal is configured by the user and is set by parameters Pn601~Pn609.

(a) Default setting

Function code	NO. of CN1 pins	Default function
Pn601	40	0x01: Servo enable

Pn602	42	0x02: Can run in forward direction
Pn603	43	0x03: Can run in reverse direction
Pn604	41	0x05: Manual P, PI control
Pn605	44	0x04: Alarm clear
Pn606	45	0x06: Torque limit switching
Pn607	46	0x07: Reserved
Pn608	39	0x00: Invalid
Pn609	38	

(b) Negation

The driver provides reverse input signal switching function in order to facilitate wiring:

1. Take the servo enable (/S-ON) as an example, the default setting is Pn601=0x01. When the signal is ON, the servo is enabled. When the setting is Pn601=0x101, the servo is disabled when the signal is ON.
2. Take the positive travel limit (POT) as an example, the default setting is Pn602=0x02. When the signal is OFF, the servo positive stroke limit is set. If the setting is Pn602=0x102, the servo forward stroke limit is released when the signal is OFF.



1. **Signal ON:** The state when the digital input signal (/S-ON, etc.) is connected to the ground terminal of the external +24 VIN power supply
2. **Signal OFF:** The status when the digital input signal (/S-ON, etc.) is disconnected from the ground terminal of the external +24VIN power supply
3. The positive travel limit (POT)/negative travel limit (NOT) in the digital input signal is the OFF valid signal, and the other input signal is the ON effective signal.

c) Always valid


Through the setting of parameters Pn610, Pn611 and Pn612, the configured input signal can always be valid. For example, when Pn610=0x01 (servo enable), the servo is always in the enabled ON state after power-on, and the external enable signal (/S-ON) does not take effect.



If the same function is configured on different pin numbers, Er.040 will be reported (parameter setting error alarm). Refer to "Diagnostics Codes and Countermeasures" for related alarms and processing methods.

3.9.3 Confirming the Input Status

The status of the input signal can be checked by input signal monitoring (Un100). The Un100 segment display and corresponding pin numbers are as follows:



Display LED	Number of input pin	Signal name (factory configuration)
1	CN1-40	/S-ON
2	CN1-41	/P-CON
3	CN1-42	P-OT
4	CN1-43	N-OT
5	CN1-44	/ALM-RST
6	CN1-45	/TLC
7	CN1-46	Reserved
8	CN1-39	Invalid
9	CN1-38	Invalid

The upper SEG (LED) lights up when the input signal is OFF.

The lower SEG (LED) lights up when the input signal is ON.

The value (address: 0XE100) read over the communication is hexadecimal, for example, the read value is 0x1FE. Under the default input configuration, it means that the input of /S-ON (CN1-40) is ON, that is, servo enable, and the input of other input pins is OFF.

3.10 Switching Output Signal

3.10.1 Output Signal Explanation

Control mode	Signal name	Needle number	Function number and explanation	
Usual	/TGON	Allocate Allocated signal 25(+) 26(-) 27(+) 28(-) 29(+) 30(-)	0x03	ON (closed) when the speed of the servo motor is higher than the set value.
	/S-RDY		0x00	ON (closed) when servo ON (/S-ON) signal is acceptable.
	/CLT		0x04	Torque limit ON (closed) when the motor output torque is limited.
	/VLT		0x05	In the speed limit, the motor speed is ON after closing the speed limit (closed).
	/BK		0x06	Brake interlocking, the output of the motor is ON during operation. Refer to "Retaining the brake" for timing details.
	/WARN		0x07	Warning output
Speed	/V-CMP			0x02
Location	/COIN		0x01	Positioning completed output ON (closed) when the difference between the command pulse number and the servomotor movement amount (position deviation) is lower than the position reach range.
	/PSELA		0x09	Command pulse override switching can be switched to operate with the value of the input command pulse n times (Pn203).
	/NEAR		0x08	Positioning close, output ON (closed) when the difference between the positioning command pulse number and the servo motor movement amount (position deviation) is lower than the position proximity signal.
	PL1 PL2 PL3	3 13 18		Position pulse is power supply for open collector command.
Usual	ALM+ ALM-	31(+) 32(-)		OFF (disconnected) at alarm (Output logic can be changed by parameter)
	PAO /PAO	33 34		Frequency division output A phase signal
	PBO /PBO	35 36		Frequency division output B phase signal
	PCO /PCO	19 20		Frequency division output C phase signal

3.10.2 Output Signal Configuration

a) Default configuration

The function of each output signal is configured by the user and is set by parameters Pn613 ~ Pn615. The default functions are as follows:

Function code	CN1 pin number	Default function
Pn613	25/26	0x00: Servo ready
Pn614	27/28	0x01: Positioning completed
Pn615	29/30	0x02: Consistent speed

b) Negation

1. General switch output signal inversion function, take the servo ready signal (/S-RDY) as an example, default setting Pn613=0x00, servo ready and then the output signal is ON; change the setting Pn613=0x100, the servo is ready, then the output signal is OFF.


2. The alarm output signal (ALM) is the output of the fixed pin number. The default setting is Pn622.1=0. If the servo alarm occurs, the output signal will be OFF. If the change is set to Pn622.1=1, the servo alarm will output the signal ON.



1. Pn622.1 indicates the first bit of parameter Pn622. Refer to function code parameter explanation for details.
2. The signal that is not output is in the "invalid" state. Example speed control, positioning complete (/COIN) signal is "invalid".
3. If the polarity of the brake signal (/BK) is reversed and used with positive logic, the brake will not be actuated when the signal line is broken. If you have to use this setting, be sure to check the operation to ensure that there are no safety issues.
4. When multiple signals are distributed on the same output circuit, the output will be XORed.

3.10.3 Confirming the Output Status

The status of the output signal can be confirmed by the output signal monitor (Un101). The Un101 segment display and corresponding pin numbers are as follows:



Display LED	The number of input pin	Signal name (factory setting)
1	CN1-31、 32	ALM
2	CN1-25、 26	/S-RDY
3	CN1-27、 28	/COIN
4	CN1-29、 30	/V-CMP

The upper SEG (LED) lights up when the output signal is OFF.

The lower SEG (LED) lights up when the output signal is ON.

The value read through communication is hexadecimal, for example: the read value is 0X8, and the default output configuration means that ALM (CN1-31, 32) output is ON, that is, no alarm output. /S-RDY (CN1-25, 26) output is OFF, that is servo ready. /COIN (CN1-27, 28) output is OFF, that is positioning is completed. /V-CMP (CN1-29 / 30) output is ON, and the speed is not consistent.

3.11 Connection with the Upper Device

3.11.1 Analog Input Circuit 3


The following describes the 5-6 (speed command input) and 9-10 (torque command input) terminals of the CN1 connector.

Analog signals are speed commands or torque command signals. The input impedance is as follows.

Speed command input: about $66k\Omega$

Torque command input: about $66k\Omega$

The maximum allowable input signal voltage is $\pm 10V$




The above wiring is an example of wiring during forward rotation.

3.11.2 Position Instruction Input Circuit

The following describes the 7-8 (command pulse input), 11-12 (command symbol input), and 14-15 (clear input) terminals of the CN1 connector. The output circuit of the open command pulse and position deviation clear signal from the host device may be one of the linear driver output and the open collector output.

Connection example of linear drive output




The differential pulse input signal voltage is $\pm 3.3V$ and the maximum frequency is 4MHz. This signal transmission

method has the best anti-noise capability. It is recommended to use this connection preferentially.


Connection example of open collector output

External 24V power supply:

1. control module is NPN type (common cathode):




2. control modules is PNP type (common anode):




Caution If the linear drive input port is used to receive the external 24 V collector open circuit input signal, please connect a 2K resistor in series to limit the current in the circuit, otherwise, the linear drive input port will be damaged

Internal 15V power supply:

1 control module is NPN type (common cathode):




2 control modules is PNP type (common anode):




3.11.3 Sequence Control Input Circuit

The following describes the 38 to 46 terminals of the CN1 port. Connect via a relay or open collector transistor circuit. When using a relay connection, select the relay for the minute current. If you do not use a minute current relay, it will cause poor contact.

Examples for Relay Circuit



Examples for Open-Collector Circuits





*Note: The external power supply (DC24V) must have a capacity of 50 mA or more.
The input loop of the servo unit uses a bidirectional optocoupler. Please select the sink circuit connection or the source circuit connection according to the specifications of the machine.*

3.11.4 Sequence Output Loop

Servo unit signal output circuit is the following three kinds:


1. Open collector output circuit

The output signal (SEN, OCZ) is an open collector transistor output circuit. Please receive through optocoupler circuit, relay circuit or linear receiver circuit.




2. Optocoupler output circuit

The brake linkage (/BK), servo alarm (ALM), servo ready (/S-RDY) and other sequence output signals belong to the optocoupler output circuit. Connect via relay or line receiver circuit.




3.Linear drive output circuit

The following describes the 33-34 (phase A signal), 35-36 (phase B signal), and 19-20 (phase C signal) terminals of the CN1 port. The output signal (PAO, /PAO, PBO, /PBO) and the origin pulse signal (PCO, /PCO) of the encoder's serial data are converted into two-phase (A-phase, B-phase) pulses and output through the line driver output circuit. On the upper device side, please use a linear receiver circuit.



3.12 Position Control Wiring Diagram



*1. \neq is twisted shields;

*2. DC24V power should be prepared by user. And double insulation or reinforced insulation equipment should be used for DC24V power.

*3. Connected while using absolute encoder. But never connect backup battery while using encoder cables with battery unit

*4. Output signal should be received by linear receiver.


Note: while using 24V breaker, DC24V power should be separated from the power for input and output signal (CN1). Please prepare other power individually, otherwise, there may be misoperation of input and output signal while power on.

!

Cautions

If the input voltage of the linear drive input port is greater than 12V, please connect the appropriate current limiting resistor in series in the circuit, otherwise, the linear drive input port may be damaged.

3.13 Speed Control Wiring Diagram



*1. is the twisted shields


*2. DC24V power should be prepared by user. And double insulation or reinforced insulation equipment should be used for DC24V power.

*3. Connected while using absolute encoder. But never connect backup battery while using encoder cables with battery unit.

*4. Output signal should be received by linear receiver.

Note: while using 24V breaker, DC24V power should be separated from the power for input and output signal (CN1). Please prepare other power individually, otherwise, there may be misoperation of input and output signal while power on.

3.14 Torque Control Wiring Diagram



FG Shields are connected to connector shell
Frame grounded

*1. $\frac{\text{---}}{\text{---}}$ is the twisted shields

*2. DC24V power should be prepared by user. And double insulation or reinforced insulation equipments should be used for DC24V power.

*3. Connected while using absolute encoder. But never connect backup battery while using encoder cables with battery unit.

*4. Output signal should be received by linear receiver.

Note: While using 24V breaker, DC24V power should be separated from the power for input and output signal (CN1). Please prepare other power individually, otherwise, there may be misoperation of input and output signal while power on.

3.15 Regenerative Resistor Connection

When the regenerative energy processing capacity is insufficient, connect an external regenerative resistor as required to set the regenerative resistor capacity (Pn012) and the regenerative resistor value(Pn013).

3.15.1 Connection of Regenerative Resistors

The driver models 1R1A,1R7A,3R3A,500D,600D,700D,800D,121D have no built-in regenerative resistor. When a regenerative resistor is externally connected, the resistor is connected to the B1/+ and B2 terminals. Refer to "A single-phase wiring diagram". Or it is connected to the + and PB terminals. Refer to "E/F single-phase wiring diagram"

In addition to 1R1A, 1R7A,3R3A,500D,600D,700D,800D,121D, the driver model has a built-in regenerative resistor. When the internal regenerative resistor does not meet the requirements, a regenerative resistor can be connected to remove the short wiring between the B2-B3 terminals and connect the external regenerative resistor to the driver. For B1/+, B2 terminals, refer to "B/C/D volume three-phase wiring diagram".

3.15.2 Selection of Regenerative Resistor

Mode	Break resistor	internal resistor	Minimal of external resistor	Maximal of external resistor
SD700-1R1A	380	/	40	400
SD700-1R7A		/	40	200
SD700-3R3A		/	40	100
SD700-5R5A		40Ω 60W	25	70
SD700-7R6A		40Ω 60W	15	50
SD700-9R5A		40Ω 60W	15	40
SD700-120A		30Ω 200W	10	30
SD700-160A		30Ω 200W	10	30
SD700-2R5D	700	80Ω 60W	80	225
SD700-3R8D		80Ω 60W	55	180
SD700-6R0D		40Ω 60W	35	110
SD700-8R4D		40Ω 60W	25	85
SD700-110D		40Ω 60W	25	70
SD700-170D		30Ω 100W	30	50
SD700-240D		30Ω 200W	15	40
SD700-300D		30Ω 200W	15	30
SD700-500D		/	10	20
SD700-600D		/	10	20
SD700-700D		/	10	15
SD700-800D		/	10	15
SD700-121D	/	8	12	

Note: When external braking resistor is needed, please select the resistance value of the braking resistor

according to the above table. Select the braking resistor's power according to the braking frequency of the field conditions and the cooling conditions of the braking resistor, you could consult factory if you have any problem.

3.16 Noise and High Harmonic Countermeasures

The following describes noise and harmonic measures:

This servo unit has a built-in microprocessor. Therefore, it may be subject to noise from its peripheral equipment.

To prevent mutual noise interference between the servo unit and its peripheral devices, the following measures to prevent noise interference can be taken as required.

- Set the input command device and noise filter as close to the servo unit as possible.
- Be sure to connect a surge suppressor to the coils of relays, solenoids, and electromagnetic contactors.
- Do not use the same bushing for the main circuit cable and the input/output signal cable/encoder cable, and do not bind them together. When wired, the main circuit cable and the input/output signal cable/encoder cable should be separated by more than 30cm.
- Do not use the same power supply as the electric welder or EDM machine. Even if it is not the same power supply, connect a noise filter to the input side of the main circuit power cable and the control power cable when there is a high-frequency generator nearby.

4 Trial operation

4.1 Inspections and Notes before Trail Operation

In order to ensure the safe and correct trail operation, please check the programs as below before that:

4.1.1 Conditions of the Servo Motor:

You need to check and confirm all programs as below, if there is any problem, please handle it properly before that trail operation

- Are the Settings, wires and connections correct?
- Is there any looseness in each fastening part?
- When you use servo motors with oil seals, is the oil seal damaged? Is it smeared with organic oil?
- Is the brake released beforehand when it is a servo motor with a holding brake?

4.1.2 Conditions of the Servo Drive

You need to check and confirm all programs as below, if there is any problem, please handle it properly before that trail operation.

- Are the Settings, wires and connections correct?
- Is the supply voltage of the servo unit normal?
- Is the driver status display interface free of warnings, alarms, etc.?

4.1.3 Installation

- Install the servo motor and servo unit according to the installation conditions.
- The servo motor may fall when it rotates, so be sure to fix it on the machine.
- Be sure to leave the servo motor at no load.

4.2 JOG trail operation


The trial run refers to the JOG operation of the servo motor unit. The purpose of the single trial operation of the servo motor is to confirm whether the servo unit and the servo motor are correctly connected and whether the servo motor is operating normally. Confirm the following points before running:

- 1.The motor is in the enabled state and the jog operation is invalid during the operation.
- 2.We suggest that the load inertia is not greater than 30 times of the motor inertia, or it could possibly cause strong mechanical vibration.
- 3.The Pn500, Pn310, Pn311 parameters set JOG speed, acceleration and deceleration time.

5 Operation

5.1 Basic Functions

5.1.1 Quick Guide



5.1.2 Servo Enable and Over-Travel Setting

Enable

Set the servo ON (/S-ON) signal that controls servo motor electrification / non-electrification. Pin numbers can be configured by parameters Pn601 ~ Pn609, and are always configured effectively by parameters Pn610~Pn612. Refer to "Input Signal Configuration". The servo internal enable could also be turned on by setting parameter pn001 (internal enable switch) to 1.

Over-travel

The over-travel prevention function of the servo unit refers to the safety function of forcibly stopping the servo motor by inputting a signal of the limit switch when the mechanical movement part exceeds the safe movement range. For rotary applications such as circular tables and conveyors, the over-travel function may not be required. In this case, the input signal wiring for over-travel is also not required.

1. In the one-way over-travel state, commands in the opposite direction of over-travel can be received.
2. In position control, when the servo motor stops due to over-travel, the position deviation remains unchanged. To clear the position deviation, a clear signal (CLR) must be input.

1. Signal Setting

Pin numbers can be configured by parameters Pn601~Pn609, and are always configured effectively by parameters Pn610~Pn612. Refer to "Input Signal Configuration".

2. Stop Mode

When an over-travel occurs, the servo motor can be stopped by any of the following three methods.

- Dynamic brake (DB) stop: By short the electrical circuit, the servo motor can be quickly stopped.
- Deceleration stop: Decelerate to stop with the emergency stop torque (Pn053).
- Free stop: Naturally stopped due to friction when the motor rotates.

The servo motor status after stopping is divided into the following two types.

- Free running state: A state that naturally stops due to friction when the motor rotates.
- Zero-position fixed state: The state of maintaining zero position in the position loop.

When the over-travel occurs, select the stopping method of the servo motor through Pn007. Refer to description of parameter Pn007.




It cannot decelerate to stop under torque control. Pn007 is set to DB or free stop. After the servo motor stops, it enters into free running state.

3. Warning Checkout

The over-travel warning function is a function that detects the over-travel warning (AL9A0) after entering into over-travel state when the servo is ON. With this function, the servo unit can transmit the information of detecting over-travel to the upper device even if the over-travel signal is input instantaneously. When using this function, please set Pn006=1 "Detect over-travel warning".

The timing of over-travel warning checkout



A. The warning is detected when an over-travel occurs in the same direction with command.

B. When an over-travel in the opposite direction to the command is issued, no warning is detected. For example, under the forward command, no warning will be issued even if the N-OT signal (reverse drive prohibited) is turned ON while moving.

C. When there is no instruction, an over-travel warning in the forward or reverse direction will be detected.

D. When the servo is turned off, no warning will be detected even if it enters the over-travel state.

E. In the over-travel state, no warning is detected when the servo is switched from the servo OFF state to the servo ON state.

F. The warning I/O will remain output for 1 second after the over-travel status is released and will be automatically cleared afterwards.

5. 1. 3 Motor Rotation Direction

The actual rotation direction of the servo motor can be switched by Pn002 without changing the polarity of the speed command/position command. At this time, although the rotation direction of the motor is changed, the polarity of the output signal from the servo unit, such as the encoder frequency-divided pulse output, does not change.

Pn002=0 in the factory setting (forward rotation direction) indicates that the counterclockwise rotation (CCW) is positive when looking at the servo motor cover.

Function code	Parameter name	Range	Default	Unit	Communication address	Enabled method
Pn002	Motor rotation direction selection	0~1	0	-	0x0002	Restart effect
	Faces to the motor end cover: 0- Counter clockwise direction is positive 1- Clockwise direction is positive					

5. 1. 4 Stop Mode

1. Stop mode when Servo OFF or in type 1 alarms

It can be selected by Pn004 when servo OFF or in type 1 alarm.

- Dynamic brake (DB) stops and maintains DB status: By shorting the electrical circuit, the servo motor can be stopped in an emergency, and the DB status is maintained after stop.
- Dynamic brake (DB) stops and DB status is released: By shorting the electrical circuit, the servo motor can be stopped in an emergency and the DB status is released after stop.
- Free running stop: Free stop due to the friction while motor rotates.



When the servo motor stops or rotates at a very low speed, when the dynamic brake is selected to stop, it will be the same as the free stop, and no braking force will be generated.

2. Stop mode when in type 2 alarms


Type 2 alarms can select zero speed stop in addition to the servo motor OFF method and type 1 alarm stop method. Refer to the description of parameter Pn053 for the torque limit at zero speed stop.




The setting of zero speed stop mode is valid only for position control and speed control.

5. 1. 5 Electromagnetic Brake

The brake is a part that holds the position when the servo unit power is off so that the moving part of the machine does not move due to its own weight or external force. It is built into the servo motor with a brake. Please use it as shown below.




The brake has a delay time for operation. Please ensure the brake operation time while ON and OFF.



1. Different types of brakes may have slightly different time for holding brakes and loosening brakes.
2. Please ensure that the input command is after the brake opening operation time to ensure the accuracy of the command
3. When the motor is locked, the motor lock time (Pn008) can be set to ensure that the motor does not operate during braking, to prevent the danger of motor action when the servo is off.

Motor running / BK signal OFF timing sequence

When an alarm occurs during servo motor rotation, the servo motor stops and the brake signal (/BK) turns OFF. At this time, the brake signal (/BK) output time can be adjusted by setting the brake command output speed value (Pn010) and the servo OFF-brake command waiting time (Pn009).




1. When the motor enters the non-energized state, when the motor speed is lower than the set value of Pn010, the /BK signal output time is subject to 1

2. When the motor enters the non-energized state, the set time of Pn009 is passed first, and the output time of /BK signal is subject to 2

Motor stopping locked / BK signal OFF timing sequence

When the servo motor is stopped, the brake (/BK) signal and the servo ON (/S-ON) signal are turned off at the same time. By setting Pn008, it is possible to change the time from when the servo ON (/S-ON) signal is OFF to when the motor actually enters the non-energized state.



The alarm occurs when the servo is locked, which has nothing to do with the setting, and the motor immediately enters the state of non-energized. At this time, the machine may move before holding brake due to the delay of brake action

5. 1. 6 Regenerative Resistor

Refer to "Regeneration Resistor Connection" for the wiring method. When connecting an external regenerative resistor, set parameters Pn012 and Pn013 according to the external resistance.

The regenerative resistor capacity should be set to a value that matches the allowable capacity of the connected external regenerative resistor. The setting differs depending on the cooling condition of the external regenerative resistor.

- Self-cooling method (natural convection cooling): Set to 20% or less of the regenerative resistor capacity (W).


- Forced air cooling: Set to 50% or less of the regenerative resistor capacity (W).

Example: When the capacity of the self-cooling external regenerative resistor is 100W, the setting value is $100W \times 20\% = 20W$. Therefore, set Pn012 = 2 (setting unit: 10W).

5. 1. 7 Overload

This servo unit can change the detection time of the overload warning (AL.910) and overload (continuous maximum) alarm (Er. 720). However, it is not possible to change the detection value of the overload characteristic and overload (instantaneous maximum) alarm (Er. 710).

1. Change the detection time of overload warning (AL.910)



The factory overload warning detection time is 20% of the overload alarm detection time. The overload warning detection time can be changed by changing the overload warning value (Pn015). In addition, we can use it as an overload protection function corresponding to the system, which can improve the security of the system.

For example, as shown below, after changing the overload warning value (Pn015) from 20% to 50%, the overload warning detection time is half (50%) of the overload alarm detection time.


2. Change the detection time of the overload warning (Er. 720)

The overload (continuous maximum) alarm (Er. 720) can be detected in advance to prevent motor overload.

Detecting the overload alarm by using the "Base current after derated", the overload alarm detection time can be shortened. The detection value of the overload (instantaneous maximum) alarm (Er. 710) cannot be changed.

Motor base current after derated = motor current threshold when starting calculating overload alarm (default 1.15 times motor) * derated value of motor overload detection base current (Pn016).

For example, as shown in the following figure, after setting Pn016 to 50%, the overload alarm can be detected earlier because the motor overload is calculated from 50% of the base current. When the value of Pn016 is changed, the overload warning detection time is changed, because the overload alarm detection time will be changed.



5. 1. 8 Multi-turn Absolute Encoder

When using a multi-turn absolute encoder, an absolute value detection system can be constructed by a host device. With the absolute value detection system, it is not necessary to perform an origin return operation every time the power is turned on. In order to save the position data of the absolute encoder, a battery unit needs to be installed. Install the battery on the battery unit of the encoder cable with battery unit. When the encoder cable with battery unit is not used, please install the battery in the upper device. The battery voltage is 3.2V ~ 4.5V. If the battery voltage is lower than 3.2V, the battery under voltage alarm (Er.830) will appear. Generally, 3.6v/3.7v lithium battery is selected.

Related setting parameters:

Function code	Name	Range	Default	Unit	Communication address	Effective mode
Pn040	Method to use absolute encoder	0~1	0	—	0x0040	Restart effect
	0 - Use an absolute encoder as an absolute encoder: If the motor is an absolute multi-turn encoder, set this parameter to 0, so to use the multi-turn absolute function. This function must be used with battery encoder line, otherwise the servo will alarm (Er. 810) 1 - Use an absolute encoder as an incremental encoder: When used as an incremental encoder, the power-off position won't be recorded and warning or alarm corresponding to multiple revolutions won't happen either when the battery is under-voltage or the motor encoder cable is unplugged					
Pn041	Absolute encoder battery under voltage alarm/warning selection	0~1	0	—	0x0041	Restart effect
	0 - Set the low battery voltage as a fault: The driver powers up/resets for 4~9 seconds to monitor the battery status. Under-voltage will be reported as an under voltage alarm (Er. 830). Over time will not be detected. The drive fails to operate normally under fault condition 1 - Set the low battery voltage as a warning: Under-voltage (below 3.2V) will be reported as an under voltage warning (Al.930). It will always monitor the battery voltage and can be self-recovery meanwhile enable running is out of restriction.					
Pn792	Absolute encoder operation	0~2	0	—	0x0792	Restart effect
	0 - No action 1 - Write motor parameters to encoder EEPROM. After modifying the motor parameters, this operation is required to write the data to the encoder 2 - Clear multi-turn encoder turns: if you use it initially or replace or insert/remove the battery during power-down of the drive, after power on again, an encoder backup alarm (Er. 810) will be reported. This parameter is set to 2 when disable the servo (if it is set to 2, the parameter will automatically return to 0, which is normal.) and it can only be cleared after re-powered. The alarm clearing will clear the encoder multi turn value and retain the single cycle value as well. 3 - Clear encoder alarm only (Er.860 / Er.810): after the encoder alarms, setting this parameter to 3					

can only clear the encoder alarm, but not clear the encoder multi turn value
--

Related monitoring data:

Monitoring code	Monitoring name	Range	Unit	Communication address
Un010	Absolute encoder single-turn value	0x80000000~0x7FFF FFFF	Encoder unit	0xE010
	Display single-turn absolute position value of the absolute encoder			
Un011	Absolute encoder multi-turn value	0x80000000~0x7FFF FFFF	-	0xE011
	Display the number of turns of the multi-turn encoder when the multi turn encoder is selected. After the multi turn encoder is reset, the value is 0.			



1. When replacing the battery, please make sure that the driver is powered on and the encoder cable is connected normally. Otherwise, the encoder will display the backup warning when reconnecting the encoder. The absolute position will be lost at this time and it needs to clear the number of turns of the multi-turn encoder.

5. 1. 9 Torque Limit

1. Torque limit method

To protect the machine etc., the output torque can be limited and set by parameter Pn050. The torque limit can be in the following five ways:

Pn050	Torque limit method description	Related parameters
0	Analog torque (torque mode is invalid)	Pn405
1	Maximum torque limit 1	Pn051
2	FWD max torque limit 1 (Pn051), REV max torque limit 2	Pn051 、 Pn052
3	Max torque limit 1 when the on-off torque limit switching (TLC) signal is OFF; Max torque limit 2 when ON.	Pn051 、 Pn052
4	Limit by internal torque command (under torque mode)	Pn410



1. The input voltage of the analog command for torque limit has no polarity. Take the absolute value of the voltage and use the torque limit value corresponding to this absolute value for both the forward direction and reverse direction.
2. The set value exceeds the maximum torque of the servo motor used, and the actual torque is also limited to the maximum torque of the servo motor.
3. When the set value is too small, the torque may be insufficient when the servo motor accelerates or decelerates. Please set according to the actual situation.

2. Torque limit output signal

The torque limit (/CLT) output is ON means the motor output torque is in the limit state. This signal can be used to confirm the status of the current torque limit of the motor. Refer to "Sequence Output Circuit" for the wiring method. Refer to "Switching Output Signal" for parameter setting.


3. Torque limit under voltage

When the instantaneous power failure and the main circuit power supply voltage are insufficient for a short period of time, the main circuit DC voltage inside the servo unit is below the specified value, an under-voltage warning is detected, and the function for limiting the output torque can be selected. Related parameters are as below:

Function code	Parameters name	Range	Default	Unit	Communication address	Effective mode
Pn045	Under-voltage function selection	0x00~0x02	0	—	0x0045	Restart effect
	0- No detection of main circuit descent warning 1- Detection of main circuit descent warning 2- Detect main circuit descent warning and perform torque limit. The relevant torque limit is matched with Pn046/Pn047. For details, refer to "Main circuit under-voltage torque limit".					
Pn046	Torque limit when main circuit voltage drops	0~100	50	%	0x0046	Immediately
	According to the under voltage warning, it will impose the torque limit inside the servo unit.					
Pn047	Torque limit release time when main circuit voltage drops	0~1000	100	ms	0x0047	Immediately
	After the under-voltage warning signal releases, the torque limit value is controlled inside the servo unit according to the set time. For details, refer to "Under-voltage limit of the main circuit".					

By combining this function with the setting function of the instantaneous stop holding time, when the power supply voltage is insufficient, it could avoid the shutdown due to the alarm and continue the operation without performing the power restoration operation.

Under-voltage warning, apply torque limit inside the servo unit. After receiving the under voltage warning release signal, the torque limit value is controlled inside the servo unit according to the set release time. The logical timing is as follows:




1: 560V when 400VAC
2: 400V when 400VAC

5. 2 Position Mode

For details on the wiring related to the position mode; see "Connection Control Example under Position Control". The position control is selected by the control mode selection (Pn000 = 0, factory default).

5. 2. 1 Quick Guide



5. 2. 2 Basic Settings






The following describes the basic settings for position control:

1. Command pulse filter selection

The appropriate command pulse filter can be selected according to the frequency of the highest pulse in operation, which can be set by parameter Pn200. For details, refer to the relevant description of the function code. If the selection is not appropriate, the received pulse of the servo unit may be lost or increased.

2. Pulse input form

Select the corresponding pulse input form according to the pulse output form of the host system.



Function code	Setting value	Command form	Forward instruction	Reverse instruction
Pn201	0	Pulse + direction positive logic	PULS (CN1-7)  SIGN (CN1-11)  High level	PULS (CN1-7)  SIGN (CN1-11)  Low level
	1	CW+CCW positive logic	CW (CN1-7)  Low level CCW (CN1-11) 	CW (CN1-7)  CCW (CN1-11)  Low level
	4	Quadrature encoding 4 times	 90° Phase A  Phase B 	 90° Phase A (CN1-7)  Phase B (CN1-11) 
	5	Pulse + direction negative logic	PULS (CN1-7)  SIGN (CN1-11)  Low level	PULS (CN1-7)  SIGN (CN1-11)  High level
	6	CW+CCW negative logic	CW (CN1-7)  High level CCW (CN1-11) 	CW (CN1-7)  CCW (CN1-11)  High level

3. Electronic gear ratio

When the reduction ratio of the motor shaft and the load side is n/m (When the motor rotates m turns, the load shaft rotates n turns), the set value of the electronic gear ratio can be obtained by the following formula (Take 23 bit absolute encoder as an example):

$$\text{Electronic gear ratio} \frac{B}{A} = \frac{Pn204}{Pn206} = \frac{\text{Encoder resolution}}{\text{Load shaft movement amount in 1 rotation (command unit)}} \times \frac{m}{n}$$

Steps	Content	Composition of mechanical system		
		Ball screw	Rotary table	Belt + Pulley

		 <p>Reference unit: 0.001 mm Load shaft Encoder: 24 bits Ball screw lead: 6 mm</p>	 <p>Reference unit: 0.01° Load shaft Gear ratio: 1/100 Encoder: 24 bits</p>	 <p>Reference unit: 0.005 mm Load shaft Gear ratio: 1/50 Pulley dia.: 100 mm Encoder: 24 bits</p>
1	Machine specification	Ball screw lead: 6mm Reduction ratio: 1/1	Rotation angle per turn: 360° Reduction ratio: 1/100	Pulley dia: 100mm (Pulley circumference: 314mm) Reduction ratio: 1/50
2	Encoder resolution	8388608 (23-bit) 16777216 (24-bit) 131072 (17-bit)	8388608 (23-bit) 16777216 (24-bit) 131072 (17-bit)	8388608 (23-bit) 16777216 (24-bit) 131072 (17-bit)
3	Command unit	0.001mm (1mm)	0.01°	0.005mm (5mm)
4	Load shaft movement amount in 1 rotation (command unit)	6mm/0.001mm = 6000	360°/0.01° = 36000	314mm/0.005mm = 62800
5	Electronic gear ratio	$\frac{B}{A} = \frac{8388608}{6000} \times \frac{1}{1}$	$\frac{B}{A} = \frac{8388608}{36000} \times \frac{100}{1}$	$\frac{B}{A} = \frac{8388608}{62800} \times \frac{50}{1}$
6	Parameter	Pn204: 8388608	Pn204: 838860800	Pn204:419430400
		Pn206: 6000	Pn206: 36000	Pn206: 62800



1. When the numerator of electronic gear ratio (pn204) is set to 0, the value set by the denominator of electronic gear ratio (pn206) is the number of command pulses corresponding to one cycle of motor operation. For example, if pn204 (numerator) is set to 0 and pn206 (denominator) is set to 10000, it means that the upper computer (PLC, motion controller, etc.) sends 10000 pulses, and the servo motor rotates one cycle..

2. If $0.001 \leq$ electronic gear ratio (B / a) ≤ 83887 exceeds the setting range, an "abnormal parameter setting (er.040) alarm" will occur (for 23 bit encoder).

5. 2. 3 Deviation Clearance

The deviation clear signal (/CLR) is the input signal to clear the servo unit deviation counter.

1. Clear signal wiring

Deviation clear signal wiring can be divided into linear driver output and open collector output. Please refer to "Position Command Input Circuit" for wiring details.

2. Setting the deviation clear mode

The state of the clear signal is set by Pn272.

Function code	Parameter name	Range	Defaults	Unit	Communication address	Effective mode
Pn272	Position deviation clear mode	0x00~0x03	0	—	0x0272	restart effective
	Set the clear mode of the switching value position deviation clear signal (/CLR): 0-clear when level ON 1-rising edge OFF->ON clear 2-clear when level OFF 3-falling edge clears when ON->OFF					

When Pn272 = 0 or 2, in order to perform clear signal processing, the amplitude of the clear signal must be 250 μ s or more.

When Pn272 = 1 or 3, in order to perform clear signal processing, the amplitude of the clear signal must be 20 μ s or more.



When set to keep clear, the servo lock function is invalid. Therefore, the servo motor will rotate at a slight speed due to the drift pulse in the speed loop.

3. Deviation clearing method selection

Depending on the status of the servo unit, you can choose when to clear the position deviation. Set the deviation clearing method by Pn273:

Function code	Parameter name	Range	Defaults	Unit	Mailing address	Effective mode
Pn273	Position deviation clear mode selection	0x00~0x02	0	—	0x0273	Restart effective
	Set the mode of the deviation clearing: 0- servo OFF, alarm, / CLR signal position deviation can be cleared 1- / CLR signal position deviation can be cleared 2- alarm, / CLR signal position deviation can be cleared 3- cleared in case of servo OFF, alarm and limit 4- position deviation clearing 5- cleared in case of servo OFF, alarm and limit					

Refer to the "Deviation Clearance" for details on the pulse amplitude of the clear signal.

In position control, the positional deviation remains unchanged when the servo motor is stopped due to the travel limit.



Under position mode, the servo motor stops running due to the travel limit. If the host computer continues to send pulses, the position deviation will increase continuously and the position deviation will not be cleared automatically. When excluding the travel limit, the motor may gallop. Please pay attention to the safety of the motor action, or use the position deviation command to clear the position deviation.

5. 2. 4 Command Pulse Inhibition

The command pulse inhibition (/INHIBIT) function is a function that prohibits the command pulse input from being counted during position control. When this function is enabled, the servo unit enters a state where it cannot receive the command pulse input.

1. Configuration of Command Pulse Inhibition

The signal is not configured in the factory default switch configuration. Therefore, the pin number configuration (0x0D) needs to be performed by parameters Pn601~Pn609.

2. Command pulse inhibited wiring

The command pulse inhibited signal is a universally configurable switching value input. Refer to "Sequence Input Circuit" for wiring details.

5. 2. 5 Positioning Approach

When positioning is near to (/NEAR) position control, the host device may receive the positioning approach signal before confirming the positioning completion signal, so as to prepare for the sequence of actions after the positioning is completed. In this way, the time required to complete the positioning can be shortened. This signal is usually used in pair with the positioning completion signal. Refer to the "Positioning completion" instruction for the positioning completion signal.

1. Configuration of positioning approach

The signal is not configured in the factory default switching value output configuration. Therefore, the pin number configuration (0x08) needs to be performed by parameters Pn613~Pn615.

When the difference between the command pulse number of the host device and the movement amount of the servo motor (position deviation) is lower than the setting value of Pn260 (position approach signal width), the signal is output when the positioning approach output condition is satisfied.

2. Position approach wiring

The positioning approach signal is a general configurable switching value output. Refer to "Sequence Output Circuit" for wiring details

5. 2. 6 Positioning Completion

In position control, it indicates the servo motor positioning completed (/COIN) signal.

1. Positioning completion configuration

In the factory default digital output configuration, the signal is configured as CN1's 27th and 28th pin numbers (Pn614=0x01) by default. Please confirm before use.

Function code	Parameter name	Range	Defaults	Unit	Communication address	When enabled
Pn262	Positioning completion range	0~1073741824	7	Command unit	0x0262 0x0263	Immediately
	In the position control, the servo motor positioning completion signal will be output when the difference between the command pulse number from the host device and the servo motor movement amount (position deviation) is lower than the set value; that means the host device confirming positioning has been completed.					


If the set value is too large, the constant positioning completion signal may be output when the deviation is small during low-speed operation. When outputting a constant positioning signal, please lower the setting until the signal is no longer output.

Function code	Parameter name	Range	Defaults	Unit	Communication address	When enabled
---------------	----------------	-------	----------	------	-----------------------	--------------

Pn274	Positioning completion signal output time	0x00~0x02	0	—	0x0274	Restart effective
	Set the output timing of the positioning completion signal /COIN: 0- Output when the absolute value of position deviation is less than the positioning completion range (Pn262). 1- Output when the absolute value of the position deviation is smaller than the positioning completion range (Pn262) and the command after the position command filtering is 0. 2- Output When the absolute value of the position deviation is smaller than the positioning completion range (Pn262) and the positioning command input is 0.					

2. Positioning completion wiring

The positioning completion signal is a universally configurable switching value output. For wiring details, refer to "Sequence Output Circuit".



5. 2. 7 Command Pulse Input Magnification Switching

The ON/OFF of the command pulse input magnification switch input signal (/PSEL) could switch the input magnification of the position command pulse to 1 and n times (n = 1 to 100). The switching of the magnification can be confirmed by output signal(/PSELA) of command pulse input magnification switching.

Please switch the command pulse magnification while the position command pulse is 0. If the position command pulse is not 0, the servo motor may cause a position deviation or cause a position loss.


1. Configuration of command pulse input magnification switching

The signal is not configured in the factory default switching value input configuration. Therefore, the pin number configuration (0x10) needs to be performed by parameters Pn601~Pn609.

Function code	Parameter name	Range	defaults	unit	Communication address	When enabled
Pn203	Command pulse input magnification	1~100	1	x1 times	0x0203	Immediately

Set the command pulse input magnification value to be used in conjunction with ON/OFF of the command pulse magnification switching signal for switching the position command pulse input magnification to 1 or the multiple of this parameter setting.

Note: If the input pulse frequency is too low or the value is set too large, the speed may not be steady.



2. Command pulse input magnification switching wiring

The command pulse input magnification signal is a universally configurable switching value input. Refer to "Sequence Input Circuit" for wiring details.

5. 2. 8 Smooth Settings


The command pulse input is filtered to make the rotation of the servo motor smoother. This function is more effective in the following situations:

- The host device that issued the command does not perform acceleration / deceleration
- When the instruction pulse frequency is extremely low
- When the position command smoothing function is set, the system response may be affected. Please use it reasonably.

The filter-related parameter settings are as follows:

Function code	Parameter name	Range	default	unit	Communication address	When enabled
Pn211	Position command low-pass filter time constant	0~655	0	ms	0x0211	After stop
	This parameter is used to set the time constant of the first-order low-pass filter corresponding to the position command and it can reduce the mechanical shock in the case of abrupt changes in the input pulse command frequency by setting this parameter. If set too large, the servo response will slow down.					
Pn212	Moving average filtering time of position command	0~1000	0	ms	0x0212	After stop
	This parameter is used to set the time constant of the moving average filter of the corresponding position instruction. It can reduce the mechanical shock in the case of abrupt changes in the input pulse command frequency by setting this parameter. If set too large, the servo response will slow down.					

The difference between the position command low-pass filter time constant and the position command's moving average filter time is shown below:



5. 2. 9 Frequency-division Output

The encoder frequency-division pulse output is a signal that is output to the outside in the form of a two-phase pulse (phase A, phase B) with a phase difference of 90° after processing the signal from the encoder inside the servo unit. Used as position feedback in the host device.

Frequency-division pulse output parameter configuration

Set the encoder frequency division pulse output as follows:

Function code	Parameter name	Range	defaults	unit	Communication address	When enabled
Pn070	Encoder frequency division pulses	16~4194304	2048	-	0x0070	restart effective
	The number of pulses per cycle from the encoder is divided by frequency in accordance with the parameter. Please set it according to the system specifications of the machine and host device.					
Pn072	Divided frequency output reversed	0~1	0	-	0x0072	restart effective
	A/B pulse phase sequence logic when setting forward/reverse: 0- Don't revert the pulse output: When forward, A leads B 1- Revert the pulse output: When forward, B leads A					

1. Frequency division pulse

The number of pulses per revolution from the encoder is processed inside the servo unit and then divided down and output to the set value of Pn070.


The encoder's number of divided pulse outputs is set according to the system specifications of the machine and the host device.

The setting of frequency division pulse number of encoder will be limited by the resolution of encoder. The maximum


output frequency of frequency division pulse of encoder shall not exceed 4MHz (after 4 times frequency), as shown in the table below:

Pulse Number of Encoder Frequency Division (pulse/r)	Setting increment	Encoder Resolution			Upper Limit of motor Speed (r/min)
		17 bits	20 bits	23 bits	
16~16384	1	o	o	o	6000
16386~32768	2	o	o	o	3000
32772~65536	4	o	o	o	1500
65544~131072	8	o	o	o	750
131088~262144	16	-	o	o	375
262176~524288	32	-	o	o	187
524352~1048576	64	-	o	o	93
1048704~2097152	128	-	-	o	46
2097408~4194304	256	-	-	o	23

Output example: When Pn070=16 (16 pulses per revolution), an output example of the encoder frequency-division pulse output A-phase (PAO) signal and the encoder frequency-division pulse output B-phase (PBO) signal is shown below.



2. Frequency division output reversed




Parameter Pn072 can be set to revert the logic of the AB phase signal of the divided output pulse.

The amplitude of the Z-phase pulse varies with the number of encoder frequency-division pulses (Pn070) and is consistent with the amplitude of the A-phase. The smaller the frequency division pulse number (Pn070) is, the wider the Z-phase pulse amplitude is.

Frequency division pulse output wiring

Refer to the "Linear Drive Output Circuit" for details on the wiring of the frequency division pulse output.




The output voltage of frequency division pulse of encoder is differential $\pm 5V$. Because the pulse width of C (Z) phase pulse is very small, it is difficult to measure the change with a multimeter. It is necessary to cooperate with the high-speed input point of the host computer to capture the pulse, or set the encoder frequency division pulse number (Pn070) to the minimum (16), and then measure with the multimeter voltage level.

5.3 Speed Mode

For details on speed mode wiring, refer to "Speed Control Wiring Diagram". It is selected by control mode selection (Pn000).

The speed control mode is divided into internal speed mode (Pn000=3) and analog speed mode (Pn000=1) according to the command source.

5. 3. 1 Quick Guide



5. 3. 2 Basic Settings

Control mode selection (Pn000=3), internal speed mode, internal speed command direction selection based on switching value input (/SPD-D), internal speed command selection A (/SPD-A), internal speed command selection B (/SPD-B) configuration to select the speed instruction.


The control mode selection (Pn000 = 1) is the analog speed mode. The speed command is given according to the voltage of V-REF (CN1-5, CN1-6) and the set value of analog speed command gain Pn300.

1. Analog speed

Function code	Parameter name	Range	Default	Unit	Communication Address	When enabled
Pn300	Analog speed command gain	150~3000	600	0.01V/rated speed	0x0300	Immediately
	This parameter is used to set the analog voltage value (V-REF) required by speed command so as to make the servo motor speed to rated value. The default is the rated speed corresponded with given voltage 6V. Caution: Do not apply the voltage that exceeds -10~10V, otherwise, it may cause damage to the driver.					
Pn301	Analog speed command reverse	0~1	0	-	0x0301	Immediately
	Set the voltage polarity of the analog speed command: 0 -Positive polarity: positive voltage corresponds to positive speed command. 1- Negative polarity: positive voltage corresponds to negative speed command.					
Pn302	Analog speed instruction filter time	0~655.35	0.40	ms	0x0302	Immediately
	The function could be set to smooth the speed command when one delay filter is applied to the analog speed command (V-REF) input and usually it does not need to be changed. If the set value is too large, the responsiveness may decrease. Please set this parameter while confirming the response.					
Pn303	Analog speed command dead zone range	0~3	0	V	0x0303	Immediately
	In the analog speed control, even if the input command is 0V, the servo motor may rotate at a slight speed. This is because there is a slight deviation in the commands inside the servo unit. This error can be eliminated by setting an appropriate analog speed command dead zone.					


Set the analog voltage value of the speed command (V-REF, refer to "Analog Input Circuit" for wiring) that makes the speed of the servo motor rated via the analog speed command gain Pn300.

Example: The factory default parameter Pn300 = 600 (6V corresponds to the rated speed (assuming 3000rpm). If the V-REF input voltage is 1V, the speed command corresponds to 500rpm. If 3V is input, the speed command corresponds to 1500rpm.



Adjustment of instruction offset:

When analog speed control is used, even if the command is 0V, the servo motor may rotate at a slight speed. This is because there is a slight deviation in the instructions inside the servo unit. This slight deviation is called "offset".



There are two methods of automatic adjustment and manual adjustment of offset adjustment. Automatic adjustment is automatic adjusting command offset (Fn100) and manual adjustment is manually adjusting command offset (Fn101). For details, refer to "Auxiliary Functions".



1. When adjusting automatically, be sure to adjust the command offset while the servo is OFF and upper device (PLC, button, etc.) gives 0V voltage command.
2. When adjusting manually, observe the running status of the motor while adjusting under servo ON.
3. The offset adjustment value will not be initialized if performing the factory restore.

2. Internal speed

Function code	Parameter name	Range	Default	Unit	Communication address	When enabled
Pn304 Pn305 Pn306	Internal speed 1	0~10000	100	rpm	0x0304	Immediately
	Internal speed 2	0~10000	200	rpm	0x0305	Immediately
	Internal speed 3	0~10000	300	rpm	0x0306	Immediately
When operating in the internal speed mode, the servo unit provides 3 internal speed commands and selects A and B through the switching value internal speed command. When the switching value internal speed command selects A and B at OFF state, the internal speed is default as 0.						


The speed is selected through the switching value input signal control:

Switching value input signal			Direction of speed command	Speed instruction size
/SPD-D	/SPD-A	/SPD-B		
OFF	OFF	OFF	Positive	0
	OFF	ON		Internal speed 1(Pn304)
	ON	ON		Internal speed 2(Pn305)
	ON	OFF		Internal speed 3(Pn306)
ON	OFF	OFF	Negative	0
	OFF	ON		Internal speed 1(Pn304)
	ON	ON		Internal speed 2(Pn305)
	ON	OFF		Internal speed 3(Pn306)

5. 3. 3 Soft Start

The soft start function is a speed command that converts a step speed command to a smoother constant acceleration/deceleration. You can set the acceleration time and deceleration time, and use this function when you want to achieve smooth speed control during speed control.

Function code	Parameter name	Range	Default	Unit	Communication address	When enabled
Pn310	Speed command trapezoidal acceleration time	0~10000	0	ms	0x0310	Immediately
	Acceleration time of the set speed is from 0r/min to the max speed (corresponding to the motor model). When the given speed is more or less than the max speed, the actual acceleration time is calculated in proportion.					
Pn311	Speed command trapezoidal deceleration time	0~10000	0	ms	0x0311	Immediately
	Deceleration time of the set speed is from max speed (corresponding to the motor model) to 0r/min. When the given speed is more or less than the max speed, the actual deceleration time is calculated in proportion.					

**Cautions**

Note that the acceleration and deceleration time refers to the time from 0 to the maximum speed or deceleration from the maximum speed to 0, and the maximum speed is taken as the judgment standard instead of the rated speed or the given speed

5. 3. 4 Zero position Fixed Functions

The zero-position fixed function means that when the zero-position fixed signal (/ZCLAMP) is ON, the servo lock is performed when the input voltage of the speed command (V-REF) is lower than the speed set by the fixed zero-position value (Pn313). Clamp after shutdown, means that the position loop is formed inside the servo unit, and the speed command will be ignored. Therefore, when used for speed control, the host device does not build a position loop.


The servo motor clamp is fixed within ± 1 pulse of the zero position fixing effective position. Even if rotation occurs due to external force, it will return to the zero position.

1. Zero-position fixed configuration

The signal is not configured in the factory default switch configuration. Therefore, the pin number configuration (0x0C) needs to be performed by parameters Pn601~Pn609.

Function code	Parameter name	Range	Defaults	Unit	Communication address	When enabled
Pn312	Zero speed clamp mode	0~3	3	-	0x0312	Immediately
	Speed mode, setting the switching value zero position clamp signal (/ZCLAMP) working mode: 0- Invalid 1- Speed command is set to 0, not clamped after stop 2- Speed command is set to 0, clamped after stop 3- Speed command is lower than "zero position clamp speed threshold", and then speed command is set to 0 at first, clamped after stop.					
Pn313	Zero position Clamp Speed Threshold	0~1000 0	10	rpm	0x0313	Immediately
	Set the zero position control switching threshold when "zero position clamp mode is set to 3.					

The relationship between zero position clamp speed thresholds and zero position clamp function is shown in the figure below:



2. Zero-position clamp wiring

The zero-position clamp signal is a universally configurable switching value input. Refer to “Sequence Input Circuit” for wiring details.

5. 3. 5 Rotation Detection Signal

When the motor speed is more than the setting value, a switching value rotation detection signal (/TGON) is output.

1. Configuration of rotation detection signal

Function code	Parameter Name	Range	Default	Unit	Communication address	When enabled
Pn317	Rotation determination threshold	1~10000	20	rpm	0x0317	Immediately
When the motor speed is higher than the set value, the switching value rotation detection signal (/TGON) is output.						


This signal is not configured in the factory default switching value output configuration. Please confirm before use.

The signal is not configured in the factory default switching value output configuration. Therefore, the pin number configuration (0x03) needs to be performed by parameters Pn613~Pn615.

The output condition is that the signal is output when the current feedback speed (absolute value) of the motor is higher than the setting value of Pn317 (rotation determination threshold).

2. Wiring of rotation detection signals

The rotation detection signal is a universally configurable switching value output signal. Refer to “Sequence Output Circuit” for wiring details.




5. 3. 6 Consistent Speed

The speed consistent signal (*V-CMP*) is a signal that is output when the difference between the servo motor speed and the command speed is equal to or lower than the set value of the speed consistent range Pn320. Used when interlocking with the upper device. This signal is the output signal during speed control.

1. Configuration of Speed-consistent Signals

Function code	Parameter name	Range	Default	Unit	Communication address	When enabled
Pn320	Speed consistent range	0~100	10	rpm	0x0320	Immediately
	When the difference between the motor speed and the command speed is lower than the set value, the switching value speed consistent signal (<i>V-CMP</i>) is output.					

In the factory default switching value output configuration, the signal is configured as CN1 29 and 30 pin numbers (Pn614=0x02) by default. Please confirm before use.




2. Wiring of speed-consistent signals

The speed-consistent signal is a universally configurable switching value output signal. For details on wiring, see "Sequence Output Circuit".

5. 4 Torque Mode

Refer to "Connection Example of Torque Control" for details on the wiring related to the torque mode. It is selected by control mode selection (Pn000=2). The torque mode is divided into the internal torque command (Pn400=0) and the analog torque command (Pn400=1, factory default) by the selection of the torque command source.

5. 4. 1 Quick Guide



5. 4. 2 Basic Settings

Torque control is the operation method of inputting the torque command to the servo unit and controlling the output of the servo motor through the torque command.


The torque command selection source Pn400=0 is the internal torque command, the torque command is set directly by the parameter Pn410. In this way, the internal torque can be given by writing to address 0x0410 via RS-485. Pn400 = 1, which is the analog torque instruction, is given according to the voltage connected to T-REF (CN1-9, CN1-10) and the setting value of analog torque command gain Pn405.

Function code	Parameter name	Range	Default	Unit	Communication address	When enabled
Pn400	Torque command selection	0~1	1	-	0x0400	Immediately
	Select the command source of torque control: 0-internal setting 1-analog input					

Pn404	Analog torque command filter time	0~655.35	0.00	ms	0x0404	Immediately
	The parameter is used to smooth the torque command when we apply a delay filtering to the analog torque command (T-REF) input, usually it does not need to be changed. If the set value is too large, the responsiveness may decrease. So please set it up as we check the response.					
Pn405	Analog torque command gain	10~100	30	0.1V/ Rated torque	0x0405	Immediately
	This parameter is used to set the analog voltage value (T-REF) required for the rated torque of the servo motor. Caution: Do not apply voltage exceeding -10~10V range, or it may cause damage to the driver.					
Pn406	Analog torque command reversed	0~1	0	-	0x0406	Immediately
	The analog voltage corresponds to the polarity setting of the torque command: 0- Positive polarity: Positive voltage corresponds to positive torque command. 1- Negative polarity: Positive voltage corresponds to negative torque command.					
Pn407	Analog torque command dead zone range	0~3	0	V	0x0407	Immediately
	In analog torque control, even if the input command is 0V, the servo motor may rotate at a slight speed. This is because a slight deviation occurs in the command inside the servo unit. This deviation can be eliminated by setting an appropriate analog torque command dead zone range.					
Pn410	Internal torque command in torque control	-500~500	0	%	0x0410	Immediately
	The torque command value setting when selecting the command source of torque control as internal setting.					

Set the analog voltage value of the rated torque command (T-REF, see "Analog Input Circuit" for wiring) through the analog torque command gain Pn405.


Example: The factory default parameter Pn405=30 (3V corresponds to the rated torque). If the input voltage at the T-REF terminal is 1.5V, the torque command corresponds to 50%. If 3V is input, the torque command corresponds to 100%.



5. 4. 3 Adjustment of Instruction Offset

When using torque control, even if the command is 0V, the servo motor may rotate at a slight speed. This is because there is a slight deviation in the instructions inside the servo unit. This slight deviation is called "offset".

There are two methods of automatic adjustment and manual adjustment of offset adjustment. Automatic adjustment is automatically adjusting the command offset (Fn100) and manual adjustment is manually adjusting command offset (Fn102). For details, see "Auxiliary Functions".



1. When adjusting automatically, be sure to adjust the command offset while the servo is off and the host computer (PLC, knob, etc.) gives 0V voltage command.
2. When adjusting manually, observe the running status of the motor while adjusting under servo ON.
3. The offset adjustment value will not be initialized if factory default

5. 4. 4 Speed Limit in Torque Control

The function to limit the servo motor speed so as to protect the driver.

In torque control, the servo motor is controlled to output the commanded torque, but the motor speed is not controlled. Therefore, when the input command torque is more than the machine torque, the motor speed will increase greatly. In this case, speed limits need to be made through this function.

5. 5 Hybrid Control Mode Selection

The servo unit can combine any two of the various control modes and switch them. The control method is selected by Pn000. The following describes the switching method and condition:


Function code	Parameter name	Range	Default	Unit	Communication address	When enabled
Pn000	Control mode selection	0~11	0	-	0x0000	Restart effective
	4- Internal Speed <-> Analog Speed: Switch control mode via ON/OFF of switching value /SPD-A and /SPD-B 5- Internal Speed <-> Position Mode: Switch control mode via ON/OFF of switching value /SPD-A and /SPD-B 6- Internal Speed <-> Torque Mode: Switch control mode via ON/OFF of switching value /SPD-A and /SPD-B 7- Position Mode <-> Analog Speed: Switch control mode via ON/OFF of switching value control mode switch (/C-SEL) signal 8- Position Mode <-> Torque Mode: Switch control mode via ON/OFF of switching value control mode switch (/C-SEL) signal 9- Torque Mode <-> Analog Speed: Switch control mode via ON/OFF of switching value control mode switch (/C-SEL) signal 10- Analog speed <-> Speed mode of zero position function: When controlling speed, zero position clamp function can be used 11- Position Mode <-> Position mode of command pulse disabled: When control position, command pulse disable function can be used. 16- EtherCAT mode					

1. Switch with internal speed control (Pn000 = 4, 5, 6)

a) The switching value input signal distribution mode is internally fixed (Pn600=0). The control mode (second mode) and internal setting speed can be switched by the /SPD-A and /SPD-B signals.

Switching value input signal			Speed positive and negative instructions	Pn000 setting		
/SPD-D (CN1-41)	/SPD-A (CN1-45)	/SPD-B (CN1-46)		4	5	6
OFF	OFF	OFF	Determined by second mode	Analog speed mode	Position mode	Torque mode
	OFF	ON	Positive	Internal speed 1 (Pn304)		
	ON	ON		Internal speed 2 (Pn305)		
	ON	OFF		Internal speed 3 (Pn306)		
ON	OFF	OFF	Determined by second mode	Analog speed mode	Position mode	Torque mode
	OFF	ON	Negative	Internal speed 1 (Pn304)		
	ON	ON		Internal speed 2 (Pn305)		
	ON	OFF		Internal speed 3 (Pn306)		

No limits for each mode switch. While motor running, speed control, position control or torque control can be switched to internally setting speed control.



Note: The internal speed mode is decelerated during the deceleration time set by Pn311 to stop the motor, then switch to the position mode.

- b) Switching value input signal distribution mode is parameter configuration (Pn600=1 default parameter)

Through the ON/OFF switching control mode of the control mode switching (/C-SEL) signal, the signal is not configured in the factory default switching value input configuration. Therefore, the pin number configuration of the function is performed by parameters Pn601~Pn609 (0x0B).

Switching value input signal	Pn000 setting		
/C-SEL (Parameter configuration)	4	5	6
ON	Analog speed mode	Position mode	Torque mode
OFF	Internal speed mode		

2. Switch excepts the internal set speed control (Pn000 = 7, 8, 9)

- a) The switching value input signal distribution mode is internally fixed (Pn600=0).

Switching value input signal	Pn000 Setting		
/C-SEL (CN1-41)	7	8	9
ON	Analog speed mode	Torque mode	Analog speed mode
OFF	Position mode	Position mode	Torque mode

- b) Switching value input signal distribution mode is parameter configuration (Pn600=1 default parameter).

Switching value input signal	Pn000 Setting		
	7	8	9
/C-SEL			
ON	Analog speed mode	Torque mode	Analog speed mode
OFF	Position mode	Position mode	Torque mode

3. Switch excepts internally set speed control switching (Pn000 = 10, 11)

- a) The switching value input signal distribution mode is internally fixed (Pn600=0)

Switching value input signal	Pn000 setting	
/C-SEL (CN1-41)	10	11
ON	Speed mode with zero position clamp function	Position mode with command pulse inhibit function
OFF	Speed mode	Position control

- b) Switching value input signal distribution mode is parameter configuration (Pn600=1 default parameter)

Switching value input signal		Pn000 Setting	
		10	11
/ZCLAMP (parameter configuration)	ON	Speed mode with zero position clamp function (*1)	-
	OFF	Speed mode	-
/INHIBIT (parameter configuration)	ON	-	Position mode with command pulse inhibit function
	OFF	-	Position control

*1: The enabled method of the switching value zero-position clamp signal (/ZCLAMP) must be used in conjunction with the parameters Pn312 and Pn313. Refer to the description of the function code.

5. 6 Other Output Signals

5. 6. 1 Servo Ready Output Signal

The servo ready output signal (/S-RDY) is a signal that indicates that the servo unit can receive servo ON (/S-ON) signals and command signals.

This signal is output under the following conditions:

- The main circuit power is on. For details of the output timing sequence of /S-RDY during power-on, refer to "Power-up enable ON timing".
- Non-hardwired base blocking status
- No alarm occurred
- When using an absolute encoder, the SEN signal turns ON (H level)

1. Servo-ready parameter configuration

In the factory default switching value output configuration, the signal is configured as CN1's 25th and 26th pin numbers (Pn613=0x00). Please confirm before use.

2. Servo ready wiring

The servo ready signal is a universal configurable switching value output. Refer to "Sequence Output Circuit" for wiring details.

5. 6. 2 Warning Output Signal

The warning output signal (*WARN*) is a warning function before the alarm, which makes it easier for the host device to judge the operation of the servo unit in advance. For detailed warning code, please refer to "Warning Code".

1. Configuration of warning output signals

This signal is not configured in the factory default switching value output configuration. The pin number configuration (0x07/0x107) needs to be performed by parameters Pn613~Pn615.


2. Polarity setting of warning output signals

The polarity of servo warning detection can be changed by setting the switching value output configuration as 0x07 / 0x107.


3. Wiring of warning output signal

The warning output signal is a general configurable switching value output signal. See "sequence control output circuit" for wiring details.

Example of optocoupler circuit




Example of relay circuit




5. 7 Timing Sequence

5. 7. 1 Power Enable ON Timing Sequence



1: There is a delay in the electromagnetic brake operation. The operation time varies depending on the type of the brake. It is recommended to be 100ms and above to ensure that the electromagnetic brake is fully released when the command is input. This time can be omitted when the motor is without brake.

5. 7. 2 Enable ON Power-Off Timing Sequence



1: Undervoltage fault occurs when the control power supply voltage drops below 170V/350V (220V series/400V series)

2: The time from /BK Output to the motor actual braking varies depending on the type of the brake. Refer to "Electromagnetic brake" for the timing of the /BK signal when the alarm or enable is OFF.

3: For the vertical shaft, if it power off while enabled On, the motor braking may not be completed and machine could move.

5. 8 Full closed-loop control


5.8.1 What is a full closed-loop system

The full closed-loop system is a system that uses external position feedback device (external encoder or grating ruler, etc.) to detect the actual machine position of the controlled object and feed back the actual machine position information to the servo unit. Because the actual machine position is directly fed back to the driver, high-precision positioning control can be realized.

The full closed-loop servo system can eliminate the error caused by mechanical transmission mechanism, while the semi closed-loop servo system can only compensate part of the error. Therefore, the accuracy of the semi-closed-loop servo system is lower than that of the full closed-loop system. Because of the position detection device, the position control accuracy of the closed-loop feed system mainly depends on the resolution and accuracy of the detection device (grating ruler, etc.) after other factors are determined.

The structure of the full closed-loop and semi closed-loop servo system is more complicated than that of the open-loop feed system because of the position detection device. In addition, because the mechanical transmission mechanism is partially or completely included in the system, the natural frequency, damping and clearance of the mechanical transmission mechanism will become unstable factors of the system. Therefore, the design and debugging of the closed-loop and semi closed-loop systems are more difficult than those of the open-loop systems.

The system structure is as follows:



1. The gain adjusted in the semi closed-loop mode may not be applicable in the full closed-loop mode. Therefore, after the adjustment is completed in the semi-closed-loop mode, it is necessary to re-optimize the gain parameters if switch to full closed-loop mode, to make the mechanical equipment in good operation
2. In order to use the full closed-loop function, the system must run normally in the semi closed-loop mode before switching to the full closed-loop mode for debugging

When setting motor rotation direction and machine moving direction for full closed-loop control, pn002 (rotation direction selection) and PN250 (use method of external encoder in full closed-loop control) must be set at the same time.

Parameter			Pn250 Application of external encoder in full closed loop control			
			1		3	
Pn002 Motor rotation direction	0	Command direction	FWD command	Reverse command	FWD command	Reverse command
		Motor rotation direction	CCW	CW	CCW	CW
		External encoder	FWD move	REV move	REV move	FWD move
	1	Command direction	FWD command	Reverse command	FWD command	Reverse command
		Motor rotation direction	CW	CCW	CW	CCW
		External encoder	REV move	FWD move	FWD move	REV move

- The frequency division pulse is independent of the setting of pn002, and becomes B-phase lead for forward rotation command.

- FWD direction: the direction in which the pulse count is positive
- REV direction: pulse counting is the direction of counting down

Other parameters**◆ Pn002 Motor rotation direction selection**

Facing the end face of the motor: 0-clockwise direction is FWD, 1-clockwise direction is FWD

◆ Pn250 Application of external encoder in full closed loop control

Set Pn250 =1 or Pn250 =3 in full closed-loop control

Parameters		Name	Definition	Effect time	Variety
Pn250	0(default)	Application of external encoder in full closed loop control	Not use full closed-loop control	Re-electrify	Set
	1		Use in standard running direction		
	2		Backup		
	3		Use in reverse running direction		

Supplementary note:

please confirm the setting value of PN250 according to the following points:

- (1) Set PN250 = 1, which is used in the standard running direction
- (2) Manually rotate the motor shaft along the CCW direction
- (3) When the full closed-loop feedback pulse counter counts positively (un012), or the servo monitoring parameter un007 (feedback pulse counter) and un012 (external encoder feedback pulse counter) change in the same direction, the setting of PN250 remains unchanged (PN250 = 1)
- (4) When the full closed loop feedback pulse counter counts down, or if the servo monitoring parameter un007 (feedback pulse counter) and un012 (external encoder feedback pulse counter) change in different directions, PN250 = 3

5.8.5 Resolution of external grating ruler

Through pn253, the pitch value of the external encoder grating ruler is set by pn253, which is also called the resolution of grating ruler


**For example:
[parameters]**

Pitch of grating ruler of external encoder: 0.5 μ M

Ball screw lead: 16mm

If the motor is not directly connected through the reduction mechanism

Then 16mm / 0.0005mm = 32000, so the setting value is "32000".



(Note) 1. When the mantissa appears, please round the number after the decimal point.

2. When the pitch value of the external encoder grating ruler with motor rotation for 1 turn is not an integer, relative to the position loop gain (KP), feedforward, position command speed, monitoring as the state of containing error. But it has nothing to do with the position loop, so it will not affect the position accuracy.

Relative parameter

Parameter code	Parameters	Range	Default value	Unit	Communication address	Effective method
Pn253	Resolution of external grating ruler	4~1048576	32768	Pulse/r	0x0253	Restart effect
Set the pitch value (feedback pulse number) of external grating ruler when the motor shaft rotates for 1 turn						

5.8.6 Setting of frequency division pulse output signal of grating ruler / encoder

Set the frequency division output of external position to pn070. The set value should input a and b phase edge values.

Pitch of grating ruler of external encoder: 16mm

Ball screw lead: 16mm

Speed: 160mm / S

The setting value is "4000" when the output is 1 μ m with 1 pulse (4 times of increasing value).


The setting value is "8000" when the output is 0.5 μ m with 1 pulse (the value after 4 times increment).

When the setting is "20", the output waveform of encoder frequency division pulse is shown in the right figure.

The upper frequency limit value of encoder signal output is 4Mpps (the value increased by 4 times), so the setting value should not exceed 4Mpps. If the upper limit value is exceeded, A.511 (frequency division pulse output over speed alarm) will be output

When the setting value is "4000", the speed is 1600mm / s,

$(1600\text{mm/s})/0.001\text{mm} = 1600000 = 4\text{Mpps}$.



1.6Mpps < 4Mpps, so this setting value can be used

5.8.7 Setting of Electronic Gear

The setting range of the electronic gear ratio is as follows:

$$0.001 \leq \text{electronic gear ratio (B/A)} \leq 16778$$

When the setting range is exceeded, ER.040 (parameter setting abnormal alarm) will occur.

Function code	Parameters	Range	Default	Unit	Communication address	Effect
Pn204	Electronic gear ratio (molecular)	0~1073741824	64	1	0x006/0x207	Restart effect
Pn206	Electronic gear ratio (denominator)	0~1073741824	1	1	0x008/0x09	Restart effect

Calculation method of electronic gear ratio setting value

◆ Semi closed-loop control

When the machine deceleration ratio of motor shaft and load side is n / M (when the motor rotates m turns, the load shaft rotates n turns), the setting value of electronic gear ratio can be obtained as following formula.

Electric gear ratio

$$\begin{aligned} \frac{B}{A} &= \frac{Pn204}{Pn206} = \frac{\text{Number of encoder lines}}{\text{Movement of load shaft 1 revolution (instruction unit)}} \times \frac{m}{n} \\ &= \frac{\text{Movement corresponded with input command 1 pulse}}{\text{Movement corresponded with grating ruler output 1 pulse}} \end{aligned}$$

Encoder resolution

The encoder resolution can be confirmed by the servo motor model. The suffix D1 or D2 is 23 bit encoder, the suffix is Q1, Q2, R1, R2 is 17 bit encoder, the suffix is E1, E2 is 24 bit encoder

◆ Full closed-loop control

Electric gear ratio

$$\begin{aligned} \frac{B}{A} &= \frac{Pn204}{Pn206} = \frac{1 \text{ instruction unit movement (instruction unit)} \times \text{number of segments of linear encoder}}{\text{Pitch of grating ruler for linear encoder}} \\ &= \frac{\text{Movement corresponded with input command 1 pulse}}{\text{Movement corresponded with grating ruler output 1 pulse}} \end{aligned}$$


Supplementary Notes

About resolution

The resolution used in the servo unit (the movement of 1 feedback pulse) can be obtained as following formula:

$$\text{Resolution(the movement of 1 feedback pulse)} = \frac{\text{the grating ruler pitch of linear encoder}}{\text{the segment number of serial conversion unit or linear encoder}}$$

The servo unit controls the servo motor in the unit of feedback pulse




5.8.8 Setting example of electronic gear ratio


The grating ruler pitch of linear encoder = 1 cycle distance of analog voltage feedback signal sent by linear encoder

The lead of screw rod is 16mm and the transmission ratio is 1:1 (direct connection).

Semi closed-loop mode:

Steps	Contents	Mechanical composition
		Command unit: 0.0005mm  24 bit encoder Ball screw lead:16mm
1	Number of motor encoder lines	24bit encoder lines number 16777216
2	The number of pulses required for one turn of the screw rod	The command unit is 0.0005mm (0.5 μm), and the number of pulses is 32000
3	Electronic gear ratio	$\frac{B}{A} = \frac{16777216}{32000}$
4	Parameters	Pn204=16777216, Pn206=32000

Full closed-loop mode:

Steps	Contents	Mechanical composition
		command unit: 0.0005mm (0.5μm)  FWD direction
1	Grating resolution of linear encoder	0.0005mm (0.5μm)
2	Command unit	0.0005mm (0.5μm)
3	Electronic gear ratio	$\frac{B}{A} = \frac{0.5}{0.5} = \frac{1}{1}$
4	Parameters	Pn204=1, Pn206=1

5.8.9 Setting of alarm detection

The alarm detection settings (Pn252, Pn257) are shown below

The setting of detection value excessive deviation between motor and load position (pn257) is the difference between motor encoder feedback (position) and full closed-loop external encoder feedback (load position). If the set value is exceeded, output = Er.d10 (alarm of excessive deviation between motor and load position)

Pn257	Detection value of excessive deviation between motor and load position				
	Position mode				
	Setting range	Setting unit	Default	Effective time	Variety
	0 ~ 1073741824	1 Command unit	1000	Immediately effective	Setting

(Note) when set to "0", Er.d10 is not output.

Setting of deviation coefficient (Pn252) between motor loads when full closed-loop rotation 1 turn


Set the "coefficient of deviation between motor and external encoder" when the motor rotates for 1 turn. It can be used to prevent out of control caused by damage of external encoder, or to detect "sliding" in belt mechanism.

◆ Setting Design

When the sliding rate of the belt is large or seriously twisted, please increase the value.

If the setting value is "0", the value of the external encoder is read directly.

When the factory setting value is "20", the second turn starts from the deviation after 1 revolution of the motor multiplied by 0.8



◆ Relavant parameters


Pn252	Coefficient of the deviation between the motor and the external encoder for one full closed-loop rotation				
	Position mode				
	Setting range	Setting unit	Default	Effective time	Variety
	0 ~ 100	1%	20	Immediately effective	Setting

6 Adjustment

6.1 Adjustments

6.1.1 Adjustments Steps

Adjustments refer to optimize the function of responsiveness by adjusting the servo unit's servo gain. Servo gain is set by the combinations of many parameters, including speed circle gain, position circle gain, filter, friction compensation, rotation inertia and so on. These parameters would influence with each other, so you must take the balance among all parameters into the consideration while setting. The factory settings of the servo gain are stable settings. Use all the adjusting functions according to the users' mechanical conditions in order to improve the responsiveness. The following figure is basic adjustment procedure flow chart; please adjust the machine according to the status and operating conditions of the machine.



6. 1. 2 Safety Precautions When Adjusting

When you are making adjustments, please set the servopack protection functions shown below under appropriate conditions.

- i. Set the overtravel

Please set the overtravel and you could refer to the servo enable and overtravel setting if you want more details.

- ii. The settings of the torque limit

The torque limit function is about calculate the torque that mechanical motions need in order to make sure that the torque is not greater than this torque limit value. If the torque is set below the value required for operation, overshoot or vibration may occur.

See more details in the "torque limit".

iii. Set excessive position deviation alarm value

The excessive position deviation alarm is an effective protection function when we are using servo unit for position control. When the motor operation does not match the command, you can detect the abnormal condition and stop the motor by setting an appropriate position deviation alarm. The position deviation is the difference between the position command value and the actual position. The position deviation can be expressed by the relationship between the following position loop gain (Pn103) and motor speed.

$$\text{Position deviation[instruction unit]} = \frac{\text{Motor speed}[\text{min}^{-1}]}{60} * \frac{\text{Encoder resolution}^{\ast 1}}{\text{Pn103}[0.1/\text{s}]/10^2} * \frac{\text{Pn206}}{\text{Pn204}}$$

When the acceleration/deceleration of the position command exceeds the tracking ability of the motor, the follow-up hysteresis will become large, resulting in the positional deviation not satisfying the above relation. Please reduce the acceleration and deceleration of the position command to the value that can be tracked by the motor or increase the value of the excessive position error alarm.

iv. Set the vibration detection function

Please initialize (Fn105) the detection value detected by the vibration and set an appropriate value for the vibration detection function. For details, refer to the corresponding "Accessibility"

v. Set excessive position deviation alarm value when servo is ON

If the servo is turned ON while the position deviation is accumulated, the motor will return to the original position to make the position deviation "0" and avoid causing a danger. In order to avoid this kind of situation, you can set an excessive position deviation alarm value when the servo is turned on to restrict the operation.

6. 2 Robust Control

In factory default, the robust control function is valid. When resonance and vibration occur, please change the attune value and load value via Fn301 or set Pn177 and Pn178.

6. 2. 1 Profile

Robust function could get stable response through adjusting the whole system automatically no matter what kind of mechanism or fluctuation of load.

Function code	Name	Range	Default	Unit	Communication address	When enabled
Pn175	Robust control selection	0x00-0x01	1	—	0x0175	After restart
	Set the robust control function switch: 0-invalid 1-valid					
Pn177	Robust control tuning value	10-80	40.0	Hz	0x0177	Immediately
	Set a greater robust control gain tuning value, systematic response gets faster, but system overshoot and excessive noise may occur					
Pn178	The minmum value of robust control	0-500	0	%	0x0178	Immediately
	Set a greater load ratio of robust control, systematic response gets faster, but the systematic excessive noise may occur, and we could increase this value in order to decrease the over-adjustment and overshoot when torque is excessive.					

Robust control function is valid in position control or speed control and invalid in torque control. When robust control is valid, some of the control functions of the table below would be restrained.

Function name	Operation	Executable conditions and notes
Vibration detection value initialization (Fn105)	Yes	Robust control is invalid in operation, and it turns to be valid when the operation is over
Bandwidth setting(Fn303)	No	
EasyFFT (Fn401)	Yes	Robust control is invalid in operation, and it turns to be valid when the operation is over
Gain shift	No	
Inertia recognition	Yes	Robust control is invalid in operation, and it turns to be valid when the operation is over
Mechanical analysis	Yes	Robust control is invalid in operation, and it turns to be valid when the operation is over

Parameters which become invalid when robust control function are valid. When we set robust control function valid in factory default, the Pn100、Pn101、Pn102、Pn103、Pn105、Pn106、Pn107、Pn140、Pn110、Pn170 are invalid.

6. 2. 2 Steps

Robust control function could be set via the auxiliary function Fn301 on panel operator and more details on "Accessibility", or we could set relevant parameters via "parameters setting"



Before operating the robust control function, please confirm the setting below, if not, it will display "NO-OP" in operation:

1. Robust control function is valid (Pn175=1)
2. No-motor debugging function is invalid (Pn730=0)

6. 2. 3 Supplement

In robust control, due to the increase of the tuning value, the system may cause resonance noise. You can set the Pn151 to choose whether to automatically set the notch. The factory default is "Auto-tuning". Only when the corresponding notch function is not needed, it is set to "Auto-adjust without auxiliary function."

Function code	Name	Range	default	Unit	Communication address	When enabled
Pn151	Automatic adjustment and selection of notch filter 2	0x00~0x0 1	1	—	0x0151	Immediately
0-No automatic adjustment via auxiliary functions 1-Automatic adjustment via auxiliary functions						

6. 2. 4 Relevant Parameters

The parameters need to be set are shown as below when operating robust control function:

Parameter	Name
Pn175	Robust switch
Pn104	First torque command filter
Pn156	Second notch filter frequency
Pn157	Second stage notch filter Q value

6. 3 Inertia Recognition

6. 3. 1 Profile:

Inertia recognition means that the servo unit performs automatic operation (forward and reverse reciprocating motion) without issuing commands from the upper device, and the load inertia moment is recognized during operation. The rotary inertia ratio (ratio of load inertia to motor rotor inertia) is the reference parameter for performing the gain adjustment, and the correct value must be set as far as possible. The load moment of inertia can be calculated based on the weight and composition of each part of the machine, but the operation is very tedious. With this function, after the motor is driven several times in the positive/negative direction, a high-precision load moment of inertia value can be obtained.

The motor operates according to the following operating specifications.

- The highest speed: $\pm 1000\text{min}^{-1}$ (changeable)
- Acceleration: $\pm 20000\text{min}^{-1}/\text{s}$ (changeable)
- Travel distance: maximum ± 2.5 turns (changeable)

6. 3. 2 Steps

The inertia recognition function can only be identified by the upper computer debugging software VCSOFT. For details on the identification procedure, refer to "Upper Position Debugging Related" - "Inertia Identification".

6. 3. 3 Supplyment

- When identifying the inertia, please make sure that the system can operate the range and set the operating conditions reasonably according to the operable range. Under different operating conditions, the recognition result may have minor deviations.
- If the servo torque limit is set too small, the result of inertia identification may be affected, resulting in discrepancy between the identification result and the actual inertia. Please confirm before identification.
- After inertia identification, after changing the inertia ratio (Pn100), the original gain-related parameters of the servo system need to be re-adjusted, otherwise vibration and noise may occur.

6. 4 Intelligent Setting

6. 4. 1 Profile

Users can choose intelligent setting with command input and no command input

(1) No command input

It means the function of automatically adjusting the servo unit according to the mechanical characteristics when the automatic operation (forward and reverse reciprocating motions) is performed within the set range. Intelligent settings can be performed without connection to the control system. The automatic operation is as follows

- Highest speed: motor rated speed
- Acceleration torque: motor rated torque about 100%
- Move distance: can be set arbitrarily. The factory setting is equivalent to 3 turns of the motor

(2) command input

It is the method of automatically adjusting the running command from the host control system. The command intelligent setting can also be used for additional adjustments after the commandless intelligent setting. When the correct moment of inertia ratio is set, no-instruction intelligent setting can be omitted, and only the intelligent setting operation with instructions is performed.



The command smart setting starts with the current speed loop gain (Pn101) as a reference. If vibration occurs at the start of the adjustment, correct adjustment cannot be performed. In this case, lower the speed loop gain (Pn101) until the vibration disappears, and then readjust.

The intelligent setting process adjusts the following items:

- Moment of inertia ratio (intelligent setting without command)
- Gain adjustment (speed loop gain, position loop gain, etc.)
- Filter adjustment (torque command filter, notch filter)
- Friction compensation
- IF suppression control
- Vibration suppression
- Low-frequency vibration suppression (only when Mode = 2 or 3) (without command smart setting)

6. 4. 2 Steps

The intelligent setting function cannot be set by the panel operator, and it needs to cooperate with the host computer debugging software to perform related operations. The instructionless intelligent setting is slightly different from the related operation of the instructional intelligent setting. For detailed steps, see "host computer operation instructions" - "Intelligent setting".

(1) Confirmation before execution

Before performing intelligent settings, be sure to confirm the following settings. If set incorrectly, this function cannot be performed during operation.

- No overtravel has occurred
- No torque control

- Gain switching selection switch is manual gain switching (Pn110 = 0) and is the first gain
- No motor test function is invalid (Pn730 = 0)
- No alarm or warning occurred
- Robust control function is invalid (Pn175 = 0)



1. When the commandless intelligent setting is executed in the speed control status, it will automatically switch to position control to perform adjustment, and return speed control after adjustment is completed.
2. The intelligent command setting cannot be executed in the speed control status.
3. During the intelligent setting process, the command pulse input override switch function becomes invalid.

(2) Failed to perform adjustment or adjustment failed example

In the following occasions, intelligent settings will not be performed properly. Please use the bandwidth setting (see "Bandwidth setting" for details).

- The motor is in power (in servo ON) in position control (with command intelligent setting)
- When the mechanical system can only run in one direction
- The scope of activities is narrow, below 0.5 laps
- When the moment of inertia changes within the set operating range
- When the mechanical dynamic friction is large
- The mechanical rigidity is low and vibration occurs during positioning
- When P (proportional) control is selected, "Load inertia moment measurement" is selected, in the moment of inertial recognition, or when switching from P/CON signal to P control
- When using the mode switch, when "Load moment of inertia measurement" is selected, the mode switch function becomes invalid during the moment of inertia recognition and becomes PI control. The mode switch function becomes active again after the moment of inertia recognition is completed.
- When speed feed forward and torque feed forward are input
- When the positioning complete width (Pn262) is small



1. When there is no command intelligent setting, when the variable inertia load is changed and the adjustment fails, please replace the adjustment mode and adjust with broadband settings or robust control.
2. In the intelligent setting, please set "electronic gear ratio (Pn204/Pn2016)" and "positioning completion range (Pn262)" to the actual running values, otherwise the adjustment may fail or the adjustment result does not match the actual operation result.

6. 4. 3 Supplyment

(1) Vibration suppression function

Before the intelligent setting, you can set whether the related vibration suppression function is automatically set. The factory default is to set automatically, please set the corresponding function switch to "Do not adjust automatically" before you want to change the value of the smart setting.

Function code	Name	Range	Default	Unit	Communication address	When enabled

Pn140	IF suppression control options	0x00~0x11	0x0010	—	0x0140	Immediately
	<p>The IF suppression control function effectively suppresses the continuous vibration of about 100 to 1000 Hz that occurs when the control gain is increased.</p> <p>0x1#: Automatically set IF vibration suppression frequency through smart setting and bandwidth setting</p> <p>0x0#: Not set automatically through intelligent setting and bandwidth setting, only manual setting</p> <p>0x#1: IF suppression frequency setting is valid</p> <p>0x#0: IF suppression frequency setting is invalid</p>					
Pn150	Notch filter 1 automatic adjustment selection	0x00~0x01	1	—	0x0150	Immediately
	<p>0- Automatic adjustment without auxiliary functions</p> <p>1- Automatic adjustment through auxiliary functions</p>					
Pn151	Notch filter 2 automatic adjustment selection	0x00~0x01	1	—	0x0151	Immediately
	<p>0- Automatic adjustment without auxiliary functions</p> <p>1- Automatic adjustment through auxiliary functions</p>					
Pn231	Low frequency vibration suppression function automatic adjustment selection	0x00~0x01	1	—	0x0231	Immediately
	<p>This parameter is set in the intelligent settings, bandwidth settings and other auxiliary functions under low-frequency vibration suppression is automatically set to choose:</p> <p>0 - Vibration suppression function is not automatically adjusted by auxiliary functions</p> <p>1- Vibration suppression function is automatically adjusted by auxiliary functions</p>					

(2) Feed forward function

In the factory setting mode, when the tuning mode is executed by "2", "3", "feedforward command (Pn109)", "speed feedforward (VREF) input", and "torque feedforward (T-REF) input" will become invalid.

According to the system configuration, if you want to use "V-REF input", "Torque feedforward (T-REF) input" and model tracking control from the upper device at the same time, set Pn249 = 1.



When using model tracking control under this function, the model tracking control will set the optimal feed forward within the servo. Therefore, the "V-REF input" and "T-REF input" from the upper device are not always used at the same time. If the input feedforward is incorrect, overshoot may be caused. However, it can be used as appropriate, so please pay attention.

6. 4. 4 Related Parameters

The parameters that may be changed when executing the smart setting function are as follows:

Parameter	Name
Pn100	Rotary inertia ratio
Pn101	First speed gain
Pn102	First speed integral time constant

Pn103	First position gain
Pn104	First torque command filter
Pn140	Medium frequency vibration suppression control selection
Pn141	Medium frequency vibration suppression inertia modification
Pn142	IF suppression frequency
Pn143	IF damper attenuation gain
Pn153	Notch filter 1 frequency
Pn154	Notch filter 1Q value
Pn155	Notch filter 1 depth
Pn156	Notch filter 2 frequency
Pn157	Notch Filter 2Q Value
Pn158	Notch filter 2 depth
Pn240	Model tracking control selection
Pn241	Model tracking control gain
Pn242	Model tracking control attenuation coefficient
Pn243	Model tracking control speed feed forward gain
Pn244	Model tracking control forward torque feed forward gain
Pn245	Model tracking control reverse torque feed forward gain

6. 5 Bandwidth Setting

6. 5. 1 Profile

The bandwidth setting is a method of inputting a speed command or a position command from the host device, and manually adjusting the running speed.

By adjusting one or two values with the bandwidth setting, the relevant servo gain setting can be automatically adjusted.

- The bandwidth setting adjusts the following items:
- Gain adjustment (speed loop gain, position loop gain, etc.)
- Filter adjustment (torque command filter, notch filter)
- Friction compensation
- IF suppression control
- Low frequency vibration suppression
- Use the bandwidth setting when you cannot achieve satisfactory response characteristics after setting it by smart settings. If you want to further fine-tune each servo gain after adjusting the bandwidth setting, see "Manual adjustment" for manual tuning.

6. 5. 2 Steps

Before performing bandwidth setting, be sure to confirm the following settings. If it is set incorrectly, "NO-OP" will be

displayed in the operation and this function cannot be performed.

- Invalid selection of no motor test function (Pn730 = 0)
- Robust control selection is invalid (Pn175 = 0)
- Tuning mode is set to 0 or 1 when tuning is performed by speed control

The bandwidth setting procedure can be performed by any one of the panel operator or the upper level debugging software. However, the panel operator can only operate when the tuning mode is set to "0-stability" or "1-high response". For detailed operation procedure, see "Bandwidth Setting (Fn303)". When positioning-specific adjustments "2-positioning" and "3-positioning are not required to be over-tuned" are required, they must be used in conjunction with "host computer debugging software".



After the inertia recognition or intelligent setting correctly set the moment of inertia ratio (Pn100), perform the broadband setting operation.

6. 5. 3 Supplyment

(1) Vibration suppression function

Before setting the bandwidth, you can set whether the related vibration suppression function is automatically set. The factory default is to set automatically. Please set the corresponding function switch to "Do not adjust automatically" before you want to change its value through the bandwidth setting.

Function code	Name	Range	Default	Unit	Communication address	When enabled
Pn140	IF suppression control options	0x00~0x11	0x0010	—	0x0140	Immediately
	The IF suppression control function effectively suppresses the continuous vibration of about 100 to 1000 Hz that occurs when the control gain is increased. 0x1#: Automatically set IF vibration suppression frequency through smart setting and bandwidth setting 0x0#: Not set automatically through intelligent setting and bandwidth setting, only manual setting 0x#1: IF suppression frequency setting valid 0x#0: IF suppression frequency setting invalid					
Pn150	Notch filter 1 automatic adjustment selection	0x00~0x01	1	—	0x0150	Immediately
	0- Automatic adjustment without auxiliary functions 1- Automatic adjustment through auxiliary functions					
Pn151	Notch filter 2 automatic adjustment selection	0x00~0x01	1	—	0x0151	Immediately
	0- Automatic adjustment without auxiliary functions 1- Automatic adjustment through auxiliary functions					
Pn231	Low frequency vibration suppression function automatic adjustment selection	0x00~0x01	1	—	0x0231	Immediately

	<p>This parameter is set in the intelligent settings, bandwidth settings and other auxiliary functions under low-frequency vibration suppression is automatically set to choose:</p> <p>0 - Vibration suppression function is not automatically adjusted by auxiliary functions</p> <p>1- Vibration suppression function is automatically adjusted by auxiliary functions</p>
--	---

(2) Feed forward function

In the factory setting mode, when the tuning mode is executed by "2", "3", "feedforward command (Pn109)", "speed feedforward (VREF) input", and "torque feedforward (T-REF) input" will become invalid. According to the system configuration, if you want to use "V-REF input", "Torque feed forward (T-REF) input", and model tracking control from the host device at the same time, set Pn249 = 1.



When using model tracking control under this function, the model tracking control will set the optimal feed forward within the servo. Therefore, the V-REF input and T-REF input from the upper device are not always used at the same time. If the input feedforward is incorrect, overshoot may be caused. However, it can be used as appropriate, so please pay attention.

6. 5. 4 Related Parameters

The relevant parameters and parameters that are automatically set when executing the bandwidth setting function are as follows:

Parameter	Name
Pn100	Rotary inertia ratio
Pn101	First speed gain
Pn102	First speed integral time constant
Pn103	First position gain
Pn104	First torque command filter
Pn140	Medium frequency vibration suppression control selection
Pn141	Medium frequency vibration suppression inertia modification
Pn142	IF suppression frequency
Pn143	IF damper attenuation gain
Pn153	Notch filter 1 frequency
Pn154	Notch filter 1Q value
Pn155	Notch filter 1 depth
Pn156	Notch filter 2 frequency
Pn157	Notch Filter 2Q Value
Pn158	Notch filter 2 depth
Pn240	Model tracking control selection
Pn241	Model tracking control gain
Pn242	Model tracking control attenuation coefficient
Pn243	Model tracking control speed feed forward gain
Pn244	Model tracking control forward torque feed forward gain


Pn245

Model tracking control reverse torque feed forward gain

6. 6 Manual Adjustment Function

After the intelligent setting and bandwidth setting adjustment, the function for further individual adjustment is required:

6. 6. 1 Servo Gain



To manually adjust the servo, gain, adjust the servo gains one by one based on understanding the composition and characteristics of the servo unit. In most cases, if there is a large change in one parameter, the other parameter must be adjusted again. In order to confirm the response characteristics, preparations must be made to observe the output waveform of the analog monitor using a measuring instrument. The servo unit consists of three feedback loops (position loop, speed loop, and current loop). The more the inner loop, the more responsive it needs to be. Failure to follow this principle will result in poor responsiveness or vibration. Since the current loop ensures sufficient responsiveness, the user does not have to make adjustments. By setting the following servo gains, the response characteristics of the servo unit can be adjusted.

Function code	parameter	Range	Default	Unit	Communication address	When enabled
Pn100	Rotary inertia ratio	0~20000	100	%	0x0100	Immediately
	Moment of inertia ratio = load inertia of motor shaft conversion / rotor moment of inertia of servo motor *100%					
Pn101	First speed gain	1~2000	40.0	Hz	0x0101	Immediately
	Determine the parameters of the speed loop responsiveness. If the response of the speed loop is low, it becomes a delay factor of the outer position loop, so overshoot or vibration of the speed command occurs. In the range where the mechanical system does not generate vibration, the larger the setting value, the more stable the servo system is. The better the responsiveness					
Pn102	First speed integration time constant	0.15~512	20.00	ms	0x0102	Immediately
	In order to respond to small input, the speed loop contains integral elements. Because this integral element is a delay element for the servo system, when the time parameter is set too large, overshoot may occur, or the positioning time may be prolonged, and the responsiveness may be deteriorated.					
Pn103	First position gain	1~2000	40.0	1/s	0x0103	Immediately
	The position loop response is determined by the position loop gain. The higher the setting of the position loop gain, the higher the responsiveness and the shorter the positioning time. The position loop gain cannot be increased beyond the rigidity of the mechanical system. To increase the position loop gain to a larger value, the rigidity of the machine must be increased.					

Pn104	First torque command filter	0~655.35	1.00	ms	0x0104	Immediately
	Adjusting the parameters of the torque command filter may eliminate the machine vibration caused by the servo drive. The smaller the value, the better the responsiveness can be controlled. However, the conditions are restricted by the machine conditions.					
Pn401	Torque command second-order low-pass filter cut-off frequency	100~5000	5000	Hz	0x0401	Immediately
	Use this parameter to set the cutoff frequency of the second-order torque filter. When this parameter is set to 5000, the function of the filter is invalid.					
Pn402	Torque command second-order low-pass filter Q	0.5~1	0.50	1	0x0402	Immediately
	By setting this parameter, the Q value of the second-order torque filter can be set. Increasing the Q value can improve the system responsiveness, but noise will be generated when the setting is too large.					

6. 6. 2 Gain Switching

The gain switching function includes "manual gain switching" that uses an external input signal and "automatic gain switching" that automatically switches. By using the gain switching function, the gain can be increased during positioning, the positioning time can be shortened, and the gain can be reduced and vibration can be suppressed when the motor stops.

Function code	Parameter name	Range	Default	Unit	Communication address	When enabled
Pn110	Gain switching mode selection switch	0x00~0x01	0	—	0x0110	Immediately
	<p>The gain switching function includes two methods of "manual gain switching" using an external input signal and "automatic gain switching" automatically switching. By using the gain switching function, the gain can be increased during positioning, and the positioning time can be shortened when the motor is stopped. Reduce gain and suppress vibration.</p> <p>0-Manual Gain Switching by Manual Gain Switching of External Input Signal (G-SEL)</p> <p>1- When the automatic switching condition is established (Pn111), it automatically switches from the first gain to the second gain; otherwise, it switches back to the first gain.</p>					
Pn111	Position control gain automatic switching condition	0x00~0x05	0	—	0x0111	Immediately
	<p>Set the conditions for automatic gain switching:</p> <p>0-positioning completion signal ON</p> <p>1- Positioning completion signal OFF</p> <p>2-positioning approach signal ON</p> <p>3-positioning proximity signal OFF</p> <p>4-position command is 0 after filter and pulse input is OFF</p> <p>5-position command pulse input ON</p> <p>If the condition is met, then switch to the second gain, otherwise switch to the first gain</p>					
Pn112	Gain switching transition time 1	0~65535	0	ms	0x0112	Immediately
	After waiting for the waiting time from the time when the switching condition has been established, the gain of the first position loop is increased to the gain of the second position loop in the transition time.					

Pn113	Gain switching transition time 2	0~65535	0	ms	0x0113	Immediately
	After waiting for the waiting time from the time when the switching condition has been established, the second position loop gain is changed to the first position loop gain to change linearly during the transition time.					
Pn114	Gain switching wait time 1	0~65535	0	ms	0x0114	Immediately
	The time from when the switching condition is established from the first gain to the second gain to when the switching is actually started					
Pn115	Gain switching wait time 2	0~65535	0	ms	0x0115	Immediately
	The time from when the switching condition is established from the second gain to the second gain to when the switching is actually started					

Switched gain combination

Switching gain	Speed loop gain	Velocity loop integration time constant	Position loop gain	Torque command filter	Model tracking control gain	Model tracking control gain correction
First gain	First speed loop gain (Pn101)	First velocity loop integration time constant (Pn102)	First position loop gain (Pn103)	First torque command filter (Pn104)	First model tracking control gain (Pn241)	First model tracking control gain attenuation coefficient (Pn242)
Second gain	Second speed loop gain (Pn105)	Second velocity loop integration time constant (Pn106)	Second position loop gain (Pn107)	Second torque command filter (Pn108)	Second model tracking control gain (Pn246)	Second model tracking control gain attenuation coefficient (Pn247)



1. Gain switching of model tracking control gain and model tracking control attenuation coefficient is only applicable to "manual switching gain"
2. Gain switching of model tracking control gain and model tracking control attenuation factor is switched only when the following conditions are met:
 - No instruction
 - The motor is stopped

(1) Manually switch

"Manual switching gain" means the first gain and the second gain are switched by the external input signal gain switching signal (/G-SEL).

a) Gain switching configuration

The signal is not configured in the factory default switch configuration. Therefore, the pin number configuration (0x0E) needs to be performed by parameters Pn601~Pn609.

b) Gain switching wiring

The gain switching signal is a universally configurable digital input. See "Sequence Input Circuit" for wiring details.

(2) Automatic switching


Function code	Parameter	Range	Default	Unit	Communication address	Way to be effective
Pn111	Position control gain automatic switching condition	0x00~0x05	0	—	0x0111	Immediately
	Set the conditions for automatic gain switching: 0-Position completion signal ON 1-Position completion signal OFF 2-positioning proximity signal ON 3-positioning proximity signal OFF 4-position command filtered to 0 and pulse input OFF 5-position command pulse input ON If the condition is met, switch to the 2nd gain, otherwise switch to the 1st gain.					

"Auto switching gain" is only valid in position control. The switching conditions are performed by the following settings:

Switching logic

parameter	Switching conditions	Switching gain	Switching waiting time	Switching time
Pn111 setting corresponding condition A	Condition A is met	The first gain → Second gain	Waiting time 1 Pn114	Switching time 1 Pn112
	Condition A isn't met	The second gain → First gain	Waiting time 2 Pn115	Switching time 2 Pn113

For example, in the automatic switching gain mode conditioned on the completion of the positioning signal (/COIN), it is assumed that the position loop gain Pn103 is switched to the second position loop gain Pn107. The /COIN signal of the switching condition is ON, and after waiting for the waiting time Pn114 from the time when the switching condition has been met, the gain is changed from Pn103 to Pn107 in a straight line during the switching time Pn112.



6. 6. 3 Speed Feedforward

Feedforward is the function of feedforward compensation to shorten the positioning time during position control. The speed feed forward is divided into internal speed feed forward (Pn121/Pn122) and analog (V-REF) given speed feed forward (using V-REF as speed feed forward selection Pn123). This command is sent to the servo together with the position command unit.

Related parameters

Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn121	Speed feed forward gain	0~100	0	%	0x0121	Immediately
	Speed feed forward is a function to shorten the positioning time. This function is effective when the servo unit performs position control. Note: When the feed forward command is too large, position overshooting will occur. Please check the response while setting appropriately					
Pn122	Speed feedforward filter time	0~64	0.00	Ms	0x0122	Immediately
	Speed feed forward low-pass filter time constant, which can slow position overshoot and torque jump caused by feed forward					
Pn123	Use V-REF as speed feedforward selection	0x00~0x01	0	—	0x0123	After restart
	Speed feedforward is a function to shorten the positioning time. It is possible to select speed feed forward via external analog V-REF. 0-None 1- Use V-REF as speed feed forward input					
Pn300	Analog speed command gain	150~3000	600	0.01V/Rated speed	0x0300	Immediately
	Required for the rated torque when using this parameter to set the analog voltage value (T-REF) of the servo motor. Caution: Do not apply -10~10V voltage. Exceeding this range may cause damage to the driver.					

6. 6. 4 Torque Feedforward

Torque feed forward is a function to shorten the positioning time. The command is generated by deviating the position command on the upper device side. This command is sent to the servo unit together with the speed command. The speed command from the upper device is connected to V-REF (CN1-5, 6), and the torque feedforward command is connected to T-REF (CN1-9, 10).

Related parameters

Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn124	Speed/position control selection (T-REF assignment)	0~1	0	—	0x0124	After restart
	Torque feed forward is a function to shorten the positioning time. Torque feedforward can be selected by external analog T-REF. 0-None 1- Use T-REF as a torque feed forward input					
Pn405	Analog torque command gain	10~100	30	0.1V/ Rated torque	0x0405	Immediately
	Required for the rated torque when using this parameter to set the analog voltage value (T-REF) of the servo motor. Caution: Do not apply -10~10V voltage. Exceeding this range may cause damage to the driver.					

6. 6. 5 PI-P Switching

When the control mode is speed control or position control, PI-P control can be switched. When the control mode is mixed, it is valid only when it is switched to internal speed, analog speed and position mode. The PI-P switching can be switched by the binary signal manual PI-P control signal (/P-CON). When the /P-CON signal is turned ON, P control is performed. The conditions for selecting automatic switching can also be selected by the parameter speed loop PI-P switching condition selection switch Pn131.

- (1) Manual PI-P Control
 - a) Manual PI-P Control Configuration


The signal is not configured in the factory default switch configuration. Therefore, the pin number configuration (0x05) needs to be performed by parameters Pn601~Pn609.

- b) Manual PI-P control wiring

The gain switching signal is a universally configurable digital input. See "Sequence Input Circuit" for wiring details.


- (2) Automatic switching

For automatic PI-P switching, the switching condition is set by Pn131, and the switching condition value is set by Pn132, Pn133, Pn134, and Pn135. By properly setting the switching conditions and condition values, overshoot during acceleration and deceleration can be suppressed and the settling time can be shortened.




Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn131	Speed loop PI-P switching condition selection switch	0x00~0x04	0	—	0x0131	Immediately
	<p>The mode switch is a function that automatically performs P control and PI control switching. Setting the switching condition by this parameter and satisfying the corresponding switching condition value can suppress overshoot during acceleration and deceleration and shorten the settling time.</p> <p>0 - Conditioned by internal torque command 1 - Conditional speed instruction 2 - Conditional acceleration 3 - Conditional position deviation pulse 4 - No mode switch function</p>					
Pn132	Speed loop PI-P switching condition (torque command)	0~800	200	%	0x0132	Immediately
	When the torque command exceeds the torque set by this parameter, the speed loop will be switched to P control, otherwise PI control					
Pn133	Speed loop PI-P switching condition (speed command)	0~10000	0	rpm	0x0133	Immediately
	When the speed command exceeds the speed set by this parameter, the speed loop will be switched to P control, otherwise PI control					
Pn134	Speed loop PI-P switching conditions (acceleration)	0~30000	0	rpm/s	0x0134	Immediately
	When the speed command exceeds the acceleration set by this parameter, the speed loop will be switched to P control, otherwise PI control					
Pn135	Speed loop PI-P switching conditions (position deviation)	0~10000	0	Instruction unit	0x0135	Immediately
	When the position deviation exceeds the value set by this parameter, the speed loop will be switched to P control, otherwise PI control					

When the switching condition of the mode switch is set as a torque command [factory setting], when the torque command exceeds the torque set in Pn10C, the speed loop will switch to P control. The factory torque command value is set to 200%.




When the switching condition of the mode switch is used as a speed instruction, when the speed command exceeds the speed set in Pn10D, the speed loop will switch to P control.




When the switching condition of the mode switch is used as acceleration

When the speed command exceeds the acceleration set in Pn10E, the speed loop will switch to P control.



When the switching condition of the mode switch is set as the position deviation, when the position deviation exceeds the value set in Pn10F, the speed loop will switch to P control. This setting is valid only for position control.



7 Accessibility

7.1 List of Auxiliary Functions

The auxiliary function is displayed with a number starting with Fn, and functions related to the operation and adjustment of the servo motor are performed.

The following table lists the auxiliary functions and reference items.

Auxiliary function number	Function description
Fn 000	Display alarm record
Fn 001	Clear alarm record
Fn 002	Software reset
Fn 003	Restore factory parameters
Fn 005	JOG operation
Fn 006	Program JOG operation
Fn 100	Automatic adjustment of instruction offset
Fn 101	Speed command offset manual adjustment
Fn 102	Torque command offset manual adjustment
Fn 103	Current offset automatic adjustment
Fn 104	Current offset manual adjustment
Fn 105	Initialize the detected value of the vibration detection
Fn 303	Bandwidth setting
Fn 401	Easy FFT
Fn 402	Online vibration monitoring

7.2 Displaying Alarm Logs (Fn000)


7.2.1 Overview

The servo unit has a record alarm function and can record up to 10 alarms that have occurred. This auxiliary function allows you to confirm the number and time of the alarm (measurement of the duration of the control power supply and the main circuit power supply in 100ms increments, and the function to display the total operation time in the event of an alarm, if it is 365 days per year. it can last for about 31 years if you operating it 24 hours a day.)



1. When the same alarm occurs continuously, if the interval between alarms is less than 1 hour, it will not be saved. If it exceeds 1 hour, it will be saved.
2. When an alarm does not occur, "□ ----" is displayed on the panel operator.
3. the alarm record can only be cleared by "clear alarm record (Fn001)".

7.2.2 Operating Procedure




7.3 Clear Alarm Record (Fn001)

7.3.1 Summary

The alarm record of the servo unit can only be cleared by clearing the alarm record (Fn001) function. Alarm recording cannot be cleared by resetting the alarm or switching off the main circuit power of the servo unit.

7.3.2 Operating Procedure



7.4 Software Reset (Fn002)


7.4.1 Summary

The function of resetting the servo unit is from the inside by software. Used to re-power on or reset the alarm after changing the parameter setting. It is also possible to validate the setting without turning the power back on.



1. This function must be started with servo off.
2. This function has nothing to do with the upper device to reset the servo unit. Same as when the power is turned on, the servo unit outputs the ALM signal, and other output signals may also be forcibly changed.

7.4.2 Operating Procedure



7.5 Restoring Factory Parameters (Fn003)

7.5.1 Overview


The parameter is restored to the function used at the factory setting.



Cautions

1. Initialization of the parameter setting value must be performed in the servo OFF state. It cannot be executed while the servo is ON.
2. For the setting to take effect, the servo unit must be turned on again after the operation.
3. When this function is executed, the values adjusted with parameters Fn100, Fn101, Fn102, Fn103, Fn104 will not be initialized.

7.5.2 Operating Procedure



7.6 JOG Operation (Fn005)

7.6.1 Profile

The JOG operation is a function that confirms the operation of the servo motor by speed control without connecting a host device.

To perform JOG operation, the following confirmation must be made in advance:


- The motor is in the enabled state and the JOG operation is invalid during the operation.
- It is recommended that the load inertia is not more than 30 times the motor inertia; otherwise it may cause large mechanical vibration;
- Parameter Pn500, Pn310, Pn311 set the JOG speed, acceleration and deceleration time; default JOG speed is 500rpm

Function code	Parameter name	Range	defaults	unit	Communication address	When enabled
Pn500	Jog speed	0~1000	500	rpm	0x0500	Immediately
Pn310	Speed command trapezoidal acceleration time	0~1000 0	0	ms	0x0310	Immediately
	Acceleration of the set speed from 0r/min to the rated speed (corresponding to the motor model). When the given speed is greater or less than the rated speed, the actual acceleration time is calculated in proportion.					
Pn311	Speed command trapezoidal deceleration time	0~1000 0	0	ms	0x0311	Immediately
	Acceleration time of the set speed from 0r/min to the rated speed (corresponding to the motor model). When the given speed is greater or less than the rated speed, the actual acceleration time is calculated in proportion.					



The overtravel prevention function is invalid during JOG operation. When running, the operating range of the machine used must be considered.

7.6.2 Operating Procedure



7.7 Program JOG Operation (Fn006)


7.7. Profile

Program JOG operation is a function that continuously runs with the previously set operation mode, movement distance, movement speed, acceleration/deceleration time, waiting time, and number of movements. This function is the same as JOG operation (Fn005). When the setting is not connected to the host device, the operation of the servo motor can be confirmed and a simple positioning operation can be performed.



1. Program JOG operation is position control, gear ratio and position command filtering are valid, but pulse instructions cannot be input to the servo unit.
2. The overtravel prevention function takes effect.

7.7.2 Operating Procedure



7.8 Automatic Adjustment of Instruction Offset (Fn100)

7.8.1 Profile

The automatic adjustment command offset is a method of automatically adjusting the command voltage after measuring the offset amount.

The measured offset will be stored in the servo unit.




Cautions

- 1, the servo is OFF
2. Offset adjustment overrange or input voltage instruction during offset adjustment may fail to adjust

7.8.2 Operating Procedure

Turn off the servo drive and input the 0V command voltage from the host device or external circuit.



7.9 Speed command Offset Manual Adjustment (Fn101)


7.9.1 Profile

Directly input the instruction offset to adjust.

Manual adjustments are used for the following occasions:

- The host device has built a position loop and sets the position deviation when the servo lock stops to zero.
- When you need to set an offset
- When confirming the offset amount set by automatic adjustment

7.9.2 Operating



7. 10 Profile Torque command Offset Manual Adjustment (Fn102)


7.10.1 Summary

It is a method of directly inputting the torque command offset.

Manual adjustments are used for the following occasions:

- When you need to set an offset
- When confirming the offset amount set by automatic adjustment

7.10.2 Operating Procedure



7. 11 Current Offset Automatic Adjustment (Fn103)


7.11.1 Profile

This function is only used when it is necessary to further reduce the torque ripple and other adjustments that need to be performed with higher precision, and usually does not require adjustment.



1. The automatic adjustment of the motor current detection signal offset must be performed with the servo off.
2. When the generated torque ripple is significantly larger than other servo units, perform automatic adjustment of the offset.

7.11.2 Operating Procedure



7.12 Current Offset Manual Adjustment (Fn104)


7.12.1 Profile

This function is used only when the torque ripple is still large after the motor current detection signal offset auto tuning (Fn103) is executed.



- When performing manual adjustments, if this function is accidentally performed, the characteristics may be degraded. When making manual adjustments, observe the following precautions.
- Make the servo motor speed about 100min-1.
 - Observe the torque command in the analog monitor state and adjust the pulsation to the minimum.
 - The U-phase current and V-phase current offset of the servo motor must be adjusted in a balanced manner. Please repeat the adjustment several times.

7.12.2 Operating Procedure



7. 13 Initializing the Detection Value of Vibration Detection (Fn105)

7.13.1 Profile

The vibration detection function can detect the vibration in the feedback speed of the servo motor. This function is used to detect the "vibration warning (Er. 520)" and "vibration warning (AL. 911)" that is more accurately after detecting the machine vibration in the running state.", and the function also could be used to automatically set the vibration detection value (Pn187).


Related parameters:

Function code	Parameter name	Range	defaults	unit	Communication address	When enabled
Pn185	Vibration detection options	0x00~0x02	0	—	0x0185	Immediately
	This function can automatically detect the value related alarms or warnings in order to detect the machine vibration under normal operating conditions. The perform way after setting the vibration detection: 0-No vibration detected 1-warning after vibration is detected 2-Alarming after vibration is detected					
Pn186	Vibration detection sensitivity	50~500	100	%	0x0186	Immediately
	Set the sensitivity of the detected vibration. The smaller the setting value is, the more sensitive it is. If the setting is too small, the vibration may be detected by mistake during normal operation. Note: The detection sensitivity of the vibration alarm and vibration alarm may differ depending on the state of the machine being used.					
Pn187	Vibration detection value	0~5000	50	rpm	0x0187	Immediately
	Set the threshold for vibration detection. The smaller the setting is, the easier it is to detect the vibration. If the setting is too small, the vibration may be detected by mistake during normal operation. Note: The vibration detection values of vibration alarm and vibration warnings may differ according to the condition of the used machine.					



- When the servo gain is set incorrectly, it may be difficult to detect the vibration. And it may not be possible to detect all the vibrations that have occurred.
- When you set the improper moment of inertia ratio (Pn100), vibration alarms and vibration alarms may be detected by mistake or not detected.
- This operation is performed when the motor is operated with actually used instructions.
- When performing this action, make sure that the motor runs at a maximum speed of 10% or more.

7.13.2 Operating Procedure




7. 14 Bandwidth Settings (Fn303)

7.14.1 Summary

For detailed description of this function, see "6.5 Bandwidth Settings."

7.14.2 Operating Procedure



7. 15 EasyFFT (Fn401)

7.15.1 Profile

EasyFFT transfers the periodic waveform commands from the servo unit to the servo motor, causing the servo motor to rotate a few times for a certain period of time, causing the machine to vibrate. The servo unit detects the resonance frequency based on the vibration generated by the machine, and then sets the corresponding notch filter according to the resonance frequency. The notch filter effectively removes high-frequency vibrations and noise. If vibration occurs due to a loud sound (abnormal sound) during operation, perform this function after the servo is turned off.



1. It must be used in the low gain state such as the initial stage of servo adjustment. If you perform the EasyFFT function after setting a high gain, accept due to mechanical characteristics and gain balance, the machine may vibrate.
2. The detected resonance frequency can be automatically set to the notch filter 1/2. If 1 has been set, it will be automatically set to 2. If 1/2 is set, the notch filter cannot be set by this operation.
3. When changing the amplitude setting value, gradually increase the amplitude value and change it while observing the situation.

8. 1. 1 Origin return trigger

The origin return trigger can automatically perform origin return via SI terminal trigger, point trigger, communication trigger and power-on.

8. 1. 2 Origin return SI terminal trigger

By configuring the universal SI terminal as the origin trigger function HomeTrig, the origin return is triggered. The rising edge of HomeTrig triggers home return. The input function definition of SI terminal related to home return is shown in Table 2.1 below:


SI Terminal Name	SI Terminal Function Code	Function Description
HomeTrig	0x1C	Origin return trigger function (valid on rising edge)
HomeReach	0x1D	External input origin signal (valid at high level)

Select the SI terminal as the origin trigger signal by configuring the general SI terminal function as 0x1C. When the rising edge of this SI terminal is valid, the origin return is triggered.

Table 2.1 SI terminal input function definition

8.1.3 Return to origin automatically trigger when power on

The home position return function can be configured to automatically find the home position after the servo drive is powered on for the first time by configuring the function code Pn800. The function definition of function code Pn800 is shown in the figure below:



As shown in the figure above, section C of Pn800 is defined as automatic trigger after homing is enabled. When the C segment is set to 1, when the servo is enabled for the first time, the home position return is automatically performed.

The A and B sections of Pn800 are defined as the point number for automatic operation after the origin return is completed.

8. 1. 4 Trigger home return by point function

The home position return function can be triggered by the point function. The definitions of SI terminals related to point functions are shown in Table 2.3 below:

SI Terminal Name	SI Terminal Function Code	Function Description
PosTrig	0x16	Point trigger function (valid on rising edge)
PosBit0	0x17	Point segment number selection Bit0 (valid at high level)
PosBit1	0x18	Point segment number selection Bit1 (valid at high level)
PosBit2	0x19	Point segment number selection Bit2 (valid at high level)
PosBit3	0x1A	Point segment number selection Bit3 (valid at high level)

PosBit4	0x1B	Point segment number selection Bit4 (valid at high level)
---------	------	---

Table 2.3 SI terminal point function definition

As shown in the above table, the point function is triggered by the external terminal. If the point segment number selection value is 0 when triggering, the origin return operation will be triggered. That is, when the rising edge of the PosTrig signal is valid, if the point segment number selection combination value is 0 (PosBit0 to PosBit4 are all 0), the origin return operation is triggered.

8. 1. 5 Communication triggers home return

In addition to triggering the home return operation with the SI terminal, the home return can also be triggered by communication. Through serial communication, USB communication, keyboard operation, etc., in the case of writing 0 to the function code Pn898, an origin return operation is triggered. Pn898 displays 10000 during the origin return process, and Pn898 displays 20000 after the origin return is completed.

Note: The origin return trigger is valid only when the servo drive is enabled. If the servo is not enabled, the home position return is invalid.

8. 2 Origin return function code

Pn899	Origin return method selection	○	Address:0x899
Factory default:1	Setting range:1~34	unit:N/A	Control mode:P

Parameter description: Origin return mode, any integer value between 1 and 34 can be set

Pn89A	Home return high speed setting	○	Address:0x89A
Factory default:100	Setting range:0~2000	unit:rpm	Control mode:P

Parameter description: During the origin return process, set the high-speed origin search speed value.

Pn89B	Origin return low speed given	○	Address:0x89B
Factory default:10	Setting range:0~1000	unit:rpm	Control mode:P


Parameter description: After the high-speed encounters the origin signal, the origin signal is searched at the low speed in the reverse direction.

Pn89C	Origin return acceleration and deceleration time given	○	Address:0x89C
Factory default:200	Setting range:10~1000	unit:ms	Control mode:P

Parameter description: The acceleration and deceleration time is given during the homing process. The acceleration/deceleration time is the time from 0rpm to the rated speed as the acceleration/deceleration time of the homing.

Pn800	Return to origin control word	○	Address:0x800
Factory default:0	Setting range:0~0x0000FFFF	unit:N/A	Control mode:P

Parameter description: Pn800 function definition is shown in Figure 3 below




Pn802	Zero offset pulse value	○	Address:0x802
Factory default:0	Setting range:- 2147483648 ~ 2147483648	unit: commanduni t	Control mode:P

Parameter description: The pulse offset value that needs to be run after the origin signal is found during the origin return process.


8. 3 Origin return method

Origin return method 1

a. Start zero return → reverse high-speed search for negative limit → encounter the rising edge of negative limit → decelerate to 0 → positive low speed finds negative limit falling edge → positive search for Z pulse




b. Start home return → negative limit valid → positive low speed find negative limit falling edge → positive Z pulse



Origin return method 1-b


Zero return method 2

- a. Start zero return → positive high-speed positive limit → encounter the positive limit rising edge → decelerate to 0 → reverse low speed positive limit falling edge → reverse Z pulse



Origin return method 2-a


- b. Start home return → positive limit valid → reverse low speed positive limit falling edge → reverse search Z pulse




Origin return method 2-b

Zero return method 3

- a. Start zero return→origin signal is OFF→forward high-speed home search signal rising edge→decelerate to 0→reverse low-speed home search signal falling edge→reverse search Z pulse




- b. Start zero return→Origin signal ON→Reverse low speed home search falling edge→Reverse search Z pulse




Zero return method4

- a. Start home return→origin signal OFF→forward high-speed home search rising edge→decelerate to 0→negotiate low-speed home search falling edge→decelerate to 0→forward low-speed home search rising edge→forward Z pulse search




b. Start home return→origin signal ON→reverse low-speed home search, falling edge→decelerate to 0→forward low-speed home search, rising edge→positive Z pulse search




Zero return method5

a. Start zero return→origin signal OFF→reverse high-speed home search rising edge→decelerate to 0→forward low-speed home search, falling edge→positive Z pulse search




b. Start zero return→origin signal ON→forward low-speed home search, falling edge→positive Z pulse search




Zero return method6


a. Start home return→origin signal OFF→reverse high-speed home search rising edge→decelerate to 0→forward low-speed home search falling edge→reverse low-speed home search rising edge→reverse search for Z pulse




b. Start home return→origin signal ON→forward low-speed home search, falling edge→reverse low-speed home search, rising edge→reverse search Z pulse

**Zero return method7**


a. Start zero return→origin signal OFF→forward high-speed home search rising edge→decelerate to 0→reverse low-speed home search falling edge→reverse search Z pulse




- b. Start zero return→Origin signal ON→Reverse low speed home search falling edge→Reverse search Z pulse




- c. Start zero return→origin OFF→forward high-speed home search rising edge→positive limit→reverse high-speed home search falling edge→decelerate to 0→forward low-speed home search rising edge→reverse low-speed home search down Find Z pulse along

**Zero return method8**


a. Start home return→origin signal OFF→forward high-speed home search rising edge→decelerate to 0→reverse low-speed home search falling edge→forward low-speed home search rising edge→forward Z pulse search



b. Start zero return→origin signal ON→reverse low-speed home search falling edge→forward low-speed home search rising edge→forward search Z pulse




c. Start home return→origin OFF→forward high-speed home search rising edge→positive limit→reverse high-speed home search falling edge→decelerate to 0→forward low-speed home search rising edge→positive Z pulse search




Zero return method9


a. Start zero return→origin signal OFF→forward high-speed home search, falling edge→decelerate to 0→reverse low-speed home search, rising edge→reverse search for Z pulse




b. Start zero return→origin signal ON→forward high-speed home search, falling edge→decelerate to 0→reverse low-speed home search, rising edge→reverse search for Z pulse




c. Start home return→origin OFF→forward high-speed home search falling edge→positive limit→reverse high-speed home search rising edge→decelerate to 0→forward low-speed home search falling edge→reverse low-speed home search rising edge → Find Z pulse in reverse direction

**Zero return method10**


a. Start home return→origin signal OFF→forward high-speed home search, falling edge→decelerate to 0→reverse low-speed home search, rising edge→forward low-speed home search, falling edge→forward search Z pulse



b. Start home return→origin signal ON→forward high-speed home search, falling edge→decelerate to 0→reverse low-speed home search, rising edge→forward low-speed home search, falling edge→forward search Z pulse




c. Start zero return → origin OFF → forward high-speed home search and falling edge → positive limit → reverse high-speed home search rising edge → decelerate to 0 → forward low-speed home search, falling edge → forward Z pulse search




Zero return method11


a. Origin return to start → origin signal OFF → reverse high-speed home search rising edge → decelerate to 0 → positive low speed home search falling edge → forward Z pulse search



b. The start of zero return → origin signal ON → forward low-speed origin search falling edge → forward Z pulse search




c. origin return to zero start → origin signal OFF → Reverse high speed find origin rising edge → negative limit → Forward high speed finds origin signal falling edge → decelerate to 0 → Reverse low speed find origin rising edge → Forward find Z pulse




Zero return method12


a. origin return start→origin signal OFF→Reverse high speed find origin rising edge→decelerate to 0→Forward low speed find origin falling edge→Reverse low speed find origin rising edge→Reverse find Z pulse



b. Origin return start→origin signal ON→Forward low speed find origin falling edge→Reverse low speed find origin rising edge→Reverse find Z pulse




c. origin return start → origin signal OFF → reverse high speed find origin rising edge → negative limit → Forward high speed finds origin signal falling edge → decelerate to 0 → reverse low speed find origin rising edge → reverse find Z pulse




Zero return method13


a. origin returns to zero start → origin signal OFF → reverse high speed find origin falling edge → decelerate to 0 → forward low speed find origin rising edge → forward find Z pulse



b. origin returns to zero start→origin signal ON→reverse high speed find origin falling edge→decelerate to 0→forward low speed find origin rising edge→forward find Z pulse




c. origin return start→origin signal OFF→Reverse high speed finds origin signal falling edge→negative limit→Forward high speed find origin signal rising edge→decelerate to 0→Reverse low speed find origin signal falling edge→Forward low speed find origin signal rising edge →Forward find Z pulse




Zero return method14


a. origin return start→origin signal OFF→reverse high speed find origin falling edge→decelerate to 0→forward low speed find origin rising edge→reverse low speed find origin falling edge→reverse find Z pulse



b. origin return start→origin signal ON→Reverse high speed find origin falling edge→decelerate to 0→Forward low speed find origin rising edge→Reverse low speed find origin falling edge→Reverse find Z pulse



c.origin return to zero start→origin signal OFF→reverse high speed find origin falling edge→negative limit→Forward high speed finds origin signal rising edge→decelerate to 0→reverse low speed find origin signal falling edge→reverse find Z pulse




Zero return method15:

After triggering this zero return method, the servo will take the current position as the zero point and clear the servo absolute position (equivalent to the 35th origin return method specified in CIA402).


Zero return method16: Reserved.

Zero return method17

a. Start origin return→Reverse high-speed search for negative limit→touch the rising edge of negative limit→decelerate to 0→Forward low speed search for negative limit and stop after falling edge




a. Start origin return → negative limit valid → Forward low speed finds negative limit and stops after falling edge




Zero return method18

a. Start origin return → Forward high-speed positive limit position → meet the rising edge of positive limit → decelerate to 0 → Reverse low-speed positive limit position and stop after falling edge




b. Start origin return → Positive limit valid → Reverse low speed positive limit and stop after falling edge




Zero return method 19


a. Start origin return → Forward find origin at high speed → reach the rising edge of origin → decelerate to 0 → reverse find origin at low speed and stop after falling edge




b. Start origin return → origin effective → Reverse finds origin at low speed and then stops after falling edge

**Zero return method 20**

a. Start origin return → origin signal OFF → Forward high speed find origin rising edge → decelerate to 0 → Reverse low speed find origin falling edge → Forward low speed find origin rising edge and then stop





b. Start origin return → origin signal ON → Reverse low speed find origin falling edge → Forward low speed find origin rising edge and then stop



Zero return method22


a. Start origin return→origin signal OFF→Reverse high speed find origin rising edge→decelerate to 0→Forward low speed find origin falling edge→Reverse low speed find origin rising edge and then stop






Zero return method23

a. Start origin return→origin signal OFF→Forward high speed find origin rising edge→decelerate to 0→reverse low speed find origin falling edge and then stop




Zero return method23-a


- b. Start origin return→origin signal ON→Reverse finds origin at low speed and stops after falling edge




- c. Start origin return→origin OFF→Forward high speed find origin rising edge→touch positive limit→Reverse high speed find origin falling edge→decelerate to 0→Forward low speed find origin rising edge→Reverse low speed find origin rising edge and stop after falling edge

**Zero return method24**


- a. Start origin return→origin signal OFF→Forward high speed find origin rising edge→decelerate to 0→Reverse low speed find origin falling edge→Forward low speed find origin rising edge and then stop



b. Start origin return→origin signal ON→Reverse low speed find origin falling edge→Forward low speed find origin rising edge and then stop




c. Start origin return→originOFF→Forward high speed find origin rising edge→touch positive limit→Reverse high speed find origin falling edge→decelerate to 0→Forward low speed find origin rising edge and then stop




Zero return method25


a. Start origin return→origin signal OFF→Forward high speed find origin falling edge→decelerate to 0→reverse low speed find origin rising edge and then stop



b. Start origin return→origin signal ON→Forward high speed find origin falling edge→decelerate to 0→reverse low speed find origin rising edge and then stop




c. Start origin return→originOFF→Forward high-speed find origin falling edge→ encounter positive limit→Reverse high-speed find origin rising edge→decelerate to 0→Forward low speed find origin falling edge→Reverse low speed find origin rising edge and then stop




Zero return method26


a. Start origin return→origin signal OFF→Forward high speed find origin falling edge→decelerate to 0→Reverse low speed find origin rising edge→Forward low speed find origin falling edge and then stop



b. Start origin return→origin signal ON→Forward high speed find origin falling edge→decelerate to 0→Reverse low speed find origin rising edge→Forward low speed find origin falling edge and then stop




c. Start origin return→originOFF→Forward high speed find origin falling edge→touch positive limit→Reverse high speed find origin rising edge→decelerate to 0→Forward low speed find origin falling edge and then stop




Zero return method 27


a. origin return start→origin signal OFF→reverse high speed find origin rising edge→decelerate to 0→forward low speed find origin falling edge and then stop



b. Origin return to start→origin signal ON→Forward low speed finds origin and stops after falling edge




c. Origin return start→origin signal OFF→Reverse high speed find origin rising edge→negative limit→Forward high speed finds origin signal falling edge→decelerate to 0→Reverse low speed find origin rising edge and then stop




Zero return method 28

a. origin return start→origin signal OFF→Reverse high speed find origin rising edge→decelerate to 0→Forward low speed find origin falling edge→Reverse low speed find origin rising edge and then stop



Zero return method28-a


b. Origin return start→origin signal ON→Forward low speed find origin falling edge→Reverse low speed find origin rising edge and then stop



Zero return method28-b

a. origin return start→origin signal OFF→reverse high speed find origin rising edge→negative limit→Forward high


speed finds origin signal falling edge→decelerate to 0→reverse low speed find origin rising edge and then stop



Zero return method28-c


Zero return method29 (6098 00h =29)

a. origin return start→origin signal OFF→reverse high speed find origin falling edge→decelerate to 0→forward low speed find origin rising edge and stop




Zero return method29-a

b. Origin return to start→origin signal ON→Reverse high speed find origin falling edge→decelerate to 0→Forward low speed find origin rising edge and then stop




a. origin return start→origin signal OFF→Reverse high speed finds origin signal falling edge→negative limit→Forward high speed find origin signal rising edge→decelerate to 0→Reverse low speed find origin signal falling edge→Forward low speed find origin signal rising edge




Zero return method30 (6098 00h =30)


a. origin return start→origin signal OFF→reverse high speed find origin falling edge→decelerate to 0→forward low speed find origin rising edge→reverse low speed find origin falling edge and then stop



b. Origin return start→origin signal ON→Reverse high speed find origin falling edge→decelerate to 0→Forward low speed find origin rising edge→Reverse low speed find origin falling edge and then stop



c. origin return start→origin signal OFF→Reverse high speed find origin signal falling edge→negative limit→Forward high speed find origin signal rising edge→decelerate to 0→Reverse low speed find origin signal falling edge and then stop




Zero return method30-c

Zero return method31 (6098 00h =31): Reserved.

Zero return method32 (6098 00h =32): Reserved.

Zero return method33 (6098 00h =33)


Origin return to zero → find the first Z pulse in the negative direction



Zero return method33

Zero return method34 (6098 00h =34)

Origin returns to zero → Forward finds the first Z pulse



9 Internal location

9.1 Internal multi-stage position control function code parameter setting

Pn000	Control mode selection	○	Address:0x000
Factory default:0	Setting range:0x0000~0x000B	unit: N/A	Control mode:P、S、T

Parameter description: Control mode selection. The internal multi-stage position control function is the internal position mode, and the position command is given by the parameter. Before running the internal multi-stage position control function, you first need to set the servo drive control mode to the position mode.

Pn000	function
0	Position control mode
Not 0 not 16	Other control mode
16	EtherCAT mode

Pn208	Position command source selection	○	Address:0x208
Factory default:0	Setting range:0x0000~0x0001	unit: N/A	Control mode:P

Parameter description: internal and external position command selection. Internal multi-stage position control function is the internal position mode, so before selecting the internal multi-stage position control mode, you need to set the position command source to the internal position mode.

Pn208	function
0	Position command source selection external pulse input
1	Position command source selection internal position command input

Pn204	Electronic gear ratio numerator	○	Address:0x204
--------------	--	---	----------------------

Factory default: 0	Setting range: 1~1073741824	unit: N/A	Control mode: P
---------------------------	------------------------------------	------------------	------------------------

Parameter description: electronic gear ratio numerator. Together with the electronic gear ratio denominator, the electronic gear ratio of the servo drive is given.

Pn206	Electronic gear ratio denominator	○	Address: 0x206
Factory default: 0	Setting range: 1~1073741824	unit: N/A	Control mode: P

Parameter description: electronic gear ratio denominator. The electronic gear ratio of the servo drive is given together with the numerator of the electronic gear ratio.

Note: The internal multi-stage position control mode is the internal position mode. When setting the electronic gear ratio, the electronic gear ratio cannot be set arbitrarily, otherwise it will cause data overflow and make operation errors. When selecting the internal position mode, you need to set the internal position mode. After the electronic gear ratio is set, it is necessary to ensure that the maximum number of command pulses per revolution is less than $2^{*}20$ (20-bit encoder).

9. 2 Internal multi-stage position control related function codes

Internal multi-stage position control function, according to the position command, positioning speed, acceleration time, deceleration time, delay time, Pr command type, absolute/incremental/relative position, interrupt function, overlap function, storage function to plan the position track. In addition, Position command trigger can be set by function code and DI terminal.

9. 2. 1 Position command trigger, select, stop

Position command triggering, selection, and stop can be realized in two ways. The first method uses an external numerical input terminal (DI terminal) to select, trigger, and stop the position command segment number. The second method uses a specific function code for position command Trigger, select, stop.

Position command triggering, selection, and stop can be realized through DI terminal. Position command triggering is realized by configuring POS0-POS4 function of DI terminal. SD700 allows planning 31 internal position commands. According to the combination of POS0-POS3, select the position segment to be operated. If the position segment number is selected as NUM, the corresponding relationship between POS0-POS4 and the position command segment number is:

POS4	POS3	POS2	POS1	POS0	Position segment number
0	0	0	0	0	0
0	0	0	0	1	1
0	0	0	1	0	2
0	0	0	1	1	3
0	0	1	0	0	4
0	0	1	0	1	5
0	0	1	1	0	6
0	0	1	1	1	7
0	1	0	0	0	8
0	1	0	0	1	9
0	1	0	1	0	10
0	1	0	1	1	11
0	1	1	0	0	12
0	1	1	0	1	13
0	1	1	1	0	14
0	1	1	1	1	15
1	0	0	0	0	16
1	0	0	0	1	17
1	0	0	1	0	18
1	0	0	1	1	19

1	0	1	0	0	20
1	0	1	0	1	21
1	0	1	1	0	22
1	0	1	1	1	23
1	1	0	0	0	24
1	1	0	0	1	25
1	1	0	1	0	26
1	1	0	1	1	27
1	1	1	0	0	28
1	1	1	0	1	29
1	1	1	1	0	30
1	1	1	1	1	31
0	0	0	0	0	

Position command triggering is achieved through the PosTrig function of the DI terminal. First select the internal position command segment number to be run through DI terminals POS0-POS3, and then use PosTrig to trigger the selected position command segment to run. The rising edge of the PosTrig signal indicates that the currently selected position command segment operation.

Note: Trigger the point with the segment number 0 for origin return operation; the points other than 0 are normal points.

During the execution of the Pr internal position command, if you want the Pr internal position command currently being executed to stop immediately, you can stop the operation through the PosStop function of the DI terminal. Use the rising edge of PosStop to stop the currently running position command segment immediately.

The DI terminal function definitions of POS0-POS3 position command selection, PosStop position command stop, and PosTrig position command trigger are as follows:

Position DI function	DI function Code number
PosTrig	0x16
POS0	0x17
POS1	0x18
POS2	0x19
POS3	0x1A
PosStop	0x20

The position command trigger, select, and stop processing can be realized through the external DI terminal, or through the assignment of specific function codes.

When there are many position commands in the Pr, many DI input terminals are required for functions such as Pr position command segment selection, position command triggering, and position command stop via DI terminals. For convenience, add functions to the Internal multi-stage position control program Code mode for position command selection, triggering and stopping operations.

The Pr internal position command sets the function code to Pn898. According to the input value of Pn898, judge the Pr command operation that needs to be performed. The Pr position command selection, trigger and stop corresponding to the value of Pn898 are shown in the following table:

Pn898 Value	Pr command function
0~31	Given the Pr instruction segment number, trigger the execution of the Pr position instruction Relative to Trig + PosNum
1000	Pr instruction to stop. Equivalent to given STOP bit
other	invalid

In addition to triggering the Pr instruction segment, Pn898 can also display the segment number of the current Pr instruction execution and whether the execution is complete. When reading Pn898, if the current Pn898 displays 10000+PosNum, it means that the current Pr instruction segment number is the Pr instruction of PosNum. Execute. If Pn898 displays 20000+PosNum, it means that the position command with the current Pr command segment number of PosNum has been executed, and the next Pr command can be received. The Pn898 function code definition is shown in the following table:

Pn898	Communication given Pr command segment number	○	Address:0x898
Factory default:10000	Setting range:0x0000~0xFFFF	unit: N/A	Control mode:P

Parameter description: Communication setting Pr position command segment number. By setting Pn898, the desired Pr command segment can be given by communication or keyboard. If the servo is enabled, when the Pr internal position

command mode is selected, set the value of Pn898 to Between 0 and 15, the corresponding Pposition instruction segment will be executed. During the execution of the Pr internal position instruction, the value of P9.30 can be read to determine whether the currently executing position instruction segment and the current position instruction segment are executed.

If Pn898 is displayed in the format of 10000+PosNum, it means that the instruction segment with the current Pr instruction segment number PosNum is being executed.

If Pn898 is displayed in the format of 2000+PosNum, it means that the current Pr instruction segment number of PosNum has been executed, and the next Pposition instruction segment can be accepted.

Note: When the servo is enabled, Pn898 will execute the point after setting the point number; when the servo is disabled, Pn898 will always display 20000 and will not perform the point operation. When Pn898=1000, it can be stopped by communication Pr instruction segment operation.

9.2.2 Position command control parameter configuration

A position command can be divided into two parts: position command control word and position command pulse number. Each position command segment is composed of the above two basic components. There are 31 position command segments defined in SD700.


Assuming the position command segment number is POSNUM, the control word of the current position command segment is given by the function code Pn804 +POSNUM*4; the current position command pulse number is given by the function code Pn806+ POSNUM*4. And so on, from the function code Pn804 A total of 15 position command segments are defined to Pn87E.

9.2.3 Definition of position command segment control word

The control word of the position command section is given by Pn804. The low 16 bits define the internal multi-stage position control operation mode, and the high 16 bits define the point operation parameter selection.

Pn804	Internal multi-segment position1 control word	○	Address:0x804
Factory default:0x00000000	Setting range:0x00000000~ 0xFFFFFFFF	unit: N/A	Control mode:P

Parameter description: The low 16 bits of the internal position command control word are the internal position command trajectory planning control word. The internal position command control word can be used to plan interruption, overlap, relative/absolute, single-stage/multi-stage/speed through the low 16-bits of the internal position command control word /Jump and other functions. The high 16 bits define the speed, acceleration, deceleration, and delay time of the Preposition instruction. The function code from P9.00 to P9.27 defines the acceleration and deceleration time and positioning during the operation of the Preposition instruction Speed and delay time.





Function definition of part A of function code:


Part A	function
0	Single position mode
1	Multi-stage position mode
2	Speed control mode
3	Jump mode

Single-segment, multi-segment description: single-segment position instruction means that after executing the current position instruction, the next position instruction will not be executed. Multi-segment position instruction means that the next position instruction will continue to be executed after the current position instruction is executed. If there are several position instructions in a row in the case of multiple stages, multiple position commands will be executed

continuously. Single/multiple position commands are executed as shown in the figure below:



Speed mode description: If the given current position command segment is speed mode, when the position command is planned, the motor will run at the set speed until the next Pr position command starts to execute.



Speed mode diagram

Jump mode description: If the current position instruction segment jump mode, then immediately jump from the current position instruction segment to the position instruction segment of the specified segment number, and execute the position instruction of the specified segment.

Function definition of part B of function code:

Part B	Single/multiple position mode	Speed mode	Jump mode
0	The current position command value is an absolute position value	Do not switch to the next stage Pr after the current speed is executed	—
1	The current position command value is the incremental position value	Automatically execute the next Pr after the current speed is executed	—

2	The current position command value is the relative position value	—	—
---	---	---	---

Description of position instruction type of part B in single/multi-segment position mode:

- ① Absolute position command: the motor operating target position value is the given position command value.
TargetPos = PosAbs.
- ② Relative position command: the motor operating target position value is the current actual position value plus the given relative position value
TargetPos = PosFdb + PosRel.
- ③ Incremental position command: the target position value of the motor operation is the previous position command value plus the current incremental position command value.
TargetPos = PosCmd + PosInc.

Function description of part B in speed mode:


In speed mode, the B part of the control word indicates whether the next Pr command value is automatically executed after the current speed command is reached. If the B part is 1, the next Pr command value is automatically executed. The next Pr command can be single Segment and multi-segment position commands can also be speed commands or jump commands. If part B is 0, the motor will run at the speed given by the current Pr until the next Pr command starts to execute.

Function definition of part C of function code:


Part C	Position mode	Speed mode	Jump mode
0	Interrupt function is not enabled	Interrupt function is not enabled	Interrupt function is not enabled
1	Interrupt function enable	Interrupt function enable	Interrupt function enable

Interrupt description: When the interrupt function is enabled, regardless of whether the current position command is completed or not, immediately switch to the next position command. The margin of the current position command will be accumulated to the next position command for position command planning. If the function is interrupted Disabled, only after the current position command is completed will it switch to the next position value execution.

The interrupt function is shown below:



Interrupt operation



Uninterrupted operation


Note: The interrupt function is the setting of the Pr command in the latter stage to take effect, and the interrupt function is judged when the latter command is triggered.

Function definition of part D of function code:

Part D	Single/multiple position mode	Speed mode	Jump mode
0	Overlap function is not turned on	Target speed unit rpm	—
1	Overlap function is on	Target speed unit PPS	—

Position overlap description: After the overlap function is turned on, when multiple position commands are executed, when each position command is executed to the deceleration stage, it will not decelerate to 0, and the next position command will be directly planned from the current speed. If the overlap function is not turned on, the current position command After the execution is completed, slow down to 0 and then plan the next position command. The overlap function only works in multiple positions, and the single position does not work. At the same time, after the overlap function is turned on, the delay time of multiple positions becomes 0.

The multi-stage position overlap function is shown in the following figure:



Note: The setting of the previous command is effective when overlapped, and the next command is overlapped when the previous command reaches the deceleration point.

Note: In speed mode, this bit represents the speed command unit.

Speed unit description: The speed unit defines whether the speed value given in the current speed command segment is the speed value of rpm (how many revolutions per minute) or the speed value of PPS (pulses per second).

Function definition of part E of function code:

Part E	Single/multiple position mode function	Speed mode	Jump mode
0	Acceleration time selection Pn880 defined time	Acceleration time selection Pn880 defined time	invalid
1	Acceleration time selection Pn881 defined time	Acceleration time selection Pn881 defined time	invalid
2	Acceleration time selection Pn882 defined time	Acceleration time selection Pn882 defined time	invalid

3	Acceleration time selection Pn883 defined time	Acceleration time selection Pn883 defined time	invalid
4	Acceleration time selection Pn884 defined time	Acceleration time selection Pn884 defined time	invalid
5	Acceleration time selection Pn885 defined time	Acceleration time selection Pn885 defined time	invalid
6	Acceleration time selection Pn886 defined time	Acceleration time selection Pn886 defined time	invalid
7	Acceleration time selection Pn887 defined time	Acceleration time selection Pn887 defined time	invalid

Function definition of part F of function code:

Part F	Single/multiple position mode function	Speed mode	Jump mode
0	Deceleration time selection Pn880 defined time	Deceleration time selection Pn880 defined time	invalid
1	Deceleration time selection Pn881 defined time	Deceleration time selection Pn881 defined time	invalid
2	Deceleration time selection Pn882 defined time	Deceleration time selection Pn882 defined time	invalid
3	Deceleration time selection Pn883 defined time	Deceleration time selection Pn883 defined time	invalid
4	Deceleration time selection Pn884 defined time	Deceleration time selection Pn884 defined time	invalid
5	Deceleration time selection Pn885 defined time	Deceleration time selection Pn885 defined time	invalid
6	Deceleration time selection Pn886 defined time	Deceleration time selection Pn886 defined time	invalid
7	Deceleration time selection Pn887 defined time	Deceleration time selection Pn887 defined time	invalid

Function definition of part G of function code:

Part G	Single/multiple position mode function	Speed mode	Jump mode
0	Speed value selection Pn888 defined value	invalid	invalid
1	Speed value selection Pn889 defined value	invalid	invalid
2	Speed value selection Pn88A defined value	invalid	invalid
3	Speed value selection Pn88B defined value	invalid	invalid
4	Speed value selection Pn88C defined value	invalid	invalid
5	Speed value selection Pn89D defined value	invalid	invalid
6	Speed value selection Pn89E defined value	invalid	invalid
7	Speed value selection Pn89F defined value	invalid	invalid

Function definition of part H of function code:

Part H	Single/multiple position mode function	Speed mode	Jump mode
0	Delay time selection Pn890 defined value	Delay time selection Pn890 defined value	invalid
1	Delay time selection Pn891 defined value	Delay time selection Pn891 defined value	invalid

2	Delay time selection Pn892 defined value	Delay time selection Pn892 defined value	invalid
3	Delay time selection Pn893 defined value	Delay time selection Pn893 defined value	invalid
4	Delay time selection Pn894 defined value	Delay time selection Pn894 defined value	invalid
5	Delay time selection Pn895 defined value	Delay time selection Pn895 defined value	invalid
6	Delay time selection Pn896 defined value	Delay time selection Pn896 defined value	invalid
7	Delay time selection Pn897 defined value	Delay time selection Pn897 defined value	invalid

9. 2. 4 Position command segment pulse reference

Assuming that the position command segment number is NUM, in single/multi-segment position mode, the number of position command pulses is given by function code Pn806+4*NUM. In speed mode, the given speed value is given by Pn804+4*NUM.

Pn806	Single/multi-segment position command pulse number Speed mode given speed value	○	Address:0x806
Factory default:0	Setting range:-2³¹~2³¹	unit: r	Control mode:P

Parameter description: In single/multi-segment position mode, position command pulse number is given. In speed mode, operation target speed is given.

Note: Pay attention to the speed setting unit when setting the speed value in the speed mode, the speed unit is given by the highest bit of Pn804

9. 2. 5 Common parameters of position command section

The speed, acceleration/deceleration time, and delay time of the Pposition command are shared parameters. Each Pposition command segment can select one of 8 speeds, acceleration/deceleration time, and delay time as the operating parameters of the current position command segment. Common parameters The definition is as follows:

Pn880	Internal multi-segment position plus Deceleration time selection 0	○	Address:0x880
Factory default:100	Setting range:0~60000	unit: N/A	Control mode:P

Parameter description: internal position command plus Deceleration time selection. From function code Pn900 to function code Pn907, a total of 8 sets of internal multi-segment position acceleration and deceleration time are defined. In actual use of internal multi-segment position command control, the word height can be controlled according to the internal multi-segment position command for the 16-bit part E, select a parameter from Pn900 to Pn907 as the acceleration time of the internal position command; according to the bit2 of the internal position multi-segment command control word, select a parameter from Pn900 to Pn907 as the deceleration time of the internal multi-segment position command.

Note: When several different position command segments select the same acceleration/deceleration time function code, modify the acceleration/deceleration time value of the corresponding function code, and change the acceleration/deceleration time of several position commands at the same time. The acceleration/deceleration time setting value is accelerated from 0rpm The time required to reach the rated speed of the motor.

Pn881	Internal multi-segment position plus Deceleration time selection 1	○	Address:0x881
Factory default:200	Setting range:0~60000	unit: ms	Control mode:P

same Pn880.

Pn882	Internal multi-segment position plus Deceleration time selection 2	○	Address:0x882
--------------	---	---	----------------------

Factory default: 300	Setting range: 0~60000	unit: ms	Control mode: P
-----------------------------	-------------------------------	-----------------	------------------------

same Pn880.

Pn883	Internal multi-segment position plus Deceleration time selection 3	○	Address: 0x883
Factory default: 400	Setting range: 0~60000	unit: ms	Control mode: P

same Pn880.

Pn884	Internal multi-segment position plus Deceleration time selection 4	○	Address: 0x884
Factory default: 500	Setting range: 0~60000	unit: ms	Control mode: P

same Pn880.

Pn885	Internal multi-segment position plus Deceleration time selection 5	○	Address: 0x885
Factory default: 600	Setting range: 0~60000	unit: ms	Control mode: P

same Pn880.

Pn886	Internal multi-segment position plus Deceleration time selection 6	○	Address: 0x886
Factory default: 700	Setting range: 0~60000	unit: ms	Control mode: P

same Pn880.

Pn887	Internal multi-segment position plus Deceleration time selection 7	○	Address: 0x887
Factory default: 800	Setting range: 0~60000	unit: ms	Control mode: P

same Pn880.

Pn888	Internal multi-segment positionSpeed value selection 0	○	Address: 0x888
Factory default: 100	Setting range: 0~6000	unit: rpm	Control mode: P

Parameter description: Internal multi-segment position command speed selection. From function code Pn910 to Pn917, a total of 8 sets of Internal multi-segment positionSpeed value selection are provided. When the actual internal multi-segment position control is performed, according to the internal multi-segment position control word The value of the upper 16 bits of the F part, select a set of parameters between Pn910 and Pn917 as the speed reference value for the internal multi-segment position operation.

Pn889	Internal multi-segment positionSpeed value selection 1	○	Address: 0x889
Factory default: 200	Setting range: 0~6000	unit: rpm	Control mode: P

same Pn888.

Pn88A	Internal multi-segment positionSpeed value selection 2	○	Address: 0x88A
Factory default: 500	Setting range: 0~6000	unit: rpm	Control mode: P

same Pn888.

Pn88B	Internal multi-segment positionSpeed value selection 3	○	Address:0x88B
Factory default:1000	Setting range:0~6000	unit: rpm	Control mode:P

same Pn888.

Pn88C	Internal multi-segment positionSpeed value selection 4	○	Address:0x88C
Factory default:1500	Setting range:0~6000	unit: rpm	Control mode:P

same Pn888.

Pn88D	Internal multi-segment positionSpeed value selection 5	○	Address:0x88D
Factory default:2000	Setting range:0~6000	unit: rpm	Control mode:P

same Pn888.

Pn88E	Internal multi-segment positionSpeed value selection 6	○	Address:0x88E
Factory default:2500	Setting range:0~6000	unit: rpm	Control mode:P

same Pn888.

Pn88F	Internal multi-segment positionSpeed value selection 7	○	Address:0x88F
Factory default:3000	Setting range:0~6000	unit: rpm	Control mode:P

same Pn888.

Pn890	Internal multi-segment positionDelay time selection 0	○	Address:0x890
Factory default:0	Setting range:0~6000	unit: 0.1s	Control mode:P

Parameter description: Internal multi-segment position command Delay time selection. From function code Pn890 to Pn897, a total of 8 sets of Internal multi-segment position Delay time selection are provided. When the actual internal multi-segment position control is performed, it is controlled according to the internal multi-segment position. For the value of the D part of the lower 16 bits of the word, select a set of parameters between Pn890 and Pn897 as the interval time between two position commands when the Internal multi-segment position is running (unit:0.1s, the delay time range is 0s~6000s).

Note: For the position command, the delay time is the delay time after the position command pulse is sent. For the speed mode, the delay time is the delay time after the speed value reaches the set target speed.

Pn891	Internal multi-segment positionDelay time selection 1	○	Address:0x891
Factory default:1	Setting range:0~60000	unit: 0.1s	Control mode:P

same Pn890.

Pn892	Internal multi-segment positionDelay time selection 2	○	Address:0x892
--------------	--	---	----------------------

Factory default: 5	Setting range: 0~60000	unit: 0.1s	Control mode: P
---------------------------	-------------------------------	-------------------	------------------------

same Pn890.

Pn893	Internal multi-segment positionDelay time selection 3	○	Address: 0x893
Factory default: 10	Setting range: 0~60000	unit: 0.1s	Control mode: P

same Pn890.

Pn894	Internal multi-segment positionDelay time selection 4	○	Address: 0x894
Factory default: 100	Setting range: 0~60000	unit: 0.1s	Control mode: P

same Pn890.

Pn895	Internal multi-segment positionDelay time selection 5	○	Address: 0x895
Factory default: 1000	Setting range: 0~60000	unit: 0.1s	Control mode: P

same Pn890.

Pn896	Internal multi-segment positionDelay time selection 6	○	Address: 0x896
Factory default: 5000	Setting range: 0~60000	unit: 0.1s	Control mode: P

same Pn890.

Pn897	Internal multi-segment positionDelay time selection 7	○	Address: 0x897
Factory default: 10000	Setting range: 0~60000	unit: 0.1s	Control mode: P

same Pn890.

9. 3 Multi-speed function operating parameters


Multi-speed function Plan the corresponding position trajectory according to the set speed, acceleration and deceleration time, delay time, and target position value. Take the operating parameters of the first position command segment as an example.

9. 3. 1 Position command

In position mode, the position command pulse number of internal multi-level position control is given by $Pn806 + POSNUM * 4$. The position command unit is a user unit. The number of pulses per revolution of position command is given by electronic gear ratios Pn204 and Pn206.


In position mode, the target position value can be incremental position value, relative position value and absolute position value.

Incremental position command is mainly used for the operation mode where the target position is clear and the target position value has nothing to do with the actual position. The reference point of the incremental position is the position command value. The incremental position operation mode is shown in the figure below:




As shown in the figure above, the first position command is set to PosCmd0. After running the pulse of Pos0, the operation ends, and the pulse of the remaining PosRem0 is not completed. If the second incremental position command PosCmd1 is inserted at this time, the second position command The total number of running pulses is PosCmd1+ PosRem0. That is, the second incremental position value PosCmd1 is based on the first position command PosCmd0 as the reference point, and the final operating position value is PosCmd0+ PosCmd1.

The relative position command uses the actual position value as the reference point. The position command value in the next paragraph uses the actual position value at runtime to calculate the target position value. The relative position operation mode is shown in the following figure:



As shown in the figure above, the first position command is set to PosCmd0. After running the pulse of Pos0, the operation ends, and the pulse of the remaining PosRem0 is not completed. If the second position command is inserted at this time, the relative position command PosCmd1 is inserted. The total number of pulses run by the command is PosCmd1. That is, the relative position value of the second segment PosCmd1 is the actual position Pos0 reference point, and the final operating position value is Pos0+ PosCmd1.

The absolute position command takes the absolute position value relative to the 0 point as the reference point. No matter what the current actual position value is, whether there is a pulse margin that has not been completed. The absolute position command value is the distance that needs to be traveled relative to absolute 0. As shown below




As shown in the figure above, the first position command is set to PosCmd0. After running the Pos0 pulse, the operation ends, and the remaining PosRem0 pulses are not completed. If the second absolute position command PosCmd1 is inserted at this time, the second position The total number of pulses run by the command is PosCmd1- Pos0. That is, the second absolute position value PosCmd1 is the absolute position 0 reference point, and the final operating position value is PosCmd1.

9. 3. 2 Acceleration and deceleration time

During the operation of Internal multi-stage position control function, the acceleration and deceleration time of the motor is calculated based on the maximum speed of the motor. For example, if the acceleration time of the motor is set to 100ms, it means that the motor is running. When accelerating from 0rpm to the maximum speed, it needs to accelerate from 0rpm to the maximum speed in 100ms.

Internal multi-stage position control function, set the maximum value of acceleration and deceleration time to 60000ms and the minimum value to 0ms. In Internal multi-stage position control position, if the relationship between the acceleration and deceleration time, speed and position value is not reasonable. If it is unable to run according to the set acceleration and deceleration time, the Internal multi-stage position control program will recalculate the acceleration and deceleration time according to the current speed and target position value, and run according to the re-planned acceleration and deceleration time, as shown in the figure below Shown:



As shown in the figure above, when the motor runs to S_0 according to the set acceleration time, if it continues to decelerate according to the set deceleration time, the final running position value of the motor will reach the distance shown by Pos1. And in the Internal multi-stage position When planning the control position command, the set target position value is Pos0. In order to ensure that the final running position of the motor accurately reaches the position of Pos0, the deceleration time needs to be re-planned to ensure that the motor finally runs to the Pos0 position.

9. 3. 3 Internal multi-stage position control speed and delay time

Internal multi-stage position control speed setting is divided into two types: position control mode and speed mode.

For the position mode, when the position command is planned, the desired operating speed is given by the speed selected by the G part of the upper 16 bits of the control word in the Pr command section. This speed value can only be given a positive speed value. According to the position command planning When, the positive and negative values of the target position are used to set the positive reverse of the desired speed.

For the speed mode, when Pr is running, the target speed value is given by $Pn804+POSNUM*4$. If you want to run in reverse in motor speed mode, you can set the value of $Pn804+POSNUM*4$ as a negative value. Speed is given by Pn804 The speed value unit uses the D part of the lower 16 bits of the Pr command control word to select whether the target speed is rpm or PPS as the unit.

During the operation of Internal multi-stage position control, whether it is the target speed in speed mode or the desired speed in position mode, the allowable maximum speed value is 5000rpm, and when the speed exceeds 5000rpm, the speed limit is 5000rpm. . When the given speed unit in speed mode is PPS, the maximum value of 5000rpm is converted into the limit of PPSunit.

For non-interrupt and non-overlapping operation, the delay time of Internal multi-stage position control is effective. After a period of Pr command is completed, how long it takes to wait before the next period of Pr command can be executed. The unit of delay time is 0.1s. For speed mode, the delay time is defined as how long it takes to delay when the motor running speed command reaches the set speed command value before it can run the next Pr command.


When the interrupt is running, the next Pr command will be executed immediately, so in the interrupt mode, the delay time can be interrupted. That is, when the current Pr command has not been executed, or the execution has not reached the delay time, you can use the interrupt function Execute the next Pr command immediately.

During overlapping operation, the set delay time is automatically ignored, and the next position command is planned immediately when the deceleration point is reached.

9. 4 Interrupt function


In Internal multi-stage position control function, the interrupt function can interrupt the operation of the previous position command and immediately execute the newly inserted position command. It runs according to the newly inserted position command target position. The position command is divided into incremental position, absolute position and relative There are three forms of position. Position commands that are not the same are interrupted with each other, and they have a non-same operation mode.

9. 4. 1 Incremental position interrupt position command




As shown in the figure above, the incremental position interrupts the position command operation. The first position command, the target position Pos_0 , is interrupted by the second position command during operation, and the remaining pulse value of the first position command is Rem . The second position command is an incremental position command, and the target position value is Pos_1 . After the second position command interrupts the first position command, it immediately runs at the speed set by the second position command, because the second position command is Increment position, so the total pulse value of the second position command running is the pulse value of $Pos_0 + Pos_1$. It is equivalent to the first position command margin as shown in the figure, and it is transferred to the second position for execution.

9. 4. 2 Quite position command interrupted position command



As shown in the figure above, it is relative position interrupt position operation. The first position command, target position Pos_0 , is interrupted by the second position command during operation, and the remaining pulse is Rem . The second position command is the relative position command, the target position Pos_1 . After the second position command is interrupted, it will run immediately at the target speed of the second position, and run the pulse digits relative to the actual position value. Pos_1 . The total pulse digits passed after the two positions are completed $Pos_0 + Pos_1 - Rem$. That is, when the relative position is interrupted, the position margin value of the previous position is ignored, and a position is run directly on the basis of the current actual position. As shown in the figure above, the position equivalent to the Rem area is ignored.

9. 4. 3 Absolute position interrupt position command



As shown in the figure above, it is an absolute position interrupt position operation. The first position command, the target position Pos_0 , is interrupted by the second position command during operation, and the remaining pulse is Rem . The second position command is an absolute position command, the target position Pos_1 . After the second position command is interrupted, it will run immediately at the target speed of the second position, and run to the absolute position Pos_1 . The total number of pulses passed after the two positions are run is Pos_1 . That is, before the interrupt is ignored A position command value, directly according to the absolute position of the interrupt

Pn864 function code definition

Function definition of part A of function code:

Part A	function
0~9	Point buffer depth


Function definition of part E of function code:

Part E	function
0	Jog invalid
1	Forward Jog
2	Negative Jog

The maximum point cache depth is 10 levels of cache. When the cache depth is set to 0, the point cache function is disabled.

Note: In the Internal multi-stage position control program, it is allowed to store up to 10 Pr command segments. The Pr command segment exceeding 10 segments will overwrite the previously stored command segment. The stored Pr command segment can be a single position command or multiple segments. The first command of the position command.

During the operation of the previous Preposition command as a single position command, a new position command is triggered through the $PosTrig$ function, and the newly triggered position command is temporarily stored. After the previous Pr command is completed, the stored position command is read for operation. The schematic diagram of the segment storage function is shown below:




Single-segment storage diagram

As shown in the figure above, during the operation of a single position command, another Pr command is triggered. If the interrupt is not set for another Pr command, you need to wait for the execution of the current Pr command to complete before executing. From the second Pr command During the time between the trigger and the execution of the second Pr command, the second Pr command is temporarily stored in the position command storage buffer.

9. 4. 4 multi-segment storage function

When the previous Pr command is a multi-segment Pr command, if a new position command is inserted, and the newly inserted position command is not set to interrupt, it will be temporarily stored. Waiting for the current multi-segment Pr command to be executed after the position segment is executed., Execute the stored position command segment immediately. The remaining unexecuted position command segments of multiple positions will be discarded and no longer executed. The multi-segment storage function is shown in the following figure:




Multi-segment storage diagram

As shown in the figure above, the first position command is a multi-segment position command, and there are 5 position command segments. During operation, when the multi-segment position command is executed to the third position, a new position command value is inserted through an external trigger. Newly inserted position The command does not set the interrupt function, so after waiting for the completion of the third position command of the previous multi-segment position command series, the newly inserted position command value will be executed. The fourth and fifth position command values of the multi-segment position command series will no longer be executed.

9. 4. 5 Overlapping storage function

When the previous position command is set to overlap the function, during the operation of the position command, if a new position command is inserted through an external trigger, and the new position command does not set the interrupt function, wait for the previous position command to execute to the deceleration point position, Start to read the stored position command value, and plan the stored position command value in an overlapping manner. The overlapping storage function is shown in the following figure:




Overlapping storage diagram

As shown in the figure above, the first position command sets the overlap function, and the new position command is inserted by external trigger during operation. When the new position command is not set to interrupt, the newly received position command is temporarily stored. When the first position When the command runs to the deceleration point position, it is judged that the first position command overlap function is turned on. At this time, the value of the temporarily stored position command is directly read, and the execution process of the temporarily stored position command is planned in an overlapping manner.

9. 4. 6 Interrupt storage function

The position command storage function of Internal multi-stage position control allows storing up to 3 position command values. If there is currently a stored position command being executed, and there is still a stored position command that has not been executed, use an external trigger to insert a new one position command. The new position command sets the interrupt function, it will immediately interrupt the executing position command segment, and execute the newly inserted position command value. After waiting for the newly inserted position command value to execute, read the stored ones that have not been executed. Position command value, continue to execute. Interrupt storage function as shown below:




Interrupt storage diagram

As shown in the figure above, during the execution of the first position command, there is a stored position waiting to be executed. When the first position is executed, a new position command is inserted through an external trigger, and the newly inserted position command enables the interrupt function and executes immediately. The newly inserted position command. After waiting for the newly inserted position command to complete, execute the stored position command value.

9. 5 Overlap function

When multiple positions are running continuously, you can achieve a smooth transition of multiple position commands by setting multiple position overlapping functions. The function of the overlapping function is to directly read the operating parameters of the next position when the first position runs to the position of the deceleration point position, speed, acceleration and deceleration time, etc.), directly plan the next position trajectory from the deceleration point, so as to achieve a smooth transition between the two position trajectories. The overlap function is shown in the following figure:




Overlapping function diagram

As shown in the figure above, when multiple positions overlap, when the deceleration point of the previous position, the operating parameters of the next position command are directly read, and the running trajectory of the next position command is planned on the basis of the current speed to realize the smoothing of the two positions Transition. In the process of overlapping operation, the remaining pulse value that is not completed in the previous position command will be compensated to run on the next position command, and there will be no pulse loss problem.

9. 6 Stop function

During the operation of Internal multi-stage position control, PosStop can be used to trigger the current running position command to stop. PosStop can be triggered by the rising edge of DI terminal by configuring external DI terminal 0x20; it can also be triggered by means of communication, set Pn898= In the case of 1000, PosStop function is realized. After stopping the currently running position command through the stop function, the remaining pulse value of the current position that is not running will be temporarily stored in the program. Before starting to run the next Pr command program, you need to consider the remaining pulse The stop function is shown in the figure below:




Stop function diagram

As shown in the figure above, the current running position command value is stopped by PosStopfunction during position command operation. After the stop command is triggered, the motor decelerates from the current speed to 0 according to the 500ms deceleration time. After the motor stops, the remaining pulse value of the current position Will not clear.

Before starting the next Preposition command planning, the current position command pulse needs to be processed. If you want to clear the remaining amount of the current position command pulse, you can clear the remaining pulse by sending a relative position command with a relative position of 0; if you want to change the current position The remaining pulse of the command is completed, and the remaining pulse can be run by sending an incremental position command with an incremental position of 0; if the next position command is an absolute position command, the current remaining pulse has no effect on the operation of the absolute position command.

9. 7 Jump function


In the Internal multi-stage position control program, the Pr command section allowed to be set is a jump command. When a certain section of the Pr command section is set as a jump command, when the current stage is executed, it will jump to Pr command section, immediately jump to the specified Pr command section for execution. The value of the Pr command jumped to can be a single-segment position command, the first value of a multi-segment position command, speed command, etc. During the jump process, if Jump command jump In its own situation, the jump error occurs, and the servo drive automatically stops. The schematic diagram of the jump function is shown below:



跳转示意图

As shown in the figure above, the current position command is executed in sequence. When executed to the Pr3 command segment, the Pr3 command segment jumps to the command, jumps to the Pr7 specified segment, and immediately jumps to the Pr7 command segment to execute the position defined by the Pr7 command value.


Jump can be realized by sequential execution or by external trigger. Jump function can be realized by external trigger jump command segment number. Jump command can enable interrupt function, if the triggered jump function is enabled Interrupt function, interrupt the currently executing Pr command, and immediately jump to the specified Pr command section; if the triggered jump function does not enable interrupt, the triggered jump command will be temporarily stored and wait for the current Pr Jump after the execution of the specified segment is completed. The interrupt jump function diagram is shown below :



Interrupt jump function

As shown in the figure above, there are two command segments 1 and 2 that are executed sequentially. When multiple segments of command1 are currently being executed, segment 5 is specified by external trigger Pr, and segment 5 is specified by Pr as a jump command, interrupt function is enabled, and jump The target command segment number is 7. The currently running multi-segment command ends and immediately starts to execute the position command value of Pr command segment 7.

In addition to jumping to any available Pr command segment number, the jump function can also implement multi-segment position command loop execution through the jump function, as shown in the following figure:



Multi-section position command loop

As shown in the figure above, when the Pr command of the last paragraph of the multi-segment position command is set, it is set as a jump command, from the last Pr command to the Pr command at the beginning of the paragraph, so that multiple Pr commands can be executed in a loop.

9. 8 Jog function

The Jog function can be Jog by communication or internal Jog operation through external terminals. The Jog function must be operated with the servo enabled. During the Jog execution process, the point function will no longer be executed. Jog execution The point can be executed normally after completion.

The internal Jog function code is shown in the following table:

Pn500	Jog speed	○	Address:0x500
Factory default:500	Setting range:0~1000	unit: rpm	Control mode:P,S

Parameter description: Jog speed setting.unit rpm

Pn505	Jog acceleration and deceleration time	○	Address:0x505
Factory default:100	Setting range:2~10000	unit: ms	Control mode:P,S

Parameter description: in Jog mode, acceleration and deceleration time setting.

Pn506	Jog delay time	○	Address:0x505
Factory default:100	Setting range:0~10000	unit: ms	Control mode:P,S

Parameter description: After the point reaches the set speed, the delay time.

9. 8. 1 Jog operation of external terminals

External terminal Jog, terminal function definition is shown in the following table:

Terminal function definition	Description
0x1E	Forward Jog
0x1F	Reverse Jog

The external terminal input and Jog execution satisfy the following logic table:

Forward Jog 0x1E terminal status	Reverse Jog 0x1F Terminal status	Jog function password
OFF	OFF	Not executed Jog
ON	OFF	Forward Jog
OFF	ON	Reverse Jog
ON	ON	Not executed Jog

As shown in the above table, the relationship between Forward Jog and Reverse Jog is "exclusive OR". That is, if only one terminal of Reverse Jog is valid, the Jog can be executed normally.

9. 8. 2 Communication Jog

Communication Jog is realized by the high 16 bits of function code Pn89F.

	function
0	Jog invalid
1	Forward Jog
2	Reverse Jog

As shown in the above table, when the given function code Pn89F is 0, the Jog function is turned off; when the given function code is 1, Forward Jog is performed; when the given value is 2, Reverse Jog is performed.

Note: Regardless of the external terminal Jog or the communication Jog., you need to set the servo enable condition first.

function code	parameter name	range	Default	unit	Address	Effective way
---------------	----------------	-------	---------	------	---------	---------------

Pn004	Selection of the stopping method when the servo is OFF and the first type of alarm occurs	0~2	0	—	0x0004	Power off takes effect
	0-stop the motor through DB 1- Stop the motor through DB, then release DB 2- Do not use DB, make the motor in free motion state Note: DB (Dynamic Brake) is a function for emergency stop. If the power is turned on or off or the servo motor is started or stopped by servo ON when the command is input, the DB circuit will operate frequently, which may cause aging of the internal components of the servo unit , Please input the speed command or position command to start and stop the servo motor.					
Pn005	Servo occurrence type 2 alarm stop method selection	0x00~0x01	0	—	0x0005	Power off takes effect
	0-zero speed stop: set the speed command to "0" and execute a rapid stop 1- Same as Pn004 stop method					
Pn006	Overtravel warning detection option	0~1	0	—	0x0006	Power off takes effect
	0-Do not detect overtravel warning when limit 1- Detection of overtravel warning when limit					
Pn007	Selection of stopping method when servo overtravel (OT)	0~2	0	—	0x0007	Power off takes effect
	Set the stop mode when the servo overtravel occurs and the state after stopping: 0-Same as Pn004 stop method 1- Take the torque set by Pn053 as the maximum value, and enter the locked state after decelerating and stopping 2- Take the torque set by Pn053 as the maximum value, and enter the free running state after decelerating to stop					
Pn008	Servo lock time after electromagnetic brake is applied	0~50	0	10ms	0x0008	Effective immediately

	<p>When the servo motor is enabled but not running, when the brake (/BK) signal and the servo ON (/S-ON) signal are OFF when the same is OFF, setting this parameter can change the brake (/BK) signal OFF to the actual motor Time to enter no power state</p> <p>Note: The action delay time of the brake is slightly different. Setting this parameter can prevent the mechanical movement of the vertical axis from being caused by the weight or external force of the mechanical movement of the vertical axis when the motor is in the brake action.</p>					
Pn009	Electromagnetic brake brake delay	10~100	50	10ms	0x0009	Effective immediately
	<p>When the servo motor is rotating when the servo is OFF/an alarm occurs/the main circuit is OFF, the servo motor is not energized. Through this parameter and the brake brake delay release speed (any one is satisfied), the output time of the brake signal (/BK) OFF can be adjusted</p> <p>Note: For the related logic, please refer to the "Holding Brake Action" Description.</p>					
Pn010	Delay release speed of electromagnetic brake	0~10000	100	rpm	0x0010	Effective immediately
	For details, please refer to the related description of "Electromagnetic brake brake delay".					

10 Function Code Instructions

10. 1 Basic Control Related Pn0 Group Parameters

Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn000	Control mode selection	0~11	0	-	0x0000	After restart
	<p>0-position mode: The position of the machine is controlled by the pulse sequence position command. The position is controlled by the number of input pulses, and the speed is controlled by the frequency of the input pulse that is used in the place where positioning action is required</p> <p>1- Analog speed: The servo motor speed is controlled by the analog voltage speed command</p> <p>2-Torque Mode: The output torque of the servo motor is controlled by the analog voltage torque command/internal torque command that's used to output the necessary torque (pressing action, etc.)</p> <p>3-Internal speed: The speed is controlled by three internally set speeds set in the servo unit. When this control method is selected, no analog voltage is required.</p> <p>4-Internal Speed <-> Analog Speed: Switch control mode via ON/OFF of switch/SPD-A and /SPD-B</p> <p>5-Internal Speed <-> Position Mode : Switch control mode via ON/OFF of switch/SPD-A and /SPD-B</p> <p>6-Internal Speed <-> Torque Mode: Switch control mode via ON/OFF of switch/SPD-A and /SPD-B</p> <p>7-Position Mode <-> Analog Speed: ON/OFF Switching Control Mode of Switching ((C-SEL) Signal by Switching Control Mode</p> <p>8-position mode <-> torque mode: ON/OFF switching control mode of the (C-SEL) signal switching</p> <p>9-Torque Mode <-> Analog Speed: ON/OFF Switching Control Mode of (C-SEL) Signal Switching Mode</p> <p>10 - Analog speed <-> Speed mode for zero function: When controlling speed, zero fixed function can be used</p> <p>11-Position Mode <-> Command Pulse Disabled Position Mode: When Control Position, Command Pulse Disable Function</p> <p>See the "mixed control mode selection" for detailed switching timing.</p>					
Pn001	Internal enable	0~1	0	-	0x001	Immediately
	0-Enable OFF 1-Enable ON					
Pn002	Motor rotation direction selection	0~1	0	-	0x0002	After restart
	<p>For motor end faces:</p> <p>0-Counterclockwise is positive</p> <p>1- Clockwise direction is positive</p>					
Pn003	Default monitoring parameters	0x0~0xff	0xff	-	0x0003	Immediately

	Set the monitoring parameters that are displayed by default after power-on. The setting values are detailed in the monitoring parameters. 0xff indicates that the monitoring parameters are not displayed and the system status is displayed. Note: The alarm is displayed first when the alarm is displayed. The setting parameter cannot be displayed normally.					
Pn004	Servo OFF and stop method selection when Type 1 alarm occurs	0~2	0	—	0x0004	After restart
	0- Stop motor by DB 1- Stop the motor through the DB and then release the DB 2- Do not use DB to keep the motor free Note: DB (Dynamic Brake) is an emergency stop function. If the servo motor is started or stopped by ON/OFF power supply or servo ON in the state that the command is input, the DB circuit will frequently operate, which may cause the internal components of the servo unit to deteriorate. Please execute start and stop of the servo motor with speed input command or position command.					
Pn005	Second type Alarm Stop Method Selection of Servo Generation	0x00~0x01	0	—	0x0005	After restart
	0 - Zero speed stop: Set the speed command to "0" and perform a quick stop 1- Same as Pn004 stop method					
Pn006	Override Warning Checkout Selection	0~1	0	—	0x0006	After restart
	0-No overtravel warning when limit is checked 1-Override warning is detected when the limit is set					
Pn007	Stopping method selection at servo overtravel (OT)	0~2	0	—	0x0007	After restart
	Set the stop mode and post-stop status when servo overtravel occurs: 0 - same as Pn004 stop method 1- Use the torque set by Pn053 as the maximum value, and enter the locked state after decelerating to stop. 2- Use the torque set by Pn053 as the maximum value, enter the free running state after decelerating to stop					
Pn008	Servo lock time after electromagnetic brake holding	0~50	0	10m s	0x0008	Immediately
	When the servo motor is enabled but not running and the brake (/BK) signal and the servo ON (/S-ON) signal are off at the same time, setting this parameter can change the non-powered time from the brake (/BK) signal OFF to the actual input of the motor. Note: The brake delay time is slightly different. When this parameter is set, the motor can be prevented from the slight moving by the weight or the external force of the vertical-axis mechanical movement.					

Pn009	Electromagnetic brake holding time delay	10~100	50	10ms	0x0009	Immediately
	The servo motor won't be electrified when the Servo OFF/Alarm/Main circuit OFF occur during the rotation. By setting this parameter and Pn010 (any one is met), the output timing of the brake signal (/BK) OFF can be adjusted. Note: The relevant logic is described in "Keep brake action"					
Pn010	Electromagnetic brake release speed	0~10000	100	rpm	0x0010	Immediately
	See the description of "Electromagnetic brake delay" for details					
Pn012	External regenerative resistor power	0~65535	0	10W	0x0012	Immediately
	When connecting an external regenerative resistor, the regenerative resistor power should be set to a value that matches the allowable capacity of the connected external regenerative resistor. The setting differs depending on the cooling condition of the external regenerative resistor. Note: Refer to "Setting the regenerative resistor" for details					
Pn013	External regenerative resistor	0~65535	0	mΩ	0x0013	Immediately
	When connecting an external regenerative resistor, the regenerative resistor value should be set to the value matching the connected external regenerative resistor. Note: The minimum regenerative resistance of each power section could be different. Please refer to "Set regenerative resistor" for details. Otherwise, the internal components of the servo unit may be damaged.					
Pn015	Overload warning value	1~100	20	%	0x0015	After restart
	Setting this parameter can change the overload warning detection time. For example, the factory overload warning detection time is 20% of the overload warning detection time. Note: The overload alarm detection time is detailed in "Overload alarm"					
Pn016	Motor overload detection base current derating setting	10~100	100	%	0x0016	After restart
	This parameter can change the motor current threshold for calculating the overload alarm, which can shorten the overload alarm detection time. Note: This value is invalid when the motor current is rated above 200%.					
Pn030	Reserved	0~65535	0	-	0x0030	Immediately
Pn031	Parameter modification operation lock	0~1	0	-	0x0031	After restart
	0-allow panel parameters modification 1-prohibit panel parameters modification					
Pn040	Method to use absolute encoder	0~1	0	—	0x0040	After restart

	0 - Use an absolute encoder as an absolute encoder: If the motor is an absolute multi-turn encoder, setting this parameter to 1 can use the multi-turn absolute function 1- Use an absolute encoder as an incremental encoder: When used as an incremental encoder, the power-off position won't be recorded and warning or alarm, corresponding to multiple revolutions, won't happen either when the battery is undervoltage or the drive is de-energized					
Pn041	Absolute encoder battery warning/warning selection	0~1	0	—	0x0041	After restart
	0- Set the low battery voltage as a fault: The driver powers up/resets for 4~9 seconds to monitor the battery status. Undervoltage will be reported as an under voltage alarm (Er. 830). Over time will not be detected. 1- Set the low battery voltage as a warning: Undervoltage (below 3V) will be reported as an under voltage alarm (Al.930). It will always monitor the battery voltage and can be self-recovery meanwhile enable running is out of restriction					
Pn044	Fully closed loop application related switches	0-51	1	-	0X0045	After restart
	0: Encoder pulse frequency division output, the grating ruler power is valid, and the grating ruler signal is not filtered 1: Pulse output, the power of the grating ruler is valid, and the grating ruler signal is not filtered 2: The pulse frequency division output of the device, the power supply of the grating ruler is invalid, and the grating ruler signal is not filtered 3: Rush output, the power of the grating ruler is invalid, and the grating ruler signal is not filtered 4: The pulse frequency division output of the device, the power supply of the grating ruler is effective, 0~4MHZ filtering 16: The grating ruler pulse output, the grating ruler power supply is valid, 0~4MHZ filtering 18: encoder pulse frequency division output, grating ruler power supply is invalid, 0~4MHZ filtering 19: Scale pulse output, grating ruler power supply is invalid, 0~4MHZ filter 32: Coder pulse frequency output, grating ruler power supply is valid, 0~1MHZ filter 33: Scale pulse output, scale power supply is valid, 0~1MHZ filter/[49] scale pulse output, scale power supply is valid, 0~500KHZ filter 34: Coder pulse frequency output, grating ruler power is invalid, 0~1MHZ filter 35: Scale pulse output, the power supply of the scale is invalid, 0~1MHZ filter 48: Coder pulse frequency output, grating ruler power is valid, 0~500KHZ filtering 50: Coder pulse frequency output, grating ruler power is invalid, 0~500KHZ filter 51: grating ruler pulse output, grating ruler power is invalid, 0~500KHZ filter					
Pn045	Undervoltage function selection	0x00~0x02	0	—	0x0045	After restart
	0 - No Detection of Main Circuit Descent Warning 1- Detection of Main Circuit Descent Warning 2 - Detect main circuit down warning and perform torque limit. The relevant torque limit is matched with Pn046/Pn047. For details, refer to "Main circuit undervoltage torque limit".					
Pn046	Torque limit when main circuit voltage drops	0~100	50	%	0x0046	Immediately
	According to the under voltage warning, it will impose the torque limit inside the servo unit. For details, see the "Torque limit under voltage" instruction.					
Pn047	Torque limit release time	0~1000	100	ms	0x0047	Immediately

	when main circuit voltage drops					
	After the under-voltage warning signal releases, the torque limit value is controlled within the servo unit according to the set time. For details, see "Under-voltage limit of the main circuit".					
Pn050	Torque limit setting	0~3	1	-	0x0050	Immediately
	0 - Analog torque (torque mode is invalid) 1 - maximum torque limit is 1 2 - maximum Forward torque limit is 1 and maximum Reverse torque limit is 2 3 - Maximum torque limit is 1 when the "Torque Limit Switching" switch is OFF while Maximum torque limit is 2 when it's ON					
Pn051	Maximum torque limit 1	0~500	500	%	0x0051	Immediately
Pn052	Maximum torque limit 2	0~500	500	%	0x0052	Immediately
Pn053	Emergency stop torque	0~800	800	%	0x0053	Immediately
	The torque when set the motor stop method to deceleration stop.					
Pn061	Panel parameter display selection	0x00~0x01	1	—	0x0061	After restart
	0- Only display setting parameters 1- Show all parameters					
Pn070	Encoder divider pulses	16~41943 04	2048	-	0x0070	After restart
	The number of pulses per cycle from the encoder is divided by frequency in accordance with the set value of this parameter. Please set it according to the system specifications of the machine and host device. Note: The set value is the number of A/B quadrature output pulses in one turn. The setting of the number of encoder crossover pulses will be limited due to the resolution of the encoder. For details, see the "Divided pulse output setting" instruction.					
Pn072	negate the divide frequency output	0~1	0	-	0x0072	After restart
	A/B pulse phase sequence logic when setting forward/reverse: 0- Don't negate the pulse output: When forward, A is ahead of B 1- Negate the pulse output: When forward, B is ahead of A					
Pn080	Local communication address	0x00~0x7F	1	—	0x0080	After restart
Pn081	485 communication baud rate selection	0~4	1	—	0x0081	After restart
	0-9600bps 1-19200bps 2-38400bps 3-57600bps 4-115200bps					
Pn082	485 communication	0~5	1	—	0x0082	After restart

	verification method					
	0-no parity (N,8,1) 2-odd check (O,8,1) 4-Even Check (E,8,2)	1-even parity (E,8,1) 3-no check (N,8,2) 5-Odd Check (O,8,2)				
Pn083	Canopen communication baud rate selection	0~6	4	-	0x0083	After restart
Pn085	Communication data storage EEPROM	0x0~0xFF	0x1	-	0x0085	Immediately
	<p>Bit0: 0: Store data to Eeprom 1: Do not store data to Eeprom Bit1: 0: When power on, the value of Pn085 is forced to Bit0 to 1 1: When power on, the value of Pn085 Bit0 is not forced to 1 Panel keyboard operation settings: 00: Modified data will be stored in Eeprom after power-off. Pn085 will change to 01 after the servo is restarted. After connecting to the host computer, it will display 00. Disconnect the host computer and re-power on. The panel displays Pn085n085 as 01 again (not stored in Eeprom after power-on Store electricity to Eeprom)</p>					
Pn086	Communication address mapping function switch	0~1	0	-	0x0086	Immediately
	<p>0: The mapping function is off 1: The mapping function is turned on</p>					
Pn087	Mapping source address 1	0x0000 ~ 0xFFFF	0x110	-	0x0087	Immediately
Pn088	Mapping target address 1	0x0000 ~ 0xFFFF	0x410	-	0x0088	Immediately
Pn089	Mapping source address 2	0x0000 ~ 0xFFFF	0x201	-	0x0089	Immediately
Pn08A	Mapping target address 2	0x0000 ~ 0xFFFF	0x304	-	0x008A	Immediately
Pn08B	Encoder alarm threshold (°C)	0~255	80	°C	0x008B	After repower
	<p>The over-temperature alarm value of Nikon encoder is fixed at 90°C, and Pn08B is invalid to the over-temperature alarm value change of Nikon encoder. 8 (inclusive) Tamagawa encoders below flange have no encoder over-temperature alarm. For encoders that cannot detect over-temperature alarms, Pn08B will be automatically written as 0 in the program; Tamagawa encoders above 130 (inclusive) flange must be in Pn08C In the case of bit4=1, Pn08B is written into the encoder EEPROM to be effective, otherwise it will not be executed (Pn08B=0 turns off the over-temperature alarm function)</p>					
Pn08C	Encoder alarm detection selection	0x00~0x11	0x00	-	0x008C	After repower
	<p>It must be valid when Pn08C bit4=1, Pn08B is written to the encoder EEPROM, otherwise it will not be executed</p>					

10. 2 Gain Related Pn1 Group

Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn100	Rotary inertia ratio	0~20000	100	%	0x0100	Immediately
	Rotary inertia ratio = load inertia of motor shaft conversion / rotor rotary inertia of servo motor *100%					
Pn101	First speed gain	1~2000	40.0	Hz	0x0101	Immediately
	Determine the parameters of the speed loop responsiveness. It becomes a delay element of the outer position loop when the response of the speed loop is low, so overshoot or vibration of the speed command occurs. In the range where the mechanical system does not vibrate, the larger the value is set, the more stable the servo system becomes and the better the responsiveness will be.					
Pn102	First speed integration time constant	0.15~51 2	20.00	ms	0x0102	Immediately
	In order to respond to small input, the speed loop contains integral elements. Since this integral element is a delay factor for the servo system, when the time parameter is set too large, overshoot may occur, or the positioning time may be extended meanwhile resulting in poor responsiveness.					
Pn103	First position gain	1~2000	40.0	1/s	0x0103	Immediately
	The position loop response is determined by the position loop gain. The higher the setting of the position loop gain is, the higher the responsiveness and the shorter the positioning time will be. The position loop gain cannot be increased beyond the rigidity of the mechanical system. To increase the position loop gain to a larger value, the rigidity of the machine must be increased.					
Pn104	First torque command filter	0~655.3 5	1.00	ms	0x0104	Immediately
	Adjusting the parameters of the torque command filter may eliminate the machine vibration caused by the servo drive. The smaller the value is, the better the responsiveness can be. However, the conditions are restricted by the machine conditions.					
Pn105	Second speed gain	1~2000	40.0	Hz	0x0105	Immediately
	Determine the parameters of the speed loop responsiveness. It becomes a delay element of the outer position loop when the response of the speed loop is low, so overshoot or vibration of the speed command occurs. In the range where the mechanical system does not vibrate, the larger the value is set, the more stable the servo system becomes and the better the responsiveness will be.					
Pn106	The second speed integration time constant	0.15~51 2	20.00	ms	0x0106	Immediately
	In order to respond to small input, the speed loop contains integral elements. Since this integral element is a delay factor for the servo system, when the time parameter is set too large, overshoot may occur, or the positioning time may be extended meanwhile resulting in poor responsiveness.					
Pn107	Second position gain	1~2000	40.0	1/s	0x0107	Immediately
	The position loop response is determined by the position loop gain. The higher the setting of the position loop gain is, the higher the responsiveness and the shorter the positioning time will be. The position loop gain cannot be increased beyond the rigidity of the mechanical system. To increase the position loop gain to a larger value, the rigidity of the machine must be increased.					
Pn108	Second torque command filter	0~655.3 5	1.00	ms	0x0108	Immediately

	Adjusting the parameters of the torque command filter may eliminate the machine vibration caused by the servo drive. The smaller the value is, the better the responsiveness can be. However, the conditions are restricted by the machine conditions.					
Pn110	Gain switching mode selection switch	0x00-0x01	0	—	0x0110	Immediately
	<p>The gain switching function includes two methods of “manual gain switching” using an external input signal and “automatic gain switching” automatically switching. By using the gain switching function, gain can be increased and positioning time can be shortened during the positioning time. When the motor is stopped. Reduce gain and suppress vibration.</p> <p>0- Manual Gain Switching of the External Input Signal (G-SEL) 1- When the automatic switching condition is met (Pn111), it automatically switches from the first gain to the second gain; otherwise, it switches back to the first gain.</p>					
Pn111	automatic switching condition of position control gain	0x00-0x05	0	—	0x0111	Immediately
	<p>Set the conditions for automatic gain switching: 0-positioning completion signal ON 1-Positioning completion signal OFF 2-positioning proximity signal ON 3- positioning proximity signal OFF 4- position command is 0 after filtering and pulse input is OFF 5- position command pulse input is ON If the conditions are met, then switch to the second gain, otherwise switch to the first gain</p>					
Pn112	Gain switching transition time 1	0-65535	0	ms	0x0112	Immediately
	After finish the Waiting Time from the time when the switching condition has been met, the gain of the first position loop is changed linearly to the gain of the second position loop in the transition time.					
Pn113	Gain switching transition time 2	0-65535	0	ms	0x0113	Immediately
	After finish the Waiting Time from the time when the switching condition has been met, the gain of the second position loop is changed linearly to the gain of the first position loop in the transition time.					
Pn114	Gain switching wait time 1	0-65535	0	ms	0x0114	Immediately
	The time from when switching condition is established from the first gain to the second gain to when the switching is actually started					
Pn115	Gain switching wait time 2	0-65535	0	ms	0x0115	Immediately
	The time from when switching condition is established from the second gain to the first gain to when the switching is actually started					
Pn121	Speed feedforward gain	0-100	0	%	0x0121	Immediately
	The time from when switching condition is established from the second gain to the first gain to when the switching is actually started					
Pn122	Speed feedforward filter time	0-64	0.00	ms	0x0122	Immediately
	Speed feedforward low-pass filter time constant can slow position overshoot and torque jump caused by feedforward					
Pn123	Use V-REF as speed feedforward selection	0x00-0x01	0	—	0x0123	After restart

	Speed feedforward is a function to shorten the positioning time. It is possible to select speed feed forward via external analog V-REF. 0-None 1- Use V-REF as speed feed forward input					
Pn124	Speed/position control selection (T-REF assignment)	0~1	0	—	0x0124	After restart
	Torque feedforward is a function to shorten the positioning time. Torque feedforward can be selected by external analog T-REF. 0-None 1- Use T-REF as a torque feed forward input					
Pn130	Speed loop control method (PI/IP)	0~1	0	—	0x0130	After restart
	0-PI control 1-I-P control					
Pn131	Speed loop P/PI switching condition selection switch	0x00~0x04	0	—	0x0131	Immediately
	The mode switch is a function that automatically switches P control and PI control. Through setting the switching condition by this parameter and meeting the corresponding switching condition value can suppress overshoot during acceleration and deceleration and shorten the settling time. 0- Conditioned by internal torque command 1- Conditioned by speed instruction 2- Conditioned by acceleration 3- Conditioned by position deviation pulse 4-No mode switch function					
Pn132	Speed loop P/PI switching condition (torque command)	0~800	200	%	0x0132	Immediately
	When the torque command exceeds the torque set by this parameter, the speed loop will be switched to P control, otherwise PI control					
Pn133	Speed loop P/PI switching condition (speed command)	0~10000	0	rpm	0x0133	Immediately
	When the speed command exceeds the speed set by this parameter, the speed loop will be switched to P control, otherwise PI control					
Pn134	Speed loop P/PI switching conditions (acceleration)	0~30000	0	rpm/s	0x0134	Immediately
	When the speed command exceeds the acceleration set by this parameter, the speed loop will be switched to P control, otherwise PI control					
Pn135	Speed loop P/PI switching conditions (position deviation)	0~10000	0	Unit	0x0135	Immediately
	When the position deviation exceeds the value set by this parameter, the speed loop will be switched to P control, otherwise PI control					
Pn140	IF suppression control options	0x00~0x11	0x0010	—	0x0140	Immediately
	The IF suppression control function effectively suppresses the continuous vibration of about 100 to 1000 Hz that occurs when the control gain is increased. 0x1#: Automatic setting of IF suppression frequency through intelligent setting and bandwidth setting 0x0#: Not set by intelligent setting, bandwidth setting, only manual setting 0x#1: IF suppression frequency setting is valid 0x#0: IF suppression frequency setting is invalid					
Pn142	IF suppression frequency	1~3000	100.0	Hz	0x0142	Immediately
	Set IF vibration frequency value					

Pn143	IF damper attenuation gain	0~300	0	%	0x0143	Immediately
	Increasing this parameter can increase the vibration suppression effect. However, if the setting is too large, the vibration may be increased. When confirming the vibration suppression effect, simultaneously gradually increase the setting value by each 10% in the range of 0% to 200%. If the vibration suppression effect is still not achieved after reaching 200%, please stop the setting and reduce the control gain appropriately.					
Pn150	Notch filter 1 automatic adjustment selection	0x00~0x01	1	—	0x0150	Immediately
	0 - Automatic adjustment without auxiliary functions 1- Automatic adjustment through auxiliary functions					
Pn151	Notch filter 2 automatic adjustment selection	0x00~0x01	1	—	0x0151	Immediately
	0 - Automatic adjustment without auxiliary functions 1- Automatic adjustment through auxiliary functions					
Pn152	Automatic trap resonance detection sensitivity	1~200	100	%	0x0152	Immediately
	It's used to set the sensitivity for automatically detecting the resonant frequency. The smaller the value is set, the more sensitive it will be for resonance, the easier it is to detect vibration, and the smaller it is, the more likely it is to falsely detect the resonance frequency.					
Pn153	Notch filter 1 frequency	50~5000	5000	Hz	0x0153	Immediately
	Sets the frequency of the first notch filter that suppresses resonance. When this parameter is set to 5000, the function of the notch filter is invalid. Note: Do not set the notch filter frequency close to the response frequency of the speed loop. At least this frequency should be set to more than 4 times of the speed loop gain, otherwise it may affect the overall performance of the system.					
Pn154	Notch filter 1Q value	0.5~10	0.70	-	0x0154	Immediately
	The Q value of the notch filter refers to the setting value of the filter frequency width related to the notch filter frequency. The width of the recess varies with the Q value of the notch filter, and the larger the Q value of the notch filter is set. The more sunk and the narrower the width of the filter frequency will be.					
Pn155	Notch filter 1 depth	0~1	0.000	-	0x0155	Immediately
	The notch filter depth refers to the setting of the filter frequency depth related to the notch filter frequency. The depth of the recess varies with the depth of the notch filter. The smaller the notch filter depth value is, the deeper the depression and the higher the vibration suppression effect will be. But setting it too small will increase the vibration					
Pn156	Notch filter 2 frequency	50~5000	5000	Hz	0x0156	Immediately
	Sets the frequency of the second notch filter that suppresses resonance. When this parameter is set to 5000, the function of the notch filter is invalid. Note: Do not set the notch filter frequency close to the response frequency of the speed loop. At least this frequency should be set to more than 4 times of the speed loop gain, otherwise it may affect the overall performance of the system.					
Pn157	Notch filter 2Q value	0.5~10	0.70	-	0x0157	Immediately
	The Q value of the notch filter refers to the setting value of the filter frequency width related to the notch filter frequency. The width of the recess varies with the Q value of the notch filter, and the larger the Q value of the notch filter is set. The more sunk and the narrower the width of the filter frequency will be.					

Pn158	Notch filter 2 depth	0~1	0.000	-	0x0158	Immediately
	The notch filter depth refers to the setting of the filter frequency depth related to the notch filter frequency. The depth of the recess varies with the depth of the notch filter. The smaller the notch filter depth value is, the deeper the depression and the higher the vibration suppression effect will be. But setting it too small will increase the vibration					
Pn160	Disturbance compensation function selection	0x00~0x01	0	—	0x0160	Immediately
	Set disturbance compensation function switch: 0- Not use 1-use					
Pn161	Disturbance observer cutoff frequency	1~1000	150.0	Hz	0x0161	Immediately
	Set the disturbance compensation gain. Increasing it can increase the effect of suppressing the disturbance effect, but excessive noise will occur.					
Pn163	Disturbance compensation coefficient	0~100	0	%	0x0163	Immediately
	Set the disturbance compensation coefficient and the received position command or speed command, then add the disturbance torque compensation value to the torque command					
Pn165	Disturbance observer inertia correction coefficient	1~1000	100	%	0x0165	Immediately
The disturbance observer inertia is set by this parameter to adjust the identification error caused by inaccurate inertia setting. Note: When the inertia ratio is set correctly, the value is set to 100						
Pn166	Speed observer switch	0~1	0		0x0166	After restart
	Set speed observation function switch: 0- Invalid 1- valid					
Pn167	Speed observer cutoff frequency	1~500	80	Hz	0x0167	Immediately
	This parameter sets the speed observer bandwidth. Increasing the set value will increase the response speed of the speed feedback value to track the real speed. If the speed is too large, vibration and noise may occur.					
Pn170	Friction torque compensation cutoff speed	0~1000	20	rpm	0x0170	Immediately
	Friction compensation function is a function that compensates for viscous friction and fixed load changes. It is adjusted according to the friction compensation coefficient. Generally, please set the friction compensation coefficient to 95% or less. If the effect is not obvious enough, please increase the friction compensation cut-off speed at a rate of 10% each within the range that does not generate vibration					
Pn171	Friction torque positive compensation coefficient	0~100	0	%/100rpm	0x0171	Immediately
	The higher the setting value is, the better the effect is. However, if the setting value is too high, the response is more likely to vibrate. Usually we set the setting value below 95%.					
Pn172	Friction torque reverse compensation coefficient	0~100	0	%/100rpm	0x0172	Immediately

	The higher the setting value is, the better the effect is. However, if the setting value is too high, the response is more likely to vibrate. Usually we set the setting value below 95%.					
Pn175	Robust control options	0x00-0x01	1	—	0x0175	After restart
	Robust control function means that the function of stable response can be obtained through automatic adjustment within a certain range, regardless of mechanical type, load fluctuation, or inertia change. Set the robust control function switch: 0-Invalid 1-valid					
Pn177	Robust control tuning value	10~80	40.0	Hz	0x0177	Immediately
	Set the gain-tuning value of the robust control. The larger the value is set, the faster the system responds, but system overshoot and excessive noise may occur.					
Pn178	Minimum load value of robust control	0~500	0	%	0x0178	Immediately
	Set the robust control load factor. The larger the value is set, the faster the system responds, but it will be noisier. When the inertia is large, increasing the value properly could reduce overshoot.					
Pn185	Vibration detection options	0x00-0x02	0	—	0x0185	Immediately
	This function can automatically detect the value related alarms or warnings in order to detect the machine vibration under normal operating conditions. The perform way after setting the vibration detection: 0-No vibration detected 1-warning after vibration is detected 2-Alarming after vibration is detected					
Pn186	Vibration detection sensitivity	50~500	100	%	0x0186	Immediately
	Set the sensitivity of the detected vibration. The smaller the setting value is, the more sensitive it is. If the setting is too small, the vibration may be detected by mistake during normal operation. Note: The detection sensitivity of the vibration alarm and vibration alarm may differ depending on the state of the machine being used.					
Pn187	Vibration detection value	0~5000	50	rpm	0x0187	Immediately
	Set the threshold for vibration detection. The smaller the setting is, the easier it is to detect the vibration. If the setting is too small, the vibration may be detected by mistake during normal operation. Note: The vibration detection values of vibration alarm and vibration warnings may differ according to the condition of the used machine					

10. 3 Position Related Pn2 Group Parameters

Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn200	Pulse input filter selection	0~2	0	-	0x0200	After restart

	<p>Use this parameter to select the position command filter to better suppress the interference in the command pulse</p> <p>0-line drive filter ~1MHZ 1-collector open-circuit filter 2-line drive filter 1~4MHZ</p> <p>Note: Please set a reasonable filter according to the pulse frequency, otherwise it may cause poor pulse immunity or pulse loss.</p>					
Pn201	Pulse input form	0~6	0	-	0x0201	After restart
	<p>0-pulse + direction positive logic 1-CW+CCW positive logic 4-4 times of quadrature encoding 5-pulse + direction negative logic 6-CW+CCW negative Logic</p>					
Pn202	Pulse input direction negation	0~1	0	-	0x0202	After restart
	<p>Select the negation of pulse input direction:</p> <p>0-positive polarity 1-negative polarity</p>					
Pn203	Command pulse input magnification	1~100	1	x1倍	0x0203	Immediately
	<p>Set the command pulse input magnification value to be used in conjunction with ON/OFF of the command pulse magnification switching signal for switching the position command pulse input magnification to 1 and the parameter setting multiple</p> <p>Note: The input pulse frequency is too low. If the value is set too large, the speed may not be steady.</p>					
Pn204 Pn206	Electronic gear ratio numerator	0~107374182 4	64	-	0x0206 0x0207	After restart
	Electronic gear ratio denominator	1~107374182 4	1	-	0x0208 0x0209	After restart
	<p>Position mode full closed loop is invalid:</p> <p>The electronic gear ratio is a function to set the movement of the workpiece in 1 pulse unit of the upper device input command, such as the screw drive, the screw pitch is 10mm, and the upper system requires the motor shaft and the machine deceleration ratio on the load side to be</p> <p>When N1/N2 (the load shaft rotates N1 times when the motor rotates N2 times), then: Electronic Gear Ratio numerator /Electronic Gear Ratio denominator = Encoder Resolution / Pulse Number of Upper System 1r * Reduction Ratio N1/N2</p> <p>When fully closed loop is valid:</p> <p>The electronic gear ratio is the ratio of the amount of movement of the workpiece per pulse unit input by the host device and the amount of movement per pulse output by the grating ruler.</p> <p>Such as screw drive, the screw pitch is 10mm, and the grating ruler resolution is 0.5um.</p> <p>The upper system requires that the number of pulses for the motor to rotate 1r is 20000, that is, the pulse equivalent is 0.5um/pulse, and the movement of the grating ruler is 0.5um to output 1 pulse, then:</p> <p>Electronic Gear Ratio numerator /Electronic Gear Ratio denominator = Input command movement amount per pulse / The grating ruler outputs the movement amount of 1 pulse=0.5/0.5=1/1</p>					
Pn208	Internal position command	0~4	0	—	0x0208	After repower

	0-position command selection external pulse input 1-position command selection internal position command 2-Tracking electronic cam 3- reserved 4-CANopen mode When using CANopen mode, Pn208 must be set to 4 (CANopen mode)					
Pn211	Position command low-pass filter time constant	0~655	0	ms	0x0211	After stop
	This parameter is used to set the time constant of the first-order low-pass filter corresponding to the position command and it can reduce the mechanical shock in the case of abrupt changes in the input pulse command frequency by setting this parameter.					
Pn212	Average filter time in position instruction rolling	0~1000	0	ms	0x0212	After stop
	This parameter is used to set the time constant of the moving average filter of the corresponding position instruction. It can reduce the mechanical shock in the case of abrupt changes in the input pulse command frequency by setting this parameter.					
Pn230	Low-frequency vibration suppression options	0x00~0x02	0	—	0x0230	Immediately
	This parameter is used with Pn231 as the automatic adjustment mode setting 0 - No vibration suppression 1- Additional vibration suppression function for specific frequency 2-Add vibration suppression to 2 different frequencies					
Pn231	Automatic adjustment selection in low-frequency vibration suppression	0x00~0x01	1	—	0x0231	Immediately
	This parameter is set to choose if the low-frequency vibration suppression is automatically set in the intelligent settings, bandwidth settings and other auxiliary functions: 0 - Vibration suppression function won't be automatically adjusted via auxiliary functions 1- Vibration suppression function will be automatically adjusted via auxiliary functions					
Pn232	Low-frequency vibration detection sensitivity	0.1~300	40.0	%	0x0232	Immediately
	This parameter is used to set the sensitivity of low-frequency vibration detection when the positioning is completed. The smaller the sensitivity is set, the easier it is to automatically detect the low frequency vibration frequency point.					
Pn235	Low-frequency	1~200	200.0	Hz	0x0235	Immediately

	vibration suppression 1 frequency					
	This parameter is used to set the frequency of low frequency vibration suppression 1					
Pn236	Low Frequency Vibration Suppression 1 Correction	10~1000	100	%	0x0236	Immediately
	This parameter is used to set the correction coefficient of low-frequency vibration suppression 1. The larger the value is set, the more obvious the suppression effect of low-frequency is, and setting it too small may cause long positioning time.					
Pn237	Low-frequency vibration suppression 2 frequency	1~200	200.0	Hz	0x0237	Immediately
	This parameter is used to set the frequency of low-frequency vibration suppression 2					
Pn238	Low-frequency Vibration Suppression 2 Correction	10~1000	100	%	0x0238	Immediately
	This parameter is used to set the correction coefficient of low-frequency vibration suppression 2. The larger the value is set, the more obvious the suppression effect of low-frequency is, and setting it too small may cause long positioning time.					
Pn240	Model tracking control selection	0x00~0x01	0	—	0x0240	Immediately
	Model-tracking control specifically selects the function of positioning, model tracking control selection switch is: 0- Not use model tracking control 1- Use model tracking control					
Pn241	Model tracking control gain	1~2000	50.0	1/s	0x0241	Immediately
	The size of the model tracking control gain determines the response speed of the servo system. If the model tracking control gain is increased, the responsiveness becomes faster and the positioning time becomes shorter. When the model tracking control is effective, the position response and deviation of the servo system are determined by this parameter, rather than position gain					
Pn242	Model tracking control attenuation coefficient	50~200	100.0	%	0x0242	Immediately

	The tracking attenuation coefficient of the model decreases, and the position tuning section is easy to cause excessive overshoot. If the setting is too small, the position oscillates easily. When the setting increases, the position overshoot decreases, but when the position is too large, the position easily rebounds, causing the positioning time to change. Long, it is recommended to keep this value unchanged during normal use.					
Pn243	Model tracking control speed feedforward gain	0~1000	100.0	%	0x0243	Immediately
	The feed forward gain of the model tracking speed is reduced, and the responsiveness is slower, but position overshoot doesn't easily occur. If the feedforward gain is too small, the position deviation will end in a long time.					
Pn244	Model tracking control forward torque feedforward gain	0~1000	100.0	%	0x0244	Immediately
	It's a forward position command and could be used when adjusting the forward response separately. When it is increased, the torque feed forward rises faster and the positioning time can be shortened appropriately.					
Pn245	Model tracking control reverse torque feedforward gain	0~1000	100.0	%	0x0245	Immediately
	It's a reverse position command and could be used when adjusting the forward response separately. When it is increased, the torque feed forward rises faster and the positioning time can be shortened appropriately.					
Pn246	Second model tracking control gain	1~2000	50.0	1/s	0x0246	Immediately
	Use second gain when model tracking is valid.					
Pn247	Second model tracking control attenuation coefficient	50~200	100.0	%	0x0247	Immediately
	Use second gain when model tracking is valid.					
Pn249	Speed feedforward/torque feedforward selection	0x00~0x01	0	—	0x0249	Immediately

	<p>0-not use model tracking control and external speed and torque feed forward at the same time 1-use model tracking control and external speed and torque feed forward at the same time When using the model tracking control, the optimal feedforward will be set inside the servo, and it is not recommended to use the "speed feed forward (V-REF) input" and "torque feed forward (T-REF) input" from the upper unit at the same time. However, it can be used at the same time as needed. In this case, if the input feed forward is incorrect, it may cause overshoot and system instability.</p>					
Pn250	The use way external encoder in full closed loop control	0~3	0	—	0x0250	After repower
	<p>0-Do not use full closed loop function 1- Use in standard running direction 2- Use in reverse running direction When setting the motor forward, the moving direction of the grating ruler is set. If the direction is set incorrectly, it may cause an alarm for overspeed or excessive deviation between the motor and the load. You can manually move the load before running, and change this parameter to make the monitoring parameter Un007 (feedback pulse counter)) Run after the change direction is consistent with Un012 (external encoder feedback pulse counter).</p>					
Pn252	The deviation coefficient between the load of the motor with 1 full closed loop rotation	0~100	20	%	0x0252	Immediately
	<p>Set the coefficient processing of the deviation between the motor and the load after the motor runs for 1 revolution. For example, if this parameter is set to 0%, the deviation will be 1000 after 1 revolution, and the deviation will be accumulated on the basis of 1000 at the beginning of the second revolution, and set to 20% . The deviation is accumulated on the basis of 200 (1000×20%=200) at the beginning of the second run. If this value is set too large, it may not be able to detect Er.d10 normally. It needs to be set according to the allowable error of the installation between the load and the motor.</p>					
Pn253	External grating ruler resolution	4~1048576	32768	Pulse/r	0x0253 0x0254	After repower
	Set the motor to run for one revolution and the resolution of the external grating ruler (after 4 times the frequency).					
Pn257	Motor-load deviation is too large setting	0~10737418 24	1000	unit	0x0257 0x0258	Immediately

	In position control, the upper device can receive the positioning approach signal before confirming the positioning completion signal to prepare for the action sequence after the positioning is completed, which can shorten the time required for the action when the positioning is completed, the command pulse number of the host device and the servo The signal is output when the difference of the motor movement amount (position deviation) is lower than the set value.					
Pn260	Position near signal width	1~107374182 4	1073741824	Command unit	0x0260 0x0261	Immediately
	In the position control, the host device can receive the positioning proximity signal before confirming the positioning completion signal, so as to prepare for the sequence of actions after the positioning is completed and shorten the time required for the positioning to complete the operation, The signal will be output as the difference between the command pulse number of the host device and the servo motor movement (position deviation) is lower than the set value					
Pn262	Positioning completion range	0~107374182 4	7	Command unit	0x0262 0x0263	Immediately
	In the position control, the servo motor positioning completion signal will be output when the difference between the command pulse number from the host device and the servo motor movement amount (position deviation) is lower than the set value that means the host device confirming positioning has been completed.					
Pn264	Maximum position deviation threshold	1~107374182 3	5242880	Command unit	0x0264 0x0265	Immediately
	When the motor operation does not match the instruction, by setting the appropriate Pn264 (maximum position deviation threshold), an abnormal condition can be detected and the motor can be stopped.					
Pn266	Excessive position deviation warning setting	10~100	100	%	0x0266	Immediately
	This parameter is used to set the position deviation excessive warning threshold. When the position deviation is greater than the product of the Pn264 (maximum position deviation threshold) and this parameter, an excessive position deviation warning will be generated.					
Pn267	Position Deviation Alarm Threshold when the Servo is ON	1~107374182 3	5242880	Command unit	0x0267 0x0268	Immediately
	This parameter is used to set the threshold for excessive position deviation alarm at the moment of servo ON. When the servo is ON, if the position deviation value exceeds this setting value, an excessive servo deviation alarm will be generated when the servo is ON.					
Pn269	Position Deviation Warning Threshold when the Servo is ON	10~100	100	%	0x0269	Immediately
	This parameter is used to set the warning threshold for excessive position deviation at the servo ON moment. When the servo is turned ON and the position deviation is greater than the product of "Excessive position deviation warning threshold at servo ON" and the parameter, the warning will be					

	generated when the servo is ON.					
Pn270	speed limit value when the Servo is ON	0~10000	10000	rpm	0x0270	Immediately
	If the servo is turned ON with the position deviation accumulated, the speed limit is executed by this parameter. When the command pulse is input in this state, the alarm Er.D02 (Excessive position deviation alarm caused by speed limit during servo ON) is displayed when the set value of Pn264 (maximum position deviation threshold) is exceeded.					
Pn272	Position deviation clear mode	0x00~0x03	0	—	0x0272	After restart
	Set the clear mode of the switch position deviation clear signal (/CLR): 0- Cleared when level is ON 1- Cleared when the rising edge OFF->ON 2-Cleared when level is OFF 3- Cleared when the falling edge ON->OFF					
Pn273	Position deviation removal method selection	0x00~0x02	0	—	0x0273	After restart
	Set the deviation removal method: 0- Servo OFF, Alarm and /CLR Signal Position Deviation can be cleared 1-/CLR signal position deviation can be cleared 2-Alarm and /CLR signal position deviation can be cleared Note: 1. For details on the pulse amplitude of the clear signal, refer to the description of "Deviation Clearance". 2. In the position control, the position deviation remains unchanged when the servo motor stops due to the travel limit.					
Pn274	Positioning completion signal output time	0x00~0x02	0	—	0x0274	After restart
	Set the deviation removal method: 0- Servo OFF, Alarm and /CLR Signal Position Deviation can be cleared 1-/CLR signal position deviation can be cleared 2-Alarm and /CLR signal position deviation can be cleared Note: 1. For details on the pulse amplitude of the clear signal, refer to the description of "Deviation Clearance". 2. In the position control, the position deviation remains unchanged when the servo motor stops due to the travel limit.					

10. 4 Speed Related Pn3 Group Parameters

Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn300	Analog speed	150 ~3000	600	0.01V / Rated speed	0x0300	Immediately

	command gain					
	This parameter is used to set servo motor speed that should be equal to analog voltage value (V-REF) required for the speed command of the rated value. Caution: Do not apply more than -10~10V and exceeding this range may cause damage to the driver.					
Pn301	Analog speed command negation	0~1	0	-	0x0301	Immediately
	Set the voltage polarity of the analog speed command: 0-Positive polarity: positive voltage corresponds to positive speed command 1- Negative polarity: positive voltage corresponds to negative speed command					
Pn302	Analog speed instruction filter time	0~6 55.35	0.4 0	ms	0x0302	Immediately
	The function could be set to smooth the speed command when one delay filter is applied to the analog speed command (V-REF) input and it does not usually need to be changed. If the set value is too large, the responsiveness may decrease. Please set this parameter while confirming the response.					
Pn303	Analog speed command dead zone range	0~3	0	V	0x0303	Immediately
	In the analog speed control, even if the input command is 0V, the servo motor may rotate at a slight speed. This is because there is a slight deviation in the commands inside the servo unit. This error can be eliminated by setting an appropriate analog speed command deadband range.					
Pn304 Pn305 Pn306	Internal speed 1	0~1 0000	100	rpm	0x0304	Immediately
	Internal speed 2	0~1 0000	200	rpm	0x0305	Immediately
	Internal speed 3	0~1 0000	300	rpm	0x0306	Immediately
	When operating in the internal speed mode, the servo unit provides three internal speed commands and through Switch Internal Speed Command Selection A and B we could select as follow: /SPD-A /SPD-B speed command OFF OFF Zero Speed OFF ON Internal speed 1 ON ON internal speed 2 ON OFF Internal Speed 3					
Pn310	Speed command trapezoidal acceleration time	0~1 0000	0	ms	0x0310	Immediately
	Acceleration of the set speed from 0r/min to the rated speed (corresponding to the motor model). When the given speed is greater or less than the rated speed, the actual acceleration time is calculated in proportion.					
Pn311	Speed command trapezoid	0~1 0000	0	ms	0x0311	Immediately

	al deceleration time					
	Acceleration time of the set speed from 0r/min to the rated speed (corresponding to the motor model). When the given speed is greater or less than the rated speed, the actual acceleration time is calculated in proportion.					
Pn312	Zero speed clamp mode	0~3	3	-	0x0312	Immediately
	Speed mode, setting the switching speed zero clamp signal (/ZCLAMP) working mode: 0-Invalid 1-speed command is set to 0, not clamped after shutdown 2-speed command is set to 0, clamped after shutdown 3-speed command is lower than "zero speed clamp speed threshold"(Pn313), the first speed command is set to 0, clamped after shutdown					
Pn313	Zero Speed Clamp Speed Threshold	0~1 0000	10	rpm	0x0313	Immediately
	Set the zero control switching threshold when "zero speed clamp mode"(Pn312) is set to 3					
Pn317	Rotation determination threshold	1~1 0000	20	rpm	0x0317	Immediately
	When the motor speed is higher than the set value, the switch rotation detection signal (/TGON) is output.					
Pn320	Speed consistent range	0~1 00	10	rpm	0x0320	Immediately
	When the difference between the motor speed and the command speed is lower than the set value, the switch-speed match signal (/V-CMP) would be output.					

10. 5 Torque Related Pn4 Group Parameters

Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn400	Torque command selection	0~1	1	-	0x0400	Immediately
	Select the torque control command source: 0-Internal settings 1- Analog input					
Pn401	Torque command second-order low-pass filter cut-off	100~5000	50 00	Hz	0x0401	Immediately

	frequenc y					
	This parameter is used to set the cut-off frequency of the second-order torque filter. When this parameter is set to 5000, the filter function is invalid.					
Pn402	Torq ue comman d second- order low-pass filter Q	0.5~1	0.5 0	1	0x0402	Immed iately
	This parameter is used to set the Q value of the second-order torque filter. Increasing the Q value can improve the system response, but noise will be generated when the setting is too large.					
Pn403	Torq ue comman d direction setting	0~1	0	-	0x0403	Immed iately
	Set the switching torque command direction selection (/T-SIGN) signal to activate the switch: 0 - Torque command direction selection (/T-SIGN) signal is invalid 1 - Torque command direction selection (/T-SIGN) signal is valid Note: Torque command is invalid when /T-SIGN is valid, torque command is positive when /T-SIGN signal is ON, and torque command is negative when /T-SIGN signal is OFF.					
Pn404	Anal og torque comman d filter time	0~65 5.35	0.0 0	ms	0x0404	Immed iately
	The parameter is used to smooth the torque command when we apply a delay filter to the analog torque command (T-REF) input, usually it does not need to be changed. If the set value is too large, the responsiveness may decrease. So please set it up as we check the response.					
Pn405	Anal og torque comman d gain	10~1 00	30	0.1V/ rated torq ue	0x0405	Immed iately
	This parameter is used to set the analog voltage value (T-REF) required for the rated torque of the servo motor. Caution: Do not apply more than -10~10V, exceeding this range may cause damage to the driver.					
Pn406	Anal og torque comman d negation	0~1	0	-	0x0406	Immed iately
	The analog voltage corresponds to the polarity setting of the torque command: 0-Positive polarity: Positive voltage corresponds to positive torque command 1-Negative polarity: Positive voltage corresponds to negative torque command					
Pn407	Anal og torque comman	0~3	0	V	0x0407	Immed iately

	d dead zone range					
	In analog torque control, even if the input command is 0V, the servo motor may rotate at a slight speed. This is because a slight deviation occurs in the command inside the servo unit. This error can be eliminated by setting an appropriate analog torque command deadband range.					
Pn410	Internal torque command in torque control	500~500	0	%	0x0410	Immediately
	The command source for selecting the torque control is the torque command size setting for internal setting.					
Pn411	Speed control mode setting in torque control	0~1	1	-	0x0411	After restart
	0- select the lower one between the speed corresponding to the analog voltage (V-REF) and the speed set by Pn413 1-select the speed set by Pn413					
Pn412	Speed limit selection	0x00 ~0x01	0	-	0x0412	After restart
	0-motor maximum speed (determined by internal part of the motor model) + torque mode speed limit (Pn411) 1- Overspeed detection alarm speed (determined by internal part of the motor model) + torque mode speed limit (Pn411)					
Pn413	Speed limit in torque control	0~10 000	10 00	rpm	0x0413	Immediately
	This parameter is used to set speed limit in torque control with Pn411					
Pn415	Internal torque control command smooth acceleration time	0 30000	~ 100	ms	0x0415	Immediately
	Internal torque control command smooth acceleration time					
Pn416	Internal torque control command smooth deceleration time	0 30000	~ 100	ms	0x0416	Immediately
	Internal torque control command smooth deceleration time					

Pn420	Target torque reaches the set value	0.0 ~ 500.0	100	-	0x0420	Immediately
	Target torque reaches the set value					
Pn421	Target torque arrival time window	0~1000	5	ms	0x0422	Immediately
	Target torque arrival time window					

10.6 Jogging Related Parameters

Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn500	JOG speed	0~1000	500	rpm	0x0500	Immediately
Pn502	Program JOG operation mode	0x00~0x05	0	-	0x0502	Immediately
	0-(waiting time->forward motion)*number of cycles 1-(waiting time->backward motion)*number of cycles 2-(waiting time->forward motion)*number of cycles->(waiting time->backward motion)*number of cycles 3-(waiting time->backward motion)*number of cycles->(waiting time->forward motion)*number of cycles 4-(waiting time->forward motion->waiting time->backward motion)*number of cycles 5-(waiting time->backward motion->waiting time->forward motion)*number of cycles					
Pn503	Program JOG moving distance	1~1073741824	32768	Command unit	0x0503	Immediately
	Set the JOG movement distance of the running program as the command unit					
Pn505	Program JOG acceleration/deceleration time	2~10000	100	ms	0x0505	Immediately
	Set the time of accelerating from 0r/min to the rated speed (corresponding to the motor model). When the set speed is greater or less than the rated speed, calculate the actual acceleration/deceleration time according to the ratio.					
Pn506	Program JOG waiting time	0~10000	100	ms	0x0506	Immediately

	Set the waiting time between JOG sections of the running program in conjunction with the program JOG operation mode (Pn502)					
Pn507	Program JOG movement times	0~100 0	1	回	0x0507	Immediately
	Set the movement times of the running program in conjunction with JOG operation mode (Pn502) Note: it is infinite when set to 0					
Pn508	Program JOG movement speed	1~100 00	5 00	rpm	0x0508	Immediately

10. 7 Switch Configuration Related Pn6 Group Parameters

Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn600	Digital input signal distribution mode	0~1	1	-	0x0600	After restart
	Set the binary input signal distribution method: 0-Internal fixed: used by pins and functions fixed inside the servo unit. See "CN1 terminal" for details. 1-parameter configuration: It is used according to the function configured on each pin and is configured and used by function code Pn601~Pn609					
Pn601 Pn602 Pn603 Pn604 Pn605 Pn606 Pn607 Pn608 Pn609	CN1-40 input configuration	0~0x114	0x01	-	0x0601	After restart
	CN1-42 input configuration	0~0x114	0x02	-	0x0602	After restart
	CN1-43 input configuration	0~0x114	0x03	-	0x0603	After restart
	CN1-41 input configuration	0~0x114	0x05	-	0x0604	After restart
	CN1-44 input configuration	0~0x114	0x04	-	0x0605	After restart
	CN1-45 input configuration	0~0x114	0x06	-	0x0606	After restart
	CN1-46 input configuration	0~0x114	0x07	-	0x0607	After restart
	CN1-39 input configuration	0~0x114	0x00	-	0x0608	After restart
	CN1-38 input	0~0x114	0x00	-	0x0609	After restart

	configuration					
	<p>0x00: invalid 0x01: Servo enable 0x101: Servo enable reverse 0x02: Positive limit 0x102: Positive limit release 0x03: Negative limit 0x103: Negative limit release 0x04: Alarm clearing 0x104: Alarm clearing inverted 0x05: Manual PI-P control 0x105: Manual PI-P control reverse 0x06: Torque limit switch 0x106: Torque limit switch reverse 0x07: reserved 0x107: reserved 0x08: Internal speed command direction selection 0x108: Internal speed command direction selection D reverse 0x09: Internal speed command selection A 0x109: Internal speed command selection A is reversed 0x0A: Internal speed command selection B 0x10A: Internal speed command selection B is reversed 0x0B: Control mode switch 0x10B: Control mode switch reverse 0x0C: Zero-speed clamp 0x10C: Zero-speed clamp reverse 0x0D: Command pulse prohibited 0x10D: Command pulse prohibited inversion 0x0E: Gain switching 0x10E: Gain switching reverse 0x0F: Torque command direction selection 0x10F: Torque command direction selection reverse 0x10: Command pulse ratio switch 0x110: Command pulse ratio switch reverse 0x12: Motor over temperature input 0x112: Motor over temperature input inverted 0x16: Internal position command trigger 0x116: Internal position command trigger inversion 0x17: Internal position command selection bit0 0x117: Internal position command selection bit0 inverted 0x18: Internal position command selection bit1 0x118: Internal position command selection bit1 inverted 0x19: Internal position command selection bit2 0x119: Internal position command selection bit2 inverted 0x1A: Internal position command selection bit3 0x11A: Internal position command selection bit3 reverse 0x1B: Internal position command selection bit4 0x11B: Internal position command selection bit4 inverted 0x1C: Zero point return enable 0x11C: Zero point return enable reverse 0x1D: Origin signal 0x11D: Origin signal reverse 0x1E: Forward jog 0x11E: Forward jog reverse 0x1F: Negative jog 0x11F: Negative jog 0x20: Internal position stop bit 0x120: Internal position stop bit inverted 0x21: The capture function is enabled 0x121: The capture function is enabled</p>					
Pn610 Pn611 Pn612	Switch input internal configuration 1	0~0x114	0x00	-	0x0610	After restart
	Switch input internal configuration 2	0~0x114	0x00	-	0x0611	After restart
	Switch input internal configuration 3	0~0x114	0x00	-	0x0612	After restart

	<p>0x00: invalid 0x01: Servo enable 0x101: Servo enable reverse 0x02: Positive limit 0x102: Positive limit release 0x03: Negative limit 0x103: Negative limit release 0x04: Alarm clearing 0x104: Alarm clearing inverted 0x05: Manual PI-P control 0x105: Manual PI-P control reverse 0x06: Torque limit switch 0x106: Torque limit switch reverse 0x07: reserved 0x107: reserved 0x08: Internal speed command direction selection 0x108: Internal speed command direction selection D reverse 0x09: Internal speed command selection A 0x109: Internal speed command selection A is reversed 0x0A: Internal speed command selection B 0x10A: Internal speed command selection B is reversed 0x0B: Control mode switch 0x10B: Control mode switch reverse 0x0C: Zero-speed clamp 0x10C: Zero-speed clamp reverse 0x0D: Command pulse prohibited inversion 0x10D: Command pulse prohibited inversion 0x0E: Gain switching 0x10E: Gain switching reverse 0x0F: Torque command direction selection direction selection reverse 0x10F: Torque command direction selection reverse 0x10: Command pulse ratio switch switch reverse 0x110: Command pulse ratio switch reverse 0x12: Motor over temperature input inverted 0x112: Motor over temperature input inverted 0x16: Internal position command trigger inversion 0x116: Internal position command trigger inversion 0x17: Internal position command selection bit0 selection bit0 inverted 0x117: Internal position command selection bit0 inverted 0x18: Internal position command selection bit1 selection bit1 inverted 0x118: Internal position command selection bit1 inverted 0x19: Internal position command selection bit2 selection bit2 inverted 0x119: Internal position command selection bit2 inverted 0x1A: Internal position command selection bit3 selection bit3 reverse 0x11A: Internal position command selection bit3 reverse 0x1B: Internal position command selection bit4 selection bit4 inverted 0x11B: Internal position command selection bit4 inverted 0x1C: Zero point return enable reverse 0x11C: Zero point return enable reverse 0x1D: Origin signal 0x11D: Origin signal reverse 0x1E: Forward jog 0x11E: Forward jog reverse 0x1F: Negative jog 0x11F: Negative jog 0x20: Internal position stop bit inverted 0x120: Internal position stop bit inverted 0x21: The capture function is enabled enabled 0x121: The capture function is enabled enabled</p>					
Pn613 Pn614 Pn615	CN1-25, 26 output configurat ion	0-0x109	0x00 0	-	0x0613	After restart
	CN1-27, 28 output configurat ion	0-0x109	0x00 1	-	0x0614	After restart
	CN1-29, 30 output configurat ion	0-0x109	0x00 2	-	0x0615	After restart

	0x00: Servo ready 0x01: Positioning completed reversed 0x02: Speed consistent reverse 0x03: Rotation detection signal signal 0x04: In the torque limit, torque limit 0x05: In the speed limit, speed limit 0x06: Brake interlock reversed 0x07: Warning 0x08: Positioning proximity signal inverted 0x09: Command pulse input ratio switching signal ratio switching signal reverse 0x0A: Torque reaches output reverse 0x11: Return to origin complete signal origin return	0x100: Servo ready signal inverted 0x101: Positioning completed signal 0x102: Speed consistent signal 0x103: Reverse rotation detection 0x104: Invert the signal in the 0x105: Invert the signal in the 0x106: The brake interlock signal is 0x107: Reverse warning signal 0x108: Positioning proximity signal 0x109: Command pulse input 0x10A: Torque reaches output 0x111: Invert the complete signal of				
Pn622	Function selection switch	0x00~0x11	0	-	0x0622	After restart
	Function selection switch: 0x1#: High binary output alarm output (ALM) signal is valid 0x0#: Low binary output alarm output (ALM) signal is valid 0x#1: Check out warning 0x#0: Not check out warning					
Pn623	SI terminal input filter time	0~32767	0	ms	0x0623	

10.8 Pn7 Expansion Related Parameters

Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn702	Inertia recognition movable range	0.2~20.0	2	r	0x0702	Immediately
	The number of rotations of the motor during the inertia identification process					
Pn705	Initial value of inertia identification	0~20000	0	%	0x0705	Immediately
	Initial value setting of inertia identification					
Pn706	Vibration detection level in inertia identification (rotation)	0~5000	0	r/min	0x0705	Immediately
	Vibration detection level setting in inertia identification					
Pn730	No motor test function selection	0x00~0x01	0	—	0x0730	After repower

	<p>The motorless test function is a function that does not start the motor, simulates the action of the motor inside the servo unit, and confirms the action of the upper device and peripheral equipment. Through this function, you can confirm the wiring, verify the parameter value, and verify the system debugging failure. , Thereby shortening the setting work time and avoiding mechanical damage caused by wrong actions. When running without the motor test function, the action of the motor can be confirmed regardless of whether the motor is connected or not.</p> <p>0-invalid 1-valid</p>					
Pn731	Encoder resolution selection without motor test function	0~3	1	—	0x0731	After repower
	<p>When the motorless test mode is selected, the motor encoder resolution setting: 0-13 bit 1-17 bit 2-20 bit 3-23 bit Note: When the encoder is actually connected, use the resolution of the actual encoder.</p>					
Pn732	Encoder type selection without motor test function	0x00~0x01	0	—	0x0732	After repower
	<p>Set the encoder type without motor test function: 0-incremental encoder 1-absolute encoder</p>					
Pn792	Absolute encoder operation	0~2	0	—	0x0792	After repower
	<p>0-No action 1- Write motor parameters into encoder EEPROM 2-Clear the number of multi-turn encoder turns: The battery is replaced/plugged during the first use or the drive is powered off, and the encoder backup alarm (Er. 810) will be reported when the power is turned on. This parameter is set to 2, and only after power on again Clear. 3-Clear encoder alarm only: When the encoder alarm (Er. 810, Er. 860,) can set this parameter to 3 to clear the encoder alarm but not the encoder multi-turn value, and keep the current position of the motor.</p>					
Pn798	Multi-turn absolute encoder zero offset	0~ 2147483647	0	Unit	0x0792	After repower
	Multi-turn absolute encoder zero offset position setting					
Pn79A	Minimum software limit absolute position (32 bits)	-2147483648~ 2147483647	-21474 83648	Unit	0x079A	After repower
	The minimum software limit absolute position setting, when the absolute position of the motor (UN021) is less than this position, the servo will enter the limit alarm state					
Pn79C	Maximum software limit absolute position (32 bits)	-2147483648~ 2147483647	-21474 83648	Unit	0x079C	After repower

	Maximum software limit absolute position, when the absolute position of the motor (UN021) is greater than this position, the servo will enter the limit alarm state					
Pn79E	Software limit absolute position switch	0~1	0	N/A	0x079E	Immediately
	Software limit absolute position switch setting: 0: off 1: on					
Pn7A0	Encoder overflow times	-32768~ 32767	0	N/A	0x07A0	Immediately
	Record the overflow times of multi-turn absolute encoder					
Pn7A1	Blocked-rotor overload protection time percentage	0~100	8	N/A	0x07A1	After repower
	This parameter sets the percentage of time that the motor will report overload after the motor is blocked. If it is set too large, the drive may be damaged. To protect the safety of the drive, please change this value under the guidance of the manufacturer's technical support.					

10.9 Pn8 group internal position/origin return parameters

Function code	Parameter	Range	Default	Unit	Communication address	When enabled
Pn800	Return to origin control word	0~0xFFFFFFFF	0x0	-	0x0800	Immediately
	Home return control word mode setting, see Chapter 8 for details					
Pn802	Zero position offset value	-2147483648~ 2147483647	0	Unit	0x0802	Immediately
	Zero position offset position setting					
Pn804	Pr1 control word	0~0x80000000	0x0	-	0x0804	Immediately
	The first position setting, see Chapter 8 for details					
Pn806	Pr1 pulse number	-2147483648~ 2147483647	0	Unit	0x0806	Immediately
	Set the position of the first paragraph					
Pn808	Pr2 control word	0~0x80000000	0x0	-	0x0808	Immediately
	Like Pn804					
Pn80A	Pr2 pulse number	-2147483648~ 2147483647	0	Unit	0x0810	After repower
	2nd position setting					
Pn80C	Pr3 control word	0~0x80000000	0x0	-	0x080C	After repower
	Like Pn804					
Pn80E	Pr3 pulse number	-2147483648~ 2147483647	0	Unit	0x080E	Immediately

	3rd position setting					
Pn810	Pr4control word	0~0x80000000	0x0	—	0x0810	Immediately
	Like Pn804					
Pn812	Pr4 pulse number	-2147483648~ 2147483647	0	Unit	0x0812	Immediately
	4th position setting					
Pn814	Pr5control word	0~0x80000000	0x0	—	0x0814	Immediately
	Like Pn804					
Pn816	Pr5 pulse number	-2147483648~ 2147483647	0	Unit	0x0816	Immediately
	5th position setting					
Pn818	Pr6control word	0~0x80000000	0x0	—	0x0818	Immediately
	Like Pn804					
Pn81A	Pr6 pulse number	-2147483648~ 2147483647	0	Unit	0x081A	Immediately
	6th position setting					
Pn81C	Pr7control word	0~0x80000000	0x0	—	0x081C	Immediately
	Like Pn804					
Pn81E	Pr7 pulse number	-2147483648~ 2147483647	0	Unit	0x081E	Immediately
	7th position setting					
Pn820	Pr8control word	0~0x80000000	0x0	—	0x0820	Immediately
	Like Pn804					
Pn822	Pr8 pulse number	-2147483648~ 2147483647	0	Unit	0x0822	Immediately
	8th position setting					
Pn824	Pr9control word	0~0x80000000	0x0	—	0x0824	Immediately
	Like Pn804					
Pn826	Pr9 pulse number	-2147483648~ 2147483647	0	Unit	0x0826	Immediately
	9th position setting					
Pn828	Pr10control word	0~0x80000000	0x0	—	0x0828	Immediately
	Like Pn804					
Pn82A	Pr10 pulse number	-2147483648~ 2147483647	0	Unit	0x082A	Immediately
	10th position setting					

Pn82C	Pr11 control word	0~0x80000000	0x0	—	0x082C	Immediately
	Like Pn804					
Pn82E	Pr11 pulse number	-2147483648~ 2147483647	0	Unit	0x082E	Immediately
	11th position setting					
Pn830	Pr12 control word	0~0x80000000	0x0	—	0x0830	Immediately
	Like Pn804					
Pn832	Pr12 pulse number	-2147483648~ 2147483647	0	Unit	0x0832	Immediately
	12th position setting					
Pn834	Pr13 control word	0~0x80000000	0x0	—	0x0834	Immediately
	Like Pn804					
Pn836	Pr13 pulse number	-2147483648~ 2147483647	0	Unit	0x0836	Immediately
	13th position setting					
Pn838	Pr14 control word	0~0x80000000	0x0	—	0x0838	Immediately
	Like Pn804					
Pn83A	Pr14 pulse number	-2147483648~ 2147483647	0	Unit	0x083A	Immediately
	14th position setting					
Pn83C	Pr15 control word	0~0x80000000	0x0	—	0x083C	Immediately
	Like Pn804					
Pn83E	Pr15 pulse number	-2147483648~ 2147483647	0	Unit	0x083E	Immediately
	15th position setting					
Pn840	Pr16 control word	0~0x80000000	0x0	—	0x0840	Immediately
	Like Pn804					
Pn842	Pr16 pulse number	-2147483648~ 2147483647	0	Unit	0x0840	Immediately
	16th position setting					
Pn844	Pr17 control word	0~0x80000000	0x0	—	0x0844	Immediately
	Like Pn804					

Pn846	Pr17 pulse number	-2147483648~ 2147483647	0	Unit	0x0846	Immediately
	17th position setting					
Pn848	Pr18 control word	0~0x80000000	0x0	—	0x0848	Immediately
	Like Pn804					
Pn84A	Pr18 pulse number	-2147483648~ 2147483647	0	Unit	0x084A	Immediately
	18th position setting					
Pn84C	Pr19 control word	0~0x80000000	0x0	—	0x084C	Immediately
	Like Pn804					
Pn84E	Pr19 pulse number	-2147483648~ 2147483647	0	Unit	0x084E	Immediately
	19th position setting					
Pn850	Pr20 control word	0~0x80000000	0x0	—	0x0850	Immediately
	Like Pn804					
Pn852	Pr20 pulse number	-2147483648~ 2147483647	0	Unit	0x0852	Immediately
	20th position setting					
Pn854	Pr21 control word	0~0x80000000	0x0	—	0x0854	Immediately
	Like Pn804					
Pn856	Pr21 pulse number	-2147483648~ 2147483647	0	Unit	0x0856	Immediately
	21th position setting					
Pn858	Pr22 control word	0~0x80000000	0x0	—	0x0858	Immediately
	Like Pn804					
Pn85A	Pr22 pulse number	-2147483648~ 2147483647	0	Unit	0x085A	Immediately
	22th position setting					
Pn85C	Pr23 control word	0~0x80000000	0x0	—	0x085C	Immediately
	Like Pn804					
Pn85E	Pr23 pulse number	-2147483648~ 2147483647	0	Unit	0x085E	Immediately
	23th position setting					
Pn860	Pr24 control word	0~0x80000000	0x0	—	0x0860	Immediately
	Like Pn804					

Pn862	Pr24 pulse number	-2147483648~ 2147483647	0	Unit	0x0862	Immediately
	24th position setting					
Pn864	Pr25 control word	0~0x80000000	0x0	—	0x0864	Immediately
	Like Pn804					
Pn866	Pr25 pulse number	-2147483648~ 2147483647	0	Unit	0x0866	Immediately
	25th position setting					
Pn868	Pr26 control word	0~0x80000000	0x0	—	0x0868	Immediately
	Like Pn804					
Pn86A	Pr26 pulse number	-2147483648~ 2147483647	0	Unit	0x086A	Immediately
	26th position setting					
Pn86C	Pr27 control word	0~0x80000000	0x0	—	0x086C	Immediately
	Like Pn804					
Pn86E	Pr27 pulse number	-2147483648~ 2147483647	0	Unit	0x086E	Immediately
	27th position setting					
Pn870	Pr28 control word	0~0x80000000	0x0	—	0x0870	Immediately
	Like Pn804					
Pn872	Pr28 pulse number	-2147483648~ 2147483647	0	Unit	0x0872	Immediately
	28th position setting					
Pn874	Pr29 control word	0~0x80000000	0x0	—	0x0874	Immediately
	Like Pn804					
Pn876	Pr29 pulse number	-2147483648~ 2147483647	0	Unit	0x0876	Immediately
	29th position setting					
Pn878	Pr30 control word	0~0x80000000	0x0	—	0x0878	Immediately
	Like Pn804					
Pn87A	Pr30 pulse number	-2147483648~ 2147483647	0	Unit	0x087A	Immediately
	30th position setting					
Pn87C	Pr31 control word	0~0x80000000	0x0	—	0x087C	Immediately
	Like Pn804					



Pn87E	Pr31 pulse number	-2147483648~ 2147483647	0	Unit	0x087E	Immediately
	31th position setting					
Pn880	Pr Acc and dec time 0	0~60000	50	ms	0x0880	Immediately
	Acc and dec time setting 0					
Pn881	Pr Acc and dec time 1	0~60000	200	ms	0x0881	Immediately
	Acc and dec time setting 1					
Pn882	Pr Acc and dec time 2	0~60000	300	ms	0x0882	Immediately
	Acc and dec time setting 2					
Pn883	Pr Acc and dec time 3	0~60000	400	ms	0x0883	Immediately
	Acc and dec time setting 3					
Pn884	Pr Acc and dec time4	0~60000	500	ms	0x0884	Immediately
	Acc and dec time setting 4					
Pn885	Pr Acc and dec time 5	0~60000	600	ms	0x0885	Immediately
	Acc and dec time setting 5					
Pn886	Pr Acc and dec time 6	0~60000	700	ms	0x0886	Immediately
	Acc and dec time setting 6					
Pn887	Pr Acc and dec time 7	0~60000	800	ms	0x0887	Immediately
	Acc and dec time setting 7					
Pn888	Pr target speed 0	0~6000	100	r/min	0x0888	Immediately
	target speed 0 setting					
Pn889	Pr target speed 1	0~6000	200	r/min	0x0889	Immediately
	target speed 1 setting					
Pn88A	Pr target speed 2	0~6000	500	r/min	0x088A	Immediately
	target speed 2 setting					
Pn88B	Pr target speed 3	0~6000	1000	r/min	0x088B	Immediately
	target speed 3 setting					
Pn88C	Pr target speed 4	0~6000	1500	r/min	0x088C	Immediately
	target speed 4 setting					
Pn88D	Pr target speed 5	0~6000	2000	r/min	0x088D	Immediately

	target speed 5 setting					
Pn88E	Pr target speed 6	0~6000	2500	r/min	0x088E	Immediately
	target speed 6 setting					
Pn88F	Pr target speed 7	0~6000	3000	r/min	0x088F	Immediately
	target speed 7 setting					
Pn890	Pr delay time0	0~6000	0	0.1s	0x0890	Immediately
	Delay time0 setting					
Pn891	Pr delay time 1	0~6000	1	0.1s	0x0891	Immediately
	Delay time 1 setting					
Pn892	Pr delay time 2	0~6000	5	0.1s	0x0892	Immediately
	Delay time 2 setting					
Pn893	Pr delay time 3	0~6000	10	0.1s	0x0893	Immediately
	Delay time 3 setting					
Pn894	Pr delay time 4	0~60000	100	0.1s	0x0894	Immediately
	Delay time4 setting					
Pn895	Pr delay time 5	0~60000	1000	0.1s	0x0895	Immediately
	Delay time 5 setting					

11 Monitoring Parameters

Monitoring code	Monitoring name	range	unit	mailing address
Un000	Motor rotation speed	0x80000000~0x7fffffff	rpm	0xE000
	Display the actual speed of the servo motor			
Un001	Speed command	0x80000000~0x7fffffff	rpm	0xE001
	Display the current speed command of the servo motor Note: When it is not enabled, this value shows the analog speed (corresponding to V-REF)			
Un002	Internal torque command	0x80000000~0x7fffffff	%	0xE002
	Display current actual torque command with servo motor rated torque as 100%			
Un003	Rotor pulse position relative to the Z axis	0x80000000~0x7fffffff	pulse	0xE003
	Shows the mechanical absolute position of the motor within one revolution of the encoder			

Un004	Electrical angle	0x80000000~0x7fffffff	°	0xE004
	Displays the electrical angle of the current position of the servo motor rotor			
Un005	Speed of input pulse command	0x80000000~0x7fffffff	rpm	0xE005
	Display input position pulse command speed			
Un006	Counter of input command pulse	0x80000000~0x7fffffff	Command Unit	0xE006
	Displays the number of command pulses received by the servo motor			
Un007	Counter of feedback pulse	0x80000000~0x7fffffff	Command Unit	0xE007
	Displays cumulative pulses fed back from the servo motor encoder			
Un008	Counter of feedback pulse 1	0x80000000~0x7fffffff	Encoder pulse unit	0xE008
	Displays cumulative pulses fed back from the servo motor encoder			
Un009	Position deviation	0x80000000~0x7fffffff	Command Unit	0xE009
	Display the difference between the command pulse number of the upper device and the servo motor movement amount			
Un010	Absolute encoder single-turn value	0x80000000~0x7FFFFFFF	Encoder unit	0xE010
	Display the absolute position value of one-turn of the absolute encoder.			
Un011	Absolute encoder multi-turn value	0x80000000~0x7FFFFFFF	-	0xE011
	Displays the number of multi-turn encoder turns value when the multi-turn encoder is used. After the multi-turn encoder reset operation is performed, the value is 0.			
Un012	External encoder feedback pulse counter	0x80000000~0x7FFFFFFF	External encoder unit	0xE012
	Display external encoder feedback pulse counter when external grating encoder is connected.			
Un021	Motor absolute position	0x80000000~0x7FFFFFFF	command unit	0xE021
	Display the absolute position of the motor, the unit is the command unit			
Un00A	Cumulative load rate	0x80000000~0x7fffffff	%	0xE00A
Un00B	Regeneration load rate	0x80000000~0x7fffffff	%	0xE00B
Un00C	Electricity consumption of DB resistance	0x80000000~0x7fffffff	%	0xE00C
Un00D	Effective gain monitoring	1~2	—	0xE00D
Un00E	Total running time	0~0xFFFFFFFF	100ms	0xE00E
Un00F	Overload rate	0~0xFFFFFFFF	%	0xE00F
Un035	DSP software version	0~0xFFFF	-	0xE035
Un036	FPGA software version	0~0xFFFF	-	0xE036
Un087	Encoder communication abnormal times	0~0xFFFF	-	0xE087
Un089	Heat sink temperature	0~0xFFFF	°C	0xE090
Un091	Motor temperature	0~0xFFFF	°C	0xE091

Un100	IO port input signal monitoring	0~0xFFFF	—	0xE100	
					
	LED	Input pin number	Signal name (Factory configuration)	LED	Input pin number
	1	CN1-40	/S-ON	6	CN1-45
	2	CN1-41	/P-CON	7	CN1-46
	3	CN1-42	P-OT	8	CN1-39
	4	CN1-43	N-OT	9	CN1-38
	5	CN1-44	/ALM-RST		
Un101	IO port output signal monitoring	0~0xFFFF	—	0xE101	
					
	LED	Input pin number			
	1	CN1-31/32			
	2	CN1-25/26			
	3	CN1-27/28			
	4	CN1-29/30			
Un102	T-REF monitoring	0~0xFFFF	%	0xE102	
	Corresponds to the T-REF input voltage, according to the analog torque command gain				
Un103	V-REF monitoring	0~0xFFFF	rpm	0xE103	
	Corresponds to the T-REF input voltage, according to the analog torque command gain				
Un104	Pulse command input frequency	0~0xFFFFFFFF	Hz	0xE104	
Un108	External input command pulse counter	0~0xFFFFFFFF	Command Unit	0xE108	
Un110	Integrated monitoring of internal signal status	0~0xFFFFFFFF	—	0xE110	

Un120	Integrated monitoring of internal input signal status	0~0xFFFFFFFF	—	0xE120
Un130	Integrated monitoring of internal output signal	0~0xFFFFFFFF	—	0xE130
Un140	Main circuit bus voltage	0~0xFFFF	V	0xE140
Un141	Effective current feedback	0~0xFFFF	0.01A	0xE141
	Three-phase synthetic feedback current effective value			
Un14B	D-axis current command monitoring	0~0xFFFF	%	0xE14B
Un220	Torque command voltage (uncorrected)	0~0xFFFF	mv	0xE220
Un221	Torque command voltage (after correction)	0~0xFFFF	mv	0xE221
Un222	Speed command voltage (uncorrected)	0~0xFFFF	mv	0xE222
Un223	Speed command voltage (after correction)	0~0xFFFF	mv	0xE223
Un300	Current alarm code	0~0xFFFF	—	0xE300
Un301	Last alarm code	0~0xFFFF	—	0xE301
Un302	Timestamp while alarm occurs	0~0xFFFFFFFF	100ms	0xE302
Un303	Motor speed while alarm occurs	0~0xFFFF	rpm	0xE303
Un304	Speed command while alarm occurs	0~0xFFFF	rpm	0xE304
Un305	Internal torque command while alarm occurs	0~0xFFFF	%	0xE305
Un306	Input command pulse speed while alarm occurs	0~0xFFFF	rpm	0xE306
Un307	Deviation counters (position deviation) while alarm occurs	0~0xFFFFFFFF	pulse	0xE307
Un308	DC bus voltage while alarm occurs	0~0xFFFF	V	0xE308
Un309	Effective current feedback while alarm occurs	0~0xFFFF	%	0xE309
Un30A	Cumulative load rate while alarm occurs	0~0xFFFF	%	0xE30A
Un30B	Regenerative load rate while alarm occurs	0~0xFFFF	%	0xE30B
Un30C	Electricity consumption of DB resistance while alarm occurs	0~0xFFFF	%	0xE30C
Un30D	Maximum cumulative load rate while alarm occurs	0~0xFFFF	%	0xE30D
Un30E	Rotation inertia ratio while alarm occurs	0~0xFFFF	%	0xE30E
Un30F	Abnormal times of serial encoder communication while alarm occurs	0~0xFFFF	—	0xE30F
Un310	Internal signal monitoring while alarm occurs	0~0xFFFFFFFF	-	0xE310
Un313	Internal input signal monitoring while alarm occurs	0~0xFFFFFFFF	-	0xE313

Un317	Internal output signal monitoring while alarm occurs	0~0xFFFFFFFF	-	0xE317
Un30F	The number of serial encoder communication abnormalities when an alarm occurs	0~0xFFFF	—	0xE30F
Un320	Fault code history 1	0~0xFFFF	-	0xE320
Un321	Fault code history 2	0~0xFFFF	-	0xE321
Un322	Fault code history 3	0~0xFFFF	-	0xE322
Un323	Fault code history 4	0~0xFFFF	-	0xE323
Un324	Fault code history 5	0~0xFFFF	-	0xE324
Un325	Fault code history 6	0~0xFFFF	-	0xE325
Un326	Fault code history 7	0~0xFFFF	-	0xE326
Un327	Fault code history 8	0~0xFFFF	-	0xE327
Un328	Fault code history 9	0~0xFFFF	-	0xE328
Un329	Fault code history 10	0~0xFFFF	-	0xE329
Un330	Fault time history 1	0~0xFFFFFFFF	100ms	0xE330
Un331	Fault time history 2	0~0xFFFFFFFF	100ms	0xE331
Un332	Fault time history 3	0~0xFFFFFFFF	100ms	0xE332
Un333	Fault time history 4	0~0xFFFFFFFF	100ms	0xE333
Un334	Fault time history 5	0~0xFFFFFFFF	100ms	0xE334
Un335	Fault time history 6	0~0xFFFFFFFF	100ms	0xE335
Un336	Fault time history 7	0~0xFFFFFFFF	100ms	0xE336
Un337	Fault time history 8	0~0xFFFFFFFF	100ms	0xE337
Un338	Fault time history 9	0~0xFFFFFFFF	100ms	0xE338
Un339	Fault time history 10	0~0xFFFFFFFF	100ms	0xE339

12 Fault Code and Countermeasures

12. 1 Fault Code

Fault code	Fault type	Solutions
Er.020	Abnormal parameter and check	<ol style="list-style-type: none"> 1. Enter the parameters again after initializing parameter settings, 2. Write the power level of the driver to 0 first, and then write the correct power level. Note: Remember to perform the current detection correction, analog input correction and bus voltage correction after writing the power level 3. servo driver failure, replace the servo drive
Er.021	Parameter formatting exception (inconsistent version number)	<ol style="list-style-type: none"> 1. Perform a soft reset. If the fault is still reported, write the driver's power level to 0 and then write the correct power level. Note: Remember to perform the current detection correction, analog input correction and bus voltage correction after writing the power level 2. servo driver failure and replace the servo drive

Er.022	Abnormal system and check	<ol style="list-style-type: none"> 1. Perform a soft reset. If the fault is still reported, write the driver's power level to 0 and then write the correct power level. Note: Remember to perform the current detection correction, analog input correction and bus voltage correction after writing the power level 2. servo driver failure and replace the servo drive
Er.030	Abnormal detection in main circuit	<ol style="list-style-type: none"> 1. Servo driver fails, replace the servo driver
Er.040	Abnormal parameter setting	<ol style="list-style-type: none"> 1. Check whether the changed parameters are out of range 2. Check if the setting of electronic gear ratio is within the setting range (electronic gear ratio: 0.001~16777216/1000) 3. Check whether the servo drive and servo motor capacity match 4. I/O terminal definition repeat
Er.041	Abnormal frequency division pulse output setting	According to the number of encoder bits, the number of encoder frequency division pulses is set to an appropriate value, see the specification
Er.042	Abnormal parameter combination	<ol style="list-style-type: none"> 1. Make the setting value of electronic gear ratio within the setting range 2. make the program JOG settings related to logic
Er.044	Abnormal setting of loop parameters	<ol style="list-style-type: none"> 1. Set the half closed loop / full closed loop parameters correctly
Er.050	Unmatched drive and motor capacity	<ol style="list-style-type: none"> 1. check if the driver power and motor power are correct 2. replace the drive or motor so that it is within a reasonable range
Er.051	Alarm caused by product technical support failure	<ol style="list-style-type: none"> 1. Connect the function modules can not be supported by the product, please select the matching combination
Er.080	Abnormal distance setting corresponding to unit pulse of encoder	<ol style="list-style-type: none"> 1. Correctly set the distance corresponding to the unit pulse of the encoder
Er.08A	Abnormal resolution setting of position sensor	<ol style="list-style-type: none"> 1. Set the resolution of position sensor correctly
Er.0B0	Invalid servo ON command alarm	Re-power on or perform a soft reset
Er.100	Over-current fault	<ol style="list-style-type: none"> 1. Check whether the motor phase sequence is wrong 2. Check whether the motor is damaged and use a multimeter to measure whether U/V/W is short together. 3. Check the motor encoder angle is correct 4. Monitor the UV phase current sampling AD value in the disabled state through a virtual oscilloscope to determine whether it is a driver hardware current sampling fault. Normally, it is near zero.

Er.300	Braking resistor failure	<ol style="list-style-type: none"> 1. Correctly wire the external regenerative resistor. 2. After troubleshooting the wiring, it may be a servo drive problem, replace the servo drive
Er.320	Regeneration overload	<ol style="list-style-type: none"> 1. Check whether the bus voltage of the driver is within a reasonable range when it is not enabled. If the bus voltage is detected incorrectly, there is a possibility of accidental braking or accidental protection. 2. Confirm the brake resistor wiring is correct; see the instructions for details. 3. According to the load situation, consider the current choice of braking resistor is appropriate; see the braking resistor selection rules for details. 4. If the wiring is correct, and the braking resistor is selected properly, and the operation still reports regenerative overload, you can monitor whether there is a small drop when the bus voltage reaches the braking point during operation by the host computer or the keyboard. If the bus voltage reaches the braking point and it still rises smoothly, it can be judged that the brake pipe is damaged. 5. If the fault is reported in the last operation, run after waiting for a while after powering on.
Er.330	Main circuit power wiring error	<ol style="list-style-type: none"> 1. Connect the main circuit power cord correctly
Er.400	Over-voltage	<ol style="list-style-type: none"> 1. When the power supply voltage is not enabled, measure the power supply voltage at the same time monitor whether the bus voltage (U_{n140}) is 1.414 times of the input power voltage (AC RMS). If the deviation is large, it can be determined as bus voltage detection hardware failure. 2. Measure the power supply voltage. If the power supply voltage is adjustable, adjust the power supply voltage within the product specification range. If it is not adjustable and the power supply voltage is in an unstable state, you may consider installing a voltage regulator. 3. consider the operating conditions and load, determine the brake resistor selection is reasonable (whether the resistance is too large), if the overvoltage caused by frequent acceleration and deceleration, you may consider replacing the brake resistor 4. there may be brake pipe damage, check the brake pipe 5. Make sure to guarantee that the motor is running at a tolerable moment of inertia ratio and mass ratio 6. servo drive failure, replace the servo drive

Er.410	Under-voltage	<ol style="list-style-type: none"> 1. check whether the power input terminal line is connected 2. When the power supply voltage is not enabled, measure the power supply voltage at the same time monitor whether the bus voltage (Un140) is 1.414 times of the input power voltage (AC RMS). If the deviation is large, it can be determined as bus voltage detection hardware failure. 3. Measure the power supply voltage. If the power supply voltage is adjustable, adjust the power supply voltage within the product specification range. 4. Measure the power supply voltage. If the power supply voltage is in an unstable state, you may consider installing a voltage regulator. 5. if the power capacity is adjustable, you can advise customers to increase in power capacity
Er.42A	Motor over temperature	<ol style="list-style-type: none"> 1. Reduce motor load 2. Strengthen motor heat dissipation 3. Check the motor over temperature signal circuit
Er.510	Over-speed	<ol style="list-style-type: none"> 1. Check whether there is any problem with the motor wiring and whether the UVW three-phase connection is reversed. 2. Confirm that the encoder connection is abnormal. 3. Check if the maximum speed setting in the motor parameters is correct 4. Check whether the input command exceeds the over-speed value 5. Reduce the servo gain or set a certain smoothing time
Er.511	Divided pulse output speed	<ol style="list-style-type: none"> 1. Reduce the number of divided output pulses per revolution (Pn070) 2. If the working conditions are allowed, you may reduce the motor speed
Er.520	Vibration alarm	<ol style="list-style-type: none"> 1. If the working conditions are allowed, you may reduce the motor speed or reduce the speed loop gain. 2. correctly set the rotary inertia ratio 3. properly set the vibration detection value (Pn187) and vibration detection sensitivity (Pn186)
Er.550	Abnormal maximum speed setting	
Er.710	Overload (instantaneous maximum load)	<ol style="list-style-type: none"> 1. Check if the motor is stalled during operation 2. Check whether there is any problem with the motor wiring (phase sequence, connection) and encoder wiring. 3. consider the operating conditions and load and determine if the driver or motor selection is reasonable 4. Observe whether there is large vibration in the running process of the motor. If there is a large noise, adjust the gain parameter to eliminate noise or jitter. At the same time, you can use the virtual oscilloscope to monitor whether the motor output torque is abnormal or not.
Er.720	Overload (continuous maximum load)	<ol style="list-style-type: none"> 1. Check whether there is any problem in the motor wiring (phase sequence and connection) and encoder wiring. 2. consider the operating conditions and load and determine the driver or motor selection is reasonable 3. Observe whether the motor has large jitter during operation. If there is a huge noise, adjust the gain parameter to eliminate noise or jitter. Also, use a virtual oscilloscope to monitor whether the motor output torque is abnormal.

Er.730	DB overload 1	<ol style="list-style-type: none"> 1. The load is too heavy when the machine stops that cause the overload of DB resistor and you could try to reduce the operating speed or reduce the load. 2. check whether the motor is driven by external force 3. according to customer needs, re-evaluate whether it needs to pass the DB mode requirements during the shutdown, if you do not need, you can choose other ways to stop 4. If the fault is reported in the last operation, run after waiting for a while after powering on.
Er.731	DB overload 2	<ol style="list-style-type: none"> 1. Reduce the command speed of servo motor. 2. Reduce the moment of inertia ratio. 3. Servo driver problem, replace servo
Er.740	Inrush current limiting resistance fault	<ol style="list-style-type: none"> 1. The servo driver is faulty. Replace the servo driver
Er.7A0	Heat sink over-heat	<ol style="list-style-type: none"> 1. Check whether the air duct is blocked and the fan is damaged with a fan drive. 2. Check the installation conditions of the driver, whether the heat dissipation condition is good or not and increase the heat dissipation condition of the driver as much as possible. 3. Check the drive load conditions, if the load is too heavy, you can suggest that customers replace a high-power segment of the drive. 4. If possible, reduce the driver carrier frequency
Er.7AA	Abnormal temperature of control board	<ol style="list-style-type: none"> 1. Improve the installation condition of servo driver and reduce the ambient temperature. 2. Reconfirm the load conditions and operation conditions. 3. Servo driver failure, replace the servo driver.
Er.7AB	The fan inside the drive does not turn	<ol style="list-style-type: none"> 1. Is there any foreign matter blocking the fan 2. Servo driver failure, replace servo driver
Er.810	Abnormal encoder backup	<ol style="list-style-type: none"> 1. Check the multi-turn encoder battery power condition 2. Perform multi-turn encoder clear operation
Er.830	Battery under-voltage	Replace multi-turn encoder battery
Er. 840	Encoder data is abnormal	Encoder data is abnormal
Er. 850	Encoder overspeed	Encoder overspeed
Er. 860	Encoder temperature is high	<ol style="list-style-type: none"> 1. Reduce the motor load rate 2. Strengthen the heat dissipation effect of the motor

Er.900	CANopen node protection failure	<ol style="list-style-type: none"> 1. Check if the slave is offline 2. Check whether the node protection time setting is correct
Er.901	CANopen heartbeat detection timeout	<ol style="list-style-type: none"> 1. Check if the host is offline 2. Check whether the heartbeat detection time matches the host heartbeat production time
Er.A00	Output UVW phase loss alarm	Check whether the motor cable are connected well, or check the inverter output voltage.
Er.BF4	Hardware over-current	Unplug the power cable and turn on the servo unit again. If an alarm still occurs, the servo unit may be malfunctioning, and then you could replace the servopack. If not, confirm whether it is power line or motor failure
Er.C10	Out of control alarm	<ol style="list-style-type: none"> 1. Check if the motor wiring is normal 2. Check if the motor and encoder are normal 3. Re-connect the servo drive power, if an alarm still occurs, it may be a servo drive failure
Er.C90	Encoder communication failure: line-broken	<ol style="list-style-type: none"> 1. Use multimeter to test every signal line of the encoder line and see if signal lines break. 2. Check the encoder line model and confirm the model is correct.
Er.C91	Abnormal encoder communication position data acceleration	<ol style="list-style-type: none"> 3. Check the length of the encoder line and the encoder line can not be too long. 4. It may be caused by interference, try to ground the driver or wire the encoder around the magnetic ring 5. check the motor group parameters and confirm the motor is correct
Er.CA0	Abnormal encoder parameters	<ol style="list-style-type: none"> 6. If you already exclude various reasons and the servo driver may malfunction, then you could consider replacing the servo unit.
Er.D00	Excessive position deviation	<ol style="list-style-type: none"> 1. Set the appropriate position deviation excessive alarm value 2. Check whether the encoder cable and motor cable are connected properly. You can use the hand to rotate the motor and monitor whether the Un003 (rotor relative Z pulse position) varies between 0 and 16777216 (24-bit encoder). 3. Calculate the pulse frequency input and acceleration planning and check if the electronic gear ratio setting is reasonable 4. Determine whether the relevant parameters are reasonable. For example: you could check the torque limit, speed limit, inertia ratio, position gain, speed gain is too small or the position filter is too large, etc. 5. Calculate if the motor selection is too small or the acceleration and deceleration are too slow that cause huge position deviation.
Er.D01	Excessive position deviation during servo ON	Set correct value of Pn267 (overrunning position deviation when servo is ON)
Er.D02	Excessive position deviation alarm caused by speed limit during servo ON	Set correct Maximum position deviation threshold (Pn264) or set correct speed limit value (Pn270) during servo ON.
Er.D10	Excessive deviation between motor and load position	<ol style="list-style-type: none"> 1. Confirm the rotation direction of the motor and the installation direction of the external encoder 2. Check the mechanical installation. 3. Set the parameter Pn250 to the correct value.

12.2 Warning Code

Warning code	Type	Solutions
AL.900	Excessive Position deviation warning	1. Correctly set relevant parameters such as gear ratio, gain, position filtering, torque limit, etc.
		2. confirm the encoder line motor wiring is correct
		3. If you already exclude various reasons, the servo driver may malfunction and you could consider replacing the servo unit.
AL.901	Excessive position deviation warning during servo ON	Set correct excessive position deviation value during servo ON
AL.910	Overload warning	1. Check if there is any problem of the motor wiring and encoder wiring.
		2. Incorrect motor or driver selection
AL.911	Vibration warning	1. Reduce the motor speed or reduce the speed loop gain.
		2. Set the moment of inertia ratio correctly
AL.920	Regeneration overload warning	1. Set the power supply voltage within the specification range.
		2. Set resistance value and capacity correctly
		3. Replace the servo drive because of servo driver failure
AL.921	DB overload warning	1. Reduce the servo motor command speed.
		2. Reduce the rotary inertia ratio.
		3. Replace the servo drive because of servo driver failure
AL.930	Battery under-voltage warning	Replace the battery
AL.941	Parameter change warning needed to re-power off	Power down the drive before restart it
AL.971	Under-voltage warning	1. Adjust the AC/DC power supply voltage to the product specifications.
		2. increase the power capacity.
AL. 9A0	Servo overtravel	1. Connect the overtravel signal correctly
		2. Confirm the accuracy of the operating instructions of the host computer device

13 Communication

13.1 Communication introduction

Servo driver can support RS485, CANopen bus type, EtherCAT bus type, MECHATROLINK-II bus type. Here we mainly introduce the related content of general model RS485 communication. Other communication needs to refer to the special communication manual. 485 communications can realize the following functions.

- a) Read and write servo driver function code related parameters
- b) Monitor the working status of the servo drive
- c) Constitute a multi-axis control system
- d) Operate the servo assist function

13.2 RS485 communication protocol description

Provide RS485 communication interface, the wiring is detailed in CN6, and the master-slave communication is carried out by the international standard Modbus communication protocol. Users can achieve centralized control through PC/PLC, control PC, etc. to suit specific application requirements.

The Modbus serial communication protocol defines the frame content and usage format for asynchronous transmission in serial communication. These include: host polling and broadcast frame, slave response frame format; host organization frame content includes: slave address (or broadcast address), execution commands, data and error check. The response of the slave is also the same structure, including: action confirmation, return data and error check. If the slave encounters an error while receiving a frame, or fails to complete the action requested by the host, it will organize a fault frame as a response to the host.

The communication protocol is an asynchronous serial master-slave Modbus communication protocol. Only one device (host) in the network can establish a protocol (called "query/command"). Other devices (slave) can only respond to the host's "query/command" by providing data, or according to the host's "query/command". The host here refers to a personal computer (PC), an industrial control device or a programmable logic controller (PLC), etc. The slave refers to a servo drive or other control device having the same communication protocol. The host can communicate with a slave separately and broadcast information to all slaves. For a host "query/command" that is accessed separately, the slave must return a message (called a response). For the broadcast message sent by the host, the slave does not need to feed back the response message to the host.

13.3 Communication frame structure

Modbus only supports RTU transmission mode. The user can configure the serial communication parameters (baud rate, check mode, etc.).

Each 8Bit byte in the message frame contains two 4Bit hexadecimal characters.

Start bit	Device address	command	data	CRC check	Terminator
T1-T2-T3-T4	8Bit	8Bit	N 8Bit	16Bit	T1-T2-T3-T4

In this mode, the message transmission starts at least at a pause interval of 3.5 characters. During transmission, the network device continuously detects the network bus, including the pause interval. When the first field (address field) is received, the corresponding device decodes the next transmitted character, and if there is a pause of at least 3.5 characters, it indicates the end of the message.

In RTU mode, the entire message frame must be transmitted as a continuous stream. If there is a pause time

of more than 1.5 characters before the frame is completed, the receiving device will refresh the incomplete message and assume that the next byte is the address of a new message. area. Similarly, if a new message begins with the previous message in less than 3.5 character times, the receiving device will consider it a continuation of the previous message. If the above two situations occur during the transmission, the CRC check will inevitably generate an error message and feed back to the sender device.

13. 4 Command code and communication data description

In the communication command, the data address read and written is the hexadecimal number of the parameter name, for example, the address of the inertia ratio Pn100 is 0x0100.

(1) Command code: 03H

Function: Read N words (Word can read up to 16 words in succession).

For example, if the servo drive with the slave address 01H reads the address e003 and reads two consecutive words, the structure of the frame is described as follows.

Host command information:

START	T1-T2-T3-T4 (3.5 bytes of transmission time)
ADDR	01H
CMD	03H
Read start address high	e0H
Read start address low	03H
high number of data (in word)	00H
low number of data is (in word)	02H
CRC CHK low bit	03H
CRC CHK high bit	CBH
END	T1-T2-T3-T4 (3.5 bytes of transmission time)

The slave responds to the message:

START	T1-T2-T3-T4 (3.5 bytes of transmission time)
ADDR	01H
CMD	03H
Number of bytes	04H
The high content of the starting data address 03F2H	3AH
Content status of the starting data address 03F2H	9AH
The content of the second data address 03F3H is high	00H
The lower content of the second data address 03F3H	05H
CRC CHK low bit	16H
CRC CHK high bit	C7H

END	T1-T2-T3-T4 (3.5 bytes of transmission time)
-----	--

(2) Command code: 10H

Function: Write N words (Word), $N \geq 2$.

For example, write 100 to the 0100H address of the slave address 01H servo drive and 400 to the 0101H address of the slave address 01H servo drive.

The structure of the frame is described as follows:

Host command information:

START	T1-T2-T3-T4 (3.5 bytes of transmission time)
ADDR	01H
CMD	10H
Write data address high	01H
Write data address low	00H
The number of data is high (in word)	00H
Number of data status (calculated in word)	02H
Number of bytes	04H
The first word high of the data content	00H
The first word of the data content is low	64H
The second word high of the data content	01H
The second word of the data content is low	90H
CRC CHK low bit	BEH
CRC CHK high bit	1CH
END	T1-T2-T3-T4 (3.5 bytes of transmission time)
The slave responds to the message:	
START	T1-T2-T3-T4 (3.5 bytes of transmission time)
ADDR	01H
CMD	10H
Write data start address high	01H
Write data start address low	00H
The number of data is high (in word)	00H
Number of data status (calculated in word)	02H
CRC CHK low bit	40H
CRC CHK high bit	34H
END	T1-T2-T3-T4 (3.5 bytes of transmission time)

13. 5 Communication frame error check mode:

The error check mode of the frame mainly includes two parts of the check, that is, the bit check of the byte (odd/even check) and the entire data check of the frame (CRC check or LRC check).

13. 5. 1 Byte Bit Check

Users can choose different bit verification methods as needed, or they can choose no parity, which will affect the parity bit setting of each byte.

The meaning of even parity: an even parity bit is added before data transmission to indicate whether the number of "1" in the transmitted data is odd or even. When it is even, the check position is "0", otherwise it is set. It is "1" to keep the parity of the data unchanged.

The meaning of the odd check: an odd parity bit is added before the data transmission to indicate whether the number of "1" in the transmitted data is odd or even. When it is odd, the check position is "0", otherwise it is set. It is "1" to keep the parity of the data unchanged.

For example, you need to transfer "11001110", the data contains 5 "1", if you use even parity, its even parity bit is "1", if you use odd parity, its odd parity bit is "0", transmission In the case of data, the parity bit is calculated at the position of the check bit of the frame, and the receiving device also performs parity check. If the parity of the accepted data is found to be inconsistent with the preset, it is considered that the communication has an error.

13.5.2 CRC check method --- CRC (Cyclical Redundancy Check)

Using the RTU frame format, the frame includes a frame error detection field calculated based on the CRC method. The CRC field detects the contents of the entire frame. The CRC field is two bytes and contains a 16-bit binary value. It is calculated by the transmission device and added to the frame. The receiving device recalculates the CRC of the received frame and compares it with the value in the received CRC field. If the two CRC values are not equal, the transmission has an error.

The CRC is first stored in 0xFFFF, and then a procedure is called to process the consecutive 6 or more bytes in the frame with the values in the current register. Only the 8Bit data in each character is valid for the CRC, and the start and stop bits as well as the parity bit are invalid.

During the CRC generation process, each 8-bit character is individually different from the register contents (XOR), and the result moves to the least significant bit direction, and the most significant bit is padded with 0. The LSB is extracted and detected. If the LSB is 1, the register is individually or different from the preset value. If the LSB is 0, it is not performed. The entire process is repeated 8 times. After the last bit (bit 8) is completed, the next octet is individually different from the current value of the register. The value in the final register is the CRC value after all the bytes in the frame have been executed.

This calculation method of CRC adopts the international standard CRC check rule. When editing the CRC algorithm, the user can refer to the CRC algorithm of the relevant standard to write a CRC calculation program that truly meets the requirements.

13. 6 Error message response

When the slave responds, it uses the function code field and the fault address to indicate whether it is a normal response (no error) or an error (called an objection response). For a normal response, the slave responds with the corresponding function code and data address or sub-function code. In response to the objection, the device returns a code equivalent to the normal code, but the first position is logic 1.

For example, if a message sent by a master device to a slave device requires reading a set of servo driver function code address data, the following function code will be generated:

0 0 0 0 0 1 1 (hex 03H)

For a normal response, the slave responds with the same function code. In response to the objection, it returns:

1 0 0 0 0 1 1 (hexadecimal 83H)

In addition to the modification of the function code due to an objection error, the slave device will respond with a one-byte exception code, which defines the cause of the exception.

After the master application responds with an objection, the typical process is to resend the message or make a command change for the corresponding failure.

Modbus exception code		
Code	name	Meaning
01H	Illegal function	When the function code received from the host computer is an operation that is not allowed, this may be because the function code is only applicable to the new device and is not implemented in the device; at the same time, the slave may also process the request in an error state.
02H	Illegal data address	For the servo drive, the request data address of the upper computer is an unallowable address; in particular, the combination of the register address and the transmitted byte number is invalid.
03H	Illegal data value	The received data value exceeds the range of the address parameter, causing the parameter change to be invalid.
11H	Parity error	When the RTU format CRC check bit or the ASCII format LRC check bit is different from the check calculation number of the lower computer in the frame information sent by the host computer, the check error information is reported.

14 Host Debugging Instruction

14. 1 System Requirements

14. 1. 1 System Configuration

1. When the user uses the software for the first time, please confirm whether the NET3.5 and NET4.0 frameworks are installed. This is a prerequisite; otherwise the software cannot be opened. But for Win7 and above operating systems, there is no need to install NET 3.5 and NET 4.0 frameworks.

2. The host computer system currently supports USB communication debugging.


3. The system only supports servo SD700 series servo product debugging;

4. Verify that the "Use FIPS-compliant algorithms for encryption" option is set to disabled (Control Panel - Administrative Tools - Local Security Policy - Security Options - Use FIPS-compliant algorithms for encryption - disabled)

14.1.2 Connection Configuration

The servo driver is connected to the computer through the communication connector, and the interface type is USB. Basic configuration:

1. Anti-jamming Android micro phone data cable.



1. Connection between PC and SD700 servo drive via Android micro mobile phone data cable
2. Click My Computer - Manage - Device Manager and find **Other devices** and **VEICHI SD700 SERIES**
3. Right-click and select "Update Driver", select "Browse calculations to find driver software"
4. Manually select the upper machine installation package file for driver installation.
5. Then the device manager **libusb-win32 devices** appears, indicating that the installation has been successful.

14.2 Main Interface

The main interface includes menu bar, toolbar, function display area, information bar, status bar and other functions, as shown in the following figure;



① Menu bar

The menu bar includes functions such as files, settings, tools, advanced applications, windows, and help;

[File]: Open and exit the system;

[Settings]: user rights, service personnel rights, developer rights;

[Tools]: parameter settings, real-time monitoring, digital oscilloscope, fault information, screenshots and other functions;

[Advanced applications]: inertia identification, JOG, program JOG, homing, mechanical characteristics, FFT analysis, single parameter adjustment, intelligent adjustment, offset adjustment;

[Window]: Cascading display, horizontal display, vertical display, all off;

[Help]: about;

② [Toolbar]

The toolbar includes communication disconnection, communication connection, JOG, program JOG, soft reset, factory reset, parameter setting, monitoring parameters, digital oscilloscope, fault maintenance, screenshot, mechanical characteristics, FFT analysis, intelligent adjustment, offset adjustment, single parameter adjustment, exit and other functions;

③ Function display area

The function display area is used as a form container to provide sub-window display of reading and writing parameters, monitoring parameters, digital oscilloscope, fault maintenance, and function debugging;

④ Information columns

[Some parameters] show supplementary explanation

⑤ Status bar

The status bar includes the current communication status and servo work status.

14. 3 Features

(1) File

Documents include open, exit, etc.;

(2) Turn on

Open function: open the existing file;

Step:

Click the menu bar [File] -> [Open] -> [Select the current system directory folder Test32] -> [Select VCDGSmisc.vcb file];

(3) Exit

Exit function: Close the current system

Step:

Click [Exit] in the file column, exit the system, or click [Exit System] on the motor toolbar to exit the system.

(4) Read and write parameters


Read and write parameters include functions such as reading and writing of function codes, import, and export;

Step:

1. Start reading and writing parameters interface:

Click on the menu bar "Tools" -> "Parameter Settings"

2. The pop-up read/write parameters (parameter setting) interface is displayed in the display area, as shown in the following figure:



1- Toolbar

The toolbar includes reading the current page function code, reading all page function codes, writing function codes to EEPROM, exporting the current page function code, exporting all function codes, importing function codes in batches, comparing the differences of two file parameters and finding out modified parameters, as shown below:



2-Multi page

Each page is displayed in different functional groups. At the same time, common parameters and different parameter pages are added to facilitate viewing of function codes.

3-function code

The function code is a specific function and provides relevant information such as the current state, name, current value, unit, default value, minimum value, maximum value, and attribute, etc. When a row is clicked, the corresponding function code comment is provided as below:

: Waiting : Communication is normal

4— Information column

Display parameter modification after the effective mode and function code supplementary explanation;

Function code reading

Function code reading can be read individually or in batches.

Step:

1. Current group read: switch to a group of parameters, left-click on [read] -> select [current group], read the current group parameters

2. Read all: Left-click on [Read] -> Select [All] to read all parameters and the pop-up dialog box will display the progress of the read function code in the form of a progress bar; as shown in the following figure:



Function code write/import


Function code writing can be individually written.

Step:

1. write individually: select a function code, click on the column corresponding to the current value, click twice in succession, it may enter the editing state, enter the value then click on Enter, the system will automatically send a write command, or directly click [Write] on the toolbar after editing to finish writing the parameters.

2. Steps to import in batches:

Click [Import] -> [Select File] -> Click [Import], as shown in the following figure:



Function code export

Function code export can export current and all function codes;

Step:


1. Click on the toolbar icon  to select the current group and complete the current group export; or select all to complete the export of all function codes.

Find different function codes

Finding different function codes can find out the modified parameters to facilitate user analysis

Step:

1. Click on the toolbar icon  to find out the modified parameters. At the same time, the pop-up dialog box will display the progress in the form of a progress bar as shown in the following figure.




Function code comparison

Compare two sets of exported function codes

Step:

1. Click on the toolbar icon , the function code comparison file selection interface appears. Select the source file and the target file respectively then click on [Compare], and the following interface appears. Click on Save to save the two parameters of the two files.




14. 4 Real-Time Monitoring

Real-time monitoring provides real-time monitoring of monitoring parameters and I/O status, as well as current fault information;

Step:

1. Start the real-time monitoring interface. As shown in the figure below, the monitoring parameters are divided into three groups. The monitoring parameters can be added to the common parameters.



2. Check the monitored parameters and monitor the servo. During the monitoring process, you can also export and save the monitoring content.

Monitoring parameter export

The export of monitoring parameters is a way to output and save the monitoring parameters, which can facilitate the customer to save the monitored parameters.

Step:

1. Check the monitored parameters. If you want to export all parameters in the current group, right-click in the monitored parameters area, select All group, and then click Export. Select the save path and save the monitoring data in the EXCEL file format.


14. 5 Auxiliary Functions

14.5.1 JOG

The JOG operation is a function to confirm the operation of the servo motor by driving the servo motor at the previously set JOG speed (rotation speed) without connecting the host device. By performing this operation confirmation, it is possible to confirm whether or not the connection to the wire is improper and whether the servo motor has failed.

Step:

1. Click the icon  on the main interface of the host computer to enter the jog operation interface. As shown in the left figure below, click Start, and then click forward rotation. The servo will execute forward rotation, click Reverse, and the motor will perform reverse rotation.



14.5.2 Inertia Identification

The inertia Identification function allows the servo unit to perform automatic operation (forward and reverse reciprocating motions), and estimates the moment of inertia of the load during operation.

Step:

1. Click [Inertia Identification]→[Next] on the host interface to enter the following interface in the inertia identification operation process, as shown in the following figure.

Inertia identification

Step 1 -> Parameter adjustment

Command selection: Maximum 2.5 circle(± 1000 [m])

Accelerated speed(rpm/s): 20000.00 (Range: 5000.00 - 20332.23)

Speed(rpm): 1000.00 (Range: 1.15 - 1100.00)

Maximum movement distance: 2.50 (Range: 0.01 - 2.50)

Speed gain(Hz): 40.0 (Range: 1.0 - 2000.0)

Speed loop integral time constant(ms): 20.00 (Range: 0.15 - 512)

Estimated starting value(W): 300 (Range: 0 - 20000)

Note The rotation inertia ratio cannot be calculated normally when there is a torque limit. When the execution is completed, reset or electrify the drive axis.

< Back Next > Cancel

2. As shown in the above figure, set the corresponding parameters according to the actual situation (usually keep the default), and click [Next] → [Write] → [Next] → [Enable] → [Forward] → [Reverse] After the forward rotation is repeated three times, the final inertia identification result is displayed, as shown in the following figure.

Inertia identification

Step 3 -> Running Measurement

step 1: Servo enabled

Servo ON

step 2: Operation

Forward Reverse

Inertia identification Result

Current value:

Write

Inertia ratio: 100

< Back Next > Cancel


3. Click [Write]→[Next]→[Complete] to finish the inertia recognition process.

14.5.3 Program JOG

The JOG operation of the program refers to the function of executing the continuous operation in the previously set operation mode (moving distance, moving speed, acceleration/deceleration time, waiting time, number of movements). This function is the same as the JOG operation, and the upper apparatus is not connected during the setting. The servo motor operation can be confirmed and a simple positioning operation can be performed.

Step:

1. Click on  of the main interface of the host computer to enter the program jog operation process, and then click on [Next] to enter the parameter adjustment interface and set related parameters as required. The detailed interface is as shown in the figure below.



The screenshot shows a software window titled "Program JOG" with a sub-header "Step 1 -> Parameters Adjustment". The interface contains three main sections, each enclosed in a red box:

- Mode selection:** A dropdown menu showing "[0](waiting time->forward movement)*Cycles".
- Speed setting:** Two dropdown menus. The first is "Movement setting(pulse)" with a value of 32768 and a range of "(Range:1-1073741824)". The second is "Speed setting(r/min)" with a value of 500 and a range of "(Range:1-10000)".
- Time and times:** Three dropdown menus. The first is "Acceleration/Deceleration time(ms)" with a value of 100 and a range of "(Range:2-10000)". The second is "Waiting time when stop(ms)" with a value of 100 and a range of "(Range:0-10000)". The third is "Running times setting (Times)" with a value of 1 and a range of "(Range:0-1000)".

At the bottom of the window, there are three buttons: "< Back", "Next >", and "Cancel".


4. After setting the corresponding parameters, click on [Next] → [Write] → [Next] → [Enable] → [Execution] → [Next] → [Complete]. The program JOG operation process ends.

14.5.4 Mechanical Characteristics


Mechanical analysis characteristics mean that the servo unit performs automatic operation (positive and negative reciprocating motion) without issuing an instruction from the host computer, and the function of estimating the common vibration frequency of the mechanical system during operation is performed.

Step:

1. Click on  of the main interface of the upper computer to enter the mechanical characteristics analysis operation process, click on [Next] → [Next] to enter the parameter adjustment interface, and adjust the corresponding parameters according to the actual situation, as shown in the following figure.



2. Click [Next] → [Write] → [Next] → [Enable] → [Forward] → [Enable] → [Reverse] → [Next] → [Complete] to enter the mechanical properties FFT analysis interface, as shown in the figure below



2. From the above figure, you can analyze the frequency, amplitude, and phase of the resonance frequency. Click on [Settings] to set the frequency of the first notch filter. After the setting is completed, the screen is closed. Mechanical properties are completed.


14.5.5 FFT Analysis

EasyFFT transfers the periodic waveform commands from the servo unit to the servo motor and rotates the

servo motor slightly for a certain time to cause the vibration of the machine. The servo unit detects the resonance frequency based on the vibration generated by the machine, and then sets the corresponding notch filter according to the resonance frequency. The notch filter effectively removes high-frequency vibrations and noise.

Step:

1. Click on  to enter the FFT measurement interface. Set the command amplitude and rotation direction in the measurement conditions. Click to start measurement and you can measure the frequency of the first notch filter, as shown in the figure below.



2. Click on [Start] to measure the first notch, and then click on [Write] to write the frequency of the first notch filter.
3. Click on [Start] to measure the second notch, and then click on [Write] to write the second notch filter frequency
4. Click on [Next] → [Done] to close the operation interface and the FFT analysis is completed.

14.5.6 Bandwidth setting

Bandwidth setting is the method of inputting a speed command or position command from the host device and manually adjusting it while it is running. By adjusting one or two values via bandwidth setting, the relevant servo gain settings can be automatically adjusted.


Bandwidth setting adjusts the following items.

- Gain adjustment (speed loop gain, position loop gain, etc.)
- Filter adjustment (torque command filter, notch filter)
- IF suppression control

Step:


1. Click  of the main interface of the upper computer to enter the single parameter adjustment prompt interface, click on [Next] to enter the parameter adjustment interface, select the organization selection according to

the actual situation, and select the desired mode, as shown in the following figure.



2. Click on [Next] to enter the setting interface of inertia moment ratio and set the inertia ratio (inertia ratio can be obtained through inertia identification function);

3. Click on [Next] to enter the single parameter tuning interface as shown in the following figure



3. Click on [Adjust Start] to tune the tuning value (generally increase). During the process of increasing the tuning value, the servo will vibrate. At this time, vibration detection will be performed automatically. If not, operation can be performed manually, and the tuning value can be set in combination with the figure captured by the digital oscilloscope, or 80% of the tuning value of the motor can be selected as the tuning value. Specific or combined with the actual site requirements for adjustment settings.

4. In the tuning process, when the servo motor is vibrating, it will detect the resonance frequency and the intermediate frequency suppression frequency. After the tuning is completed, click on [Next] to enter the auto tuning completion interface and click on [Finish] to complete the single parameter adjustment operation.

14.5.7 Offset Adjustment

Offset adjustment is divided into two parts:

- 1: Speed/torque command offset (automatic/manual) adjustment
- 2: Motor/current detection signal offset (automatic/manual) adjustment

Step:

1. Click  on the main interface of the host computer to enter the offset wizard interface. Click on [Next] to enter the offset adjustment function selection interface, select the function you need to adjust, and click on [Next] to enter the adjustment interface.


2. Set the adjustment method, click on [Next], click on [Finish], the offset adjustment screen closes, and the adjustment process ends.

14.5.8 Back to Origin

The origin search is a function that determines the position of the origin pulse (Z phase) of the incremental encoder and stops at this position.

Step:

1. Click  on the main interface of the host computer to enter the origin setting wizard interface. Click [Next] to enter the execution instruction interface, as shown in the following figure.



2. Click [Enable] to enable the servo motor to enter the enable state, and then click [Forward Run] or [Reverse Run] to perform the origin search. After the search is completed, click [Next] to enter the back to origin setting interface and click [Completed] to return to origin operation

14.5.9 Soft Reset (Same as Power on again)

The function could reset the servo unit from the inside by software. Used to re-power on or reset the alarm after changing the parameter setting. It is also possible to validate the setting without turning the power back on.

Step:

Click  on the main interface of the host computer to perform a soft reset operation.

14.5.10 Restoring the Factory Value

The function is used to restore the parameter to the factory setting. Parameter initialization should note the problems as below:


1. Initialization of the parameter setting value must be performed during the servo OFF and it cannot be executed during the servo ON.
2. For the setting to take effect, the servo unit must be turned on again after the operation.

Steps:

Click  on the main interface of the upper computer to restore the factory value. After the operation is completed, power it on again.

14.5.11 Fault Information

The fault information can display current faults, historical faults, causes of faults, handling measures, information related to faults, and clearing of fault information. Click  to display the following interface



The screenshot shows a software window titled "Fault Information" with a tabbed interface. The "Current Fault" tab is active, displaying a table with columns "Fault Code" and "Fault Name". A "Clearance" button is located to the right of the table. Below the table are two text areas labeled "Fault Reason" and "Treatment". At the bottom, a section titled "Relevant information while fault" contains two columns of parameter readouts, each with a numerical input field and a unit label.

Fault Code	Fault Name

Clearance

Fault Reason

Treatment

Relevant information while fault

Alarm time stamp	<input type="text"/>	(100ms)	Main circuit bus voltage	<input type="text"/>	(V)
Motor Rotation Speed	<input type="text"/>	(rpm)	Current feedback effective value	<input type="text"/>	(%)
Speed Command	<input type="text"/>	(rpm)	Accumulative load rate	<input type="text"/>	(%)
Internal torque command	<input type="text"/>	(%)	Regenerative load rate	<input type="text"/>	(%)
Input command pulse speed	<input type="text"/>	(rpm)	DB resistor consume power	<input type="text"/>	(%)
Deviation counter (position deviation)	<input type="text"/>	(pulse)	Maximum accumulative load rate	<input type="text"/>	(%)

According to the above information, the servo fault is repaired.

14. 6 Digital Oscilloscope

Digital oscilloscopes collect data at high speeds and display them graphically to analyze data.

Steps:

1, start the data oscilloscope interface (provide two ways):

Method one: Click on the main menu of the host computer menu [Tools] -> [Oscilloscope], start the oscilloscope;

Method 2: Click the icon  on the main interface of the host computer to start the oscilloscope.

3, display data oscilloscope interface, as shown below



1 - Toolbar

The toolbar includes open, save, full screen, style (switch to display background), settings, screenshots, legend, timeline, back, forward, rewind, fast forward, zoom in, zoom out, adaptive, zero position, dot/line, measurement and other functions

2 - Curve display area

Different curves provide visual display and measurement results for display;

3-channel setting and trigger setting

It provides channel-related parameter settings and trigger related parameter settings. Parameter setting includes trigger condition settings and channel settings; data channel detailed functions are as follows

Data channel	I/O channel
<div style="border: 1px solid gray; padding: 5px;"> <div style="border-bottom: 1px solid gray; height: 20px; margin-bottom: 5px;"></div> <ul style="list-style-type: none"> ▶ Command speed Feedback speed Torque command Position command speed Command speed before position l... Position command difference Position feedback difference Position error Speed feedforward Torque feedforward Friction compensating torque Vibration deviation control speed Position loop regulator deviation </div>	<div style="border: 1px solid gray; padding: 5px;"> <div style="border-bottom: 1px solid gray; height: 20px; margin-bottom: 5px;"></div> <ul style="list-style-type: none"> ▶ /S-ON Servo enable /P-CON Manual P-PI control P-OT Positive position limit N-OT Negative position limit /ALM-RST Alarm clearance /TLC Torque limit selection /SPD-D Internal speed command ... /SPD-A AInternal speed command... /SPD-B Internal speed command s... /C-SEL Control mode switch /ZCLAMP Zero speed clamping /INHIBIT Pulse input inhibit /G-SEL Gain switching </div>
<div style="border: 1px solid gray; padding: 5px;"> <div style="border-bottom: 1px solid gray; height: 20px; margin-bottom: 5px;"></div> <ul style="list-style-type: none"> Torque command before disturba... Active gain Main circuit voltage Current detection value Cumulative load rate Regeneration load rate Motor position feedback difference Full closed loop position feedback ... Electric angle VREF ▶ TREF None </div>	<div style="border: 1px solid gray; padding: 5px;"> <ul style="list-style-type: none"> SEN PULS SIGN CLR Pulse clearance /HWBB1 /HWBB2 ALM Alarm output /COIN Position finished /V-CMP Same speed ▶ /TGON Rotational detection signal /S-RDY Servo ready /CLT Torque limit /VLT Speed limit /BK Brake linkage /WARN Warning output /NEAR Position approach signal /C-PHASE PAO Frequency division output A PBO Frequency division output B PCO Frequency division output C ACON DEN None </div>

4 - Waveform display selection area

It provides selection and display of desired waveforms.

5 - Digital display of measured value

It provides display of current value, effective value, average value, maximum value, minimum value, peak value, etc.

6 - Record button operation button

It's used to start and stop recording

7 - Collection method selection

It's used to choose the mode of wave recording, real-time and triggered acquisition

14. 6. 1 Real-Time Acquisition

Real-time acquisition is displayed in real time in the form of waveforms on the servo operating conditions.

Steps:

1. Start: Select real-time acquisition mode, set the channel settings, as shown in the figure below, then click the record button , start recording, and the status of the icon changes to 



2. Stop: click on the record button  to stop recording, and the status of the icon changes to .

14.6.2 Trigger Acquisition

The trigger acquisition is based on the trigger condition and the acquisition cycle and makes the servo operation status displayed in the form of a waveform.

Steps:

1. Select the trigger for the acquisition mode. After the data channel and trigger conditions are set, as shown in the following figure, click the record button , which triggers the start of recording.



Note: After setting the trigger condition parameters, the terminal receives the trigger condition and will automatically judge according to the conditions.

2. After the waveform to be triggered is received, the waveform will remain in the last state; the record button will change to .

3. If you need to trigger again, you need to start recording again;


14.6.3 Graphic Operations

Graphic operations include X/Y zoom, XY label value, Y axis curve point and point display/hide and measurement, X axis curve point and point display/hide and measurement, curve zoom in/out, curve shift, curve zero adjustment, curve adaptive adjustment, graphics attribute settings and other functions

X axis cursor

Steps:

1. Click on the toolbar icon , the graph will automatically display the two axes of the X-axis, and the upper right corner will automatically display the two axis values corresponding to the X-axis cursor, the difference between the data and real time as shown in the figure below:



Y axis cursor


The Y-axis has two coordinate axes and functions are similar to the X-axis.

1. Click on the toolbar icon  to check the Y axis. The graph will automatically display the two axes of the Y axis. The two axes of the X axis cursor are automatically displayed in the upper right corner. The data difference between the two axes is shown in the figure below:



XY digital display

There are multiple axes on the Y axis, which can be selected according to the needs. Through the measurement function, the mouse will display the XY value of the current point in digital form as shown in the following figure.





Y axis scale display/hide

The Y coordinate scale is displayed as a fixed value, and the Y axis scale display/hide can be modified through the toolbar settings.

Steps:

1. Click the top right corner of the oscilloscope interface and in the Y axis option, check the label visibility and scale visibility.

Y-axis curve display/hide

The Y-axis has multiple curves, which can be selected according to the channel. The Y-axis curve is displayed by default.

Steps:

1. In the interface of digital oscilloscope, remove the unnecessary waveform options, and the corresponding Y-axis curve will be automatically hidden in the graphics; for example, let the position instruction speed waveform be hidden, remove the check signal in the corresponding options as shown in the following figure.



Curve zooms in/out

Steps:

- Zoom in the area: Press the left mouse button and pull a zone from the upper left corner to the lower right corner, this area can be enlarged.
- Zoom out the area: Press the left mouse button and pull a zone from the lower right corner to the upper left corner, this area can be reduced.
- Zoom in curve X/Y: click on the button ;
- Zoom out curve X/Y: click on the button ;
- Zoom in curve X: Click on the button  to decrease the time in the options.
- Zoom out curve X: Click on the button  to increase the time in the options.
- Zoom in curve Y: Click on the gain option of the corresponding curve to decrease the gain value. As shown in the figure below, you can adjust the gain of six Y curves.
- Zoom out curve Y: Click on the gain option of the corresponding curve to increase the gain value. As shown below:



Curve translation

Steps:

- Horizontal panning of the curve: left-click on the toolbar , move left and right and move right and left fast (Note: When you move to the right to the maximum scale point, it will no longer move to the right).
- A single curve vertical translation: left-click and hold the corresponding curve number and drag it up and down

to perform a vertical translation.

Graphic import/export

According to the current graph, data and pictures can be exported at the same time. Only the bak format export is supported. In addition, the exported data can be imported for viewing.

Steps:

1. Data import: Click the digital oscilloscope toolbar icon  to pop up the open dialog box and find the existing file;


2. Data export: Click the toolbar icon  to pop up the save dialog and save it to the specified path.

Background:

Digital oscilloscope display area provides two backgrounds, black color and white color

Steps:

1. Click the icon  on the oscilloscope toolbar to display the prompt interface. As shown in the figure below, click OK to switch the display interface.



14. 7 Others

14.7.1 Window Display

The window display is divided into: cascade, horizontal, vertical display, all off;

1. Cascade: click on the main menu of the host computer window [window] -> [cascade display];

2. level: click on the host computer interface menu bar [window] -> [horizontal display];

3. vertical: click on the main interface of the host computer menu window [window] -> [vertical display];


4. Close: Click on the main window of the host computer menu bar [Window] -> [Close all];

14.7.2 Help

It provides servo debugging software version and other information.

Steps:

Click on the menu bar [help] -> [about], the software version information appears, as shown below



Scan the following QR code to download the relevant electronic files:



SD700 Servo drive manual



SD700 Servo product catalog