

M56S Sseries AC Servo System

RS-485 Type User Manual



SHANGHAI AMP&MOONS' AUTOMATION CO.,LTD.

Contents

| | |
|---|----|
| 1 Introduction | 9 |
| 1.1 About this manual | 9 |
| 1.2 M56 Series RS-485 Documentation | 9 |
| 1.3 Safety | 9 |
| 1.4 Safety sign | 9 |
| 1.5 Safety Precautions | 10 |
| 1.5.1 Installation Precautions | 10 |
| 1.5.2 Wiring | 10 |
| 1.5.3 Test run | 11 |
| 1.6 Certified Specifications | 11 |
| 1.7 Maintenance and Inspection | 11 |
| 1.7.1 Check items and cycles | 11 |
| 1.7.2 Replacement of parts | 12 |
| 2 Basic Information | 13 |
| 2.1 Product confirmation | 13 |
| 2.2 Drive model introduction | 13 |
| 2.2.1 Drive model description | 13 |
| 2.2.2 Drive model description | 14 |
| 2.2.3 Drive Specifications | 14 |
| 2.2.4 Regeneration resistor specification | 17 |
| 2.2.5 Dimensions of the driver (Unit: mm) | 18 |
| 2.3 Motor model introduction | 20 |
| 2.3.1 Motor nameplate description | 20 |
| 2.3.2 Motor model description | 20 |
| 2.3.3 □40mm Frame Low Inertia | 21 |
| 2.3.4 □40mm Frame High Inertia | 22 |
| 2.3.5 □60mm Frame Low Inertia | 23 |
| 2.3.7 □60mm Frame High Inertia | 24 |
| 2.3.8 □80mm Frame Low Inertia | 25 |
| 2.3.9 □80mm Frame High Inertia | 26 |
| 2.3.10 □100mm Frame Low Inertia | 27 |
| 2.3.11 □130mm Frame Medium Inertia | 28 |
| 2.3.12 □130mm Frame Medium Inertia | 29 |
| 2.3.13 □130mm Frame High Inert | 30 |
| 2.3.14 □180mm Frame High Inert | 31 |
| 2.3.15 □180mm Frame High Inert | 32 |
| 2.4 Motor General Specifications | 33 |
| 2.4.1 Motor Encoder Specifications | 33 |
| 2.4.2 Brake Specifications | 33 |
| 2.5 Servo Drive and Motor Selection Reference Information Sheet | 34 |
| 2.6 Matching Cable and Connector Accessories | 36 |
| 2.6.1 Servo motor matching cable | 36 |
| 2.6.2 Driver plug kit | 39 |
| 2.6.3 Motor plug kit | 39 |
| 2.6.4 Absolute value battery kit | 39 |
| 2.6.5 Communication cable | 39 |
| 2.6.6 Other cable | 39 |

| | | |
|-------|--|----|
| 2.6.7 | Regenerative resistor | 39 |
| 2.6.8 | Dynamic brake resistor | 39 |
| 2.6.9 | EMI filter | 39 |
| 3 | Installation..... | 40 |
| 3.1 | Storage Conditions | 40 |
| 3.1.1 | Drive storage environment conditions..... | 40 |
| 3.1.2 | Motor Storage Conditions | 40 |
| 3.2 | Installation Conditions | 40 |
| 3.2.1 | Driving environment conditions..... | 40 |
| 3.2.2 | The motor operation ambient conditions are as follows:..... | 40 |
| 3.3 | Drive installation space..... | 41 |
| 3.4 | Motor Installation | 41 |
| 3.4.1 | Encoder and Bearing Protection..... | 41 |
| 3.4.2 | Precautions for the use of the motor in the oil and water environment..... | 42 |
| 3.4.3 | Wiring..... | 42 |
| 3.4.4 | Motor temperature rise..... | 43 |
| 4 | System Configuration and Wiring | 44 |
| 4.1 | Electromagnetic compatibility (EMC)..... | 44 |
| 4.1.1 | EMI Noise Filter..... | 44 |
| 4.1.2 | Grouding | 46 |
| 4.1.3 | Motor cable selection and installation precautions | 46 |
| 4.1.4 | EMI Noise Filters..... | 47 |
| 4.1.5 | Ferrite Ring | 48 |
| 4.2 | External main circuit wiring..... | 49 |
| 4.2.1 | Main circuit wiring diagram..... | 49 |
| 4.2.2 | Servo Drive Connectors and Terminals (750W and below models)..... | 52 |
| 4.2.3 | Servo Drive Connectors and Terminals (1.0/1.5/2.5/3.0kW Type) | 52 |
| 4.2.4 | Servo Drive Connectors and Terminals(5.0/6.0/7.5kW Type) | 53 |
| 4.2.5 | Connecting and Wiring Notes | 54 |
| 4.2.6 | Precautions for the use of towline cables | 55 |
| 4.2.7 | Recommended Wires..... | 56 |
| 4.2.8 | Ground wire terminal..... | 57 |
| 4.3 | Drive Power Supply Interface | 58 |
| 4.3.1 | AC220V Single Phase Input (750W and below models)..... | 58 |
| 4.3.2 | AC220V Three Phase Input (750W and below models)..... | 59 |
| 4.3.3 | AC220V Single Phase Input (1.0/1.5kW Type) | 60 |
| 4.3.4 | AC220V Three Phase Input (1.0/1.5/2.5kW Type) | 61 |
| 4.3.5 | AC400V Three Phase (3kW Type)..... | 62 |
| 4.3.6 | AC400V Three Phase (5.0/6.0/7.5kW Type) | 63 |
| 4.4 | P2--Connect Motor to Drive..... | 64 |
| 4.4.1 | Motor Power Cable Configuration..... | 64 |
| 4.4.2 | Definition of Motor Power Connector | 64 |
| 4.4.3 | Motor Power Cable Connector Specifications | 66 |
| 4.5 | CN3--Encoder Connection | 68 |
| 4.5.1 | Encoder Connection between Motor and Drive | 68 |
| 4.5.2 | CN3-Encoder PIN Assignment..... | 68 |
| 4.5.3 | Motor Encoder connector specifications | 69 |
| 4.5.4 | Encoder Wire Connection Definition | 70 |

| | |
|--|-----|
| 4.5.5 Battery of Absolute Encoder | 71 |
| 4.6 Electromagnetic Brake | 72 |
| 4.6.1 Wiring Diagram | 72 |
| 4.6.2 Precautions for the use of brake | 73 |
| 4.6.3 The Timing Charts of Electromagnetic Brake..... | 73 |
| 4.7 Regeneration Resistor P2 | 74 |
| 4.7.1 Calculation method of regenerative energy | 74 |
| 4.7.2 Wiring a Regenerative Resistor | 76 |
| 4.7.3 Parameter Settings for Regenerative Resistor | 76 |
| 4.8 CN1---Connecting to a PC | 76 |
| 4.9 CN2 -Input/Output Signal Connection | 77 |
| 4.9.1 CN2 Input and Output Specifications | 77 |
| 4.9.2 CN2 Input and Output Signals Pin Diagram (-RF) | 78 |
| 4.9.3 CN2 Input and Output Signals Pin Diagram (-RD Type)..... | 79 |
| 4.9.4 CN2 Input and Output Pin Definition..... | 80 |
| 4.9.5 Position Pulse Signal Wiring Instructions..... | 84 |
| 4.9.6 CN2-Input and Output Signals Wiring Instructions | 87 |
| 4.9.7 Analog Signal Wiring Instructions | 91 |
| 4.9.8 Encoder Divided Output..... | 92 |
| 4.10 CN4-Second Encoder Input--Full-closed Loop Control | 93 |
| 4.11 CN5-Safety Torque Off (STO)..... | 94 |
| 4.11.1 Precautions | 94 |
| 4.11.2 STO Input and Output Signals | 95 |
| 4.12 CN6,CN7--RS-485 Communication Port | 97 |
| 4.12.1 CN6 and CN7 Pin Definitions | 97 |
| 4.12.2 RS-485 and RS-422 Connection Method | 97 |
| 5 Display and Touch Panel | 99 |
| 5.1 Description of Touch Panel..... | 99 |
| 5.2 Switch the Display Mode | 100 |
| 5.3 LED Display Description..... | 101 |
| 5.3.1 Decimal Point Description..... | 101 |
| 5.3.2 Data Display..... | 101 |
| 5.3.3 Other Display | 102 |
| 5.3.4 Point to Point Move Function Display | 102 |
| 5.3.5 JOG Mode Display | 102 |
| 5.3.6 Parameter Lock and Unlock..... | 102 |
| 5.4 States Monitor Motor | 103 |
| 5.5 Function Mode | 105 |
| 5.5.1 Functions | 105 |
| 5.5.2 Operation Flow Chart in Function Mode | 106 |
| 5.6 Parameter Setting Mode..... | 107 |
| 5.6.1 How to Set parameters | 107 |
| 5.6.2 Parameter Edit and Save Example | 108 |
| 5.7 Key Lock..... | 109 |
| 5.8 Alarm Code Display | 109 |
| 6 Trial Operatio | 111 |
| 6.1 Inspection Before Trail Operation | 111 |
| 6.2 Steps of Trail Operation..... | 111 |

| | | |
|--------|---|-----|
| 6.3 | JOG Operation | 112 |
| 6.4 | Configuration by Personal Computer | 112 |
| 7 | Operation Mode and Functions | 113 |
| 7.1 | Input and Output Signal Settings..... | 113 |
| 7.1.1 | Input Signal Settings | 113 |
| 7.1.2 | Output Signal Settings | 115 |
| 7.1.3 | Servo On Setting..... | 116 |
| 7.1.4 | Alarm Reset..... | 116 |
| 7.1.5 | CW, CCW Limit | 117 |
| 7.1.6 | Gain Select(Gain Switch)..... | 118 |
| 7.1.7 | Control Mode Select | 120 |
| 7.1.8 | Emergency Stop | 121 |
| 7.1.9 | Fault Output | 122 |
| 7.1.10 | Warning Output | 123 |
| 7.1.11 | Motor Brake Release Control | 124 |
| 7.1.12 | Servo Ready Output | 125 |
| 7.1.13 | Servo-on Status Output | 126 |
| 7.1.14 | Dynamic Position Output | 127 |
| 7.1.15 | Rotation Limit Output | 128 |
| 7.1.16 | Sequence diagram | 129 |
| 7.2 | Position Mode..... | 130 |
| 7.2.1 | Overview of Position Mode Setting Process | 130 |
| 7.2.2 | Wiring Diagram of Digital Pulse Position Mode | 133 |
| 7.2.3 | Position Command Input Settings..... | 134 |
| 7.2.4 | Electronic Gear Ratio | 139 |
| 7.2.5 | Command Smoothing Filter | 142 |
| 7.2.6 | Pulse Input Prohibition Function | 144 |
| 7.2.7 | Clear the Position Following Error Counter Input..... | 144 |
| 7.2.8 | In-position Output Signal..... | 145 |
| 7.2.9 | Near Target Position Output..... | 146 |
| 7.2.10 | Gain Parameters in Position Mode | 147 |
| 7.2.11 | Using Luna Software to Configure Position Control Mode | 148 |
| 7.3 | Velocity Mode | 150 |
| 7.3.1 | Wiring Diagram of Speed Control Mode | 151 |
| 7.3.2 | Related Parameters to Analog Speed Control | 152 |
| 7.3.3 | Analog Speed Mode Settings..... | 153 |
| 7.3.4 | Zero Speed Clamp | 157 |
| 7.3.5 | Start/Stop Control and Direction Changing in Analog Speed Mode..... | 158 |
| 7.3.6 | Zero Speed Detected Output | 160 |
| 7.3.7 | Velocity Reach Output | 161 |
| 7.3.8 | Velocity Coincidence Output | 162 |
| 7.3.9 | Gain parameters and Speed Control Type in Speed Mode | 163 |
| 7.3.10 | Using Luna Software to Configure Speed Control Mode | 164 |
| 7.4 | Torque Mode..... | 166 |
| 7.4.1 | Torque Control Mode Instructions | 166 |
| 7.4.2 | Wiring Diagram of Torque Control Mode..... | 166 |
| 7.4.3 | Related Parameters to Analog Torque Control..... | 167 |
| 7.4.4 | Analog Torque Mode Settings | 168 |

| | | |
|--------|---|-----|
| 7.4.5 | Speed Limit in Torque Control Mode..... | 172 |
| 7.4.6 | Speed Limited Output(V-LTD)..... | 174 |
| 7.4.7 | Torque Reach Output..... | 174 |
| 7.4.8 | Torque Coincidence Output..... | 175 |
| 7.4.9 | Using Luna Software to Configure Torque Control Mode..... | 176 |
| 7.5 | Torque Limit..... | 178 |
| 7.5.1 | Torque Limit Methods..... | 178 |
| 7.5.2 | Torque Limit Sources..... | 178 |
| 7.5.3 | Torque Limited Output(T-LMT)..... | 181 |
| 7.6 | Encoder/Pulse Divided Output..... | 182 |
| 7.6.1 | Pin Numbers of Pulse Output Function..... | 182 |
| 7.6.2 | 脉冲分频输出模式设定..... | 183 |
| 7.6.3 | Pulse Divided Output Settings..... | 183 |
| 7.6.4 | Pulse Output Gear Ratio..... | 185 |
| 7.7 | Analog Output..... | 186 |
| 7.7.1 | Analog Output Wiring Method..... | 186 |
| 7.8 | Full Closed-loop Control..... | 187 |
| 7.8.1 | Full Closed-loop Wiring Method..... | 187 |
| 7.8.2 | Full Closed-loop Control Gain Tuning..... | 188 |
| 7.8.3 | Full Closed-loop Control Setting Steps..... | 190 |
| 7.8.4 | Enable Full Closed-loop Control Mode..... | 193 |
| 7.8.5 | Common Error and Trouble-shooting in Full Closed-loop Control Mode..... | 194 |
| 7.9 | Dynamic Brake..... | 195 |
| 7.9.1 | Dynamic braking resistor wiring method..... | 196 |
| 7.9.2 | Dynamic Brake when Servo-off..... | 197 |
| 7.9.3 | Dynamic Brake when Drive Fault Occurs..... | 197 |
| 7.10 | Homing Mode..... | 198 |
| 7.10.1 | Homing Function Instructions..... | 199 |
| 7.10.2 | Homing Methods Summary..... | 200 |
| 7.11 | Internal Velocity Control..... | 226 |
| 7.11.1 | Set the Control Mode to Internal Velocity..... | 226 |
| 7.11.2 | Digital Inputs Settings..... | 227 |
| 7.11.3 | Internal Velocity Settings..... | 227 |
| 7.11.4 | Input Signal and 8-segment Internal Speed Selection..... | 228 |
| 7.11.5 | Rotation Direction Switching in Internal Velocity Mode..... | 228 |
| 8 | Parameter Settings..... | 230 |
| 8.1 | Parameter Definitions..... | 230 |
| 8.2 | Parameter List..... | 230 |
| 8.3 | Parameter Description..... | 235 |
| 8.3.1 | Group P0-XX: PID Parameters..... | 235 |
| 8.3.2 | Group P1-XX: Configurations..... | 242 |
| 8.3.3 | Group P2-XX: Trajectory..... | 251 |
| 8.3.4 | Group P3-XX: Encoder & Step/Dir Configuration..... | 254 |
| 8.3.5 | Group P4-XX: Analog..... | 264 |
| 8.3.6 | Group P5-XX: IO Configuration..... | 267 |
| 9 | Troubleshooting..... | 274 |
| 9.1 | Alarm List..... | 274 |
| 9.2 | Driver Alarm Causes and Measures..... | 276 |

| | |
|--|-----|
| 10 Servo Gain Tuning..... | 281 |
| 10.1 Instructions for Gain Tuning Mode and Procedures | 281 |
| 10.1.1 Servo Tuning Procedures | 281 |
| 10.1.2 What is the Gain Tuning Mode..... | 282 |
| 10.2 Auto Tuning Mode..... | 282 |
| 10.2.1 Required Motion Profile in Auto Tuning Mode..... | 283 |
| 10.2.2 Auto Tuning Flowchart | 284 |
| 10.2.3 Start Auto Tuning-- By Operation Panel..... | 285 |
| 10.2.4 Start Auto Tuning-- By Luna software | 286 |
| 10.3 Fine Tuning Mode..... | 289 |
| 10.3.1 Introducton of Fine Tuning Mode | 289 |
| 10.3.2 Parameters in Fine Tuning Mode..... | 289 |
| 10.3.3 Description for Gain Parameters..... | 290 |
| 10.3.4 Gain Parameters for Velocity Loop | 291 |
| 10.4 Resonance Suppression | 292 |
| 10.4.1 Torque Command Filter..... | 292 |
| 10.4.2 Notch Filter..... | 292 |
| 10.4.3 Mechanical Analysis and Manual Setting of Notch Filtes..... | 295 |
| 10.5 End Effector Suppress..... | 301 |
| 10.6 Load Disturbance Suppress | 303 |
| 11 Modbus/RTU Commucation..... | 304 |
| 11.1 Modbus/RTU Configurations..... | 304 |
| 11.1.1 Data Encode..... | 304 |
| 11.1.2 Communication Address | 304 |
| 11.1.3 Communication Protocol and Baud Rate | 304 |
| 11.1.4 Power-on Mode | 305 |
| 11.2 Modbus/RTU Message Frame..... | 305 |
| 11.3 Supported Function Codes for Modbus | 305 |
| 11.3.1 Function Code :0x03: Read Hold Register..... | 305 |
| 11.3.2 Function Code 0x06: Write a Single Register | 307 |
| 11.3.3 Function Code 0x10: Write Multiple Register | 308 |
| 11.4 SCL Command Code..... | 309 |
| 11.4.1 Command Code | 309 |
| 11.4.2 I/O Code | 310 |
| 11.5 Modbus Register Table of M56S Series..... | 311 |
| 11.5.1 M56S Series General Purpose Registers | 311 |
| 11.5.2 M56S Series—P0 Group (PID) | 316 |
| 11.5.3 M56S Series—P1 Group (Configuration) | 319 |
| 11.5.4 M56S Series—P2 Group (Trajectory) | 321 |
| 11.5.5 M56S Series—P3 Group(Encoder & Step/Dir)..... | 323 |
| 11.5.6 M56S Series—P4 Group(Analog) | 324 |
| 11.5.7 M56S Series—P5 Group(I/O)..... | 325 |
| 11.6 Alarm Code and Status Code of M56S:..... | 328 |
| 11.6.1 Servo M56S Drive Alarming Code (Main Code) Table | 328 |
| 11.6.2 M56S Drive Alarming Code (auxiliary code) Table | 328 |
| 12 Appendix 1: LED Display character comparison table..... | 329 |
| 13 Contact Us..... | 330 |

Disclaimer

The information in this manual was accurate and reliable at the time of its publication. Shanghai Anpu Mingzhi Automation Equipment Co., Ltd. reserves the right to change the product specifications described in this manual at any time without prior notice.

Trademark Rights

All proper names mentioned in this manual are the trademarks of their respective owners.

Customer service

Shanghai Anpu Mingzhi Automation Equipment Co., Ltd. is committed to providing quality customer service and support for all of our products. Our goal is to provide our clients with the information and resources they need in a timely and reliable manner. For quick service, we recommend that you contact your local sales representative for order status and logistics information, product information and documentation, as well as on-site technical support and applications. If you have special reasons and cannot contact your sales representative, please use the following relevant contact methods:

If you need technical support, please contact: ama-support@moons.com.cn

1 Introduction

1.1 About this manual

This manual is manual of M56S Series RS-485 AC Servo Driver.

It provides installation, configuration and basic operation of M56 servo unit.

This document is intended for qualified personnel who transport, assemble, and maintain this equipment.

1.2 M56 Series RS-485 Documentation

This manual is part of a series of documents, the entire series consists of the following:

- M56S RS-485 Quick Start Guide. Basic setup and operation of the drive.
- M56S RS-485 User Manual. Hardware installation, configuration and operation.
- Luna software user manual. Introduce how to use the Luna software.

1.3 Safety

To prevent hazards to people and damage to property, installation should only be performed by qualified personnel.



M56S series AC servo products use dangerous voltage. The drive must be properly grounded.

Before you install M56S series AC servo products, please read the product manual carefully. Failure to follow safe operating instructions may result in personal injury or equipment damage.

1.4 Safety sign

Safety signs indicate potential personal hazards or equipment damage, such as failure to follow recommended precautions and actual safe practices. The following are cautionary safety symbols used in this manual and on the drive:



Caution



Dangerous Voltage



Earth



Caution, Hot Surface

1.5 Safety Precautions

1.5.1 Installation Precautions

| | |
|---|---|
|  | ◆ DO NOT subject the product to water, corrosive or flammable gases, and combustibles. |
| | ◆ DO NOT use the motor in a place subject to excessive vibration or shock. |
| | ◆ Never connect the motor directly to the AC power supply. |
| | ◆ DO NOT use cables soaked in water or oil. |
| | ◆ DO NOT extrude or pull-off the cable, nor damage the cables as electrical shocks, damages may result |
| | ◆ DO NOT block the heat dissipating holes. Please prevent any metal filings drop into the drive when mounting. |
| | ◆ DO NOT switch the power supply repeatedly. |
| | ◆ DO NOT touch the rotating shaft when the motor is running. |
| | ◆ DO NOT strike the motor when mounting as the motor shaft or encoder may be damaged. |
| | ◆ In order to prevent accidents, the initial trial run for servo motor should be conducted ◆ under no load conditions (separate the motor from its couplings and belts). |
| | ◆ Starting the operation without matching the correct parameters may result in servo drive or motor damage, or damage to the mechanical system. |
| | ◆ DO NOT Touch either the drive heat sink or the motor and regenerative resister during operation as they may become hot. |
| | ◆ DO NOT hold the motor cable during the transportation or mounting. |

1.5.2 Wiring

| | |
|---|---|
|  | ◆ Do not connect the power grid to the UVW motor terminal on the drive side, it will damage the drive or cause a fire |
| | ◆ Please connect the output UVW of the driver and the UVW of the servo motor directly, and do not pass the electromagnetic contactor in the middle. |
| | ◆ Please tighten the fixing screws of the power supply and motor output terminals, otherwise it may cause fire |
| | ◆ Do not switch the main power supply of the driver frequently. If you really need to switch the power supply repeatedly, please control it to less than 1 time per minute. |
| | ◆ Avoid bundling the main circuit cable with the input and output signal cables. |
| | ◆ Please use twisted pair shielded wire for input signal wire and encoder signal wire |
| | ◆ 即使关闭电源，驱动器内任会残留高压；在Charge灯亮时，请勿触碰电源端子 |
| | ◆ Please use the specified power supply voltage |
| | ◆ 在配线时，请将端子座从伺服驱动器上拆下来 |
| | ◆ One wire insertion port of the terminal block, please insert only one wire |
| | ◆ When inserting the wire, do not short the core wire with the adjacent wire |
| | ◆ Be sure to ensure that the driver power supply and motor are well grounded |
| | ◆ Before powering on, make sure all wiring is correct |

1.5.3 Test run

| | |
|---|---|
|  | ◆ Do not directly touch the rotating motor shaft with your hands. |
| | ◆ In the first test run, first separate the coupling or belt of the mechanical equipment, so that the motor is in a no-load state. |
| | ◆ Incorrect parameters will cause abnormal operation under load. |
| | ◆ The temperature of the drive radiator, motor, and external regeneration resistor will rise during operation, please avoid touching. |
| | ◆ Before the machine starts running, please confirm whether the emergency stop device can be activated at any time. |
| | ◆ Use servo motors with brakes on vertical loads to avoid equipment falling during alarm, failure, power failure. |

1.6 Certified Specifications

M56S series low voltage servo products are designed to meet the following standards.



| | | Drive | Motor |
|------------------------|---------------|--------------------|------------------|
| Europe | EMC Directive | EN 61800-3 | EN 60034-1 |
| | | | EN 61000-6-2 |
| | | | EN 61000-6-4 |
| | LVD | EN 61800-5-1 | EN 60034-1 |
| | | | EN 60034-5 |
| Functional Safety(STO) | | UL61800-5-2(SIL 3) | |
| | | IEC61508(SIL 3) | |
| | | ISO13849-1(PL e) | |
| UL Standard | | UL 61800-5-1 | UL 1004-1 |
| | | | UL 1004-6 |
| CSA Standard | | C22.2 No.274.13 | CSA C22.2 No.100 |

1.7 Maintenance and Inspection

1.7.1 Check items and cycles

The normal use conditions of the servo are:

Annual average ambient temperature: 30 °C.

Average load rate: below 80%.

Daily operating time: 20 hours or less.

The items of daily inspection are as follows:

| Type | Inspection cycle | Check item |
|------------------|------------------|---|
| Daily inspection | Daily | ◆ Check the ambient temperature, humidity, dust, foreign matter, and condensation |
| | | ◆ Is there any abnormal vibration or noise |
| | | ◆ Voltage |
| | | ◆ Peculiar smell |
| | | ◆ Are there any foreign objects in the vents? |
| | | ◆ Whether the connector is loose |
| | | ◆ Whether there is foreign matter between the cable and the connector, and whether the cable conductor is exposed |
| | | ◆ Is the fastening part loose? |

1.7.2 Replacement of parts

The components inside the servo products will wear and age over time, and the replacement time of the components varies according to the environmental conditions and usage methods. When replacement is required, please contact our company or our agent. Please do not disassemble and repair by yourself.

| Product | Part | Standard replacement cycle | Note |
|---------|--|---|--|
| Driver | Filter capacitor | About 6 years | The standard replacement cycle is for reference only. Even if the standard replacement cycle is not completed, it needs to be replaced in the event of an abnormality. |
| | Aluminum electrolytic capacitors on circuit boards | About 6 years | |
| | Power-up buffer relay | About 100,000 times (depending on usage conditions) | |
| | Power-on snubber resistor | About 20,000 times (depending on usage conditions) | |
| | Cooling fan | 2~3 years (10,000~30,000 hours) | |
| Motor | Oil seal | 5000 hours | |
| | Battery for absolute encoder | Depending on working condition | |

2 Basic Information

2.1 Product confirmation

Please refer to the following chapters to confirm the model of the driver and the model of the servo motor. A complete operational servo should include the following components:

- Power-matched servo drives and servo motors
- 用于连接驱动器及伺服电机的电机动力线(选购品)
- 用于连接驱动器及伺服电机的编码器线(选购品)
- 用于CN1口至PC机的Mini USB通讯线(选购品)
- 用于CN2口的连接器(标配品)
- 用于CN3口的编码器连接器(选购品)
- 用于CN4口的第二编码器连接器(适用于带全闭环功能型驱动器, 选购品)
- 用于CN5口的STO连接器(适用于带STO功能型驱动器, 选购品)
- 用于CN6及CN7口的RJ-45连接器, 用于总线类产品通讯用(选购品)
- 用于P1口的驱动器电源输入连接器(标配品)
- 用于P2口的电机动力及再生电阻连接器(标配品)

2.2 Drive model introduction

2.2.1 Drive model description

| | | MOONS' <i>moving in better ways</i> | | Designed in California by Assembled in China | |  Applied Motion Products | |
|--------------------------------|-----------|---|--|---|--|---|--|
| Model Number | Model No. | M56S ^{AC SERVO} DRIVE | | M3DV-21A8RF | | Serial No. 23240001 | |
| Input/output Voltage | | INPUT | | OUTPUT | |    | |
| Input/output Phase | VOLT. | 200-240VAC | | 0-240VAC | | | |
| Rated Input/output Current | PHASE | 1 ϕ / 3 ϕ | | 3 ϕ | | | |
| Input/output Current Frequency | F.L.C | 2.4 A / 1.2A | | 1.8 A | | | |
| Rated Output Power | FREQ. | 50/60Hz | | 0-400Hz | | | |
| | POWER | | | 200W | |  RoHS | |

2.2.2 Drive model description

M56S - 2 3A0 R F - ***

① ② ③ ④ ⑤ ⑥

① M56S Series

② Supply Voltage *1

2 : Single/Three-Phase 220VAC

3 : Three-Phase 400VAC

④ Function Type

⑤ Model Type

⑥ 版本号

③ Current

| Supply Voltage | Current | Rated Current A(rms) | Peak Current A(rms) | Rated Power |
|----------------|-----------|----------------------|---------------------|-------------|
| *2 2 | 1A8 | 1.8 | 5.4 | 200W |
| | 3A0 | 3 | 9 | 400W |
| | 4A5 | 4.5 | 13.5 | 750W |
| | 6A0 | 6 | 18 | 1.0kW |
| | *3 10A | 10 | 33 | 1.5kW |
| | *3 13A | 13 | 40 | 2.5kW |
| 3 | 13A | 13 | 40 | 3.0kW |
| | 17A | 17 | 42.5 | 5.0kW |
| | 21 | 21 | 52.5 | 6.0kW |
| | 26 | 26 | 65 | 7.5kW |

*1 Line to Line Voltage

*2 Use Single/Three-Phase 220VAC input

*3 Available for single-phase while the motor power is under 1.5kW

*4 It will be released in the first quarter of 2024.

2.2.3 Drive Specifications

2.2.3.1 AC220V Electrical Specifications

■ Single/three-phase 220V rated AC servo drives

| Drive Model | M56S-21A8R ◆ | M56S-23A0R ◆ | M56S-24A5R ◆ | M56S-26A0RF | M56S-210ARF |
|--------------------------------|--|--------------|--------------|-------------|-------------|
| Main Circuit | Single / Three-phase, AC200 ~ 240V ± 10%, 50/60Hz | | | | |
| Control Circuit | Single-phase, AC200 ~ 240V ± 10%, 50/60Hz | | | | |
| Continuous Power Output A(rms) | 1.8 | 3 | 4.5 | 6 | 10 |
| Maximum Output A(rms) | 5.4 | 12 | 15 | 21 | 30 |
| Withstand Voltage | Primary to earth: withstand 1500 VAC, 1 min, (Leakage current: 20 mA) [220V Input] | | | | |

◆: Type of machine

■ Three-phase 220V rated AC servo drives

| Drive Model | M56S-213ARF |
|--------------------------------|--|
| Main Circuit | Three-phase, AC200 ~ 240V ± 10%, 50/60Hz |
| Control Circuit | Single-phase, AC200 ~ 240V ± 10%, 50/60Hz |
| Continuous Power Output A(rms) | 13 |
| Maximum Output A(rms) | 45 |
| Withstand Voltage | Primary to earth: withstand 1500 VAC, 1 min, (Leakage current: 20 mA) [220V Input] |

2.2.3.2 AC220V Common Specification

| | | | | | | | | | |
|-------------------------|--------------------|----------------------|---|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| Environment | Temperature | | Ambient temperature: 0°C ~ 55°C (If the ambient temperature of servo drive is higher than 45°C, please install the drive in a well-ventilated location) Storage temperature: -20°C ~ 65°C | | | | | | |
| | Humidity | | Both operating and storage : 10 ~ 85%RH or less | | | | | | |
| | Altitude | | Derating is not required for altitudes not higher than 1000m Derating 1% for every additional 100m for altitudes between 1000m and 2000m | | | | | | |
| | Vibration | | 9.8m/s ² or less, 10 ~ 60Hz (Do not use continuously at resonance frequency) | | | | | | |
| Control Mode | | | IGBT: PWM control | | | | | | |
| Motor Encoder Feedback | | | <ul style="list-style-type: none"> ● 26-bit Multi-turn Absolute Optical Encoder ● 21-bit Multi-turn Absolute Magnetic Encoder ● 17-bit Battery-less Multi-turn Absolute Encoder | | | | | | |
| Second Encoder Feedback | | | A/B/Z phase signal differential input | | | | | | |
| I/O | Digital Signal | Input | 10 Configurable optically isolate digital general inputs, 24VDC, 20mA | | | | | | |
| | | Output | 6 Configurable optically isolate digital general outputs, Max. 30VDC, 100mA | | | | | | |
| | Analog Signal | Input | 2 Analog inputs, -10 ~ +10V, 12bit | | | | | | |
| | | Output ^{*2} | 2 Analog outputs, -10 ~ +10V, Max.10mA | | | | | | |
| | Pulse Signal | Input | 2 Pulse Inputs (Optocoupler input, Line Receiver input): <ul style="list-style-type: none"> ● Optocoupler input: 5 ~ 24V, minimum pulse width 1μs, max. pulse frequency 500KHz ● Line Receiver input: 5V differential signal, minimum pulse width 0.125μs, max. pulse frequency 4MHz | | | | | | |
| | | Output | 4 Outputs(3 Line Driver outputs, 1 open collector output) <ul style="list-style-type: none"> ● Line Driver output: Encoder A、B、Z feedback output ● Open collector output: Encoder Z phase | | | | | | |
| Comm Port | USB | | Connection with PC for configuration | | | | | | |
| | RS-485 | | Modbus/RTU Communication protocol | | | | | | |
| Front Panel | | | 4 keys (MODE, UP, DOWN, SET) 5 - digital LED Display | | | | | | |
| Regeneration Resistor | | | <ul style="list-style-type: none"> ● -F Type Built-in regenerative resistor ● -D Type 750W Built-in regenerative resistor ● All models can be equipped with external absorption resistors | | | | | | |
| Control Mode | | | 1. Pulse Position Mode 2. Analog Velocity Mode 3. Analog Torque Mode 4. Internal Position Mode 5. Internal Torque Mode 6. Internal Velocity Mode 7. Command Torque Mode 8. Full Closed Loop Control Mode ^{*3} , Each control mode can be switched by digital input | | | | | | |
| Control Input Signal | | | Servo-ON, Alarm Reset, CW/CCW Limit, Control Mode Select, Gain Select, Clear Position Error, Zero Speed Clamp, Command and Velocity input Direction control, Command and Torque input Direction control, Emergency Stop, Homing Switch, Torque Limit, Speed Limit, Pulse Inhibit, Multi-velocity Switch, Start Q Program, General Purpose Input | | | | | | |
| Control Output Signal | | | Warning Output, Fault Output, Servo Ready, Velocity Reached, Torque Reached, Position Reached, Servo-on Status, Brake Release, Dynamic Position Error Following, Positioning Complete, Zero Speed Detected, Velocity Coincidence, Torque Coincidence, Velocity limit, Torque limit, Homing Finished, Soft Limit CW/CCW, General Purpose Output | | | | | | |
| Protection | | | Over Current, Over Voltage, Under Voltage, Over Temperature, Bad Encoder Feedback, Over Load, Over Speed, Position Error, STO, CW/CCW Limit, Full Closed-loop Hybrid Deviation Fault, Main Power Phase Loss | | | | | | |
| Dynamic Brake | | | -F Built in | | | | | | |
| STO | | | -F Built in | | | | | | |
| Weight | | | <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;">M56S-21A8R◆: 0.8Kg</td> <td style="width: 50%;">M56S-26A0RF: 1.9Kg</td> </tr> <tr> <td>M56S-23A0R◆: 1.1Kg</td> <td>M56S-210ARF: 1.9Kg</td> </tr> <tr> <td>M56S-24A5R◆: 1.6Kg</td> <td>M56S-213ARF: 1.9Kg</td> </tr> </table> | M56S-21A8R◆: 0.8Kg | M56S-26A0RF: 1.9Kg | M56S-23A0R◆: 1.1Kg | M56S-210ARF: 1.9Kg | M56S-24A5R◆: 1.6Kg | M56S-213ARF: 1.9Kg |
| M56S-21A8R◆: 0.8Kg | M56S-26A0RF: 1.9Kg | | | | | | | | |
| M56S-23A0R◆: 1.1Kg | M56S-210ARF: 1.9Kg | | | | | | | | |
| M56S-24A5R◆: 1.6Kg | M56S-213ARF: 1.9Kg | | | | | | | | |

Note: *1, *2, *3 -RD models don't support this function ◆: Model Type

2.2.3.3 AC400V Electrical Specifications

■ three-phase 400V rated AC servo drives

| Drive Model | M56S-313ARF | M56S-317ARF | M56S-321ARF | M56S-326ARF |
|--------------------------------|--|-------------|-------------|-------------|
| Main Circuit | Three-phase, AC380 ~ 480V±10%, 50/60Hz | | | |
| Control Circuit | Single-phase, AC380 ~ 480V±10%, 50/60Hz | | | |
| Continuous Power Output A(rms) | 13 | 17 | 21 | 26 |
| Maximum Output A(rms) | 40 | 42.5 | 52.5 | 65 |
| Withstand Voltage | Primary to earth: withstand 1500 VAC, 1 min, (Leakage current: 20 mA) [220V Input] | | | |

2.2.3.4 AC400V Common Specification

| | | | |
|-------------------------|----------------|--------|---|
| Environment | Temperature | | <ul style="list-style-type: none"> Ambient temperature: 0°C ~ 55°C (If the ambient temperature of servo drive is higher than 45°C, please install the drive in a well-ventilated location) Storage temperature: -20°C ~ 65°C |
| | Humidity | | Both operating and storage : 10 ~ 85%RH or less |
| | Altitude | | Derating is not required for altitudes not higher than 1000m Derating 1% for every additional 100m for altitudes between 1000m and 2000m |
| | Vibration | | 9.8m/s ² or less, 10 ~ 60Hz (Do not use continuously at resonance frequency) |
| Motor Encoder Feedback | | | <ul style="list-style-type: none"> 23-bit Multi-turn Absolute Optical Encoder 21-bit Multi-turn Absolute Magnetic Encoder |
| Second Encoder Feedback | | | A/B/Z phase signal differential input |
| I/O | Digital Signal | Input | 10 Configurable optically isolate digital general inputs, 24VDC, 20mA |
| | | Output | 6 Configurable optically isolate digital general outputs, Max. 30VDC, 100mA |
| | Analog Signal | Input | 2 Analog inputs, -10 ~ +10V, 12bit |
| | | Output | 2 Analog outputs, -10 ~ +10V, Max.10mA |
| | Pulse Signal | Input | 2 Pulse Inputs (Optocoupler input, Line Receiver input): <ul style="list-style-type: none"> Optocoupler input: 5 ~ 24V, minimum pulse width 1μs, max. pulse frequency 500KHz Line Receiver input: 5V differential signal, minimum pulse width 0.125μs, max. pulse frequency 4MHz |
| | | Output | 4 Outputs(3 Line Driver outputs, 1 open collector output) <ul style="list-style-type: none"> Line Driver output: Encoder A、 B、 Z feedback output Open collector output: Encoder Z phase |
| Comm Port | USB | | Connection with PC for configuration |
| | RS-485 | | Modbus/RTU Communication protocol |
| Front Panel | | | 4 keys (MODE, UP, DOWN, SET) 5 - digital LED Display |
| Regeneration Resistor | | | Built-in regenerative resistor (All models can be equipped with external absorption resistors) |
| Control Mode | | | 1. Pulse Position Mode 2. Analog Velocity Mode 3. Analog Torque Mode 4. Internal Position Mode 5. Internal Torque Mode 6. Internal Velocity Mode 7. Command Torque Mode 8. Full Closed Loop Control Mode ^{*3} , Each control mode can be switched by digital input |
| Control Input Signal | | | Servo-ON, Alarm Reset, CW/CCW Limit, Control Mode Select, Gain Select, Clear Position Error, Zero Speed Clamp, Command and Velocity input Direction control, Command and Torque input Direction control, Emergency Stop, Homing Switch, Torque Limit, Speed Limit, Pulse Inhibit, Multi-velocity Switch, Start Q Program, General Purpose Input |
| Control Output Signal | | | Warning Output, Fault Output, Servo Ready, Velocity Reached, Torque Reached, Position Reached, Servo-on Status, Brake Release, Dynamic Position Error Following, Positioning Complete, Zero Speed Detected, Velocity Coincidence, Torque Coincidence, Velocity limit, Torque limit, Homing Finished, Soft Limit CW/CCW, General Purpose Output |
| Protection | | | Over Current, Over Voltage, Under Voltage, Over Temperature, Bad Encoder Feedback, Over Load, Over Speed, Position Error, STO, CW/CCW Limit, Full Closed-loop Hybrid Deviation Fault, Main Power Phase Loss |
| Dynamic Brake | | | Built in |
| STO | | | Built in |
| Weight | | | M56S-313ARF: 1.9Kg M56S-321ARF: 3.8Kg M56S-317ARF: 3.8Kg M56S-326ARF: 3.8Kg |


2.2.4 Regeneration resistor specification

When the output torque of the motor shaft is opposite to the direction of rotation, the energy is fed back from the motor load end to the drive bus capacitor, which makes the bus voltage increase. When it reaches the braking voltage point, the energy can only be consumed by the regeneration resistor, otherwise it will damage the servo drive. The regeneration resistor can be built-in or the user can be connected externally; the built-in and external regeneration resistors cannot be used simultaneously. The related specifications of the built-in regeneration resistor in the M3 EtherCAT series servo drive are as follows:


| Drive P/N | Built-in resistor | | External resistor |
|-------------|-------------------|-----------|----------------------------|
| | ohm (Ω) | Power (W) | Minimal value (Ω) |
| M56S-21A8RD | no-built in | | 40 |
| M56S-21A8RF | 200 | 40 | 40 |
| M56S-23A0RD | no-built in | | 40 |
| M56S-23A0RF | 200 | 40 | 40 |
| M56S-24A5RD | 100 | 60 | 40 |
| M56S-24A5RF | 100 | 60 | 40 |
| M56S-26A0RF | 25 | 80 | 15 |
| M56S-210ARF | 25 | 80 | 15 |
| M56S-213ARF | 25 | 80 | 15 |
| M56S-313ARF | 25 | 80 | 15 |
| M56S-317ARF | 35 | 100 | 35 |
| M56S-321ARF | 35 | 100 | 25 |
| M56S-326ARF | 35 | 100 | 25 |

2.2.5 Dimensions of the driver (Unit: mm)


□ M56S-21A8R◆(100/200W models)




□ M56S-23A0R◆(400W models)



□ M56S-24A5R◆(750W models)




□ M56S-26A0RF(1.0kW models)
 M56S-210ARF(1.5kW models)
 M56S-213ARF(2.5kW models)




◆: 机种类别

□ M56S-313ARF(3.0kW models)




□ M56S-317ARF(5.0kW models)
 M56S-321ARF(6.0kW models)
 M56S-326ARF(7.5kW models)




2.3 Motor model introduction

2.3.1 Motor nameplate description



2.3.2 Motor model description



2.3.3 □40mm Frame Low Inertia


□ Specification

| Type* | | SM3L - 042A◇□D△ |
|------------------------------------|-------------------|---------------------------|
| Rated Output Power | watts | 100 |
| Rated Speed | rpm | 3000 |
| Max.Speed | rpm | 6000 |
| Rated Torque | N·m | 0.32 |
| Peak Torque | N·m | 1.28 |
| Rated Current | A (rms) | 1.2 |
| Peak Current | A (rms) | 5.9 |
| Voltage Constant ± 5% | V (rms) / K rpm | 16.8 |
| Torque Constant ± 5% | N·m / A (rms) | 0.267 |
| Rotor Inertia | Kg·m ² | 0.038 × 10 ⁻⁴ |
| Rotor Inertia - With Brake | Kg·m ² | 0.0433 × 10 ⁻⁴ |
| Shaft Load - Axial | N (max.) | 50 |
| Shaft Load - Radial (End of Shaft) | N (max.) | 60 |
| Weight | Kg | 0.49 |
| Weight - With Brake | Kg | 0.73 |

*◇Encoder Options: □Brake Options: △Oil Seal Options


□ Dimensions (Unit: mm)

1) Without Brake




| Without Brake | L |
|---------------|------|
| SM3L-042A◇ND△ | 91.5 |
| SM3L-042ABND△ | 100 |

2) With Brake



| With Brake | L |
|---------------|-------|
| SM3L-042A◇BD△ | 134.5 |
| SM3L-042ABBD△ | 143 |

□ Torque Curves



----- Max. Intermittent Torque
 _____ Max. Continuous Torque

2.3.4 □40mm Frame High Inertia


□ Specification

| Type* | | SM3H - 041A◇□P△ | SM3H - 042A◇□P△ |
|------------------------------------|-------------------|---------------------------|---------------------------|
| Rated Output Power | watts | 50 | 100 |
| Rated Speed | rpm | 3000 | 3000 |
| Max.Speed | rpm | 6000 | 6000 |
| Rated Torque | N·m | 0.16 | 0.32 |
| Peak Torque | N·m | 0.64 | 1.28 |
| Rated Current | A (rms) | 1.4 | 1.4 |
| Peak Current | A (rms) | 4.8 | 5.7 |
| Voltage Constant ± 5% | V (rms) / K rpm | 9.24 | 14.8 |
| Torque Constant ± 5% | N·m / A (rms) | 0.277 | 0.277 |
| Rotor Inertia | Kg·m ² | 0.0383 × 10 ⁻⁴ | 0.0702 × 10 ⁻⁴ |
| Rotor Inertia - With Brake | Kg·m ² | 0.0395 × 10 ⁻⁴ | 0.0724 × 10 ⁻⁴ |
| Shaft Load - Axial | N (max.) | 50 | 50 |
| Shaft Load - Radial (End of Shaft) | N (max.) | 60 | 60 |
| Weight | Kg | 0.31 | 0.42 |
| Weight - With Brake | Kg | 0.55 | 0.66 |

*◇Encoder Options: □Brake Options: △Oil Seal Options


□ Dimensions (Unit: mm)

1) Without Brake





| Without Brake | L |
|---------------|----|
| SM3H-041A◇NP△ | 70 |
| SM3H-042A◇NP△ | 84 |

2) With Brake



| With Brake | L |
|---------------|-------|
| SM3H-041A◇BP△ | 100.3 |
| SM3H-042A◇BP△ | 114.3 |

□ Torque Curves



----- Max. Intermittent Torque
 ————— Max. Continuous Torque

2.3.5 □60mm Frame Low Inertia


□ Specification

| Type* | | SM3L - 061A◇□P△ | SM3L - 062A◇□P△ |
|------------------------------------|-------------------|--------------------------|--------------------------|
| Rated Output Power | watts | 200 | 400 |
| Rated Speed | rpm | 3000 | 3000 |
| Max.Speed | rpm | 6000 | 6000 |
| Rated Torque | N·m | 0.64 | 1.27 |
| Peak Torque | N·m | 1.9 | 3.8 |
| Rated Current | A (rms) | 1.5 | 2.8 |
| Peak Current | A (rms) | 5.4 | 10 |
| Voltage Constant ± 5% | V (rms) / K rpm | 26.5 | 28.3 |
| Torque Constant ± 5% | N·m / A (rms) | 0.427 | 0.454 |
| Rotor Inertia | Kg·m ² | 0.152 × 10 ⁻⁴ | 0.237 × 10 ⁻⁴ |
| Rotor Inertia - With Brake | Kg·m ² | 0.182 × 10 ⁻⁴ | 0.268 × 10 ⁻⁴ |
| Shaft Load - Axial | N (max.) | 70 | 70 |
| Shaft Load - Radial (End of Shaft) | N (max.) | 200 | 240 |
| Weight | Kg | 0.85 | 1.2 |
| Weight - With Brake | Kg | 1.3 | 1.7 |

*◇Encoder Options: □Brake Options: △Oil Seal Options


□ Dimensions (Unit: mm)

1) Without Brake





| Without Brake | L |
|-----------------|------|
| SM3L - 061A◇NP△ | 84.5 |
| SM3L - 061ABND△ | 85.5 |
| SM3L - 062A◇NP△ | 103 |
| SM3L - 062ABND△ | 104 |

2) With Brake



| With Brake | L |
|-----------------|-------|
| SM3L - 061A◇BP△ | 125 |
| SM3L - 061ABBD△ | 126 |
| SM3L - 062A◇BP△ | 143.5 |
| SM3L - 062ABBD△ | 144.5 |

□ Torque Curves



----- Max. Intermittent Torque
 _____ Max. Continuous Torque

2.3.7 □60mm Frame High Inertia


□ Specification

| Type* | | SM3H - 061A◇□P△ | SM3H - 062A◇□P△ |
|------------------------------------|-------------------|-------------------------|--------------------------|
| Rated Output Power | watts | 200 | 400 |
| Rated Speed | rpm | 3000 | 3000 |
| Max.Speed | rpm | 6000 | 6000 |
| Rated Torque | N·m | 0.64 | 1.27 |
| Peak Torque | N·m | 2.24 | 4.445 |
| Rated Current | A (rms) | 1.7 | 2.8 |
| Peak Current | A (rms) | 5.9 | 9.8 |
| Voltage Constant ± 5% | V (rms) / K rpm | 24.3 | 28.9 |
| Torque Constant ± 5% | N·m / A (rms) | 0.376 | 0.423 |
| Rotor Inertia | Kg·m ² | 0.31 × 10 ⁻⁴ | 0.566 × 10 ⁻⁴ |
| Rotor Inertia - With Brake | Kg·m ² | 0.32 × 10 ⁻⁴ | 0.62 × 10 ⁻⁴ |
| Shaft Load - Axial | N (max.) | 70 | 70 |
| Shaft Load - Radial (End of Shaft) | N (max.) | 200 | 240 |
| Weight | Kg | 0.79 | 1.2 |
| Weight - With Brake | Kg | 1.15 | 1.5 |

*◇Encoder Options: □Brake Options: △Oil Seal Options


□ Dimensions (Unit: mm)

1) Without Brake





| Without Brake | L |
|---------------|----|
| SM3H-061A◇NP△ | 77 |
| SM3H-062A◇NP△ | 97 |

2) With Brake



| With Brake | L |
|---------------|-----|
| SM3H-061A◇BP△ | 106 |
| SM3H-062A◇BP△ | 126 |

□ Torque Curves



----- Max. Intermittent Torque
 _____ Max. Continuous Torque

2.3.8 □ 80mm Frame Low Inertia


□ Specification

| Type* | | SM3L - 083A◇□P△ | SM3L - 084A◇□P△ |
|------------------------------------|-------------------|--------------------------|-------------------------|
| Rated Output Power | watts | 750 | 1000 |
| Rated Speed | rpm | 3000 | 3000 |
| Max.Speed | rpm | 6000 | 6000 |
| Rated Torque | N·m | 2.4 | 3.2 |
| Peak Torque | N·m | 6.7 | 9.6 |
| Rated Current | A (rms) | 4.5 | 5.6 |
| Peak Current | A (rms) | 14 | 19 |
| Voltage Constant ± 5% | V (rms) / K rpm | 33.9 | 36.65 |
| Torque Constant ± 5% | N·m / A (rms) | 0.533 | 0.63 |
| Rotor Inertia | Kg·m ² | 0.829 × 10 ⁻⁴ | 1.01 × 10 ⁻⁴ |
| Rotor Inertia - With Brake | Kg·m ² | 0.961 × 10 ⁻⁴ | 1.12 × 10 ⁻⁴ |
| Shaft Load - Axial | N (max.) | 90 | 90 |
| Shaft Load - Radial (End of Shaft) | N (max.) | 270 | 270 |
| Weight | Kg | 2.29 | 2.77 |
| Weight - With Brake | Kg | 3.1 | 3.62 |

*◇Encoder Options: □Brake Options: △Oil Seal Options


□ Dimensions (Unit: mm)

1) Without Brake





| Without Brake | L |
|---------------|-----|
| SM3L-083A◇NP△ | 115 |
| SM3L-083ABND△ | 115 |
| SM3L-084A◇NP△ | 129 |
| SM3L-084ABND△ | 129 |

2) With Brake



| With Brake | L |
|---------------|-------|
| SM3L-083A◇BP△ | 157 |
| SM3L-083ABBP△ | 157.5 |
| SM3L-084A◇BP△ | 171 |
| SM3L-084ABBD△ | 171.5 |

□ Torque Curves



----- Max. Intermittent Torque
 _____ Max. Continuous Torque

2.3.9 □80mm Frame High Inertia


□ Specification

| Type* | | SM3H - 083A◇□P△ |
|------------------------------------|-------------------|-------------------------|
| Rated Output Power | watts | 750 |
| Rated Speed | rpm | 3000 |
| Max.Speed | rpm | 6000 |
| Rated Torque | N·m | 2.4 |
| Peak Torque | N·m | 8.4 |
| Rated Current | A (rms) | 4.5 |
| Peak Current | A (rms) | 16.7 |
| Voltage Constant ± 5% | V (rms) / K rpm | 32.3 |
| Torque Constant ± 5% | N·m / A (rms) | 0.53 |
| Rotor Inertia | Kg·m ² | 1.46 × 10 ⁻⁴ |
| Rotor Inertia - With Brake | Kg·m ² | 1.63 × 10 ⁻⁴ |
| Shaft Load - Axial | N (max.) | 90 |
| Shaft Load - Radial (End of Shaft) | N (max.) | 270 |
| Weight | Kg | 2.1 |
| Weight - With Brake | Kg | 2.85 |

*◇Encoder Options: □Brake Options: △Oil Seal Options


□ Dimensions (Unit: mm)

1) Without Brake




| Without Brake | L |
|---------------|-----|
| SM3H-083A◇NP△ | 101 |

2) With Brake



| With Brake | L |
|---------------|-----|
| SM3H-083A◇BP△ | 132 |

□ Torque Curves



----- Max. Intermittent Torque
 _____ Max. Continuous Torque

2.3.10 □ 100mm Frame Low Inertia


□ Specification

| Type* | | SM3L - 102A◇□U△ | SM3L - 103A◇□U△ | SM3L - 104A◇□U△ | SM3L - 105A◇□U△ |
|------------------------------------|-------------------|-------------------------|-------------------------|-------------------------|-------------------------|
| Rated Output Power | watts | 1000 | 1500 | 2000 | 2500 |
| Rated Speed | rpm | 3000 | 3000 | 3000 | 3000 |
| Max.Speed | rpm | 6000 | 5700 | 5600 | 5600 |
| Rated Torque | N·m | 3.2 | 4.9 | 6.4 | 8 |
| Peak Torque | N·m | 9.6 | 14.7 | 19.2 | 24 |
| Rated Current | A (rms) | 6.0 | 9.6 | 12.7 | 13 |
| Peak Current | A (rms) | 21 | 36.5 | 44 | 45 |
| Voltage Constant ± 5% | V (rms) / K rpm | 32.9 | 34.1 | 34.3 | 37.4 |
| Torque Constant ± 5% | N·m / A (rms) | 0.543 | 0.563 | 0.565 | 0.61 |
| Rotor Inertia | Kg·m ² | 1.79 × 10 ⁻⁴ | 2.37 × 10 ⁻⁴ | 2.98 × 10 ⁻⁴ | 3.68 × 10 ⁻⁴ |
| Rotor Inertia - With Brake | Kg·m ² | 2.67 × 10 ⁻⁴ | 3.25 × 10 ⁻⁴ | 3.86 × 10 ⁻⁴ | 4.56 × 10 ⁻⁴ |
| Shaft Load - Axial | N (max.) | 90 | 90 | 90 | 90 |
| Shaft Load - Radial (End of Shaft) | N (max.) | 270 | 270 | 270 | 270 |
| Weight | Kg | 4 | 4.39 | 5.2 | 6.3 |
| Weight - With Brake | Kg | 5.2 | 5.64 | 6.12 | 7.6 |

*◇Encoder Options: □ Brake Options: △ Oil Seal Options


□ Dimensions (Unit: mm)

1) Without Brake







| Without Brake | L |
|---------------|-----|
| SM3L-102A◇NU△ | 137 |
| SM3L-103A◇NU△ | 152 |
| SM3L-104A◇NU△ | 168 |
| SM3L-105A◇NU△ | 186 |

2) With Brake



| With Brake | L |
|---------------|-----|
| SM3L-102A◇BU△ | 179 |
| SM3L-103A◇BU△ | 194 |
| SM3L-104A◇BU△ | 210 |
| SM3L-105A◇BU△ | 228 |

□ Torque Curves



----- Max. Intermittent Torque
 _____ Max. Continuous Torque


2.3.12 □ 130mm Frame Medium Inertia

□ Specification

| Type* | | SM3M - 135Y◇□M△ |
|------------------------------------|-------------------|-------------------------|
| Rated Output Power | watts | 3000 |
| Rated Speed | rpm | 2000 |
| Max.Speed | rpm | 3000 |
| Rated Torque | N·m | 14.3 |
| Peak Torque | N·m | 42.9 |
| Rated Current | A (rms) | 10.5 |
| Peak Current | A (rms) | 30 |
| Voltage Constant ± 5% | V (rms) / K rpm | 93.2 |
| Torque Constant ± 5% | N·m / A (rms) | 1.47 |
| Rotor Inertia | Kg·m ² | 36.4 × 10 ⁻⁴ |
| Rotor Inertia - With Brake | Kg·m ² | 38.6 × 10 ⁻⁴ |
| Shaft Load - Axial | N (max.) | 396 |
| Shaft Load - Radial (End of Shaft) | N (max.) | 980 |
| Weight | Kg | 12.05 |
| Weight - With Brake | Kg | 13.95 |


*◇Encoder Options: □ Brake Options: △ Oil Seal Options

□ Dimensions (Unit: mm)



| Models | | L |
|---------------|---------------|-----|
| Without Brake | SM3M-135Y◇NM△ | 205 |
| With Brake | SM3M-135Y◇BM△ | 238 |

□ Torque Curves



----- Max. Intermittent Torque
————— Max. Continuous Torque

2.3.13 □ 130mm Frame High Inert


□ Specification

| Type* | | SM3H - 132A◇□U△ | SM3H - 133A◇□U△ | SM3H - 134A◇□U△ |
|------------------------------------|-------------------|-------------------------|-------------------------|-------------------------|
| Rated Output Power | watts | 850 | 1300 | 1800 |
| Rated Speed | rpm | 1500 | 1500 | 1500 |
| Max.Speed | rpm | 3000 | 3000 | 3000 |
| Rated Torque | N·m | 5.39 | 8.34 | 11.5 |
| Peak Torque | N·m | 16.2 | 25 | 34.5 |
| Rated Current | A (rms) | 6 | 9.6 | 13 |
| Peak Current | A (rms) | 19 | 29.6 | 45 |
| Voltage Constant ± 5% | V (rms) / K rpm | 55.3 | 54.2 | 51 |
| Torque Constant ± 5% | N·m / A (rms) | 0.891 | 0.869 | 0.88 |
| Rotor Inertia | Kg·m ² | 13 × 10 ⁻⁴ | 18.3 × 10 ⁻⁴ | 24.4 × 10 ⁻⁴ |
| Rotor Inertia - With Brake | Kg·m ² | 15.2 × 10 ⁻⁴ | 20.5 × 10 ⁻⁴ | 26.6 × 10 ⁻⁴ |
| Shaft Load - Axial | N (max.) | 196 | 343 | 396 |
| Shaft Load - Radial (End of Shaft) | N (max.) | 490 | 686 | 980 |
| Weight | Kg | 5.92 | 7 | 8.5 |
| Weight - With Brake | Kg | 7.84 | 8.8 | 10.15 |

*◇ Encoder Options: □ Brake Options: △ Oil Seal Options


□ Dimensions (Unit: mm)

1) Without Brake




| Without Brake | L |
|---------------|-----|
| SM3H-132A◇NU△ | 138 |
| SM3H-133A◇NU△ | 152 |
| SM3H-134A◇NU△ | 169 |

2) With Brake



| With Brake | L |
|---------------|-----|
| SM3H-132A◇BU△ | 171 |
| SM3H-133A◇BU△ | 185 |
| SM3H-134A◇BU△ | 202 |

□ Torque Curves



2.3.15 □ 180mm Frame High Inert


□ Specification

| Type* | | SM3H - 184Y◇□U△ | SM3H - 185Y◇□U△ |
|------------------------------------|-------------------|-----------------------|------------------------|
| Rated Output Power | watts | 5500 | 7500 |
| Rated Speed | rpm | 1500 | 1500 |
| Max.Speed | rpm | 3000 | 3000 |
| Rated Torque | N·m | 35 | 48 |
| Peak Torque | N·m | 105 | 120 |
| Rated Current | A (rms) | 20.9 | 25.2 |
| Peak Current | A (rms) | 69.9 | 73.4 |
| Voltage Constant ±5% | V (rms) / K rpm | 114 | 115 |
| Torque Constant ±5% | N·m / A (rms) | 1.67 | 1.93 |
| Rotor Inertia | Kg·m ² | 89 × 10 ⁻⁴ | 125 × 10 ⁻⁴ |
| Rotor Inertia - With Brake | Kg·m ² | 92 × 10 ⁻⁴ | 145 × 10 ⁻⁴ |
| Shaft Load - Axial | N (max.) | 588 | 588 |
| Shaft Load - Radial (End of Shaft) | N (max.) | 1764 | 1764 |
| Weight | Kg | 21 | 26.8 |
| Weight - With Brake | Kg | 23 | 28.9 |

*◇Encoder Options: □Brake Options: △Oil Seal Options


□ Dimensions (Unit: mm)

1) Without Brake





| Without Brake | L |
|---------------|-----|
| SM3H-184Y◇NU△ | 230 |
| SM3H-185Y◇NU△ | 281 |

2) With Brake



| With Brake | L |
|---------------|-----|
| SM3H-184Y◇BU△ | 280 |
| SM3H-185Y◇BU△ | 316 |

□ Torque Curves



----- Max. Intermittent Torque
 _____ Max. Continuous Torque

2.4 Motor General Specifications

| | |
|-------------------------|---|
| Encoder Type | 26-bit, 21-bit, 17-bit Multi-turn Absolute Encoder |
| Insulation class | Class F (155℃) |
| Protection level | IP67 (Except transfixion part of shaft) |
| Installation conditions | indoor installation, avoiding direct sunlight, corrosive and flammable gas |
| Ambient temperature | Working temperature: 0℃~ 40℃ Storage temperature: -20℃ ~ 60℃ |
| Humidity | Storage and usage: 20 ~ 85%RH (no condensation) |
| Altitude | Derating is not required for altitudes not higher than 1000m Derating 1% for every additional 100m for altitudes between 1000m and 2000m |
| Vibration | Under 49m/s ² , 10 ~ 60Hz(Do not use continuously at resonance frequency) |

2.4.1 Motor Encoder Specifications


| Item | Content | | |
|---|--|------------------|-----------------|
| Motor P/N | SM3*_*T*** | SM3*_*X*** | SM3*_*B*** |
| Power Voltage VCC | DC 4.5V~5.5V (Typ 5V) | | |
| External battery voltage | DC 3.3~5.5V (Typ 3.6V) | | --- |
| Power supply voltage VCC consumes current | Typ 160mA | | |
| External battery consumption current | Typ 15μA | | --- |
| Number of pulses per revolution | 67108864 (26-bit) | 8388608 (23-bit) | 131072 (17-bit) |
| Number of multi turn gyrometers | 65536 (16-bit) | | |
| Communication mode | Half-duplex acyclic serial communication | | |
| Baud rate | 4Mbps | | |
| Operation temperature | 0~105℃ | | |

2.4.2 Brake Specifications

Motor brake is used to prevent motor from rotating by power off the servo system. The most common way of use is in vertical application, when the motor is disabled or powered off, in order to prevent the displacement of the mechanical mechanism driven by the motor due to gravity and other reasons, the servo motor with brake needs to be used.

When the brake is powered on, the armature is retracted, the brake pad is released, and the motor can operate normally. When the brake is powered off, the armature is released, the brake pad is locked, and the motor can't rotate.

| Frame | 40mm | 60mm | 80mm | 100mm | 130mm | 180mm |
|-----------------------------|----------------------------------|------|------|-------|-------|-------|
| Static Friction Torque (Nm) | 0.32 | 1.5 | 3.2 | 8 | 18.5 | 60 |
| Rated Voltage (VDC) | 24 | | | | | |
| Power Waste (W @ 20℃) | 6.3 | 7.2 | 9.6 | 14.4 | 24.3 | 52 |
| Current (A) | 0.26 | 0.3 | 0.4 | 0.6 | 1.05 | 2.16 |
| Braking Time | < 70ms (Standard air gap,at 20℃) | | | | | |
| Release Time | <25ms | | | | | |
| Release Voltage | 18.5VDC max.(at 20℃) | | | | | |




During normal operation, do not use the motor's brake to decelerate the motor, it will cause damage to the brake.

2.5 Servo Drive and Motor Selection Reference Information Sheet

| Servo Drives | | | |
|-----------------------------|---|--|--|
| 50pin 焊接型I/O连接器 |  |  |  |
| RS-485 | M56S-21A8RD | M56S-23A0RD | M56S-24A5RD |
| | M56S-21A8RF | M56S-23A0RF | M56S-24A5RF |
| Matching Motors | | | |
| Motor Frame Size & Power |  |  |  |
| | Frame 40, 100W | - | - |
| | Frame 60, 200W | Frame 60, 400W | - |
| | - | - | Frame 80, 750W |
| Low Inertia | Without Brake | SM3L-042A◇ND△ SM3L-042ABND△ SM3L-061A◇NP△ | SM3L-062A◇NP△ SM3L-062ABND△ SM3L-083A◇NP△ SM3L-083ABND△ |
| | With Brake | SM3L-042A◇BD△ SM3L-042ABBD△ SM3L-061A◇BP△ | SM3L-062A◇BP△ SM3L-062ABBD△ SM3L-083A◇BP△ SM3L-083ABBD△ |
| High Inertia | Without Brake | SM3H-042A◇ND△ SM3H-061A◇NP△ | SM3H-062A◇NP△ SM3H-083A◇NP△ |
| | With Brake | SM3H-042A◇BD△ SM3H-061A◇BP△ | SM3H-062A◇BP△ SM3H-083A◇BP△ |

◇ Encoder Option △ Oil Seal Options

| Servo Drive | | | | |
|-----------------------------|------------------|---|--|---|
| 50pin 焊接型I/O连接器 | |  |  |  |
| RS-485 | | M56S-26A0RF | M56S-210ARF | M56S-213ARF |
| Matching Motor | | | | |
| Motor Frame Size & Power | |  |  |  |
| | | Frame 80, 1000W | - | Frame 100, 2000W |
| | | Frame 100, 1000W | Frame 100, 1500W | Frame 100, 2500W |
| | | Frame 130, 850W | Frame 130, 1300W | Frame 130, 1800W |
| | | Frame 130, 1000W | Frame 130, 1500W | Frame 130, 2000W |
| Low Inertia | Without Brake | SM3L-084A◇NP△ SM3L-102A◇NU△ | SM3L-103A◇NU△ | SM3L-103A◇NU△ SM3L-104A◇NU△ |
| | With Brake | SM3L-084A◇BP△ SM3L-102A◇BU△ | SM3L-103A◇BU△ | SM3L-103A◇BU△ SM3L-104A◇BU△ |
| Medium Inertia | Without Brake | SM3M-132ATNU△ SM3M-132AXNU△ | SM3M-133ATNU△ SM3M-133AXNU△ | SM3M-134ATNU△ SM3M-134AXNU△ |
| | With Brake | SM3M-132ATBU△ SM3M-132AXBU△ | SM3M-133ATBU△ SM3M-133AXBU△ | SM3M-134ATBU△ SM3M-134AXBU△ |
| High Inertia | Without Brake | SM3H-132ATNU△ SM3H-132AXNU△ | SM3H-133ATNU△ SM3H-133AXNU△ | SM3H-134ATNU△ SM3H-134AXNU△ |
| | With Brake | SM3H-132ATBU△ SM3H-132AXBU△ | SM3H-133ATBU△ SM3H-133AXBU△ | SM3H-134ATBU△ SM3H-134AXBU△ |

◇ Encoder Option △ Oil Seal Options

2.6 Matching Cable and Connector Accessories

2.6.1 Servo motor matching cable

| Motor Model 1* | Description | Common Type Model | Flexible Type Model 2* | Length (Unit: m) |
|---|--|----------------------------------|------------------------|------------------|
| SM3L-042A ◇ □ D△ SM3L-061A ◇ □ P△ SM3L-062A ◇ □ P△ SM3L-083A ◇ □ P△ SM3L-084A ◇ □ P△ SM3H-042A ◇ □ P△ SM3H-061A ◇ □ P△ SM3H-062A ◇ □ P△ SM3H-083A ◇ □ P△ | Encoder Cables With Battery Absolute Encoder Standard | 2639-0100 | 2639-0100-C10 | 1 |
| | | 2639-0200 | 2639-0200-C10 | 2 |
| | | 2639-0300 | 2639-0300-C10 | 3 |
| | | 2639-0400 | 2639-0400-C10 | 4 |
| | | 2639-0500 | 2639-0500-C10 | 5 |
| | | 2639-0800 | 2639-0800-C10 | 8 |
| | | 2639-1000 | 2639-1000-C10 | 10 |
| | | 2639-1500 | 2639-1500-C10 | 15 |
| | | 2639-2000 | 2639-2000-C10 | 20 |
| | Encoder Cables Incremental Encoder Standard | 2640-0100 | 2640-0100-C10 | 1 |
| | | 2640-0200 | 2640-0200-C10 | 2 |
| | | 2640-0300 | 2640-0300-C10 | 3 |
| | | 2640-0400 | 2640-0400-C10 | 4 |
| | | 2640-0500 | 2640-0500-C10 | 5 |
| | | 2640-0800 | 2640-0800-C10 | 8 |
| | | 2640-1000 | 2640-1000-C10 | 10 |
| | | 2640-1500 | 2640-1500-C10 | 15 |
| | | 2640-2000 | 2640-2000-C10 | 20 |
| SM3L-042AB □ D△ SM3L-061AB □ D△ SM3L-062AB □ D△ SM3L-083AB □ D△ SM3L-084AB □ D△ SM3M-062AB □ D△ SM3M-083AB □ D△ | Encoder Cables With Battery Absolute Encoder Standard | 2641-0100 | 2641-0100-C10 | 1 |
| | | 2641-0200 | 2641-0200-C10 | 2 |
| | | 2641-0300 | 2641-0300-C10 | 3 |
| | | 2641-0400 | 2641-0400-C10 | 4 |
| | | 2641-0500 | 2641-0500-C10 | 5 |
| | | 2641-0800 | 2641-0800-C10 | 8 |
| | | 2641-1000 | 2641-1000-C10 | 10 |
| | | 2641-1500 | 2641-1500-C10 | 15 |
| | | 2641-2000 | 2641-2000-C10 | 20 |
| SM3L-042A ◇ □ D△ SM3L-061A ◇ □ P△ SM3L-062A ◇ □ P△ SM3L-083A ◇ □ P△ SM3L-084A ◇ □ P△ SM3H-042A ◇ □ P△ SM3H-061A ◇ □ P△ SM3H-062A ◇ □ P△ SM3H-083A ◇ □ P△ SM3L-042AB □ D△ SM3L-061AB □ D△ SM3L-062AB □ D△ SM3L-083AB □ D△ SM3L-084AB □ D△ SM3M-062AB □ D△ SM3M-083AB □ D△ | Motor Cables Standard | 1645-0100 | 1645-0100-C10 | 1 |
| | | 1645-0200 | 1645-0200-C10 | 2 |
| | | 1645-0300 | 1645-0300-C10 | 3 |
| | | 1645-0400 | 1645-0400-C10 | 4 |
| | | 1645-0500 | 1645-0500-C10 | 5 |
| | | 1645-0800 | 1645-0800-C10 | 8 |
| | | 1645-1000 | 1645-1000-C10 | 10 |
| | | 1645-1500 | 1645-1500-C10 | 15 |
| | | 1645-2000 | 1645-2000-C10 | 20 |
| | | Motor Cables With Brake Cable | 1646-0100 | 1646-0100-C10 |
| | 1646-0200 | | 1646-0200-C10 | 2 |
| | 1646-0300 | | 1646-0300-C10 | 3 |
| | 1646-0400 | | 1646-0400-C10 | 4 |
| | 1646-0500 | | 1646-0500-C10 | 5 |
| | 1646-0800 | | 1646-0800-C10 | 8 |
| | 1646-1000 | | 1646-1000-C10 | 10 |
| | 1646-1500 | | 1646-1500-C10 | 15 |
| | 1646-2000 | | 1646-2000-C10 | 20 |

* ◇ Encoder Options △ Oil Seal Options

* Flexible -C10 10 million times

Test Conditions: Bend Radius 50mm, Frequency 40 times/min, Distance 1000mm

| Motor Model 1* | Description | Common Type Model | Flexible Type Model 2* | Length (Unit: m) | |
|--|---|---|------------------------|------------------|---------------|
| SM3L-102A ◇ □ U△ SM3L-103A ◇ □ U△ SM3L-104A ◇ □ U△ SM3L-105A ◇ □ U△ SM3M-132A ◇ □ U△ SM3M-133A ◇ □ U△ SM3M-134A ◇ □ U△ SM3M-135Y ◇ □ M△ SM3H-132A ◇ □ U△ SM3H-133A ◇ □ U△ SM3H-134A ◇ □ U△ SM3H-182Y ◇ □ U△ SM3H-183Y ◇ □ U△ SM3H-184Y ◇ □ U△ SM3H-185Y ◇ □ U△ | Encoder Cables With Battery Absolute Encoder Standard | 2642-0100 | 2642-0100-C10 | 1 | |
| | | 2642-0300 | 2642-0300-C10 | 3 | |
| | | 2642-0500 | 2642-0500-C10 | 5 | |
| | | 2642-1000 | 2642-1000-C10 | 10 | |
| | | 2642-1500 | 2642-1500-C10 | 15 | |
| | | 2642-2000 | 2642-2000-C10 | 20 | |
| | | Encoder Cables Incremental Encoder Standard | 2643-0100 | 2643-0100-C10 | 1 |
| | 2643-0300 | | 2643-0300-C10 | 3 | |
| | 2643-0500 | | 2643-0500-C10 | 5 | |
| | 2643-1000 | | 2643-1000-C10 | 10 | |
| | 2643-1500 | | 2643-1500-C10 | 15 | |
| | 2643-2000 | | 2643-2000-C10 | 20 | |
| | SM3L-102A ◇ NU△ SM3M-132A ◇ NU△ SM3H-132A ◇ NU△ | | Motor Cables Standard | 1658-0100 | 1658-0100-C10 |
| | | 1658-0300 | | 1658-0300-C10 | 3 |
| 1658-0500 | | 1658-0500-C10 | | 5 | |
| 1658-1000 | | 1658-1000-C10 | | 10 | |
| 1658-1500 | | 1658-1500-C10 | | 15 | |
| 1658-2000 | | 1658-2000-C10 | | 20 | |
| SM3L-102A ◇ BU△ SM3M-132A ◇ BU△ SM3H-132A ◇ BU△ | Motor Cables With Built-in Brake Cable Standard | 1660-0100 | 1660-0100-C10 | 1 | |
| | | 1660-0300 | 1660-0300-C10 | 3 | |
| | | 1660-0500 | 1660-0500-C10 | 5 | |
| | | 1660-1000 | 1660-1000-C10 | 10 | |
| | | 1660-1500 | 1660-1500-C10 | 15 | |
| | | 1660-2000 | 1660-2000-C10 | 20 | |
| SM3L-103A ◇ NU△ SM3M-133A ◇ NU△ SM3H-133A ◇ NU△ | Motor Cables Standard | 1656-0100 | 1656-0100-C10 | 1 | |
| | | 1656-0300 | 1656-0300-C10 | 3 | |
| | | 1656-0500 | 1656-0500-C10 | 5 | |
| | | 1656-1000 | 1656-1000-C10 | 10 | |
| | | 1656-1500 | 1656-1500-C10 | 15 | |
| | | 1656-2000 | 1656-2000-C10 | 20 | |
| SM3L-103A ◇ BU△ SM3M-133A ◇ BU△ SM3H-133A ◇ BU△ | Motor Cables With Built-in Brake Cable Standard | 1662-0100 | 1662-0100-C10 | 1 | |
| | | 1662-0300 | 1662-0300-C10 | 3 | |
| | | 1662-0500 | 1662-0500-C10 | 5 | |
| | | 1662-1000 | 1662-1000-C10 | 10 | |
| | | 1662-1500 | 1662-1500-C10 | 15 | |
| | | 1662-2000 | 1662-2000-C10 | 20 | |
| SM3L-104A ◇ NU△ SM3L-105A ◇ NU△ SM3M-134A ◇ NU△ SM3M-135Y ◇ NM△ SM3H-134A ◇ NU△ | Motor Cables Standard | 1650-0100 | 1650-0100-C10 | 1 | |
| | | 1650-0300 | 1650-0300-C10 | 3 | |
| | | 1650-0500 | 1650-0500-C10 | 5 | |
| | | 1650-1000 | 1650-1000-C10 | 10 | |
| | | 1650-1500 | 1650-1500-C10 | 15 | |
| | | 1650-2000 | 1650-2000-C10 | 20 | |
| SM3L-104A ◇ BU△ SM3L-105A ◇ BU△ SM3M-134A ◇ BU△ SM3M-135Y ◇ BM△ SM3H-134A ◇ BU△ | Motor Cables With Built-in Brake Cable Standard | 1652-0100 | 1652-0100-C10 | 1 | |
| | | 1652-0300 | 1652-0300-C10 | 3 | |
| | | 1652-0500 | 1652-0500-C10 | 5 | |
| | | 1652-1000 | 1652-1000-C10 | 10 | |
| | | 1652-1500 | 1652-1500-C10 | 15 | |
| | | 1652-2000 | 1652-2000-C10 | 20 | |

* ◇ Encoder Options △ Oil Seal Options

* Flexible -C10 10 million times

Test Conditions: Bend Radius 100mm, Frequency 40 times/min, Distance 1000mm

| Motor Model 1* | Description | Common Type Model | Flexible Type Model 2* | Length (Unit: m) |
|------------------------------------|---|-------------------|------------------------|------------------|
| SM3H-182Y ◇ NU△ SM3H-183Y ◇ NU△ | Motor Cables Standard | 1666-0100 | 1666-0100-C10 | 1 |
| | | 1666-0300 | 1666-0300-C10 | 3 |
| | | 1666-0500 | 1666-0500-C10 | 5 |
| | | 1666-1000 | 1666-1000-C10 | 10 |
| | | 1666-1500 | 1666-1500-C10 | 15 |
| | | 1666-2000 | 1666-2000-C10 | 20 |
| SM3H-182Y ◇ BU△ SM3H-183Y ◇ BU△ | Motor Cables With Built-in Brake Cable Standard | 1681-0100 | 1681-0100-C10 | 1 |
| | | 1681-0300 | 1681-0300-C10 | 3 |
| | | 1681-0500 | 1681-0500-C10 | 5 |
| | | 1681-1000 | 1681-1000-C10 | 10 |
| | | 1681-1500 | 1681-1500-C10 | 15 |
| | | 1681-2000 | 1681-2000-C10 | 20 |
| SM3H-184Y ◇ NU△ SM3H-185Y ◇ NU△ | Motor Cables Standard | 1667-0100 | 1667-0100-C10 | 1 |
| | | 1667-0300 | 1667-0300-C10 | 3 |
| | | 1667-0500 | 1667-0500-C10 | 5 |
| | | 1667-1000 | 1667-1000-C10 | 10 |
| | | 1667-1500 | 1667-1500-C10 | 15 |
| | | 1667-2000 | 1667-2000-C10 | 20 |
| SM3H-184Y ◇ BU△ SM3H-185Y ◇ BU△ | Motor Cables With Built-in Brake Cable Standard | 1680-0100 | 1680-0100-C10 | 1 |
| | | 1680-0300 | 1680-0300-C10 | 3 |
| | | 1680-0500 | 1680-0500-C10 | 5 |
| | | 1680-1000 | 1680-1000-C10 | 10 |
| | | 1680-1500 | 1680-1500-C10 | 15 |
| | | 1680-2000 | 1680-2000-C10 | 20 |

* ◇ Encoder Options △ Oil Seal Options

* Flexible -C10 10 million times

Test Conditions: Bend Radius 100mm, Frequency 40 times/min, Distance 1000mm

2.6.2 Driver plug kit

| Name | P/N | Description |
|--------------------------|-------------------|--|
| I/O Connector | M2-50P | CN2, 50pin Density IO connector |
| Motor Encoder Connector | MSOP-CN310P | CN3, Driver side motor encoder connector |
| Second encoder Connector | MSOP-CN408P | CN4, Full closed loop function encoder connector |
| STO Function Connector | STO Connector Kit | CN5, STO Connector |
| Drive Connector Kit | MSOP-DRPWKITA | 200/400/750W Drive P1, P2, Adjusting handle |
| | MSOP-DRPWKITB | 1.0/1.5/2.5/3.0kW Drive P1, P2, Adjusting handle |

2.6.3 Motor plug kit

| Name | P/N | Description |
|-----------------|-------------|--|
| Motor Connector | MSOP-MTKITA | Frame 80mm and below motor connector kit (without brake connector) |
| | MSOP-MTKITD | Frame 80mm and below motor connector kit (with brake connector) |
| | MSOP-MTKITF | Frame100mm/130mm motor connector kit (Straight) |
| | MSOP-MTKITE | Frame 180mm motor connector kit (Straight) |

2.6.4 Absolute value battery kit

| Name | P/N | Description |
|---------------------------|--------------|--|
| Battery | MSOP-BA01 | Used for absolute value encoder motor with battery |
| Battery and battery cases | MSOP-BAKIT01 | |

2.6.5 Communication cable

| Name | P/N | Length (m) | Description |
|--------------------------------|----------|------------|--|
| USB Config Cable | 2620-150 | 1.5 | CN1, Servo driver and PC communication configuration cable |
| CN6/CN7 Communication Cable | 2012-030 | 0.3 | Twisted-pair, Unshielded type, 0.3m servo driver and controller communication cable Communication cables between servo drives |
| | 2012-300 | 3 | |
| | 2013-030 | 0.3 | Twisted-pair, Shielded type, 0.3m servo driver and controller communication cable Communication cables between servo drives |
| | 2013-300 | 3 | |

2.6.6 Other cable

| Name | P/N | Length (m) | Description |
|---------------------------------|--------------|------------|---|
| Second encoder feedback line | 1643-300 | 3 | Ordinary type, no need for bending times |
| | 1643-500 | 5 | |
| | 1643-300-C05 | 3 | Flexible type, 5 million times of bending |
| | 1643-500-C05 | 5 | |

2.6.7 Regenerative resistor

| P/N | Specification | Description |
|-------------|---------------|---------------------------------|
| REG100W120R | 100W, 120Ω | Regenerative absorbing resistor |
| REG200W120R | 200W, 120Ω | |
| REG300W120R | 300W, 120Ω | |

2.6.8 Dynamic brake resistor

| P/N | Specification | Description |
|-----------|---------------|--|
| DBR85W3R5 | 85W, 3.5Ω | 1.0/1.5/2.5/3.0kW type external dynamic brake resistor |

2.6.9 EMI filter

| P/N | Specification | Description |
|-------------|---------------|---|
| MSOP-EMI020 | 250VAC, 20A | EMI filter for AC power of drive side(Single Phase) |

3 Installation

3.1 Storage Conditions

3.1.1 Drive storage environment conditions

Please note the following when storing:

- Correctly packaged and store in a clean and dry place, avoid direct sunlight
- Store within an ambient temperature range of $-10^{\circ}\text{C} \sim +65^{\circ}\text{C}$
- Store within a relative humidity rang of 10% to 85% and non-condensing
- DO NOT store in a place subjected to corrosive gasses

3.1.2 Motor Storage Conditions

- Correctly packaged and stored in a clean and dry place, avoid direct sunlight
- Store within an ambient temperature range of $-20^{\circ}\text{C} \sim +60^{\circ}\text{C}$
- Store within a relative humidity rang of 20% to 85% and non-condensing
- DO NOT store in a place subjected to corrosive gasses

3.2 Installation Conditions

3.2.1 Driving environment conditions


1. Temperature is $0^{\circ}\text{C} \sim 55^{\circ}\text{C}$. If the ambient temperature exceeds 45°C , please place it in a well-ventilated place. It is recommended to operate at 45°C for a long time
2. If this product is installed in a distribution box, the distribution box must be sized and ventilated so that there is no danger of overheating of all electronic devices used inside.
3. Ambient humidity is 10%~85% RH, no condensation
4. Vibration below 9.8m/s^2
5. Do not use the driver near corrosive gas, flammable gas or combustible material
6. Please install the driver in an indoor electrical control box without water and direct sunlight
7. Please avoid using these drive-in dusty places

3.2.2 The motor operation ambient conditions are as follows:

- The ambient temperature is $0^{\circ}\text{C} \sim 40^{\circ}\text{C}$.
- Ambient humidity is 10%~85% RH, no condensation.
- Vibration below 49m/s^2 .
- Do not use the motor near corrosive gas, flammable gas, or combustible materials.
- Do not use the motor in a closed environment, the closed environment will cause the motor to high temperature and shorten the service life.

3.3 Drive installation space


- When installing the drive, please reserve enough around space for the drive to ensure a good circulating cooling effect.
- Do not block the cooling holes of the drive.
- To ensure the temperature in the cabinet, it is recommended to install a cooling fan in the cabinet.
- Please ground the drive well during installation.




3.4 Motor Installation

3.4.1 Encoder and Bearing Protection

- DO NOT strike the motor when mounting as the motor shaft or encoder may be damaged.




- It is recommended to use a disturbing coupling specially designed for servo motors, which can provide some cushioning during eccentricity or deflection.
- When installing the coupling, please wipe clean the anti-rust oil on the output shaft end of the motor.
- When using the keyway motor, please use the standard key in the motor box.
- When installing a pulley on a servo motor with a keyway, please use the threaded hole of the motor shaft to push the pulley into the motor shaft with a screw.



- When disassembling the pulley, please use professional tools such as pulley remover to prevent the bearing from being injured.
- When connecting the shaft, make sure to achieve the required concentricity. If the concentricity is not good, it will produce vibration and damage the bearing and encoder.
- The load applied in the axial or radial direction of the motor should not exceed the range specified in the specifications, please refer to the specifications table of each servo motor.
- The output shaft material of the servo motor does not have the ability to prevent rust. Although grease has been used for rust protection before leaving the factory, if the storage time exceeds six months, to ensure that the motor shaft is free from rust, please check the condition of the motor shaft regularly every three months and add appropriate anti-rust grease in time.

3.4.2 Precautions for the use of the motor in the oil and water environment

- Do not allow oil and water to enter the inside of the motor
- Do not place cables in water or oil
- Since the through part of the motor shaft and the motor lead wires are not IP65 protected, please ensure that no water or oil enters the motor from such parts
- The motor industrial grade skeleton oil seal can block pollutants (oil, impurities) to prolong the life of the motor. When leaving the factory, the oil seal will be attached to the box, but will not be installed on the motor output shaft. After the oil seal is installed, the oil seal will cause a certain resistance and torque loss to the rotation of the motor shaft. It is recommended that the motor be dated.
- In the application with liquid, please install the motor wiring port downward



3.4.3 Wiring

- If using a cable chain, use a super flexible cable. And ensure that there is a bending diameter of more than 100mm.
- Do not twist the cable.
- When moving the motor, do not pull on the cable.
- Do not use the same sleeve for the main circuit cable and the input/output signal cable / encoder cable, and do not bundle them together. Wiring in this case, the main circuit cable and the input/output signal cable / encoder cable should be separated by at least 30cm.

3.4.4 Motor temperature rise

Servo motors are rated for continuous operation when mounted on a standard heat sink and in an ambient temperature of 40 °C. When the servo motor is installed in a small device, the temperature may rise significantly due to the reduced heat dissipation area of the servo motor.

The dimensions of the standard cooling plate of the servo motor are as follows:

| Base series | Power | Heat sink size |
|-------------|---------------|---------------------|
| 40mm | 50W、100W | 200*200*6 aluminum |
| 60mm | 200W、400W | 250*250*6 aluminum |
| 80mm | 750W | 250*250*6 aluminum |
| | 1kW | 300*300*12 aluminum |
| 100mm | 1kW ~ 2.5kW | 300*300*12 aluminum |
| 130mm | 850W ~ 3kW | 400*400*20 aluminum |
| 180mm | 2.9kW ~ 7.5kW | 550*550*30 aluminum |

If the installation environment makes it difficult to use a large heat sink, or if the ambient temperature exceeds the specification requirements, the following requirements need to be followed:

- Do not work at rated power, choose a motor that is 1~2 times larger than the actual motor power required.
- Reduce the acceleration and deceleration of the duty cycle to reduce the motor load.
- Reduced duty cycle for work.
- External forced air cooling of the servo motor using a cooling fan or other means.
- When using a motor with an oil seal, the oil seal will cause a certain resistance and torque loss to the rotation of the motor shaft, and heat is generated due to the friction between the two. The required load torque needs to be 70% of the rated torque of the motor.

Note: Do not put any thermal insulation material between the servo motor and the metal heat sink, so as to avoid the failure of the motor to dissipate heat and cause the motor temperature to rise, which may cause the motor to malfunction.

4 System Configuration and Wiring

4.1 Electromagnetic compatibility (EMC)

| | |
|---|---|
|  | High-speed switching elements are used in the M56S series, which will produce high frequency interference during operation, and interfere with peripheral equipments through conduction or radiation. |
| | There is also a low voltage unit inside the servo drive, which is likely to be interfered by the noise of the drive's peripheral equipments. The interfered signal may cause the device to make unexpected actions. |

By following the electromagnetic compatibility specifications listed in this manual during installation and wiring, this product can meet the following specifications.

EN 61800-3


In order to prevent mutual electromagnetic interference between the servo drive and its peripheral equipments, the following countermeasures can be taken.

- Install an appropriate EMI noise filter on the power input side.
- Make sure that the drive and motor are well grounded. AWG 10 is recommended for the grounding wire.
- Do not use the same sleeve for the main circuit cable and the input/output signal cable and encoder cable, or tie them together. When wiring, the main circuit cable and the input/output signal cable/encoder cable should be separated by more than 30cm.
- Use twisted-pair shielded wire for digital in-out signal cables and encoder signal cables.
- The length of input and output signal cables should be less than 3m. And the encoder cable is less than 20m.
- Do not use the same power source with electric welders, EDM machines, etc, even if it is not the same power source, when there is a high-frequency generator nearby, connect a EMI noise filter to the input side of the main circuit power and control power cable.

4.1.1 EMI Noise Filter

The EMI noise filter adopts correct installation method to minimize the interference. It is recommended to use EMI filter tested by MOON'S company to maximize the suppression effect.

The recommended EMC protection wiring diagram is as follows.




More measures are as follows

- 1) Remove the paint layer on the contact surface when the drive is mounted on a metal plate
- 2) Servo drive and EMI filter are mounted on the same metal plate.
- 3) Position the input noise filter as close to the drive as possible
- 4) Route the input wires and output wires separately, do not bundle them together
- 5) EMI filter should be well grounded.
- 6) Use shield cables for main circuit. Shield of cable should be directly grounded to PE connector
- 7) Please install a ferrite magnetic ring as shown in the figure above for the input and output signal cables and power cables to get a better EMC effect.

4.1.2 Groudingg

Well grounding treatment can give full play to the effect of EMI filter and greatly reduce interference.

- Must be parallel single-point grounding




- Use a shielded cable for the extension cable between the drive and motor.
- The shielding net of cable should be well grounded and connected to the ground terminal of drive.

4.1.3 Motor cable selection and installation precautions

Select the motor cable with shield and install it correctly to get better EMC effect and interference suppression effect. Please note the following.

- Use a cable that has braided shielding (the effect of double shielding is better).
- The shield on both ends of the motor cable should be grounded with the shortest cable length and the largest contact area.
- Remove the protective paint on the U-shape saddle and metal plate in order to ensure good contact. Please see the figure below.
- A correct connection between the braided shielding of the motor cable and the metal plate is required. The braided shielding on both ends of the motor cable should be fixed by the U-shape saddle and metal plate. Please see the figure below for the correct connection.




4.1.4 EMI Noise Filters

You must attach Noise Filters in appropriate places to protect the servo system from the adverse effects of noise.

NOTE:

- **Select a noise filter that matches the drive power**
- **Separate input cables from output cables. Do not place input cables and output lines in the same duct or bundle them together**



Recommended EMI filter

| MOONS' P/N | Specification | Manufacturer | Description |
|-------------|---------------|--------------|---------------------------|
| MSOP-EMI020 | 250VAC, 20A | LCR | EMI Noise Filter (Single) |

More recommended EMI filters

| Drive Model | Main Supply | Manufacturer | Filter P/N |
|--------------|-------------|--------------|--------------|
| M56S-21A8R ◆ | Single | TYCO | 3ET1 |
| M56S-23A0R ◆ | | TYCO | 6ET1 |
| M56S-24A5R ◆ | | TYCO | 6ET1 |
| M56S-26A0RF | | TYCO | 10ET1 |
| M56S-210ARF | 3-Phase | Dephir | DF300-16A-01 |
| M56S-213ARF | | Dephir | DF300-16A-01 |

◆ Represents the Function type

4.1.5 Ferrite Ring

The Ferrite Ring is used to absorb the radiation interference of the wire.


The ferrite ring has different impedance characteristics at different frequencies. Normally, the impedance is very small at low frequencies. When the signal frequency increases, the impedance of the ferrite ring rises sharply, which makes it easy for normal useful signals to pass through, and can effectively suppress high frequencies. Use the ferrite ring to optimize signal transmission and suppress high-frequency noise, and reduce high-frequency interference in the power and signal cables.

When the ferrite ring suppresses common mode interference, the eddy current loss of the magnetic ring to the high-frequency signal converts the high-frequency component into heat loss, so that a low-pass filter can be formed, which can cause greater attenuation of high-frequency noise, and The impedance of low-frequency useful signals can be ignored and does not affect the normal operation of the circuit.

Winding several turns of wire onto the ferrite ring can increase inductance and the ability to filter out high-frequency noise. But too many turns will cause too much loss and rise the temperature of the ferritering.

The suggested winding methods are shown below:

| | |
|-----------------------|---|
| Digital signal Cables | Winding necessary turns. (2-3 Turns) |
| Motor Power Cables | Remove the jacket to the length so that wires can be wound on the ferrite ring. For effective noise reduction capability, U, V and W should be wound together. and wound 2-3 turns. The ground wire and shield cannot be wound into the ferrite ring. |
| Encoder Cables | Winding necessary turns. (2-3 Turns) |




Recommend Ferrite Ring

| MOONS' PN | P/N | Manufacturer |
|-----------|---------------|--------------|
| M2-OP3035 | ZCAT3035-1330 | TDK |

4.2 External main circuit wiring


4.2.1 Main circuit wiring diagram

4.2.1.1 200/400/750W Type




Note: *1 Certain models don't support this function, please refer to page 16.

4.2.1.2 1.0/1.5/2.5/3kW Type



Note: *1 Certain models don't support this function, please refer to page 16.

4.2.1.3 5.0/6.0/7.5kW Type



4.2.2 Servo Drive Connectors and Terminals (750W and below models)

| Connector Port | Symbol | Description | | |
|----------------|---------------------|--|--|-------------|
| P1 | L1、L2、L3 | Main power supply, connect to single phase and 3-phase | | |
| | L1C、L2C | Control power supply, connect to single phase | | |
| P2 | U、V、W | Servo motor connector | | |
| | | Symbol | Color | Description |
| | | U | Red | |
| | | V | Yellow | |
| | W | Blue | Connecting to three-phase motor main circuit cable | |
| B1+、B2、B3 | Internal Resistor | Ensure the circuit is closed between B2 and B3, and the circuit is open between B1+ and B3. | | |
| | External Resistor | Ensure the circuit is open between B2 and B3, and connect the external regenerative resistor between B1+ and B2. | | |
| CN1 | Mini USB Port | Connect to PC | | |
| CN2 | I/O Connetor Port | Input and output signals | | |
| CN3 | Encoder Port | Used to connect encoder of motor | | |
| CN4 | Second Encoder Port | Connect the external encoder in full closed loop mode | | |
| CN5 | STO Port | The input for Safety Torque Off | | |
| CN6 | RS-485 Port | RS-485 Communication Port | | |
| CN7 | RS-485 Port | RS-485 Communication Port | | |

4.2.3 Servo Drive Connectors and Terminals (1.0/1.5/2.5/3.0kW Type)

| Connector Port | Symbol | Description | | |
|----------------|-----------------------------------|---|--|-------------|
| P1 | L1、L2、L3 | Main power supply, connect to single phase and 3-phase | | |
| | L1C、L2C | Control power supply, connect to single phase | | |
| | B1+、B2、B3 | Internal Resistor | Ensure the circuit is closed between B2 and B3, and the circuit is open between B1+ and B3. | |
| | | External Resistor | Ensure the circuit is open between B2 and B3, and connect the external regenerative resistor between B1+ and B2. | |
| N、R1、R2 | External dynamic braking resistor | When using the dynamic braking function with an external dynamic braking resistor, the resistor is connected between R1 and R2, and the resistor model is DBR85W3R5 | | |
| P2 | U、V、W | Used to connect servo motor | | |
| | | Terminal Symbol | Wire color | Description |
| | | U | Red | |
| | | V | Yellow | |
| W | Blue | Connecting to three-phase motor main circuit cable | | |
| CN1 | Mini USB Port | Connect to PC | | |
| CN2 | I/O Connetor Port | Input and output signals | | |
| CN3 | Encoder Port | Used to connect encoder of motor | | |
| CN4 | Second Encoder Port | Connect the external encoder in full closed loop mode | | |
| CN5 | STO Port | The input for Safety Torque Off | | |
| CN6 | RS-485 Port | RS-485 Communication Port | | |
| CN7 | RS-485 Port | RS-485 Communication Port | | |

4.2.4 Servo Drive Connectors and Terminals(5.0/6.0/7.5kW Type)

| Connector Port | Symbol | Description | | |
|----------------|---------------------|---|--|-------------|
| Power Supply | R、S、T | Used to connect three-phase AC main circuit power | | |
| | L1C、L2C | Used to connect single-phase AC for control circuit power | | |
| | B1+、B2、B3 | Internal Resistor | Ensure the circuit is closed between B2 and B3, and the circuit is open between B1+ and B3. | |
| | | External Resistor | Ensure the circuit is open between B2 and B3, and connect the external regenerative resistor between B1+ and B2. | |
| | N1、N2 | External reactor | DC reactor used for suppressing high-order harmonics in power supply, connected between N1 and N2. When a reactor is not needed, short circuit between N1 and N2 | |
| | U、V、W | Used to connect servo motor | | |
| | | Terminal Symbol | Wire color | Description |
| U | | Red | Connecting to three-phase motor main circuit cable | |
| V | | Yellow | | |
| W | Blue | | | |
| CN1 | Mini USB Port | Connect to PC | | |
| CN2 | I/O Connector Port | Input and output signals | | |
| CN3 | Encoder Port | Used to connect encoder of motor | | |
| CN4 | Second Encoder Port | Connect the external encoder in full closed loop mode | | |
| CN5 | STO Port | The input for Safety Torque Off | | |
| CN6 | RS-485 Port | RS-485 Communication Port | | |
| CN7 | RS-485 Port | RS-485 Communication Port | | |

4.2.5 Connecting and Wiring Notes


- Please ensure grounding wires are securely connected, wires with more than AWG 10(5.3mm²) on sectional area is recommended.
- 请勿在端子台螺丝松动或者电缆线松动的情况下上电，容易引发火灾
- Grounding method must be single point grounding.
- Ensure L1/L2/L3 and L1C/L2C are correctly wired, and voltage supplies are within the specification range.(3kW and below models)
- 检查R、S、T及L1C、L2C接线是否正确，且接入正确的电压(5kW及以上机型)
- When using single-phase power supply, please connect to the L1, L3 pins.(1.5kW and below models)
- Ensure U/V/W is following the order of RED/YELLOW/BLUE. Wrong connections will cause motor stop rotation, or wrong rotatory directions.
- Isolation transformer and EMI filter are recommended on drive' s power supply to ensure safety and improve its anti-interference level.
- Please setup an emergence stop circuitry to switch off the power supply when fault occurs.
- Please DO NOT touch drive or motor's connector terminals 5 minutes after drive and motor is powered off. There are electrical charge components in the circuitry. Therefore, even power is off, there might still be hazardous voltages within the circuitry, before its total discharge.
- Install the encoder cables in a separate conduit from the motor power cables to avoid signal noise. Separate the conduits by 30cm above.
- Use multi-stranded twisted-pair wires or multi-core shielded-pair wires for signal, encoder feedback cables.
- The maximum length of signal input/output cable is 3 meters, and the maximum length of encoder (PG) feedback cables is 20 meters.

4.2.6 Precautions for the use of towline cables

When you need to move the motor cable or install the cable in a drag chain, please use a dedicated flexible cable. Ordinary cables are easy to be damaged during repeated bending, causing the servo motor to fail to work normally.

When using drag chain cables, make sure that:

- Correctly choose the cable that meets the required bending resistance
- The bending radius of the cable is generally more than 10 times the outer diameter of the cable
- Avoid pulling the cable. When wiring inside the drag chain, do not fix or bundle it, so as to avoid the bending radius is not enough and the cable will be pulled
- Please bundle the cables at the two ends of the drag chain and the fixed place of the mechanical part.



- The wiring in the drag chain should not be too dense to ensure that the cable occupies less than 60% of the internal space of the drag chain.
- Avoid mixing cables with large outer diameter differences. If you really need to mix cables, please install baffles.

4.2.7 Recommended Wires

- The main circuit is recommended to use insulated wires with a withstand voltage of 600V and above 75°C.
- Be sure to choose the corresponding allowable current cable to prevent the cable from overheating.

Recommended wires for each part of the drive are as follows:

| Driver and matching servo motor | | Rated Power (W) | Diameter of cable (AWG) | | | | | | | | | |
|---------------------------------|-------------------|-----------------|--|--|---|---|---------------|-------|-----|-----------------------------|--|--|
| | | | Connector P1 | | Connector P2 | | Connector CN3 | -- | | | | |
| | | | L1/L2/L3 R/S/T | L1C/L2C | U/V/W | B1+, B3 | Encoder | Brake | GND | | | |
| M56S-21A8R ◆ | SM3H-041A ◆ □ P △ | 50 | 2.0mm ² (AWG14) | | 0.75 ~ 2.0mm ² (AWG14 ~ 18) | 1.25 ~ 2.0mm ² (AWG14 ~ 16) | | | | | | |
| | SM3L-042A ◆ □ D △ | 100 | | | | | | | | | | |
| | SM3H-042A ◆ □ D △ | | | | | | | | | | | |
| | SM3L-061A ◆ □ P △ | 200 | | | | | | | | | | |
| SM3H-061A ◆ □ P △ | | | | | | | | | | | | |
| M56S-23A0R ◆ | SM3L-062A ◆ □ P △ | 400 | | | | | | | | | | |
| | SM3H-062A ◆ □ P △ | | | | | | | | | | | |
| M56S-24A5R ◆ | SM3L-083A ◆ □ P △ | 750 | | | | | | | | | | |
| | SM3H-083A ◆ □ P △ | | | | | | | | | | | |
| M56S-26A0RF | SM3L-084A ◆ □ P △ | 1000 | | | | | | | | 2.0mm ² AWG14 | 2.0 ~ 3.5mm ² AWG12 ~ 14 | |
| | SM3L-102A ◆ □ U △ | | | | | | | | | | | |
| | SM3M-132A ◆ □ U △ | | | | | | | | | | | |
| | SM3H-132A ◆ □ U △ | 850 | | | | | | | | | | |
| M56S-210ARF | SM3L-103A ◆ □ U △ | 1500 | | | | | | | | | | |
| | SM3M-133A ◆ □ U △ | | | | | | | | | | | |
| | SM3H-133A ◆ □ U △ | 1300 | | | | | | | | | | |
| M56S-213ARF | SM3L-104A ◆ □ U △ | 2000 | 2.0 ~ 3.5mm ² AWG12 ~ 14 | 3.5 ~ 5.3mm ² AWG10 ~ 12 | 2.0 ~ 3.5mm ² AWG12 ~ 14 | | | | | | | |
| | SM3L-105A ◆ □ U △ | 2500 | | | | | | | | | | |
| | SM3M-134A ◆ □ U △ | 2000 | | | | | | | | | | |
| | SM3H-134A ◆ □ U △ | 1800 | | | | | | | | | | |
| M56S-313ARF | SM3H-182Y ◆ □ U △ | 2900 | 2mm ² AWG14 | 2mm ² AWG14 | | | | | | | | |
| | SM3M-135Y ◆ □ U △ | 3000 | | | | | | | | | | |
| M56S-317ARF | SM3H-183Y ◆ □ U △ | 4400 | 5.3mm ² AWG10 | 5.3mm ² AWG10 | | | | | | | | |
| M56S-321ARF | SM3H-184Y ◆ □ U △ | 5500 | | | | | | | | | | |
| M56S-326ARF | SM3H-185Y ◆ □ U △ | 7500 | | | | | | | | | | |

◆ Model Type, ◇ Encoder Options, □ Brake Options, △ Oil Seal Options

- Please use insulated pin terminals for power connectors P1 and P2



- Please select the pin terminal according to the recommended wire
 Connector applicable wire type: AWG14~AWG18
 The outer diameter of the wire for the connector: $\varnothing 2.1 \sim 4.2\text{mm}$

4.2.8 Ground wire terminal

- In order to obtain a better EMC effect, please use 5.3mm²/AWG10 dedicated copper conductor cable
- Please use O-shaped cold pressed terminals
- Tightening torque of ground wire terminals

| Drive Model | Grounding screw | |
|--|-----------------|-------------------|
| | Specification | Tightening torque |
| M56S-21A8R ◆ M56S-23A0R ◆ M56S-24A5R ◆ M56S-26A0RF M56S-210ARF M56S-213ARF M56S-313ARF | M3 | 1.2 N.m |
| M56S-317ARF M56S-321ARF M56S-326ARF | M4 | 1.4 N.m |

◆ Represents the Function type


Notes:

- Exceeding the maximum tightening torque will cause damage to the screw hole.
- Do not install the grounding screw when the power is on, it may cause electric sparks.
- Please regularly check whether the grounding screw is loose.

4.3 Drive Power Supply Interface

220V AC servo drive supports single phase or three phase wiring method. Three phase wiring method for 1.5KW or above drives is recommended.

4.3.1 AC220V Single Phase Input (750W and below models)



Notes:


| Symbol | Description | Symbol | Description |
|--------|------------------|--------|-----------------------|
| MCCB | Circuit Breaker | E_stop | Emergency Stop Switch |
| NF | EMI Noise Filter | MC | Magnetic Contactor |
| P_on | Power On Switch | Alm_R | Alarm Relay |
| P_off | Power Off Switch | Alarm | Alarm Relay Contactor |

■ Peripheral equipment capacity for wiring

| Drive | Voltage (VAC) | Motor Rated Output Power (W) | Drive Power capacity kVA (Rated Load) | Circuit Breaker Rated Current (A) | Contactor Rated Current(A) |
|-------------|------------------|------------------------------|---------------------------------------|-----------------------------------|----------------------------|
| M56S-21A8R◆ | Single-Phase 220 | 100 | 0.4 | 6 | 9A (3P+1a) |
| M56S-23A0R◆ | | 200 | 0.5 | | |
| M56S-24A5R◆ | | 400 | 0.9 | 10 | |
| | | 750 | 1.3 | 16 | |

◆ Represents the Function type

4.3.2 AC220V Three Phase Input (750W and below models)



Note: Three-phase 220V is the line voltage

Notes:


| Symbol | Description | Symbol | Description |
|--------|------------------|--------|-----------------------|
| MCCB | Circuit Breaker | E_stop | Emergency Stop Switch |
| NF | EMI Noise Filter | MC | Magnetic Contactor |
| P_on | Power On Switch | Alm_R | Alarm Relay |
| P_off | Power Off Switch | Alarm | Alarm Relay Contactor |

■ Peripheral equipment capacity for wiring

| Drive | Voltage (VAC) | Motor Rated Output Power (W) | Drive Power capacity kVA (Rated Load) | Circuit Breaker Rated Current (A) | Contactor Rated Current(A) |
|--------------|-----------------|------------------------------|---------------------------------------|-----------------------------------|----------------------------|
| M56S-21A8R ◆ | Three Phase 220 | 100 | 0.4 | 4 | 9A (3P+1a) |
| M56S-23A0R ◆ | | 200 | 0.5 | | |
| M56S-24A5R ◆ | | 400 | 0.9 | | |
| M56S-24A5R ◆ | | 750 | 1.3 | 16 | |

◆ Represents the Function type

4.3.3 AC220V Single Phase Input (1.0/1.5kW Type)




Notes:

| Symbol | Description | Symbol | Description |
|--------|------------------|--------|-----------------------|
| MCCB | Circuit Breaker | E_stop | Emergency Stop Switch |
| NF | EMI Noise Filter | MC | Magnetic Contactor |
| P_on | Power On Switch | Alm_R | Alarm Relay |
| P_off | Power Off Switch | Alarm | Alarm Relay Contactor |

■ Peripheral equipment capacity for wiring

| Drive | Voltage (VAC) | Motor Rated Output Power (W) | Drive Power capacity kVA (Rated Load) | Circuit Breaker Rated Current (A) | Contactors Rated Current(A) |
|-------------|------------------|------------------------------|---------------------------------------|-----------------------------------|-----------------------------|
| M56S-26A0RF | Single-Phase 220 | 850, 1000 | 1.8 | 16 | 12A (3P+1a) |
| M56S-210ARF | | 1300, 1500 | 2.3 | 20 | 18A (3P+1a) |

4.3.4 AC220V Three Phase Input (1.0/1.5/2.5kW Type)



Note: Three-phase 220V is the line voltage


Notes:

| Symbol | Description | Symbol | Description |
|--------|------------------|--------|-----------------------|
| MCCB | Circuit Breaker | E_stop | Emergency Stop Switch |
| NF | EMI Noise Filter | MC | Magnetic Contactor |
| P_on | Power On Switch | Alm_R | Alarm Relay |
| P_off | Power Off Switch | Alarm | Alarm Relay Contactor |

■ Peripheral equipment capacity for wiring

| Drive | Voltage (VAC) | Motor Rated Output Power (W) | Drive Power capacity kVA (Rated Load) | Circuit Breaker Rated Current (A) | Contactor Rated Current(A) |
|-------------|-----------------|------------------------------|---------------------------------------|-----------------------------------|----------------------------|
| M56S-26A0RF | Three Phase 220 | 850, 1000 | 1.8 | 10 | 9A (3P+1a) |
| M56S-210ARF | | 1300, 1500 | 2.3 | 16 | |
| M56S-213ARF | | 1800, 2000, 2500 | 3.3 | | |

4.3.5 AC400V Three Phase (3kW Type)



Note: Three-phase 400V is the line voltage


Notes:

| Symbol | Description | Symbol | Description |
|--------|------------------|--------|-----------------------|
| MCCB | Circuit Breaker | E_stop | Emergency Stop Switch |
| NF | EMI Noise Filter | MC | Magnetic Contactor |
| P_on | Power On Switch | Alm_R | Alarm Relay |
| P_off | Power Off Switch | Alarm | Alarm Relay Contactor |

■ Peripheral equipment capacity for wiring

| Drive | Voltage (VAC) | Motor Rated Output Power (W) | Drive Power capacity kVA (Rated Load) | Circuit Breaker Rated Current (A) | Contactor Rated Current(A) |
|-------------|-----------------|------------------------------|---------------------------------------|-----------------------------------|----------------------------|
| M56S-313ARF | Three Phase 400 | 2900, 3000 | 15.15 | 16 | 9A (3P+1a) |

4.3.6 AC400V Three Phase (5.0/6.0/7.5kW Type)



Note: Three-phase 400V is the line voltage

Notes:


| Symbol | Description | Symbol | Description |
|--------|------------------|--------|-----------------------|
| MCCB | Circuit Breaker | E_stop | Emergency Stop Switch |
| NF | EMI Noise Filter | MC | Magnetic Contactor |
| P_on | Power On Switch | Alm_R | Alarm Relay |
| P_off | Power Off Switch | Alarm | Alarm Relay Contactor |

■ Peripheral equipment capacity for wiring

| Drive | Voltage (VAC) | Motor Rated Output Power (W) | Drive Power capacity kVA (Rated Load) | Circuit Breaker Rated Current (A) | Contactor Rated Current(A) |
|-------------|-----------------|------------------------------|---------------------------------------|-----------------------------------|----------------------------|
| M56S-317ARF | Three Phase 400 | 4400 | 22.25 | 20 | 18A |
| M56S-321ARF | | 5500 | 25 | 25 | (3P+1a) |
| M56S-326ARF | | 7500 | 31.25 | 32 | 25A (3P+1a) |

4.4 P2--Connect Motor to Drive

4.4.1 Motor Power Cable Configuration



4.4.2 Definition of Motor Power Connector

4.4.2.1 PIN Assignment for Frme 80mm and below

| Motor Model | PIN.No | Name | Define |
|---|--------|------|-------------------|
| SM3L-042A◇□D△ SM3L-061A◇□P△ SM3L-062A◇□P△ SM3L-083A◇□P△ SM3L-084A◇□P△ | 1 | PE | Motor ground wire |
| SM3H-042A◇□P△ SM3H-061A◇□P△ SM3H-062A◇□P△ SM3H-083A◇□P△ | 2 | U | U Phase |
| | 3 | V | V Phase |
| | 4 | W | W Phase |

◇ Encoder Options, □ Brake Options, △ Oil Seal Options


4.4.2.2 PIN Assignment for Frme100mm/130mm

| Motor Model | PIN.No | Name | Define |
|--|--------|---------|-------------------|
| SM3M-132A◇□U△ | A | PE | Motor ground wire |
| SM3L-102A◇□U△ SM3M-133A◇□U△ SM3L-103A◇□U△ SM3M-134A◇□U△ | F | U | U Phase |
| SM3L-104A◇□U△ SM3M-135Y◇□M△ | I | V | V Phase |
| SM3L-105A◇□U△ SM3H-132A◇□U△ | B | W | W Phase |
| SM3H-132A◇□U△ | C | Brake 1 | 电机抱闸1 |
| SM3H-134A◇□U△ | D | Brake 2 | 电机抱闸2 |

◇ Encoder Options, □ Brake Options, △ Oil Seal Options

4.4.2.3 PIN Assigenment for Frme 180mm


| Motor Model | PIN.No | Name | Define |
|--|--------|---------|-------------------|
| SM3H-182Y◇□U△ SM3H-183Y◇□U△ SM3H-184Y◇□U△ SM3H-185Y◇□U△ | A | PE | Motor ground wire |
| | F | U | U Phase |
| | I | V | V Phase |
| | B | W | W Phase |
| | D | Brake 1 | 电机抱闸1 |
| | E | Brake 2 | 电机抱闸2 |



◇ Encoder Options, □ Brake Options, △ Oil Seal Options

4.4.3 Motor Power Cable Connector Specifications

4.4.3.1 Frame size 80mm and below Motor Power Cable Wiring Definition




| Motor Model | Drive side | Item | Color | Motor side |
|---|--------------------------|-------------|-------------------------|------------------|
| | (JST)061JFAT-SBXGF-I | | | DGFA4S-B1-00A(H) |
| SM3L-042A◇□D△ SM3L-061A◇□P△ SM3L-062A◇□P△ SM3L-083A◇□P△ SM3L-084A◇□P△ | Grounding Screw 3 | PE U | Yellow/Green Red | 1 2 |
| SM3H-042A◇□P△ SM3H-061A◇□P△ SM3H-062A◇□P△ SM3H-083A◇□P△ | 2 1 | V W | Yellow Blue | 3 4 |

□Encoder Options ◇Brake Optionst △Oil seal Options

NOTE: Ensure U/V/W is following the order of RED/YELLOW/BULE. Wrong connections will cause motor stop rotation, or wrong rotary directions.

4.4.3.2 Frame size 100mm/130mm Motor Power Cable Wiring Definition




| Motor Model | | Drive side | Item | Color | 电机侧对插连接器 |
|--|---------------|-----------------|---------|--------------|----------------|
| | | | | | XMS3108E20-18S |
| SM3L-102A◇□U△ SM3L-103A◇□U△ SM3L-104A◇□U△ SM3L-105A◇□U△ | SM3M-132A◇□U△ | U | U | Red | F |
| | SM3M-133A◇□U△ | V | V | Yellow | I |
| | SM3M-134A◇□U△ | W | W | Blue | B |
| | SM3M-135Y◇□M△ | Grounding Screw | FG | Yellow/Green | A |
| | SM3H-132A◇□U△ | - | Brake 1 | Red | C |
| | SM3H-134A◇□U△ | - | Brake 2 | Black | D |

□Encoder Options ◇Brake Optionst △Oil seal Options

NOTE: Ensure U/V/W is following the order of RED/YELLOW/BULE. Wrong connections will cause motor stop rotation, or wrong rotary directions.

4.4.3.3 Frame size 180mm Motor Power Cable Wiring Definition




| Motor Model | Drive side | Item | Color | 电机侧对插连接器 |
|--|-----------------|---------|--------------|----------|
| | | | | WS32K6TS |
| SM3H-182Y◇□U△ SM3H-183Y◇□U△ SM3H-184Y◇□U△ SM3H-185Y◇□U△ | U | U | Red | 2 |
| | V | V | Yellow | 3 |
| | W | W | Blue | 4 |
| | Grounding Screw | FG | Yellow/Green | 1 |
| | - | Brake 1 | Red | 5 |
| | - | Brake 2 | Black | 6 |

□Encoder Options ◇Brake Optionst △Oil seal Options


NOTE: Ensure U/V/W is following the order of RED/YELLOW/BULE. Wrong connections will cause motor stop rotation, or wrong rotary directions.

4.5 CN3--Encoder Connection

4.5.1 Encoder Connection between Motor and Drive




4.5.2 CN3-Encoder PIN Assignment



| PIN.No | Symbol | Description |
|--------|-------------|----------------------------|
| 1 | Encoder +5V | Encoder Power +5V |
| 2 | GND | Encoder Power GND |
| 7 | CLK- | CLK- Signal |
| 8 | CLC+ | CLC+ Signal |
| 9 | SD-/DATA- | SD-Signal, or DATA- Signal |
| 10 | SD+/DATA+ | SD+Signal, or DATA+ Signal |
| Shield | Shield | Shield |

4.5.3 Motor Encoder connector specifications


4.5.3.1 Frame size 80mm and below motor encoder connector pin definition



| Motor Model | | PIN.No | Symbol | Description |
|---------------|---------------|--------|----------|---------------------------------|
| SM3L-042AT□D△ | SM3L-042AX□D△ | 1 | Shield | Shield GND |
| SM3L-061AT□D△ | SM3L-061AX□D△ | 2 | -- | -- |
| SM3L-062AT□D△ | SM3L-062AX□D△ | 3 | VCC | Encoder Power 5V |
| SM3L-083AT□D△ | SM3L-083AX□D△ | 4 | VBAT | Absolute value encoder battery+ |
| SM3L-084AT□D△ | SM3L-084AX□D△ | 5 | SD+ | Encoder communication data + |
| SM3H-042AT□P△ | SM3H-042AX□P△ | 6 | -- | -- |
| SM3H-061AT□P△ | SM3H-061AX□P△ | 7 | VCC_GND | Encoder Power GND |
| SM3H-062AT□P△ | SM3H-062AX□P△ | 8 | VBAT_GND | Absolute value encoder battery- |
| SM3H-083AT□P△ | SM3H-083AX□P△ | 9 | SD- | Encoder communication data - |

| Motor Model | | PIN.No | Symbol | Description |
|---------------|--|--------|--------|-------------------|
| SM3L-041AB□D△ | | 1 | -- | -- |
| SM3L-042AB□D△ | | 2 | CLK+ | CLK+ |
| SM3L-061AB□D△ | | 3 | CLK- | CLK- |
| SM3L-062AB□D△ | | 4 | DATA- | DATA- |
| SM3L-083AB□D△ | | 5 | DATA+ | DATA+ |
| SM3L-084AB□D△ | | 6 | 5V | Encoder Power 5V |
| SM3M-062AB□D△ | | 7 | -- | -- |
| SM3M-083AB□D△ | | 8 | GND | Encoder Power GND |
| | | 9 | -- | -- |

4.5.3.2 Frame size 100mm/130mm/180mm motor encoder connector pin definition




| Motor Model | | PIN.No | Symbol | Description |
|---------------|---------------|--------|----------|---------------------------------|
| SM3L-102AT□U△ | SM3L-102AX□U△ | 1 | VCC | Encoder Power 5V |
| SM3L-102AT□U△ | SM3L-102AX□U△ | | VCC_GND | Encoder Power GND |
| SM3L-102AT□U△ | SM3L-102AX□U△ | 3 | SD+ | Encoder communication data + |
| SM3M-132AT□U△ | SM3M-132AX□U△ | 4 | SD- | Encoder communication data - |
| SM3M-133AT□U△ | SM3M-133AX□U△ | 5 | VBAT+ | Absolute value encoder battery+ |
| SM3M-134AT□U△ | SM3M-134AX□U△ | | VBAT_GND | Absolute value encoder battery- |
| SM3M-135YT□M△ | SM3M-135YX□M△ | 7,8,9 | NC | --- |
| SM3H-132AT□U△ | SM3H-132AX□U△ | | Shield | Shield GND |
| SM3H-133AT□U△ | SM3H-133AX□U△ | | | |
| SM3H-134AT□U△ | SM3H-134AX□U△ | | | |

□ Brake Options △ Oil seal Options

Note: DO NOT connect the UN-defination PINs

4.5.4 Encoder Wire Connection Definition

4.5.4.1 Frame size 80mm and below encoder wire connection definition




| For motor encoder type | Drive side J1 | Battery | Signal | Color | Motor side J2 |
|--|---------------|---------|----------|------------|---------------|
| -T Type: 26 Multi-turn Absolute -X Type: 21 Multi-turn Absolute | 1 | -- | VCC | Red | 3 |
| | 2 | -- | VCC_GND | Black | 7 |
| | -- | Vbat+ | VBAT | Green | 4 |
| | -- | Vbat- | VBAT_GND | Orange | 8 |
| | 9 | -- | SD- | Blue/Black | 9 |
| | 10 | -- | SD+ | Blue | 5 |
| | -- | -- | Shield | | 1 |

| For motor encoder type | Drive side J1 | Signal | Color | Motor side J2 |
|--|---------------|---------|------------|---------------|
| -B Type: 17 Battery-less Multi-turn Absolute | 1 | VCC | Red | 6 |
| | 2 | VCC_GND | Black | 8 |
| | 7 | CLK- | Green | 3 |
| | 8 | CLK+ | Orange | 2 |
| | 9 | DATA- | Blue/Black | 4 |
| | 10 | DATA+ | Blue | 5 |

Note: DO NOT connect the UN-defination PINs

4.5.4.2 Frame size 100mm/130mm/180mm encoder wire connection definition



| For motor encoder type | Drive side J1 | Battery | Signal | Color | Motor side J2 |
|--|---------------|---------|----------|------------|---------------|
| -T Type : 23 Multi-turn Absolute -X Type : 21 Multi-turn Absolute | 1 | -- | VCC | Red | 1 |
| | 2 | -- | VCC_GND | Black | 2 |
| | -- | Vbat+ | VBAT | Green | 5 |
| | -- | Vbat- | VBAT_GND | Orange | 6 |
| | 9 | -- | SD- | Blue/Black | 3 |
| | 10 | -- | SD+ | Blue | 4 |
| | -- | -- | Shield | | 10 |

Note: DO NOT connect the UN-defination PINs


4.5.5 Battery of Absolute Encoder

When the SM3 series absolute encoder motor is used in a multi-turn absolute value system, it needs to use battery power to record multi-turn data when the drive is powered off. After power-on, the drive calculates the absolute position of the mechanical load through the absolute position of the encoder. There is no need to repeat the mechanical homing operation.

When using our company's encoder cable with a battery box, the battery box has a built-in battery MSOP-BA01, which meets the UL lithium battery standard and the IEC lithium battery international safety standard. Please refer to the figure below for the battery dimensions.

■ Battery replacement

There is a risk of electrolyte leakage after long-term use of the battery. It is recommended to replace the battery every two years. It is recommended to replace the battery when the drive is powered on, otherwise the absolute position of the encoder will be lost due to no power supply after the battery is removed.



■ Battery selection

Please refer to the information in the table below to select a battery of appropriate specifications.

| Battery Spec. | Item&Unit | Rated Value | | | Description |
|-----------------------------|---------------------------|-------------|---------|--|---|
| | | Min. | Typical | Max. | |
| Output Spec. 3.6V, 2.7Ah | Battery Voltage(V) | 3.3 | 3.6 | 5 | Standby work |
| | Battery low Voltage(V) | --- | 2.8 | --- | |
| | Battery alarm Voltage(V) | --- | 3.2 | --- | |
| | Current consumption(μ A) | --- | 2 | --- | During normal work |
| | | --- | 10 | --- | During standby operation, the shaft is stationary |
| | Operation Ambient(°C) | --- | 30 | --- | During standby operation, the shaft rotates |
| Storage Ambient(°C) | 0 | --- | 40 | Same as the ambient temperature of motor | |
| | -20 | --- | 60 | | |

■ Precautions for battery use


1. Connect the positive and negative electrodes correctly.
2. If a battery that has been used for a long time or an unusable battery is installed in the machine, liquid leakage may occur. It will not only corrode the surrounding parts, but also has the risk of short circuit. It is recommended to replace it regularly (reference period: it is recommended to replace it every two years).
3. It is forbidden to disassemble the battery to prevent the electrolyte from flying and affecting personal safety.
4. It is forbidden to throw the battery into the fire to avoid the danger of explosion.
5. It is strictly forbidden to short-circuit between the positive and negative electrodes of the battery
6. It is forbidden to charge the battery.
7. It is forbidden to solder directly on the surface of the battery, and the battery with solder feet or leads should be used.
8. Please discard the replaced battery according to local regulations.

4.6 Electromagnetic Brake

Servo motors are used in applications such as vertical axes. When the motor is disabled or powered off, to prevent the mechanical mechanism driven by the motor from falling due to gravity and other reasons, it is necessary to use a servo motor with an electromagnetic brake.

Note: The brake of the servo motor can only be used to maintain the position of the motor when the motor is not enabled or power-off. Do not use it for braking during deceleration, otherwise the motor will be damaged.

4.6.1 Wiring Diagram



PIN Definition

| Motor Model | PIN.No | Item | Definition | |
|---|--------|------|----------------------|--|
| SM3L-041A◇BD△ SM3L-042A◇BP△ SM3L-061A◇BP△ SM3L-062A◇BP△ SM3L-083A◇BP△ SM3L-084A◇BP△ SM3H-041A◇BP△ SM3H-042A◇BP△ SM3H-061A◇BP△ SM3H-062A◇BP△ SM3H-083A◇BP△ | 1 | 24V | Brake power supply+ | |
| | 2 | 0V | Brake power supply- | |
| SM3L-102A◇BU△ SM3L-103A◇BU△ SM3L-104A◇BU△ SM3L-130A◇BU△ SM3M-132A◇BU△ SM3M-133A◇BU△ SM3M-134A◇BU△ SM3M-135Y◇BM△ SM3H-132A◇BU△ SM3H-133A◇BU△ SM3H-134A◇BU△ | C | 24V | Brake power supply+ | |
| | D | 0V | Brake power supply- | |
| SM3H-182Y◇BU△ SM3H-183Y◇BU△ SM3H-184Y◇BU△ SM3H-185Y◇BU△ | 5 | 24V | Brake power supply + | |
| | 6 | 0V | Brake power supply - | |


4.6.2 Precautions for the use of brake

- The signal of the drive control brake can not directly drive the motor's brake. The external 24V power supply and relay must be provided. It is best to try a separate 24V power supply to prevent other equipment from causing abnormal power supply which will eventually cause the motor brake to malfunction.
- The digital output signal of the driver is an optocoupler output, the maximum is 30VDC, 30mA. When controlling inductive loads such as relays, be sure to install a freewheeling diode, otherwise the output pin circuit of the driver will be damaged and the signal will not be output normally.
- The electromagnetic brake is a normally closed type, and the motor shaft cannot rotate when the brake is not powered
- Electromagnetic brake has no polarity requirement
- Avoid the voltage drop as the wire is too thin
- The brake specifications are as follows:

| Motor | Power | Holding Torque Nm | Release Continuous Current A | Release Continuous Power W@20°C | Rated Voltage VDC | Release Time ms | Release Voltage VDC | Brake Time ms |
|--------------|---------------|-------------------|------------------------------|---------------------------------|-------------------|-----------------|---------------------|---------------|
| SM3*-04***** | 50W、100W | 0.32 | 0.26 | 6.3 | 24V±10% | 40 | 15 | 20 |
| SM3*-06***** | 200W、400W | 1.5 | 0.3 | 7.2 | | | | |
| SM3*-08***** | 750W、1000W | 3.2 | 0.4 | 9.6 | | 70 | 16 | 25 |
| SM3*-10***** | 1kW ~ 2.5kW | 8.0 | 0.6 | 14.4 | | 120 | | |
| SM3*-13***** | 850W ~ 3kW | 18.5 | 1.05 | 24.3 | | 120 | 60 | |
| SM3*-18***** | 2.9kW ~ 7.5kW | 60 | 2.16 | 52 | | 150 | 19 | 100 |

4.6.3 The Timing Charts of Electromagnetic Brake

由于制动器在释放及制动时都有动作延时，为避免制动器的损坏，在使用中需要注意动作时序。



Motion waiting time and disable delay time can be set using Luna software, or by modifying parameters P5-24 and P5-25 through the panel.

4.7 Regeneration Resistor P2

当电机的转矩方向和转速方向相反时，电机处于类似发电模式，外部能量由电机端转换为电压回灌到驱动器，使得驱动器母线电压升高，这个过程能量称之为再生能量。比如电机在减速过程中。过高的母线电压会损伤驱动器，因此当母线电压高于一定限值时，必须使用再生能量吸收电阻来消耗这部分电压，否则驱动器会产生过压报警。

M56S系列驱动器内置的再生能量吸收电阻的规格参考下表。

| Drive P/N (kW) | Built-in Resistor | | External Resistor Minimum Resistor (Ω) |
|----------------|-------------------|--------------------------|---|
| | Resistor (Ω) | Power P _R (W) | |
| M56S-21A8RD | no built-in | no built-in | 50 |
| M56S-21A8RF | 200 | 40 | 50 |
| M56S-23A0RD | no built-in | no built-in | 50 |
| M56S-23A0RF | 200 | 40 | 50 |
| M56S-24A5RD | 100 | 60 | 50 |
| M56S-24A5RF | 100 | 60 | 50 |
| M56S-26A0RF | 25 | 80 | 15 |
| M56S-210ARF | 25 | 80 | 15 |
| M56S-213ARF | 25 | 80 | 15 |
| M56S-313ARF | 25 | 80 | 15 |
| M56S-317ARF | 35 | 100 | 35 |
| M56S-321ARF | 35 | 100 | 25 |
| M56S-326ARF | 35 | 100 | 25 |

4.7.1 Calculation method of regenerative energy

A. Reciprocating motion

When the motor decelerates, the kinetic energy during deceleration will be converted into electrical energy and fed back to the bus capacitor.

The energy during deceleration is divided into two parts:

- A) Energy generated when the motor decelerates
- B) Energy generated when the external load decelerates

The following provides a simple method to simply calculate the required regenerative energy absorption resistance.

1) Calculate the energy E_M when the motor is decelerating

The following table shows the energy produced when the M56S series servo motor decelerates from 3000 rpm to 0 rpm without external load.

| Motor Series | Frame Size (mm) | Power (W) | Servo Motor P/N | Rotor Inertia J _M (10 ⁻⁴ Kgm) | Energy produced by decelerating E _M (J) | Maximum energy absorbed by the driver capacitor E _C (J) |
|----------------|-----------------|---------------|-----------------|---|--|--|
| Low Inertia | 40 | 100 | SM3L-042***** | 0.043 | 0.21 | 8.7 |
| | | 60 | 200 | SM3L-061***** | 0.152 | 0.75 |
| | 400 | | SM3L-062***** | 0.243 | 1.20 | 13 |
| | 80 | | 750 | SM3L-083***** | 0.856 | 4.22 |
| | | 1000 | SM3L-084***** | 1.07 | 5.27 | 27 |
| | 100 | 1000 | SM3L-102***** | 1.79 | 8.82 | 40.6 |
| | | 1500 | SM3L-103***** | 2.37 | 11.68 | 40.6 |
| 2000 | | SM3L-104***** | 3.68 | 14.69 | 40.6 | |
| Medium Inertia | 130 | 1000 | SM3M-132***** | 13.9 | 68.52 | 27 |
| | | 1500 | SM3M-133***** | 19.4 | 95.64 | 40.6 |
| | | 2000 | SM3M-134***** | 23.3 | 114.86 | 40.6 |

| | | | | | | |
|--------------|-----|------|---------------|------|--------|------|
| High Inertia | 130 | 850 | SM3H-132A**** | 13.9 | 68.52 | 40.6 |
| | | 1300 | SM3H-133A**** | 19.4 | 95.64 | 40.6 |
| | | 1800 | SM3H-134A**** | 23.3 | 114.86 | 40.6 |

2) Calculate the energy E_L generated by the dragged load during deceleration.

Assuming that the inertia of the load is N times the inertia of the motor, the energy generated when the dragged load is decelerated from 3000rpm to 0rpm is:

$$E_L = N \times E_M$$

If $E_M + E_L < E_C$, that means during deceleration, the energy generated by the motor and the dragged load during deceleration is less than the energy that the drive capacitor can absorb, so there is no need to worry about regenerative energy absorption.

3) Calculate the average power P_{AV} of the required regenerative energy absorption resistance

$$P_{AV} = \frac{E_M + E_L - E_C}{t_{dec}}$$

t_{dec} is the deceleration time + the interval time between two deceleration's

4) Judgement

If $P_{AV} < P_R$, The total power generated during deceleration is less than the power of the built-in regenerative energy absorption resistance of the drive, so no external resistance is needed.

If $P_{AV} > P_R$, The total power generated during deceleration is greater than the power of the built-in regenerative resistance of the drive, and an external resistance is required. In order to reasonably control the temperature rise of the external absorption resistance, the minimum resistance power is $P_{AV} / 0.5$.

For example:

Use 400W motor SM3L-062A****, The load inertia is 15 times the motor inertia. Assuming t_{dec} (deceleration time + interval between two deceleration's) is 0.5s, and each movement is decelerated from 3000rpm to 0rpm, the required power of the regeneration resistance is calculated as::

$$E_M = 1.2J, E_C = 13.04J$$

$$E_L = N \times E_M = 15 \times 1.2 = 18J$$

$$P_{AV} = (1.2 + 18 - 13.04) / 0.5 = 12.32Watt$$

Since the 400W driver has a built-in absorption resistor power of 40W, there is no need to connect an external resistor.

B. The external load torque drives the motor, and most of the continuous negative power output of the motor is doing positive work, that is, the torque output direction of the motor is the same as the direction of rotation. In some special applications, the torque output direction of the motor is just opposite to the speed direction, and the external energy will be fed back into the drive at this time. The servo system will output the opposite force to overcome the gravity of the external load in order to meet the requirements of position and speed. Such as the vertical downward movement of a large load, when running for a long time, the bus capacitance is full and it cannot continue to absorb the regenerative energy. At this time, the regenerative resistor is required to absorb the energy. The power calculation formula is as follows:

$$P_T = 2\pi T_M N_M$$

Where:

T_M is the output torque, Unit: Nm

N_M is the speed, Unit: rps

For example :



The torque output direction of the motor is opposite to the direction of rotation. When the motor output torque is 0.6Nm and the speed is 2400rpm, the power at this time is:

$$P_T = 2 \times 3.14 \times 0.6 \times 2400 / 60 = 150.72$$

At this time, an external absorption resistor is required, and the minimum power is 150.72W. In order to reasonably control the temperature rise of the external absorption resistor, the minimum power is 300W.

4.7.2 Wiring a Regenerative Resistor

在某些应用中，当内部吸收电阻无法吸收再生电动势时，为防止造成驱动器过压报警，需要外接功率更大的吸收电阻。

| Using the build-in resistor | Using external resistor |
|---|--|
| Short-circuit the B2 and B3 of the drive's P2 connector | Disconnect B2 and B3, and connect the resistor to B1+ and B2. |
|  |  |

4.7.3 Parameter Settings for Regenerative Resistor

Relevant parameters:

| Para. | Command | Parameter Name | Rang | Default | Unit | Description |
|-------|---------|--|------------|---------|------|--|
| P1-19 | ZR | Regeneration Resistor Value | 10 ~ 32000 | 200 | Ohm | The resistance of regenerative resistor. |
| P1-20 | ZC | Regeneration Resistor Continuous Wattage | 1 ~ 32000 | 40 | Watt | The regeneration resistor power. |
| P1-21 | ZT | Regeneration Resistor Time Constant | 0 ~ 8000 | 1000 | ms | The regeneration resistor time constant. Decides the peak time that the resistor can tolerate full regeneration voltage. |

Note:

Set the resistance, power and time constant of the regenerative resistor correctly, otherwise it will affect working and cause the drive to get a over-voltage, regenerative energy absorbing failure or other alarms.

When connecting an external resistor, make sure that the total resistance cannot be less than the minimum allowable resistance of the drive. If multiple resistors are connected in series or in parallel, calculate the total resistance and total power correctly.

| | |
|--|---|
| Connect a 100Ω, 200W resistor | Parameter Settings: P1-19 = 100 P1-20 = 200 |
| Connect two 50Ω, 200W resistors in series | Parameter Settings: P1-19 = 100 P1-20 = 400 |
| Connect two 100Ω, 200W resistors in parallel | Parameter Settings: P1-19 = 50 P1-20 = 400 |

4.8 CN1----Connecting to a PC

The CN1 port is used for the communication between drive and PC. By using Luna software, you can set control mode, modify parameters,online tuning and more settings.


| PIN NO | Symbol | Description |
|--------|--------|-------------|
| 1 | +5V | USB Power |
| 2 | D- | Data - |
| 3 | D+ | Data + |
| 4 | — | Reserve |
| 5 | GND | GND |

4.9 CN2 -Input/Output Signal Connection

The CN2 port of the M56S series AC servo driver is used to connect input and output signals.

4.9.1 CN2 Input and Output Specifications


CN2 Pin assignments are as follows.




Specifications of input and output signals are as follows:

| Signals | Descriptions | RS-485 Type | | |
|-----------------|--------------|--|---------|---------|
| | | -F Type | -R Type | |
| Digital Signals | Input | 10 configurable optical isolate digital inputs 24VDC, max input current 20mA | Support | Support |
| | Output | 6 configurable optical isolate digital outputs, up to 30VDC, 30mA | Support | Support |
| Analog signals | Input | 12bit A/D: 2 inputs: -10~+10V | Support | Support |
| | Output | D/A: 2 outputs, -10~+10V | Support | Support |
| Pulse signals | Input | 2 inputs (Photocoupler input, Line Receiver input) : ◆ Photocoupler input : 5V differential or 24V open-collector pulse input, minimum pulse width 1μs, maximum frequency 500KHz ◆ Line Receiver input: 5V differential pulse input, minimum pulse width 0.125μs, maximum frequency 4MHz | Support | Support |
| | Output | 4 outputs (Line driver: 3 output, open collector: 1 output) ◆ Line Driver output : Feed out the encoder feedback pulse A、B、Z ◆ Open collector output: Feed out the encoder feedback pulse Z | Support | Support |

4.9.2 CN2 Input and Output Signals Pin Diagram (-RF)



4.9.3 CN2 Input and Output Signals Pin Diagram (-RD Type)



4.9.4 CN2 Input and Output Pin Definition

50Pin高密度连接器机型所支持的功能不同，输入输出引脚也有区别，具体引脚定义见表一和表二。

◆ Table 1: -RF type pin definition

| PIN NO. | Symbol | Description | PIN NO. | Symbol | Description | PIN NO. | Symbol | Description |
|---------|--------|-----------------------------------|---------|--------|--|---------|--------|---|
| 1 | OPC1 | Pull-up for open collector inpu-1 | 18 | AIN2 | Analog input 2 | 35 | Y2+ | Digital output 2+ |
| 2 | OPC2 | Pull-up for open collector inpu-2 | 19 | OCZ | Encoder's Z signal open collector output | 36 | Y3- | Digital output 3- |
| 3 | STEP+ | Position command pulse input+ | 20 | N/C | N/C | 37 | Y3+ | Digital output 3+ |
| 4 | STEP- | Position command pulse input- | 21 | AOUT+ | Encoder output A+ | 38 | Y4- | Digital output 4- |
| 5 | DIR+ | Position command direction input+ | 22 | AOUT- | Encoder output A- | 39 | Y4+ | Digital output 4+ |
| 6 | DIR- | Position command direction input- | 23 | ZOUT+ | Encoder output Z+ | 40 | Y6 | Digital output 6 |
| 7 | XCOM | Digital inputs common point | 24 | ZOUT- | Encoder output Z- | 41 | YCOM | Digital output common point |
| 8 | X1 | Digital input 1 | 25 | DGND | Digital output | 42 | AO1 | Analog output 1 |
| 9 | X2 | Digital input 2 | 26 | X3 | Digital input 3 | 43 | AO2 | Analog output 2 |
| 10 | Y1- | Digital output 1- | 27 | X4 | Digital input 4 | 44 | PULSH+ | Position command High speed pulse input+ |
| 11 | Y1+ | Digital output 1+ | 28 | X5 | Digital input 5 | 45 | PULSH- | Position command High speed pulse input- |
| 12 | Y5 | Digital output 5 | 29 | X6 | Digital input 6 | 46 | SIGNH+ | Position command High speed pulse sign input+ |
| 13 | DGND | Digital Ground | 30 | X7 | Digital input 7 | 47 | SIGNH- | Position command High speed pulse sign input- |
| 14 | DGND | Digital Ground | 31 | X8 | Digital input 8 | 48 | BOUT+ | Encoder output B+ |
| 15 | DGND | Digital Ground | 32 | X9 | Digital input 9 | 49 | BOUT- | Encoder output B- |
| 16 | AIN1 | Analog input 1 | 33 | X10 | Digital input 10 | 50 | N/C | N/C |
| 17 | DGND | Digital Ground | 34 | Y2- | Digital output 2- | - | | |

◆ Table 2: -RD type pin definition

| PIN NO. | Symbol | Description | PIN NO. | Symbol | Description | PIN NO. | Symbol | Description |
|---------|--------|-----------------------------------|---------|--------|--|---------|--------|---|
| 1 | OPC1 | Pull-up for open collector inpu-1 | 18 | AIN2 | Analog input 2 | 35 | Y2+ | Digital output 2+ |
| 2 | OPC2 | Pull-up for open collector inpu-2 | 19 | OCZ | Encoder's Z signal open collector output | 36 | Y3- | Digital output 3- |
| 3 | STEP+ | Position command pulse input+ | 20 | N/C | N/C | 37 | Y3+ | Digital output 3+ |
| 4 | STEP- | Position command pulse input- | 21 | AOUT+ | Encoder output A+ | 38 | Y4- | Digital output 4- |
| 5 | DIR+ | Position command direction input+ | 22 | AOUT- | Encoder output A- | 39 | Y4+ | Digital output 4+ |
| 6 | DIR- | Position command direction input- | 23 | ZOUT+ | Encoder output Z+ | 40 | Y6 | Digital output 6 |
| 7 | XCOM | Digital inputs common point | 24 | ZOUT- | Encoder output Z- | 41 | YCOM | Digital output common point |
| 8 | X1 | Digital input 1 | 25 | DGND | Digital output | 42 | N/C | Analog output 1 |
| 9 | X2 | Digital input 2 | 26 | X3 | Digital input 3 | 43 | N/C | Analog output 2 |
| 10 | Y1- | Digital output 1- | 27 | X4 | Digital input 4 | 44 | PULSH+ | Position command High speed pulse input+ |
| 11 | Y1+ | Digital output 1+ | 28 | X5 | Digital input 5 | 45 | PULSH- | Position command High speed pulse input- |
| 12 | Y5 | Digital output 5 | 29 | X6 | Digital input 6 | 46 | SIGNH+ | Position command High speed pulse sign input+ |
| 13 | DGND | Digital Ground | 30 | X7 | Digital input 7 | 47 | SIGNH- | Position command High speed pulse sign input- |
| 14 | DGND | Digital Ground | 31 | X8 | Digital input 8 | 48 | BOUT+ | Encoder output B+ |
| 15 | DGND | Digital Ground | 32 | X9 | Digital input 9 | 49 | BOUT- | Encoder output B- |
| 16 | AIN1 | Analog input 1 | 33 | X10 | Digital input 10 | 50 | N/C | N/C |
| 17 | DGND | Digital Ground | 34 | Y2- | Digital output 2- | - | | |

4.9.4.1 Position Pulse Command

◆ Open-collector Pulse Inputs (or Low-speed pulse signal input)

| CN2-Pin NO. | Signals | Description | Wiring Method |
|-------------|---------|-----------------------|---|
| 1 | OPC1 | Pulse command input | Refer to Chapter 4.9.5 A1 |
| 3 | STEP+ | | |
| 4 | STEP- | | |
| 2 | OPC2 | Pulse direction input | |
| 5 | DIR+ | | |
| 6 | DIR- | | |

When bit4 of P3-03 is set to "0", this low-speed pulse input is valid. The pulse position control mode will use this input as position command reference.

- ◆ Opto-coupler input:
 - 1) Open collector pulse signals, 5V or 24VDC
 - 2) Low-speed different pulse signals, 5VDC
- ◆ Maximum pulse frequency is 500KHz.
- ◆ Support pulse & direction signal, CW/CCW signal and A/B quadrature signal
- ◆ When using 24V open collector pulse signal, you need to use OPC1 and OPC2 input for pull-up.
- ◆ Connecting diagram when a current regulating resistor is not used with 24 V power supply

◆ Line Driver pulse Inputs(or High-speed pulse signal input)

| CN2-Pin NO. | Signals | Description | Wiring Method |
|-------------|---------|-----------------------|---|
| 44 | PULSH+ | Pulse command input | Refer to Chapter 4.9.5 A2 |
| 45 | PULSH- | | |
| 46 | SIGNH+ | Pulse direction input | |
| 47 | SIGNH- | | |

When bit4 of P3-03 is set to "1", this line driver pulse input is valid. The pulse position control mode will use this input as position command reference.

- ◆ For Line driver pulse input, 5VDC
- ◆ Maximum pulse frequency is 4MHz
- ◆ Support pulse & direction signal, CW/CCW signal and A/B quadrature signal

4.9.4.2 Analog Command Inputs

RS-485 type all have two analog signal inputs.

| CN2-Pin NO. | Signals | Description | Wiring Method |
|-------------------|---------|---------------|---|
| 16 | AIN1 | Analog inputs | Refer to Chapter 4.9.7 A3 |
| 18 | AIN2 | | |
| 13,14 15,17,25 | DGND | | |

Analog speed command
-10V ~ +10V

Analog torque command
-10 ~ +10V

Ground of analog signals

NOTE: Pules control type drive does not support analog input or output.

4.9.4.3 Analog Outputs

-RF type all have two analog signal outputs.

| CN2-Pin NO. | Signals | Description | Wiring Method |
|-------------------|---------|--------------------------|---|
| 42 | AO1 | Analog output | Refer to Chapter 4.9.7 A4 |
| 43 | AO2 | | |
| 13,14 15,17,25 | DGND | Ground for analog output | |

Use the analog output signal to monitor the operating parameters of the motor: actual current, actual speed, etc. The data corresponding to the two outputs can be set by parameters

NOTE: -RD does not support analog input

4.9.4.4 Encoder Divided Outputs

编码器分频输出功能是将电机编码器的反馈信号以A,B,Z的方式差分输出，通过参数可设定每转脉冲数及脉冲输出分频比。

| CN2-Pin NO. | Signals | Description | Wiring Method |
|-------------------|---------|--|--|
| 21 | AOUT+ | The serial position datas of the encoder are converted to line driver signals phase A,B,and phase Z. The number of pulses per revolution and the frequency division ratio of pulse output can be set by parameters. | Refer to Chapter 4.9.8 |
| 22 | AOUT- | | |
| 48 | BOUT+ | | |
| 49 | BOUT- | | |
| 23 | ZOUT+ | | |
| 24 | ZOUT- | | |
| 19 | OCZ | Output the Z-signal of the encoder in open collector | |
| 13,14 15,17,25 | DGND | Ground for OCZ output. | |

4.9.4.5 Digital Inputs

The M56S series AC servo drive's 50Pin high-density connector type has 10 digital inputs. Each digital input can be configured to a specific function by parameters.

- ◆ **Specific function signal:** such as alarm reset, limit sensor input, enable input, etc.
- ◆ **General purpose input**

| CN2-Pin NO. | Symbol | Function | Parameter No. | Command | Default Settings | | |
|-------------|--------|-----------------------------|---------------|---------|------------------|----------------|---------------|
| | | | | | Signal | Input Logic *1 | Default value |
| 8 | X1 | Digital Input 1 | P5-00 | MU1 | CCW-LMT | Closed | 7 |
| 9 | X2 | Digital Input 2 | P5-01 | MU2 | CW-LMT | Closed | 5 |
| 26 | X3 | Digital Input 3 | P5-02 | MU3 | A-CLR | Closed | 3 |
| 27 | X4 | Digital Input 4 | P5-03 | MU4 | S-ON | Closed | 1 |
| 28 | X5 | Digital Input 5 | P5-04 | MU5 | C-CLR | Closed | 17 |
| 29 | X6 | Digital Input 6 | P5-05 | MU6 | CM-SEL | Closed | 9 |
| 30 | X7 | Digital Input 7 | P5-06 | MU7 | GPIN | Closed | 0 |
| 31 | X8 | Digital Input 8 | P5-07 | MU8 | GPIN | Closed | 0 |
| 32 | X9 | Digital Input 9 | P5-08 | MU9 | GPIN | Closed | 0 |
| 33 | X10 | Digital Input 10 | P5-09 | MUA | GPIN | Closed | 0 |
| 7 | XCOM | COM port for digital inputs | - | - | - | - | - |

Note:

1. The input logic state of the pin is as follows:

CLOSED: If current is flowing into or out of an input, the logic state of that input is low or closed.

OPEN: If no current is flowing, or the input is not connected, the logic state is high or open.

2. Refer to [Chapter: 7.1.1 Input Signals Setting](#)

3. Refer to the input signal wiring method: [Chapter 4.9.6 CN2 - Input and Output Signals Wiring Instructions](#)

4.9.4.6 Digital Output

The M56S series AC servo drive's 50Pin high-density connector type has 6 digital outputs. Each digital output can be configured to a specific function by parameters.

| CN2-Pin NO. | Symbol | Function | Parameter No. | Command | Default Settings | | |
|-------------|--------|------------------------------|---------------|---------|------------------|-----------------|---------------|
| | | | | | Signal | Output Logic *1 | Default value |
| 11 | Y1+ | Digital output 1+ | P5-12 | MO1 | SON-ST | Closed | 7 |
| 10 | Y1- | Digital output 1- | | | | | |
| 35 | Y2+ | Digital output 2+ | P5-13 | MO2 | S-RDY | Closed | 23 |
| 34 | Y2- | Digital output 2- | | | | | |
| 37 | Y3+ | Digital output 3+ | P5-14 | MO3 | FLT | Closed | 1 |
| 36 | Y3- | Digital output 3- | | | | | |
| 39 | Y4+ | Digital output 4+ | P5-15 | MO4 | IN-POS | Closed | 9 |
| 38 | Y4- | Digital output 4- | | | | | |
| 12 | Y5 | Digital output 5 | P5-16 | MO5 | HOMED | Closed | 25 |
| 40 | Y6 | Digital output 6 | P5-17 | MO6 | T-LMT | Closed | 15 |
| 41 | YCOM | COM port for digital outputs | - | - | - | - | - |

Note:

1. The output logic state of the pin is as follows:

CLOSED: If current is flowing into or out of an output, the logic state of that output is low or closed.

OPEN: If no current is flowing, or the output is not connected, the logic state is high or open.

2. Refer to [Chapter: 7.1.2 Output Signals Setting](#)

3. Refer to the input signal wiring method: [Chapter 4.9.6 CN2 - Input and Output Signals Wiring Instructions](#)

4.9.5 Position Pulse Signal Wiring Instructions

M56S series AC servo driver 50Pin high-density connector type has two pulse input sources:

Low Speed Pulse Signal Input : STEP/DIR

High Speed Pulse Signal Input : PULSH/SIGNH

◆ Low Speed Pulse Signal Input (Open-collector Pulse Inputs)

| CN2-Pin NO. | Signals | | Description | Maximum pulse frequency | Minimum pulse width | Wiring Method |
|-------------|---------|-----------------------|---|-------------------------|---------------------|---------------|
| 1 | OPC1 | Pulse command input | <ul style="list-style-type: none"> ◆ When bit4 of P3-03 is set to "0", this low-speed pulse input is valid. The pulse position control mode will use this input as position command reference. ◆ Opto-coupler input: <ol style="list-style-type: none"> 1) Open collector pulse signals, 5V or 24VDC 2) Low-speed different pulse signals, 5VDC ◆ Maximum pulse frequency is 500KHz. ◆ Support pulse & direction signal, CW/CCW signal and A/B quadrature signal ◆ When using 24V open collector pulse signal, you need to use OPC1 and OPC2 input for pull-up. ◆ Connecting diagram when a current regulating resistor is not used with 24 V power supply | 500KHz | 1μs | A1 |
| 3 | STEP+ | | | | | |
| 4 | STEP- | | | | | |
| 2 | OPC2 | Pulse direction input | | | | |
| 5 | DIR+ | | | | | |
| 6 | DIR- | | | | | |

◆ High Speed Pulse Signal Input (Line Driver pulse Inputs)

| CN2-Pin NO. | Signals | | Description | Maximum pulse frequency | Minimum pulse width | Wiring Method |
|-------------|---------|-----------------------|--|-------------------------|---------------------|---------------|
| 44 | PULSH+ | Pulse command input | <ul style="list-style-type: none"> ◆ When bit4 of P3-03 is set to "1", this line driver pulse input is valid. The pulse position control mode will use this input as position command reference. ◆ For Line driver pulse input, 5VDC ◆ Maximum pulse frequency is 4MHz ◆ Support pulse & direction signal, CW/CCW signal and A/B quadrature signal | 4MHz | 0.125μs | A2 |
| 45 | PULSH- | | | | | |
| 46 | SIGNH+ | Pulse direction input | | | | |
| 47 | SIGNH- | | | | | |

Note: STEP/DIR and PULSH/SIGNH cannot be used at the same time. Please use Bit4 of parameter P3-03 to select the position pulse signal input source.

0: Open-collector Pulse Inputs

1: Line Driver pulse Inputs

A1----Low-speed pulse signal input STEP/DIR wiring method

| | |
|--|--|
| <p>A. The source for the pulse input is open-collector NPN type equipment, which uses external 24V power supply.</p> | <p>B. The source for the pulse input is open-collector PNP type equipment, which uses external 24V power supply.</p> |
| <p>C. The source for the pulse input is open-collector NPN type equipment, which uses external 5V power supply.</p> | <p>D. The source for the pulse input is open-collector PNP type equipment, which uses external 5V power supply.</p> |
| <p>E. The source for the pulse input is Line driver. It can only be used with 5V power system.</p> | |


- ◆ For 24VDC power signal
Pulse input signal is valid: higher than 16V
Pulse input signal is invalid: less than 8V

- ◆ For 5VDC power signal
Pulse input signal is valid: higher than 3V
Pulse input signal is invalid: less than 2V

The voltage of pulse signal input should be avoided to appear in the fuzzy area of above voltage, so as to avoid uncertain pulse input.

A2---High-speed pulse signal input STEP/DIR wiring method

PULSH/SIGNH inputs can only be used with 5V line drivers signals. Do not use with 24V DC.



◆ Pulse Input Description

| Pulse&Direction | CW/CCW Pulse Signal |
|--|--|
| <p>--When both Pulse and Direction input signal is CLOSED, the motor will rotate in one direction</p> <p>--When Pulse input signal is CLOSED, and Direction input signal is OPEN, the motor will rotate in the opposite direction.</p> <p>*Direction signal can be configured via bit3 of P3-03.</p> <p>The following shows motor rotates in CW when Direction input is CLOSED.</p> | <p>--When STEP or PULSH input signal is CLOSED, and DIR or SIGNH input signal is OPEN, the motor will rotate in one direction.</p> <p>--When DIR or SIGNH input signal is CLOSED, and STEP or PULSH input signal is OPEN, the motor will rotate in one direction.</p> <p>*Direction can be configured via bit3 of P3-03.</p> |
| | |
| A&B Quadrature signal | |
| <p>In A/B Quadrature mode, motor rotary direction is based on the the leading signal between A and B.</p> <p>The following shows motor rotates in CW when phase-A is 90 degrees ahead of phase-B.</p> <p>*Direction signal can be configured via bit3 of P3-03.</p> | |
| | |

4.9.6 CN2-Input and Output Signals Wiring Instructions

4.9.6.1 Digital Inputs X1 ~ X10

The M56S series servo drives(-F&-R type) include 10 single-ended, optically isolated inputs that can be used with sourcing or sinking signals, 24 volts. This allows connection to PLCs, sensors, relays and mechanical switches. Because the input circuits are isolated, they require a source of power. If you are connecting to a PLC, you need be able to get power from the PLC power supply. If you are using relays or mechanical switches, you need a 24 V power supply. Rated current is 20mA.

What is COM?


"Common" is an electronics term for an electrical connection to a common voltage. Sometimes "common" means the same thing as "ground". If you are using sourcing (PNP) input signals, then you will want to connect COM to ground (power supply -). If you are using sinking (NPN) signals, then COM must connect to power supply +.

Note:

CLOSED: If current is flowing into or out of an input, the logic state of that input is low or closed.

OPEN: If no current is flowing, or the input is not connected, the logic state is high or open.

The internal circuit block diagram of X1 ~ X10 is as shown below.




◆ For 24VDC power signal

Pulse input signal is valid: higher than 16V

Pulse input signal is invalid: less than 8V

The voltage of pulse signal input should be avoided to appear in the fuzzy area of above voltage, so as to avoid uncertain pulse input.

The diagrams on the following pages show how to connect X1 ~X10 to various commonly used devices.




4.9.6.2 Digital Output Y1 ~ Y4


The M56S series servo drives include 6 differential, optically isolated outputs that can be used with sourcing or sinking signals.

Rated Specification :30VDC, 100mA.

The internal circuit block diagram of Y1 ~ Y4 is as shown below.



The following diagrams show how to connect Y1 ~Y4 to various commonly used devices.




4.9.6.3 Digital Output Y5 ~ Y6


The M56S series servo drives include two single-ended, optically isolated outputs that can be used with sourcing signals.

Rated Specification :30VDC, 100mA.

The internal circuit block diagram of Y5 and Y6 is as shown below.



The following diagrams show how to connect Y5 and Y6 to various commonly used devices.




4.9.7 Analog Signal Wiring Instructions

4.9.7.1 Analog Command Inputs

The RS-485 model of M56S series servo drive includes two single-ended analog inputs, which can be used as speed command reference or torque command reference.

| CN2-PIN NO. | Signals | Description |
|-------------------|---------|--------------|
| 16 | AIN1 | Analog input |
| 18 | AIN2 | |
| 13,14 15,17,25 | DGND | |

A3---Analog input connection diagram



4.9.7.2 Analog Outputs

The RS-485 model of M56S series servo drive includes two single-ended analog outputs. Using the analog output signal to monitor the operating states of the motor: actual current, actual speed, etc. The data corresponding to the two outputs can be set by parameters.

Output Specifications:


Voltage: -10 ~ +10V

Maximum output capacity: 8mA

The output impedance is 1 kOhm. Pay an attention to the input impedance of the measuring instrument or the external circuit to be connected.

| CN2-PIN NO. | Signals | Description |
|-------------------|---------|---|
| 42 | AO1 | Using the analog output signal to monitor the operating states of the motor: actual current, actual speed, etc. |
| 43 | AO2 | |
| 13,14 15,17,25 | DGND | Ground for analog output |

A4---Analog output connection diagram




4.9.8 Encoder Divided Output

The M56S series AC servo driver(-X &-N type) can output the encoder signal A-phase, B-phase, and Z-phase through the Line Driver differential mode, and the output specification is 5V.

Line Receiver must be used to receive the signal, and the transmission line should use twisted-pair shielded wires.

| CN2-PIN NO. | Signals | Description |
|----------------|---------|---|
| 21 | AOUT+ | Encoder Signal Pulse Output The serial position datas of the encoder are converted to line driver signals phase A,B,and phase Z. The number of pulses per revolution and the frequency division ratio of pulse output can be set by parameters. |
| 22 | AOUT- | |
| 48 | BOUT+ | |
| 49 | BOUT- | |
| 23 | ZOUT+ | |
| 24 | ZOUT- | |
| 19 | OCZ | Z Signal Output 将编码器的Z信号以集电极开路形式输出 |
| 13,14,15,17,25 | DGND | OCZ输出的地 |


4.9.8.1 A/B/Z Example of differential signal connection



NOTE: The digital ground between controller and drive should be connected together.


4.9.8.2 Phase-Z Open-collector Output

Output phase-Z signal of encoder feedback in open-collector. Receive this signal with high-speed photocoupler at the controller side, since the pulse width of this signal is narrow.




4.10 CN4-Second Encoder Input--Full-closed Loop Control

The CN4 connector is used to connect externally installed encoders or scales for full-closed loop control of the servo drive.



| CN2-PIN NO. | Signals | | Description |
|-------------|---------|----------------------|---|
| 1 | 5V | 5V Power Supply | Power supply for the second feedback signal |
| 2 | GND | 5V Power Supply GND | |
| 8 | A+ | Encoder Signal Input | Pulse type: differential Maximum frequency: 1Mpps Minimum pulse width: 0.5 μs |
| 7 | A- | | |
| 6 | B+ | | |
| 5 | B- | | |
| 4 | Z+ | | |
| 3 | Z- | | |

■ Signal Connection Diagram



Precautions:

- Please use a twisted-pair shielded cable for the external second encoder signal wire, with a wire diameter of 0.18mm2AWG22 or more
- The total length of the cable is recommended to be within 10 meters. When the wiring is long, to prevent 5V voltage drop and signal attenuation, please increase the wire diameter
- To prevent interference, the digital ground of the external encoder must be connected to the one of the driver, and the cable shielding layer while the driver must be well grounded.
- The maximum 5V output current of the driver is 5V ± 5% 200mA Max. If the current consumption of the external encoder exceeds this specification, please use an external power supply.
- When using an external power supply, do not connect the external 5V to the 5V power output of CN4. However, the 0V of the external power supply must be connected to the 0V pin of CN4 of the driver to form an equipotential.

4.11 CN5-Safety Torque Off (STO)

The M56S series AC servo drive has a safe torque off function, namely STO, and the signal connection input port is the CN5 of the drive.

Safe Torque Off (Safe Torque Off) is a hardware-level safety protection function. When the STO function is working, the hardware circuit of the drive will be triggered to forcibly turn off the power transistor inside the drive, thereby preventing the motor from working. The drive will be disabled and is a hardware-level safety protection device that can protect the safety of people and equipment in emergency situations.


When the STO function is triggered, the Servo-ready signal of the drive will be cleared. The motor is disabled, and became an alarm states. The LED on the drive's panel will display a alarm code `r20to`.

4.11.1 Precautions


- 1) If you don't need to use the STO function, make sure that the STO short-circuit terminal is correctly inserted into the CN5 port.
- 2) When using the STO function, perform an equipment risk assessment to ensure that the system conforms to the safety requirements
- 3) Even when the STO function is enabled, the servo motor may move due to external force (e.g. gravitational force on the vertical axis). Make sure a holding brake is used in applications where this is possible.
- 4) When the STO function engages and removes the torque, the motor will be "free running", requiring more distance until the motion stops. Make sure this will not be a safety issue.
- 5) When the STO function is triggered, it will turn off the current to the motor, but it does not turn off the power to the servo drive. Make sure to disconnect the power to the drive before performing any maintenance on it.
- 6) After the STO function is triggered, the drive will have a fault alarm states(Alarm code:`r20to`), and the motor will be disabled.
- 7) After the STO signal return to normal, the drive will automatically clear the STO fault alarm, but the motor will remain disabled . To restore the system to normal operation, re-enable is needed.

4.11.2 STO Input and Output Signals

■ Internal Circuit Diagram



■ Input/Output Pin No.



The model of housing and conductor is as follows:

| Name | P/N | Vendor |
|-----------|------------|--------|
| Housing | 43025-1000 | MOLEX |
| Conductor | 43030-0005 | MOLEX |


■ STO Signal Definition

| Signal | Symbol | Pin | Description | Control Mode |
|------------------|--------|------|--|----------------------------------|
| Safety Input SF1 | SF1+ | 1 | When SF1 has no input signal, e.g. the port is disconnected, SF1 will be considered OFF. The upper half of the internal power transistor will be shut off. | Compatible with all control mode |
| | SF1- | 5 | | |
| Safety Input SF2 | SF2+ | 3 | When SF2 has no input signal, e.g. the port is disconnected, SF2 will be considered OFF. The upper half of the internal power transistor will be shut off. | |
| | SF2- | 2 | | |
| Safety Output | EDM+ | 6 | Output monitor signal used to check the safety function. | |
| | EDM- | 4 | | |
| Ground | DGND | 7,8 | +12VDC power ground, 750W and below type +24VDC power ground, 1000W and above type | |
| Power supply | VCC | 9,10 | +12VDC power ground, 750W and below type +24VDC power ground, 1000W and above type | |


Note: When any of the safety inputs SF1 and SF2 are OFF, the STO function will start to work.

■ STO Connection Diagrams

● Connection to safety switch



● Safety light curtain connection




4.12 CN6,CN7--RS-485 Communication Port

RS-485 drives(-R type) use port CN6 and CN7 for standard RJ45 (8p8C) design. This can be used to build RS-485 or RS-422 daisy chain networks. Customers can use Modbus/RTU protocol to control the drive.

4.12.1 CN6 and CN7 Pin Definitions

The diagram of dual port RJ45 connectors of servo drive is as follows.



RJ45 (8p8c) Pin definitions:

| PIN | Definition |
|------|------------|
| 1 | RX+ |
| 2 | RX- |
| 3 | TX+ |
| 4, 5 | NC. |
| 6 | TX- |
| 7, 8 | GND |


4.12.2 RS-485 and RS-422 Connection Method

RS-422/485 communication allows connection of more than one drive to a single host PC, PLC, HMI or other computer. It also allows the use of longer communication cables. The use of Category 5 cable is recommended as it is widely used for computer networks, inexpensive, easily obtained and certified for quality and data integrity.

The RS-485/RS-422 communication of M56S series AC servo supports half-duplex mode or full-duplex mode. The connection mode for host control can be point-to-point (one host to one M56S drive), or a multi-axis network (each can support up to 32 M56S drives).


4.12.2.1 RS-422 Full-Duplex Mode

RS-422 full-duplex mode utilize separate transmit and receive wires. One pair of wires must connect the host's transmit signals to each drive's RX+ and RX- terminals. The other pair connects the drive's TX+ and TX- terminals to the host's receive signals. A logic ground terminal is provided on each drive and can be used to keep all drives at the same ground potential. This terminal connects internally to the DC power supply return (V-), so if all the drives on the RS-422/485 network are powered from the same supply it is not necessary to connect the logic grounds. One drive's GND terminal should still be connected to the host computer ground.



4.12.2.2 RS-485 Half-duplex Mode


The same cable is used for data transmission and reception in the RS-485 half-duplex mode. In this mode, the host must disable its transmitter before it can receive data. This must be done quickly before a drive begins to answer a query. The M56S drive includes a transmit delay parameter that can be adjusted to compensate for a host that is slow to disable its transmitter. This adjustment can be made over the network using the TD command, or it can be set using the Luna software. It is not necessary to set the transmit delay in a four wire system.



注意: 由于使用 RJ45水晶头, 我们强烈建议使用标准CAT5e类线。

5 Display and Touch Panel

5.1 Description of Touch Panel




| KEY | Function | Description |
|---|-------------|---|
| | LED Display | The LED displays (5 digits, 7 segments) show the drive's operating condition and warning codes, parameters and settings values. |
|  | MODE | Press and hold on mode button to switch LED display mode a). Monitoring selection mode b). Function selection mode c). Parameter setting mode When editing the parameters, press on MODE button can move the cursor to the left and then change parameters by using arrow keys. |
|  | UP/DOWN | UP and DOWN Key. Pressing the UP and DOWN key can scroll through and change monitor codes, parameter groups and various parameter settings. |
|  | SET | Press to entering mode Press and hold to save parameters/settings |

5.2 Switch the Display Mode

- 1) Pressing MODE key and SET key can change display modes such as states monitoring, function control, parameters setting and etc.
- 2) If no warnings or faults has occur, the drive will not go into warning and fault display mode.
- 3) If any alarms are detected, the LED display on the drive will switch into alarm or fault display mode immediately. Press M key and S key on the drive will switch back to previous display mode.
- 4) In monitoring selection mode, function selection mode and parameter setting mode, when editing the parameters, short press MODE key to switch the operation digits of addition and subtraction, and the selected digit will flash.
- 5) In the states monitoring mode, press and hold SET key will lock the control panel. To unlock the panel press and hold SET key again.

Refer to the figure below for switching each mode.



Note:

- (1) When power is applied, drive's display will show customer defined monitoring mode. In factory default mode, it will display motor's rotary velocity.
- (2) In parameter setting mode, short press SET key will quit from parameter setting mode, and return back to parameter selection mode, and changes will not be saved.
- (3) In parameter setting mode, press and hold SET key will confirm and apply current parameter setting. This will effect immediately. However, this change will not save to drive's Flash. If parameter is required for permanent use, please go to parameter setting mode, select the parameter which you want to save, and then press and hold SET key to save the parameter change.
- (4) Do not save the parameters when the motor is running.

5.3 LED Display Description

5.3.1 Decimal Point Description

| LED Display | Description |
|--|---|
| <p>High-order flag More than 4-digits</p> <p>Negative Flag</p> <p>Motor enable status flag</p> | <ul style="list-style-type: none"> ◆ Motor enable states flag: The decimal point in the lower right corner of the LED panel is the identification bit of whether the driver is enabled <ul style="list-style-type: none"> Solid: Drive and motor is enabled. No display: Drive and motor is disabled. ◆ Negative flag: This indicates whether the displayed number is positive or negative. <ul style="list-style-type: none"> Solid: Indicates that the displayed data is negative. No display: Indicates that the displayed data is positive. ◆ High-order flag: When the displayed data is greater than 4 digits, they will be displayed in pages, and the identification flag will mark the digit of the data at this time. For details, please refer to Chapter 5.3.2 Display of More Than 4 Digits. |

5.3.2 Data Display

1) 4 digits and less positive number display

| LED Display | Description |
|--|---|
| <p>High-order flag More than 4-digits Solid</p> <p>Negative Flag</p> | <ul style="list-style-type: none"> ◆ The first bit from the left is the data high-order flag. <ul style="list-style-type: none"> Solid: It means that the displayed data is the lower 4 bits of data, and there are no higher bits of data. Flashing: It means that the displayed data is the lower 4 bits of data, and there are more than 4 digits. ◆ When the decimal point of the negative flag is off, it means that the displayed data is a positive number. <p>As shown in the figure, the number displayed is: 2345</p> |

2) 4 digits and less negative number display

| LED Display | Description |
|--|---|
| <p>High-order flag More than 4-digits Solid</p> <p>Negative Flag</p> | <ul style="list-style-type: none"> ◆ The data high-order flag is solid, that means the displayed data is the lower 4 bits of data, and there are no higher bits of data. ◆ The decimal point of the negative flag is solid, that means that the displayed data is a negative number. <p>As shown in the figure, the number displayed is: -2345</p> |

3) Display of More Than 4 Digits

Since the M56S series AC servo LED display panel has only 5 digits, when displaying data with more than 5 digits, the following method is used.

Example: If want to show -1234567890

| | LED Display | Description |
|------------------------------------|--|--|
| Display the lower 4 digits "7890" | <p>High-order flag Flashing</p> <p>Negative Flag</p> | <ul style="list-style-type: none"> ◆ The data high-order flag is flashing, that means the displayed data is the lowest 4 bits of data, and there are more data digits. ◆ The decimal point of the negative flag is solid, that means that the displayed data is a negative number. |
| Display the middle 4 digits "3456" | <p>High-order flag Flashing</p> <p>Negative Flag</p> | <ul style="list-style-type: none"> ◆ The middle of data high-order flag is flashing, that means the displayed data is the middle 4 bits of data, and there are more data digits. ◆ The decimal point of the negative flag is solid, that means that the displayed data is a negative number. |
| Display the highest digits "12" | <p>High-order flag Flashing</p> <p>Negative Flag</p> | <ul style="list-style-type: none"> ◆ The middle of data high-order flag is flashing, that means the displayed data is the middle 4 bits of data, and there are more data digits. ◆ The decimal point of the negative flag is solid, that means that the displayed data is a negative number. |

Note: When the high-order is flashing, it means there are more data digits. Short press the "UP" and "DOWN" keys to switch the number of pages displayed.

5.3.3 Other Display

| LED Display | Description |
|---|--|
|  | Means "SET". Press and hold SET key will confirm and apply current parameter setting. This will effect immediately. However, this change will not save to drive's Flash.After re-power on, the parameters will be restored to the last saved settings. |
|  | Means"SAVED". Select a parameter which you want to save(P3-03 for example), and then press and hold SET key to save the parameter change.This change will save the parameter to the flash of servo drive. |
|  | When motor is rotating, parameters can not be saved. It will show "busy" when you attempt to save a parameter. Stop the motor before save a parameter. |

5.3.4 Point to Point Move Function Display

| LED Display | Description |
|---|---|
|  | P--CW shows that the motor is rotating at CW direction in point-to-point mode. |
|  | P-CCW shows that the motor is rotating at CCW direction in point-to-point mode. |

5.3.5 JOG Mode Display

| LED Display | Description |
|---|--|
|  | J--CW shows that the motor is rotating at CW direction in JOG mode. |
|  | J-CCW shows that the motor is rotating at CCW direction in JOG mode. |

5.3.6 Pamameter Lock and Unlock


| LED Display | Description |
|---|--|
|  | Indicates that the keys are locked. In the states display mode, long press means "SET". 1 second, you can lock the keys. |
|  | When the keys are locked, long press means "SET" for 1 second, and the keys will be unlocked. |

5.4 States Monitor Motor

How to monitor the state of drive.

1. Press and hold M key to switch the display mode to States Monitor Selection Mode.
2. Short press the "UP" and "DOWN" keys to switch a parameter.
3. Press and hold S key 1 sec. to confirm selection.

The operation is as shown in the figure below



| n-States | Display Symbol | Description | Unit | Display example |
|----------|----------------|--------------------------|----------|--------------------------------|
| n-00 | n00 iu | Motor Actual Speed | RPM | ◆ Display "3000" rpm |
| n-01 | n01 i. | Position Error | Pulse | ◆ Display -1234567890 |
| n-02 | n02 i. | Pulses Input Counter | counts | |
| n-03 | n03 i. | Encoder Feedback Counter | counts | |
| n-04 | n04 i. | Position Command Counter | counts | |
| n-05 | n05 i. | Drive Temperature | x 0.1 °C | ◆ Display "62.5" degree C |
| n-06 | n06 i. | DC-Bus Voltage | x 0.1V | ◆ Display "315.7" VDC |
| n-07 | n07 i. | Communications Address | | ◆ Display "7" Node-ID |
| n-08 | n08 i. | Alarm History 1 | | ◆ Display "r07" Alarm code |
| n-09 | n09 i. | Alarm History 2 | | ◆ Display "r07" Alarm code |

| n-States | Display Symbol | Description | Unit | Display example |
|----------|----------------|------------------------|----------|--|
| n-10 | | Alarm History 3 | | ◆ Display "r07" Alarm code |
| n-11 | | Alarm History 4 | | ◆ Display "r07" Alarm code |
| n-12 | | Alarm History 5 | | ◆ Display "r07" Alarm code |
| n-13 | | Alarm History 6 | | ◆ Display "r07" Alarm code |
| n-14 | | Alarm History 7 | | ◆ Display "r07" Alarm code |
| n-15 | | Alarm History 8 | | ◆ Display "r07" Alarm code |
| n-16 | | Analog Input 1 | x 0.001V | ◆ Display "8.211" V |
| n-17 | | Analog Input 2 | x 0.001V | ◆ Display "8.707" V |
| n-18 | | Digital Inputs States | | ◆ Each 7-seg. digital LED indicates the input state of a digital input: 1: The input state is CLOSED. 0: The input state is OPEN. |
| n-19 | | Digital Outputs States | | ◆ Each 7-seg. digital LED indicates the output state of a digital input: 1: The output state is CLOSED. 0: The output state is OPEN. |
| n-20 | | Torque Output percent | 0.1% | ◆ Torque Output is 72.5% |

NOTE:

CLOSED: If current is flowing into or out of an input or output, the logic state of that input is low or closed.


OPEN: If no current is flowing, or the input or output is not connected, the logic state is high or open.

5.5 Function Mode

In Function Mode(display F+ parameter number), you can select a function that needs to be execute.

1. Press and hold M key to switch the display mode to Function Mode.
2. Short press the "UP" and "DOWN" keys to select a function.
3. Press and hold S key 1 sec. to confirm or execute the selection.

The operation is as shown in the figure below




5.5.1 Functions

Executable functions are as follows

| F-Functions | Display Symbol | Description |
|-------------|----------------|--|
| F00 | F00FL | (F00FL) ---- Point to point move 1) Target speed: 1 rps 2) Target distance: 1 turn |
| F01 | F01CJ | (F01CJ) ---- Run the motor with 1rps in JOG mode. |
| F02 | F02AR | (F02AR) ---- Alarm reset. |
| F03 | F03SA | (F03SA) ---- Parameter save. |
| F04 | F04MD | (F04MD) ---- Disable the drive. |
| F05 | F05ME | (F05ME) ---- Enable the drive. |
| F06 | F06AZ | (F06AZ) ---- Automatically set the analog input offset |
| F07 | F07SK | (F07SK) ---- Stop internal profile move / Stop Q program. |
| F08 | F08ERF | (F08ERF) ---- Restore the parameters of the drive to the default settings. |
| F09 | F09EM | (F09EM) ---- Absolute encoder initialization. |
| F10 | F 10ARt | (F10AT) ---- Start Auto-tuning. |

5.5.2 Operation Flow Chart in Function Mode




5.6.2 Parameter Edit and Save Example

A. Parameter Edit:


- 1) Short press M key to move the digit which needs to be change to high-order
- 2) Press and hold M key for 1 second to move the digit which needs to be change to low-order.
- 3) Press UP key to increase
- 4) Press DOWN key to decrease
- 5) Press and hold M key for 1 second to save the changes.

Example: Change the value of parameter P0-05 to 15531.




B Parameter Save

When parameter change has been confirmed and applied. This change will effect immediately. However, it will not save to drive' s Flash. It means the value will be restored after next power cycle. If parameter is required for permanent use, follow the instruction bellow.



5.7 Key Lock


To prevent misoperation by people who are not familiar with the servo drive, a key lock function is provided. When the keys are locked, parameters can not be changed by operation panel.



5.8 Alarm Code Display

If any alarms are detected, the LED display on the drive will switch into alarm or fault display mode immediately.

- ◆ If the first digits of LED from right side flash quickly, it means there are more alarms. Press UP and DOWN key to check more.
- ◆ Press M key and S key on the drive will switch back to previous display mode.



Alarm codes

| Alarm Code | Description | Alarm Type | Drive status after the alarm occurs |
|------------|--------------------------|------------|-------------------------------------|
| r01ot | Drive over temperature | Fault | Servo off |
| r02ur | Internal voltage error | Fault | Servo off |
| r03uH | Over-voltage | Fault | Servo off |
| r04HC | Over current | Fault | Servo off |
| r05LC | | Fault | Servo off |
| r06rC | | Fault | Servo off |
| r09Eb | Encoder feedback error | Fault | Servo off |
| r10PL | Position following error | Fault | Servo off |
| r11Lu | Low voltage | Fault | Servo off |

| Alarm Code | Description | Alarm Type | Drive status after the alarm occurs |
|------------|--|------------|--|
| r12ou | Over speed | Fault | Servo off |
| r13lt | Limit switch trigger alarm | Warning | Does not change the current state |
| r14LL | Negative limit alarm | Warning | Does not change the current state, the motor cannot rotate negatively. |
| r15JL | Positive limit alarm | Warning | Does not change the current state, the motor cannot rotate positively. |
| r16CL | Current limit | Warning | Does not change the current state |
| r17CE | Communication error | Warning | Does not change the current state |
| r18EF | Parameter save failed | Warning | Does not change the current state |
| r19LP | Phase loss of main circuit | Fault | Servo off |
| r20to | STO is triggered | Warning | Servo off |
| r21rF | Regeneration failed | Fault | Servo off |
| r22uH | Undervoltage warning | Warning | Does not change the current state |
| r239E | No Q program warning | Warning | Does not change the current state |
| r24dd | Motion command received while motor disable | Warning | Does not change the current state |
| r25ur | Internal voltage error | Fault | Servo off |
| r26ur | | Fault | Servo off |
| r27E3 | Emergency Stopped | Warning | Motor decelerates to stop |
| r28FP | Full-closed loop hybrid deviation excess error | Fault | Servo off |
| r29FE | External encoder error | Fault | Servo off |
| r30nE | Memory error | Fault | Servo off |
| r31bt | Absolute encoder battery undervoltage | Warning | Does not change the current state |
| r32AP | Absolute position lost | Warning | Does not change the current state |
| r33oP | Absolute position overflow | Warning | Does not change the current state |
| r34nt | Motor over temperature | Fault | Servo off |
| r35ct | Drive MCU over temperature | Fault | Servo off |
| r36nr | Absolute encoder multi-turn error | Fault | Servo off |
| r373t | Motor stalled | Fault | Servo off |
| r39Hr | Homing parameters configuration error | Warning | Does not change the current state |
| r40H1 | Motor collision alarm | Fault | Servo off |
| r41Er | Encoder Communications error | Fault | Servo off |
| r42io | Wrong configuration of I/O function in Q mode | Warning | Does not change the current state |

6 Trial Operatio

Remove the load from the servo motor, including coupling on the shaft before trail operation.

6.1 Inspection Before Trail Operation

To ensure the safety of servo drive and mechanical, it is strongly recommended to check the followings before the drive power on.

1) Wiring Inspection

Check the power input terminal P1,the motor power output P2, the encoder input C3 are correctly wired, firmed, without short-circuit and well ground.


2) Power Supply Voltage Check

Check the input voltage meets the specification of the drive, both L1/L2/L3 and L1C/L2C.

3) Ensure the motor and drive are installed firmly

4) Operate the motor without load.

6.2 Steps of Trail Operation

| Steps | Details | Description |
|-------|--|---|
| 1 | Install the motor firmly.  | 1) Servo motor can be installed on the machine. 2) Do not connect the load to the servo motor in trail operation. |
| 2 | Check the connection between the motor and the drive. | 1) Motor U, V, W must correspond to the red, yellow, and blue of the lead wires. PE corresponds to yellow-green. Wrong connection will make the motor run abnormally. 2) Confirm the motor encoder is correctly connected to CN3 |
| 3 | Check that the power circuit is connected correctly | Refer to Chapter 4.2 Main Power Supply Input to confirm whether the power input circuit is correct. |
| 4 | Switch on the Power | Do not input 380VAC. |
| 5 | Normally, it will display  If alarms occur,it will display  | 1) Normally, the drive has no alarm display and is disabled 2) If r09 alarm occurs, it indicates that there is a problem with the cable connection of the encoder. Please check whether the wiring is correct after power off. 3) For other alarms, please refer to Chapter 9 Troubleshooting |
| 6 | If a motor brake is used, the brake control circuit should be set up before use. | Refer to Chapter 4.6 Wiring to Motor Holding Brake |
| 7 | JOG mode operation | If there is no abnormality in the above steps, you can start a trial operation in JOG mode |

6.3 JOG Operation


| Steps | LED Display | Description |
|-------|-------------|---|
| 1 | F00FL | Press and Hold M key to Function Mode. |
| 2 | F05NE | Use UP and DOWN key to select F05ME function. This function could enable the drive. |
| 3 | F05NE | Press and hold S key, when the decimal point in the lower right corner of the LED panel is solid, that means the driver is enabled. |
| 4 | F01CJ | Use UP and DOWN key to select F01CJ function. |
| 5 | JOG | Short press S key to JOG mode. |
| 6 | J--C8 | Short press UP key, the motor rotates positive in 1 rps. |
| 7 | or J-C88 | Short press UP key, the motor rotates positive in 1 rps. |
| 8 | JOG | Short press S key to stop JOG move. |
| 9 | F01CJ | Short press M key back to Function mode. |
| 10 | F04MD | Select F04MD and hold S key for 1second, the motor will be disabled. |

6.4 Configuration by Personal Computer

In order to ensure servo drive and motor meet your operation requirements, we strongly recommend customers to use "Luna Software" for following configuration setups:

1. Configure encoder usage mode
2. Define drive's input/output mode
3. Apply auto tuning function on PID parameters for optimized motor performance

Connection method



Luna's detail, please refer to the software manual.

7 Operation Mode and Functions

7.1 Input and Output Signal Settings

The input and output signals have pre-assigned functions, which can also be changed to other functions, including changing the input/output logic state. Functions and logic state can be changed by parameters as follows.

7.1.1 Input Signal Settings

7.1.1.1 Assignable Functions of Input Signal

Assignable functions and input logic state list as follows. Parameters P5-00 to P5-09 define the functions of digital inputs X1 to X10. The function of digital input can be set by writing the corresponding values of the functions in the table below into the parameters.

| Signal Functions | Symbol | Setup value and corresponding input logic state | |
|--------------------------------------|----------|---|-----------------|
| | | Valid when Closed | Valid when Open |
| General Purpose Input | GPIN | 0 | |
| Servo On | S-ON | 1 | 2 |
| Alarm Reset | A-CLR | 3 | 4 |
| CW Limit | CW-LMT | 5 | 6 |
| CCW Limit | CCW-LMT | 7 | 8 |
| Control Mode Select | CM-SEL | 9 | 10 |
| Gain Select | GAIN-SEL | 11 | 12 |
| Emergency Stop | E-STOP | 13 | 14 |
| Start Homing | S-HOM | 15 | 16 |
| Position Error Clear | C-CLR | 17 | 18 |
| Torque Limit | TQ-LMT | 19 | 20 |
| Zero Speed Clamp | ZCLAMP | 21 | 22 |
| Pulse Input Inhibit | INHP | 25 | 26 |
| Internal Speed Select 1 | SPD1 | 27 | 28 |
| Internal Speed Select 2 | SPD2 | 29 | 30 |
| Internal Speed Select 3 | SPD3 | 31 | 32 |
| Torque and Velocity Control | SP-STA | 33 | 34 |
| Torque and Velocity Direction Switch | SPD-DIR | 35 | 36 |
| Speed Limit Select | V-LMT | 37 | 38 |
| Home Switch | HOM-SW | 39 | 40 |
| Start Q Program | START-Q | 45 | 46 |

The output logic state of the pin is as follows:

CLOSED: If current is flowing into or out of an output, the logic state of that output is low or closed.

OPEN: If no current is flowing, or the output is not connected, the logic state is high or open.

7.1.1.2 Input Signal Default Setting (50pin High-Density Connectors)

There are 10 digital inputs in 50pin high-density type drive. Default settings of X1 to X10 are as follows.

| CN2-Pin NO. | Input NO. | Signal Description | Parameter | Command | Default Settings | | |
|-------------|-----------|----------------------------|-----------|---------|------------------|-------------|-------------|
| | | | | | Signal Symbol | Input Logic | Setup Value |
| 8 | X1 | Digital Input 1 | P5-00 | MU1 | CCW-LMT | Closed | 7 |
| 9 | X2 | Digital Input 2 | P5-01 | MU2 | CW-LMT | Closed | 5 |
| 26 | X3 | Digital Input 3 | P5-02 | MU3 | A-CLR | Closed | 3 |
| 27 | X4 | Digital Input 4 | P5-03 | MU4 | S-ON | Closed | 1 |
| 28 | X5 | Digital Input 5 | P5-04 | MU5 | E-STOP | Closed | 13 |
| 29 | X6 | Digital Input 6 | P5-05 | MU6 | CM-SEL | Closed | 9 |
| 30 | X7 | Digital Input 7 | P5-06 | MU7 | GPIN | Closed | 0 |
| 31 | X8 | Digital Input 8 | P5-07 | MU8 | GPIN | Closed | 0 |
| 32 | X9 | Digital Input 9 | P5-08 | MU9 | GPIN | Closed | 0 |
| 33 | X10 | Digital Input 10 | P5-09 | MUA | GPIN | Closed | 0 |
| 7 | XCOM | COM port for digital input | - | - | X input COM port | | |

7.1.1.3 Input Signal Default Setting (26pin quick plug connectors)

There are 4 digital inputs in 26pin quick plug connectors drive type drive only. Default settings of X1 to X4 are as follows.

| CN2-Pin NO. | Input NO. | Signal Description | Parameter | Command | Default Settings | | |
|-------------|-----------|----------------------------|-----------|---------|----------------------------|-------------|-------------|
| | | | | | Signal Symbol | Input Logic | Setup Value |
| 22 | X1 | Digital Input 1 | P5-00 | MU1 | CCW-LMT | Closed | 7 |
| 21 | X2 | Digital Input 2 | P5-01 | MU2 | CW-LMT | Closed | 5 |
| 20 | X3 | Digital Input 3 | P5-02 | MU3 | A-CLR | Closed | 3 |
| 19 | X4 | Digital Input 4 | P5-03 | MU4 | S-ON | Closed | 1 |
| 18 | XCOM | COM port for digital input | | | X1,X2,X3,X4 input COM port | | |

7.1.2 Output Signal Settings

7.1.2.1 Assignable Functions of Output Signal

Assignable functions and output logic state list as follows. Parameters P5-12 ~ P5-17 define the functions of digital outputs Y1 to Y6. The function of digital output can be set by writing the corresponding values of the functions in the table below into above parameters.

| Signal Functions | Symbol | Output logic state and set value when the output signal is valid | |
|-----------------------------|----------|--|------|
| | | Closed | Open |
| General Purpose Output | GPOUT | 0 | |
| Fault Output | FLT | 1 | 2 |
| Warning Output | WARN | 3 | 4 |
| Brake Release Output | BRK | 5 | None |
| Servo-on Status Output | SON-ST | 7 | 8 |
| In-position Output | IN-POS | 9 | 10 |
| Dynamic Position Output | DYM-LMT | 11 | 12 |
| Torque Reach Output | TQ-REACH | 13 | 14 |
| Torque Limit Output | T-LMT | 15 | 16 |
| Velocity Coincidence Output | V-COIN | 17 | 18 |
| Velocity Reach Output | AT-SPD | 19 | 20 |
| Velocity Limit Outout | V-LMT | 21 | 22 |
| Servo Ready Output | S-RDY | 23 | 24 |
| Homing Finished Output | HOMED | 25 | 26 |
| Soft Limit CW | SLCW | 27 | 28 |
| Soft Limit CCW | SLCCW | 29 | 30 |
| Near Target Position Output | P-COIN | 31 | 32 |
| Zero Speed Detected | Z-SPD | 33 | 34 |
| Torque Coincidence Output | T-COIN | 35 | 36 |

The output logic state of the pin is as follows:

CLOSED: If current is flowing into or out of an output, the logic state of that output is low or closed.

OPEN: If no current is flowing, or the output is not connected, the logic state is high or open.

7.1.2.2 Output Signal Default Setting(50pin High-Density Type)

There are 6 digital outputs. Default settings of Y1 to Y6 are as follows.

| CN2-Pin NO. | Input NO. | Signal Description | Parameter | Command | Default Settings | | |
|-------------|-----------|-----------------------------|-----------|---------|-----------------------|-------------|-------------|
| | | | | | Signal Symbol | Input Logic | Setup Value |
| 11 | Y1+ | Digital Output 1+ | P5-12 | MO1 | SON-ST | Closed | 7 |
| 10 | Y1- | Digital Output 1- | | | | | |
| 35 | Y2+ | Digital Output 2+ | P5-13 | MO2 | S-RDY | Closed | 23 |
| 34 | Y2- | Digital Output 2- | | | | | |
| 37 | Y3+ | Digital Output 3+ | P5-14 | MO3 | FLT | Closed | 1 |
| 36 | Y3- | Digital Output 3- | | | | | |
| 39 | Y4+ | Digital Output 4+ | P5-15 | MO4 | IN-POS | Closed | 9 |
| 38 | Y4- | Digital Output 4- | | | | | |
| 12 | Y5 | Digital Output 5 | P5-16 | MO5 | HOMED | Closed | 25 |
| 40 | Y6 | Digital Output 6 | P5-17 | MO6 | T-LMT | Closed | 15 |
| 41 | YCOM | COM port for digital output | - | | Y5,Y6 output COM port | | |

7.1.3 Servo On Setting

Set the digital input for controlling the motor enable or disable. In the default setting, the servo-on input signal is set by follows.

| Signal Symbol | Input NO. | CN2-Pin NO | Parameter | Command | Setup Value | Description | Control Mode | | | |
|---------------|-----------|------------|-----------|---------|-------------|--|--------------|---|---|---|
| S-ON | X4 | 27 | P5-03 | MU4 | 1 | Set the digital input for controlling the motor enable or disable. | P | V | T | F |
| | XCOM | 7 | | | | | | | | |

Signal logic state:

| Setup Value | Signal Logic | Function |
|-------------|--------------|--|
| 1 | Closed | When the input logic state is CLOSED, the drive will be enabled. |
| 2 | Open | When the input logic state is OPEN, the drive will be enabled. |

7.1.4 Alarm Reset

Set digital input to clear abnormal warning or fault of the drive and reset the drive to pre-operation. In the default setting, the alarm clear signal is set by the following table.


| Signal Symbol | Input NO. | CN2-Pin NO | Parameter | Command | Setup Value | Description | Control Mode | | | |
|---------------|-----------|------------|-----------|---------|-------------|---|--------------|---|---|---|
| A-CLR | X3 | 26 | P5-02 | MU3 | 3 | Clear abnormal warning or alarm of the drive and reset the drive to pre-operation | P | V | T | F |
| | XCOM | 7 | | | | | | | | |

Signal Input Logic State

| Set Value | Input Logic | Instructions | |
|-----------|-------------|---|---|
| 3 | Closed | In normal state, the input must remain in OPEN(High level) state. This is an edge trigger signal, that means the alarm will be cleared only when the input changes from OPEN(High level) to CLOSED(Low level). | |
| | | | |
| | | When alarm occurs: 1) A-CLR input logic is OPEN, alarm is not reset. 2) At point A, A-CLR changes from OPEN to CLOSED, the alarm is cleared. | When alarm occurs: 1) A-CLR input logic is CLOSED, alarm is not reset. 2) At point A, A-CLR changes from CLOSED to OPEN, the alarm is NOT reset. 3) At point B, A-CLR changes from Open to Closed, the alarm is cleared. |
| 4 | Open | In normal state, the input must remain in CLOSED(Low level) state. This is an edge trigger signal, that means the alarm will be cleared only when the input changes from CLOSED(Low level) to OPEN(High level). | |
| | | | |
| | | When alarm occurs: 1) A-CLR input logic is CLOSED, alarm is NOT reset. 2) At point A, A-CLR changes from CLOSED to OPEN, the alarm is reset. | When alarm occurs: 1) A-CLR input logic is OPEN, alarm is NOT reset. 2) At point A, A-CLR changes from OPEN to CLOSED, the alarm is NOT cleared. 3) At point B, A-CLR changes from CLOSED to OPEN, the alarm is reset. |

NOTE:

When all digital inputs of the drive are not configured with the "Servo Enable" function, "Alarm Reset" can be used to enable the drive, as shown below:



7.1.5 CW, CCW Limit

In order to prevent the movable part of the machine from exceeding the travel range and avoid accidents, it is necessary to set up limit switches or sensors.

In the default setting, the CW/CCW Limit is set by the followings.

| Signal Symbol | Input NO. | CN2-Pin NO | Parameter | Command | Setup Value | Description | Control Mode | | | |
|---------------|-----------|------------|-----------|---------|-------------|--------------------------------------|--------------|---|---|---|
| CCW-LMT | X1 | 8 | P5-00 | MU1 | 7 | Motor negative direction limit input | P | V | T | F |
| | XCOM | 7 | | | | | | | | |
| CW-LMT | X2 | 9 | P5-01 | MU2 | 5 | Motor positive direction limit input | | | | |
| | XCOM | 7 | | | | | | | | |

Signal Input Logic State:

| Input Type | Signal Symbol | Setup Value | Input Logic | Description |
|------------|---------------|-------------|-------------|---|
| Input | CCW-LMT | 7 | Closed | When the input state is CLOSED, the drive shows a Negative Limit alarm, motor cannot be continoed rotate at negetive direction. |
| | | 8 | Open | When the input state is OPEN, the drive shows a Negative Limit alarm, motor cannot be continoed rotate at negetive direction. |
| | CW-LMT | 5 | Closed | When the input state is CLOSED, the drive shows a Positive Limit alarm, motor cannot be continoed rotate at positive direction. |
| | | 6 | Open | When the input state is OPEN, the drive shows a Positive Limit alarm, motor cannot be continoed rotate at positive direction. |


7.1.6 Gain Select(Gain Switch)

Use the Gain Select function to meet different loads.

- 1) Increase gain can decrease and suppress vibration when doing position control.
- 2) Reduce the gain can decrease the setting time when motor is stopping.
- 3) When the motor is running, increasing the gain can get better command following performance.

For example:

When the motor is running at low speed or stopped, a lower gain can be used to reduce noise, meanwhile when the motor is running at high speed or positioning, switch to a higher gain to improve command following performance.



1) Gain Switch Related Parameters

| Parameter | Command | Description | Class | Default Value | Unit |
|-----------|---------|---|-----------------------------|---------------|----------|
| P0-05 | KP | 1st Position Loop Gain | 1st Gain Group | 52 | 0.1Hz |
| P0-07 | KD | 1st Position Loop Derivative Time Constant | | 0 | ms |
| P0-08 | KE | 1st Position Loop Derivative Filter | | 20000 | 0.1Hz |
| P0-11 | KF | 1st Velocity Command Gain | | 10000 | 0.01% |
| P0-12 | VP | 1st Velocity Loop Gain | | 183 | 0.1Hz |
| P0-13 | VI | 1st Velocity Loop Integral Time Constant | | 189 | ms |
| P0-16 | KC | 1st Torque Command Filter | | 1099 | 0.1Hz |
| P0-17 | UP | 2nd Position Loop Gain | 2nd Gain Group | 52 | 0.1Hz |
| P0-19 | UD | 2nd Position Loop Derivative Time Constant | | 0 | ms |
| P0-20 | UE | 2nd Position Loop Derivative Filter | | 20000 | 0.1Hz |
| P0-21 | UF | 2nd Velocity Command Gain | | 10000 | 0.01% |
| P0-22 | UV | 2nd Velocity Loop Gain | | 183 | 0.1Hz |
| P0-23 | UG | 2nd Velocity Loop Integral Time Constant | | 189 | ms |
| P0-24 | UC | 2nd Torque Command Filter | | 1099 | 0.1Hz |
| P0-25 | XP | Full Closed-loop Position Loop Gain | Full Closed-loop Gain Group | 52 | 0.1Hz |
| P0-27 | XD | Full Closed-loop Position Loop Derivative Time Constant | | 0 | ms |
| P0-28 | XE | Full Closed-loop Position Loop Derivative Filter | | 20000 | 0.1Hz |
| P0-29 | XF | Full Closed-loop Velocity Command Gain | | 10000 | 0.01% |
| P0-30 | XV | Full Closed-loop-Velocity Loop Gain | | 183 | 0.1Hz |
| P0-31 | XG | Full Closed-loop Velocity Loop Integral Time Constant | | 189 | ms |
| P0-32 | XC | Full Closed-loop Torque Command Filter | | 1099 | 0.1Hz |
| P0-33 | SD | Automatic Gain Switching Method | - | 0 | - |
| P0-34 | PN | Gain Switch with Position Error Condition Change | - | 0 | counts |
| P0-35 | VN | Gain Switch with Actual Speed Condition Change | - | 0 | 0.025rps |
| P0-36 | TN | Gain Switch with Actual Torque Condition Change | - | 10 | 0.1% |
| P0-37 | SE1 | Gain Switching Delay Time 1 | - | 10 | ms |
| P0-38 | SE2 | Gain Switching Delay Time 2 | - | 10 | ms |

2) Gain switching method

Gain switching can be done using:

- A. External input signal B. Automatic gain switching.

3) External input signal switching

Servo drive will switch the first gain to the second gain, when the external input signal GAIN-SEL input is valid.

| Signal Type | Signal Symbol | Setup Value | Input Logic | Description |
|-------------|---------------|-------------|-------------|--|
| Input | GAIN-SEL | 11 | Closed | The default is that the 1st Gain Group takes effect. When GAIN-SEL input is CLOSED, 2nd Gain Group takes effect. When GAIN-SEL input is OPEN, 1nd Gain Group takes effect. |
| | | 12 | Open | When GAIN-SEL input is OPEN, 2nd Gain Group takes effect. When GAIN-SEL input is CLOSED, 1nd Gain Group takes effect. |


NOTE:

- ◆ When in full closed-loop control mode, the gain is switched between Full Closed-loop Gain Group(P0-25 ~ P0-32) and 2nd Gain Grpup(P0-17 ~ P0-24).
- ◆ Automactic gain switching is invalid when the gain switching method is set to external input switching, the GAIN-SEL. That means no matter how P0-33 is set, the gain switching determined by the external input signal.

4) Automatic Gain Switch

Parameter P0-33 is used to set the method of automatic gain switching.

| Parameter | Setup Value | Conditions | Swithing Delay Time |
|---|-------------|---|---------------------|
| P0-33 | 0(Default) | Fix at 1st Gain Group | - |
| | 1 | Condition for switching to 2nd Gain Group: Absolute Position following error \geq P0-34 | P0-38 |
| | | Condition for switching to 1st Gain Group: Absolute Position following error $<$ P0-34 | P0-37 |
| | 2 | Condition for switching to 2nd Gain Group: Absolute value of motor speed \geq P0-35 | P0-38 |
| | | Condition for switching to 1st Gain Group: Absolute value of motor speed $<$ P0-35 | P0-37 |
| | 3 | Condition for switching to 2nd Gain Group: Absolute value of motor torque \geq P0-36 | P0-38 |
| | | Condition for switching to 1st Gain Group: Absolute value of motor torque $<$ P0-36 | P0-37 |
| | 4 | Condition for switching to 2nd Gain Group: the positioning is not completed. | P0-38 |
| Return to 1st Gain Group: the positioning is kept in completed. | | P0-37 | |




5) Gain Switch Delay Time

To avoid jitter caused by immediate gain switch, when switch condition is not met, the 1st gain group will gradually switch to the 2nd gain group with the gain switch delay time P0-38.

In the same way, when switch condition is met, the 2st gain group will gradually switch to the 1nd gain group with the gain switch delay time P0-37.

As shown below.



7.1.7 Control Mode Select

In addition to position control, velocity control, and torque control, M56S series can also combine two control modes and switch these two modes. Switch the current control mode to another one by using external input signal which is called CM-SEL.

1) Control Mode Select Related Parameters

The control mode is set by parameters P1-00 and P1-01.

| Parameter | Command | Description | Default Setting |
|-----------|---------|---------------------|-----------------|
| P1-00 | CM | Main Control Mode | 7 |
| P1-01 | CN | Second Control Mode | 21 |

2) Control Modes

The control modes that can be switched are as follows.

| Setting Value | Control Mode | Reference Command | Descriptions |
|---------------|-----------------------------|---|---|
| 1 | Command torque mode | SCL Command | Use SCL command to control the output torque |
| 2 | Analog torque mode | +10~-10V analog input | Use external analog for torque control, the output torque of the motor is linear with the analog input value. |
| 7 | Digital pulse position mode | Pulse&Direction CW/CCW A/B quard. | External digital pulse signal control |
| 11 | Analog velocity mode | +10~-10V analog input | Use external analog for speed control, the output speed of the motor is linear with the analog input value. |
| 15 | Internal velocity mode | Digital Inputs | Use digital input to control the speed of the motor, the target speed of the motor has been preset. |
| 21 | Internal position mode | Communication Command | Use Modbus and Q programming for point-to-point position mode control |

3) Switchable Control Modes

| Control Mode | P1-00 | P1-01 |
|--|-------|-------|
| Pulse position <====> Internal velocity | 7 | 15 |
| Pulse position <====> Analog velocity | 7 | 11 |
| Pulse position <====> Analog torque | 7 | 2 |
| Pulse position <====> Command torque | 7 | 1 |
| Analog velocity <====> Analog torque | 11 | 2 |
| Analog velocity <====> Command torque | 11 | 1 |
| Internal velocity <====> Analog velocity | 15 | 11 |
| Internal velocity <====> Analog torque | 15 | 2 |
| Internal velocity <====> Command torque | 15 | 1 |


4) Control Mode Switch Input Signal Setting

When using the control mode switching function, configuration is required in all control modes, and the input logic must be consistent. If it is not configured correctly, the switching function cannot work.

| Signal Symbol | Input NO. | CN2-Pin NO | Parameter | Command | Setup Value | Signal Logic | Description | Control Mode | | | |
|---------------|-----------|------------|-----------|---------|-------------|--------------|--|--------------|---|---|---|
| CM-SEL | X6 | 29 | P5-05 | MU6 | 9 | Closed | Main control mode--->Second control mode | P | V | T | F |
| | XCOM | 7 | | | | Open | Second control mode--->Main control mode | | | | |

◆ **How to set by using Luna software**

Directly select the desired control mode in control mode page.



7.1.8 Emergency Stop

Emergency stop is a function to forcibly stop the servo motor rotating through an external digital input.

The E-stop signal needs to be assigned to the digital input when using emergency stop function.

When emergency stop input signal is triggered, the motor will stop to zero with a quick stop deceleration(P2-01), then disabled. Meanwhile an "Emergency Stop" fault is reported.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|---|
| Input | E-STOP | 13 | Closed | When E-STOP inputs is CLOSED, the motor is emergency stopped. When E-STOP inputs is OPEN, the motor runs normally. |
| | | 14 | Open | When E-STOP inputs is CLOSED, the motor runs normally. When E-STOP inputs is OPEN, the motor is emergency stopped. |

Under default settings, the servo emergency stop signal is set in the table below.

| Signal Symbol | Input NO. | CN2-Pin NO | Parameter | Command | Setup Value | Signal Logic | Description | Control Mode | | | |
|---------------|-----------|------------|-----------|---------|-------------|--------------|-----------------------|--------------|---|---|---|
| E-STOP | X5 | 28 | P5-04 | MU5 | 13 | Closed | Motor emergency stop. | P | V | T | F |
| | XCOM | 7 | | | | Open | motor runs normally. | | | | |

7.1.9 Fault Output

When the drive fails, the drive will have a fault alarm output and the servo system will change from the enabled state to the disable state.

To use this function, a digital output of the servo drive is configured as ALM function.

Parameters P5-12 ~ P5-17 set the function of the digital output Y1 ~ Y6 of the drive.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | ALM | 1 | Closed | When the output is CLOSED, it means that the drive has a fault. |
| | | | Open | When the output is OPEN, it means the drive is in normal state and no fault is occurred. |
| | | 2 | Open | When the output is OPEN, it means that the drive has a fault. |
| | | | Closed | When the output is CLOSED, it means the drive is in normal state and no fault is occurred. |

| LED Display | Description | Alarm Type | Drive status after the alarm occurs | LED Display | Description | Alarm Type | Drive status after the alarm occurs |
|-------------|----------------------------|------------|-------------------------------------|-------------|---|------------|-------------------------------------|
| r01ot | Drive over temperature | Fault | Servo off | r25ur | Internal voltage error | Fault | Servo off |
| r02ur | Internal voltage error | Fault | Servo off | r26ur | | Fault | Servo off |
| r03uH | Over-voltage | Fault | Servo off | r28FP | Full-closed loop position following error | Fault | Servo off |
| r04HC | Over current | Fault | Servo off | r29FE | External encoder error | Fault | Servo off |
| r05LC | | Fault | Servo off | r30nE | Memory error | Fault | Servo off |
| r06rC | | Fault | Servo off | r34nE | Motor over temperature | Fault | Servo off |
| r09Eb | Encoder feedback error | Fault | Servo off | r35Ct | Drive MCU over temperature | Fault | Servo off |
| r10PL | Position following error | Fault | Servo off | r36nr | Absolute encoder multi-turn error | Fault | Servo off |
| r11Lu | Low voltage | Fault | Servo off | r37Et | Motor stalled | Fault | Servo off |
| r12ou | Over speed | Fault | Servo off | r40H1 | Motor collision alarm | Fault | Servo off |
| r19LP | Phase loss of main circuit | Fault | Servo off | r41Er | Encoer Communications error | Fault | Servo off |
| r21rF | Regeneration failed | Fault | Servo off | | | | |

Under default settings, the servo emergency stop signal is set in the table below.

| Signal Symbol | Output NO. | CN2-Pin NO | Parameter | Command | Setup Value | Signal Logic | Description | Control Mode | | | |
|---------------|------------|------------|-----------|---------|-------------|--------------|--|--------------|---|---|---|
| FLT | Y3+ | 37 | P5-14 | MO3 | 1 | Closed | The drive has a fault. | P | V | T | F |
| | Y3- | 36 | | | | Open | The drive is in normal state and no fault is occurred. | | | | |

7.1.10 Warning Output

When a warning occurs, the drive will have a warning output and the servo system maintains current working status.

To use this function, a digital output of the servo drive is configured as WARN function.

Parameters P5-12 ~ P5-17 set the function of the digital output Y1 ~ Y6 of the drive.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | WARN | 3 | Closed | When the output is CLOSED, it means that the drive has a warning. |
| | | | Open | When the output is OPEN, it means the drive is in normal state and no warning is occurred. |
| | | 4 | Open | When the output is OPEN, it means that the drive has a warning. |
| | | | Closed | When the output is CLOSED, it means the drive is in normal state and no warning is occurred. |

| LED Display | Description | Alarm Type | Drive status after the alarm occurs |
|-------------|---|------------|--|
| | Limit switch trigger alarm | Warning | Does not change the current state |
| | Negative limit alarm | Warning | Does not change the current state, the motor cannot rotate negative. |
| | Positive limit alarm | Warning | Does not change the current state, the motor cannot rotate positive. |
| | Current limit | Warning | Does not change the current state |
| | Communication error | Warning | Does not change the current state |
| | Parameter save failed | Warning | Does not change the current state |
| | STO is triggered | Warning | Servo off |
| | Under-voltage warning | Warning | Does not change the current state |
| | No Q program warning | Warning | Does not change the current state |
| | Motion command received while motor disable | Warning | Does not change the current state |
| | Emergency Stopped | Warning | Motor decelerates to stop |
| | Absolute encoder battery undervoltage | Warning | Does not change the current state |
| | Absolute position lost | Warning | Does not change the current state |
| | Absolute position overflow | Warning | Does not change the current state |
| | Homing parameters configuration error | Warning | Does not change the current state |
| | Wrong configuration of I/O function in Q mode | Warning | Does not change the current state |


7.1.11 Motor Brake Release Control

The motor brake is used to hold the shaft not rotating when the motor is disabled or power off. When motor drives the vertical axis, brake is be used to hold and prevent the work (moving load) from falling by gravity while the power or servo is shut off.

When controlling a servo motor with brake, a digital output of the servo drive must be configured as a BRK function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Function |
|-------------|---------------|-------------|--------------|--|
| Output | BRK | 5 | Closed | When the servo is enabled, the BRK signal is output, and the output state is CLOSED. |
| | | | Open | When the servo is disabled, the BRK signal is NOT output, and the output status is OPEN. |

Since the brake has an action delay when it works(brake or release), the timing sequence should be noticed to avoid damage to brake.



The release delay and brake delay time can be set using Luna software. Or set by parameter P5-24 and parameter P5-25.

Note: For more precautions, refer to [Chapter 4.6 Wiring to the Motor Holding Brake](#).

7.1.12 Servo Ready Output

When the servo drive is power on and there is no alarm, the drive will output a Servo Ready signal, which means that the servo is ready for operation. Servo Ready refers to the situation that all of the following conditions are met.

- 1) The drive has no alarms.
- 2) Main power input is ready.
- 3) STO is not triggered.
- 4) Emergency stop(E-STOP) is not triggered.

When the servo system is not ready, even if the drive receives servo-on input signal, the drive will not be enabled or start to work.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Function |
|-------------|---------------|-------------|--------------|--|
| Output | S-RDY | 23 | Closed | When the servo is ready for operation, the S-RDY signal is output, and the output state is CLOSED. |
| | | | Open | When the servo is NOT ready for operation, the S-RDY signal will NOT output, and the output state is OPEN. |
| | | 24 | Open | When the servo is ready for operation, the S-RDY signal is output, and the output state is OPEN. |
| | | | Closed | When the servo is NOT ready for operation, the S-RDY signal will NOT output, and the output state is CLOSED. |

By default, the Servo Ready signal is set in the table below.

| Signal Symbol | Output NO. | CN2-Pin NO | Parameter | Command | Setup Value | Signal Logic | Description | Control Mode | | | |
|---------------|------------|------------|-----------|---------|-------------|--------------|--------------------------------------|--------------|---|---|---|
| S-RDY | Y2+ | 35 | P5-13 | MO2 | 23 | Closed | The servo is ready for operation | P | V | T | F |
| | Y2- | 34 | | | | Open | The servo is not ready for operation | | | | |

7.1.13 Servo-on Status Output

The Servo-on Status output signal reflects whether the servo motor is in enabled status.

To use this function, a digital output of the servo drive is configured as SON-ST function.


Parameters P5-12 ~ P5-17 set the function of the digital output Y1 ~ Y6 of the drive.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|---|
| Output | SON-ST | 7 | Closed | When the servo is enabled, the SON-ST signal is output, and the output state is CLOSED. |
| | | | Open | When the servo is NOT enabled, the SON-ST signal will NOT output, and the output state is OPEN. |
| | | 8 | Open | When the servo is enabled, and the output state is OPEN. |
| | | | Closed | When the servo is NOT enabled, and the output state is CLOSED. |

Under default settings, the servo emergency stop signal is set in the table below.

| Signal Symbol | Output NO. | CN2-Pin NO | Parameter | Command | Setup Value | Signal Logic | Description | Control Mode | | | |
|---------------|------------|------------|-----------|---------|-------------|--------------|---------------------------|--------------|---|---|---|
| SON-ST | Y1+ | 11 | P5-12 | MO1 | 7 | Closed | The servo is enabled. | P | V | T | F |
| | Y1- | 10 | | | | Open | The servo is not enabled. | | | | |

The sequence diagram is as follows:



Note 1: When main power is cut off, it may take 1s or longer to stop outputting the Servo Ready signal due to the capacitor in the drive.


Note 2: If cut off main power input when the drive is enabled, possible alarms may occur as following, under-voltage alarm(Warning), low-voltage alarm(Fault), position following error.

Note 3: When main power is not applied, the Servo Ready will not output. There will be a low-voltage alarm if trying to enable the servo.

7.1.14 Dynamic Position Output

Dynamic position following error output refers to the output of this signal when the difference between the motor actual position and the command position is greater than P5-38 Dynamic Follow Error Threshold during the motor is rotating.

The following figure shows that the dynamic following error exceeds the setting of P5-38, the DYM-LMT signal outputs.



| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | DYM-LMT | 11 | Closed | When the dynamic following error exceeds the setting of P5-38, the DYM-LMT signal is output, and the output state is CLOSED. |
| | | | Open | When the dynamic following error does NOT exceed the setting of P5-38, the DYM-LMT signal will NOT output, and the output state is OPEN. |
| | | 12 | Open | When the dynamic following error exceeds the setting of P5-38, the DYM-LMT signal will NOT output, and the output state is OPEN. |
| | | | Closed | When the dynamic following error does NOT exceed the setting of P5-38, the DYM-LMT signal is output, and the output state is CLOSED. |

7.1.15 Rotation Limit Output

Rotation limit output refers to this output when the limit sensor of current rotation direction is touched or triggered when the motor is rotating, and the motor cannot continue to rotate in the same direction.

There are two outputs of this function.

- 1) Forward rotation limit SLCW
- 2) Negative rotation limit SLCCW


| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | SLCW | 27 | Closed | Motor cannot rotate forward when the forward rotation limit switch is triggered, SLCW signal is output and the output state is CLOSED. |
| | | | Open | Motor rotates forward normally when the forward rotation limit switch is NOT triggered. SLCW signal will NOT output and the output state is OPEN. |
| | | 28 | Open | Motor cannot rotate forward when the forward rotation limit switch is triggered. SLCW signal will NOT output and the output state is OPEN. |
| | | | Closed | Motor rotates forward normally when the forward rotation limit switch is NOT triggered. SLCW signal is output and the output state is CLOSED. |
| Output | SLCCW | 29 | Closed | Motor cannot rotate forward when the forward rotation limit switch is triggered, SLCCW signal is output and the output state is CLOSED. |
| | | | Open | Motor rotates forward normally when the forward rotation limit switch is NOT triggered. SLCCW signal will NOT output and the output state is OPEN. |
| | | 30 | Open | Motor cannot rotate forward when the forward rotation limit switch is triggered. SLCCW signal will NOT output and the output state is OPEN. |
| | | | Closed | Motor rotates forward normally when the forward rotation limit switch is NOT triggered. SLCCW signal is output and the output state is CLOSED. |

In the absolute encoder servo system, when any of the following conditions are met, the rotation limit signal will be output.

- 1) Limit signal of digital inputs
- 2) Software limit set by parameter P5-47(Software positive limit) and P5-48(Software negative limit)

7.1.16 Sequence diagram

7.1.16.1 Sequence Diagram When Power-on




Note 1: When main power is cut off, it may take 1s or longer to stop outputting the Servo Ready signal due to the capacitor in the drive.

Note 2: If cut off main power input when the drive is enabled, possible alarms may occur as following, under-voltage alarm(Warning), low-voltage alarm(Fault), position following error.

Note 3: When main power is not applied, the Servo Ready will not output. There will be a low-voltage alarm if trying to enable the servo.

7.1.16.2 Sequence Diagram When Faults Occur




7.2 Position Mode

7.2.1 Overview of Position Mode Setting Process

Position Mode is to control the position by the position command input from the host controller. The following describes the basic setting for position control.

◆ Function setting block diagram



◆ Position Control Method

Position control is widely used in devices that require precise positioning. There are two position control methods in the M56S series servo system: Digital pulse command position mode and Internal command position mode.

Set the following values to parameter P1-00 through the drive's LED operation panel of Luna Software, and the servo drive will work in the corresponding mode.

| Parameter | Command | Setup Value | Position Mode | Command | Description |
|-----------|---------|-------------|-------------------------------------|---|---|
| P1-00 | CM | 7 | Digital pulse command position mode | <ul style="list-style-type: none"> ◆ Pulse & Direction ◆ CW/CCW Pulse ◆ A/B quad | 500KHz Open-collector input or 4MHz Line driver pulse |
| | | 21 | Internal command position mode | <ul style="list-style-type: none"> ◆ Q Program ◆ Modbus/RTU | Use Q programming or Modbus/RTU communication commands for position control |

◆ Pulse position command input setting

- Pulse command input source
- Pulse command type
- Rotation direction setting
- Valid pulse edge setting
- Pulse input noise filter

Related parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|--------------------------|--------|---------|------|---|
| P3-03 | PT | Pulse input setting | 1 ~ 30 | 9 | - | Set the input pulse command source, pulse type, rotation direction and pulse edge valid type: <ul style="list-style-type: none"> ◆ bit0 bit1: Pulse command type ◆ bit2: Rotation direction ◆ bit3: Valid pulse setting ◆ bit4: Pulse input source |
| P3-02 | SZ | Pulse input noise filter | 0~3200 | 2 | - | Set the pulse input noise filter |

For detailed parameter setting, please refer to [Chapter 7.2.3 Position Command Input Settings](#)

◆ Electronic Gear Ratio

The Electronic Gear Ratio means that multiply the pulse command input by the electronic gear ratio as the position command in position mode. By using this function, you can easily set the motor speed and movement distance corresponding to the pulse input command.

Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|-----------------------------------|--------------|---------|------|--|
| P3-00 | EN | Electronic gear ratio-Numerator | 0 ~ 100000 | 32000 | - | Set the numerator of electronic gear ratio |
| P3-01 | EU | Electronic gear ratio-Denominator | 0 ~ 100000 | 32000 | - | Set the denominator of electronic gear ratio |
| P3-05 | EG | Command Pulses per revolution | 200 ~ 131072 | 10000 | - | Set the number of pulses required for each turn of the motor |

For detailed parameter setting, please refer to [Chapter 7.2.4 Electronic Gear Ratio](#)

◆ Command Smoothing Filter

Filter the motion command such as position command or speed command can reduce the vibration caused by sudden change of motor speed, and make the mechanical system operation more smoother.

Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|----------------------|-----------|---------|------|--|
| P2-05 | JT | Jerk Time | 0 ~ 125 | 10 | ms | Smoothing filter for internal motion command. |
| P2-28 | KJ | Jerk Filter | 0 ~ 10000 | 10 | ms | Set the time constant of the low-pass filter of the position command or speed command. |
| P2-29 | FF | Interpolation Filter | 0 ~ 100 | 10 | ms | Time constant of smoothing filter under pulse position command. |

For detailed parameter setting, please refer to [Chapter 7.2.5 Command Smoothing Filter](#)

◆ Clear position following error counter

In pulse position mode, use an external input to clear the position following error counter. When input C-CLR is true, this counter is set to zero and no position compensation is performed.

Related Parameters

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|---|
| Input | C-CLR | 17 | Closed | C-CLR function is enabled, position error counter is set to zero. |
| | | | Open | C-CLR function is NOT enabled, the value of Position error counter = Position command-Encoder feedback. |
| | | 18 | Open | C-CLR function is enabled, position error counter is set to zero. |
| | | | Closed | C-CLR function is NOT enabled, the value of Position error counter = Position command-Encoder feedback. |

For detailed parameter setting, please refer to [Chapter 7.2.7 Clear the Position Following Error Counter](#)

◆ Pulse Input Prohibition Function

The pulse command input prohibition function means that in the pulse position mode, an external digital input is used to stop the input pulse command counting. The drive will ignore the input pulses and will not rotate immediately.

Related Parameters

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|---|
| Input | INHP | 25 | Closed | INHP function is enabled, drive ignores input pulses. |
| | | | Open | INHP function is NOT enabled, motor works under the control of input pulse. |
| | | 26 | Open | INHP function is enabled, drive ignores input pulses. |
| | | | Closed | INHP function is NOT enabled, motor works under the control of input pulse. |

For detailed parameter setting, please refer to [Chapter 7.2.6 Pulse Input Prohibition Function](#)

◆ In Position Output

In the position mode, use the In Position Output signal to indicate the current positioning status of the servo drive. When the difference between the total number of pulse commands received by the drive and the number of pulses actually moved by the servo motor, that is, the position following error is less than the parameter setting value, the positioning completion signal will be output.

Related Parameters

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | IN-POS | 9 | Closed | When positioning finished condition is met, the IN-POS signal is output, and the output state is CLOSED. |
| | | | Open | When positioning finished condition is NOT met, the IN-POS signal will NOT output, and the output state is OPEN. |
| | | 10 | Open | When positioning finished condition is met, the IN-POS signal is output, and the output state is OPEN. |
| | | | Closed | When positioning finished condition is NOT met, the IN-POS signal will NOT output, and the output state is CLOSED. |

For detailed parameter setting, please refer to [Chapter 7.2.8 In Position Output](#).

◆ Encoder Divided Output


The Encoder Divided Output function is used to output the position feedback from the motor encoder or the external position pulse command in A/B quadrature pulse. Z-phase pulse output is support.

Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|-------------------------------------|------------|---------|------|--|
| P3-12 | PO | Pulse Output Mode | 0 ~ 256 | 1 | - | Set the pulse division output mode. |
| P3-13 | ON | Pulse Output Gear Ratio-Numerator | 0 ~ 131072 | 10000 | - | Set the numerator of the pulse output gear ratio |
| P3-14 | OD | Pulse Output Gear Ratio-Denominator | 0 ~ 131072 | 131072 | - | Set the denominator of the pulse output gear ratio |

For detailed parameter setting, please refer to [Chapter 7.6 Encoder Divided Output](#).

7.2.2 Wiring Diagram of Digital Pulse Position Mode



7.2.3 Position Command Input Settings

When P1-00 is set to 7, which is digital pulse position mode, the followings need to be set.

- ◆ Pulse command input source
- ◆ Pulse command type
- ◆ Rotation direction setting
- ◆ Valid pulse edge setting
- ◆ Pulse input noise filter

Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|--------------------------|--------|---------|------|---|
| P3-03 | PT | Pulse input setting | 1 ~ 30 | 9 | - | Set the input pulse command source, pulse type, rotation direction and pulse edge valid type: ◆ bit0 & bit1: Pulse command type ◆ bit2: Rotation direction ◆ bit3: Valid pulse setting ◆ bit4: Pulse input source |
| P3-02 | SZ | Pulse input noise filter | 0~3200 | 2 | - | Set the pulse input noise filter |

Parameters P3-03

Parameter P3-03 is used to set the input pulse command source, pulse type, rotation direction and pulse edge valid type.

| P3-03 Pulse input setting | | | | | | | |
|--|------|------|-------------------------|--------------------------|-----------------------|----------------------------------|------|
| bit7 | bit6 | bit5 | bit4 | bit3 | bit2 | bit1 | bit0 |
| 0 | 0 | 0 | 0: Open-collector input | 0: Valid on falling edge | 0: Positive Direction | bit1=0,bit0=1: Pulse & Direction | |
| | | | 1: Line receiver input | 1: Valid on raising edge | 1: Negative Direction | bit1=1,bit0=0: CW/CCW | |
| bit1=1,bit0=1: A/B Quadrature | | | | | | | |
| bit0 & bit1: Pulse command type bit2: Rotation direction bit3: Valid pulse setting bit4: Pulse input source | | | | | | | |

7.2.3.1 Pulse Input Source

The pulse input source is set by bit4 of parameter P3-03.

| P3-03 Pulse input setting | | | | | | | |
|---------------------------|------|------|-------------------------|------|------|------|------|
| bit7 | bit6 | bit5 | bit4 | bit3 | bit2 | bit1 | bit0 |
| 0 | 0 | 0 | 0: Open-collector input | | | | |
| | | | 1: Line receiver input | | | | |

- ◆ When bit4 = 0, Open-collector Pulse Inputs (or Low-speed pulse signal input) is selected.

| CN2-Pin NO. | Signals | Description |
|-------------|---------|--|
| 1 | OPC1 | When bit4 of P3-03 is set to "0", this low-speed pulse input is valid. The pulse position control mode will use this input as position command reference. ◆ Optocoupler input: 1) Open collector pulse signals, 5V or 24VDC 2) Low-speed differenct pulse signals, 5VDC |
| 3 | STEP+ | |
| 4 | STEP- | |
| 2 | OPC2 | ◆ Maximum pulse frequency is 500KHz. ◆ Support pulse & direction signal, CW/CCW signal and A/B quadrature signal ◆ When using 24V open collector pulse signal, you need to use OPC1 and OPC2 input for pull-up. |
| 5 | DIR+ | |
| 6 | DIR- | |

- ◆ When bit4 = 1, Line Driver pulse Inputs(or High-speed pulse signal input) is selected.

| CN2-Pin NO. | Signals | Description |
|-------------|---------|---|
| 44 | PULSH+ | When bit4 of P3-03 is set to "1", this line driver pulse input is valid. The pulse position control mode will use this input as position command reference. ◆ For Line driver pulse input, 5VDC, Maximum pulse frequency is 4MHz |
| 45 | PULSH- | |
| 46 | SIGNH+ | ◆ Support pulse & direction signal, CW/CCW signal and A/B quadrature signal |
| 47 | SIGNH- | |

7.2.3.2 Input Pulse Type Setting

◆ Pulse type, Rotation direction, Valid Pulse Edge Setting

Parameter P3-03 is used to set the input pulse type, rotation direction and pulse edge valid type.

| P3-03 Pulse input setting | | | | | | | |
|---------------------------|------|------|------------------------|--------------------------|-----------------------|--|------|
| bit7 | bit6 | bit5 | bit4 | bit3 | bit2 | bit1 | bit0 |
| 0 | 0 | 0 | 0: Open-colector input | 0: Valid on falling edge | 0: Positive Direction | bit1=0,bit0=1: Pulse & Direction | |
| | | | 1: Line receiver input | 1: Valid on raising edge | 1: Negative Direction | bit1=1,bit0=0: CW/CCW bit1=1,bit0=1: A/B Quadrature | |

1) Input Pulse Type:

There are three types of input pulse: Pulse & Direction, CW/CCW pulse, A/B quadrature pulse that is set by bit0 and bit1 of parameter P3-03.

| bit 1 | bit 0 | Input pulse type |
|-------|-------|----------------------------|
| 0 | 1 | Pulse & Direction(Default) |
| 1 | 0 | CW/CCW pulse |
| 1 | 1 | A/B quadrature pulse |

2) Rotation Direction:

Bit 2 of parameter P3-03 determines the relationship between the input pulse and the rotation direction of the motor, as shown in the figure below.

| Bit2 | Input pulse type | Positive Direction | Negative Direction |
|----------------|-------------------|---|---|
| 0 (Default) | Pulse & Direction | Positive rotation when the direction signal keeps CLOSED. | Negative rotation when the direction signal keeps OPEN. |
| | CW/CCW pulse | When the CW pulse input, and the CCW keeps Open, it is positive rotation. | When the CCW pulse input, and the CW keeps Open, it is negative rotation. |
| | A/B quadrature | When phase-A leads phase-B by 90 degree, it is positive rotation. | When phase-B leads phase-A by 90 degree, it is negative rotation. |
| 1 | Pulse & Direction | Positive rotation when the direction signal keeps OPEN | Negative rotation when the direction signal keeps CLOSED. |
| | CW/CCW pulse | When the CCW pulse input, and the CW keeps Open, it is positive rotation. | When the CW pulse input, and the CCW keeps Open, it is negative rotation. |
| | A/B quadrature | When phase-B leads phase-A by 90 degree, it is positive rotation. | When phase-A leads phase-B by 90 degree, it is negative rotation. |

3) Valid Pulse Edge Setting:



















Bit3 of parameter P3-03 determines the valid edge condition of input pulse.

| bit 3 | Valid edge |
|-------|--------------------------------|
| 0 | Valid on falling edge(Default) |
| 1 | Valid on raising edge |

7.2.3.3 Quick Setup for Input Pulse Type

The following table lists the quick setup of parameter P3-03 based on the following conditions.

- ◆ Pulse command input source
- ◆ Pulse command type
- ◆ Rotation direction setting
- ◆ Valid pulse edge setting

| Valid pulse edge bit3 | Rotation direction bit2 | Pulse command type | | | Positive | Negative | Parameter P3-03 Set value (Decimal) | |
|--------------------------|----------------------------|--------------------|------|-------------------|---|---|-------------------------------------|---------------|
| | | bit1 | bit0 | | | | Open-collector | Line receiver |
| 0 | 0 | 0 | 1 | Pulse & Direction | Pulse Input  Direction  Closed | Pulse Input  Direction  Open | 1 | 17 |
| 0 | 0 | 1 | 0 | CW/CCW | CW  CCW  Open | CW  Open CCW  | 2 | 18 |
| 0 | 0 | 1 | 1 | A/B | Phase-A  Phase-B  | Phase-A  Phase-B  | 3 | 19 |
| 0 | 1 | 0 | 1 | Pulse & Direction | Pulse Input  Direction  Open | Pulse Input  Direction  Closed | 5 | 21 |
| 0 | 1 | 1 | 0 | CW/CCW | CW  Open CCW  | CW  CCW  Open | 6 | 22 |
| 0 | 1 | 1 | 1 | A/B | Phase-A  Phase-B  | Phase-A  Phase-B  | 7 | 23 |
| 1 | 0 | 0 | 1 | Pulse & Direction | Pulse Input  Direction  Closed | Pulse Input  Direction  Open | 9 | 25 |
| 1 | 0 | 1 | 0 | CW/CCW | CW  CCW  Open | CW  Open CCW  | 10 | 26 |
| 1 | 1 | 0 | 1 | Pulse & Direction | Pulse Input  Direction  Open | Pulse Input  Direction  Closed | 13 | 29 |
| 1 | 1 | 1 | 0 | CW/CCW | CW  Open CCW  | CW  CCW  Open | 14 | 30 |

7.2.3.4 Specification of Pulse command

The minimum pulse width of the input pulse should meet the following conditions.

| | | Low speed pulse input STEP+, STEP-, DIR+, DIR- | | | | | | Line receiver input PULSH+,PULSH- SIGN+,SIGN- | | |
|-------------------|--|--|------|------|--|----|----|---|-------|-------|
| | | Line Driver Min. pluse width(μ s) | | | Open Collector Min. pluse width(μ s) | | | Line Driver Min. pluse width(μ s) | | |
| Pulse & Direction | | t1 | t2 | t3 | t1 | t2 | t3 | t1 | t2 | t3 |
| | | 0.25 | 0.25 | 0.25 | 1 | 1 | 1 | 0.125 | 0.125 | 0.125 |
| CW/CCW | | t4 | t5 | t6 | t4 | t5 | t6 | t4 | t5 | t6 |
| | | 0.25 | 0.25 | 0.25 | 1 | 1 | 1 | 0.125 | 0.125 | 0.125 |
| A/B | | t7 | | | t7 | | | t7 | | |
| | | 0.25 | | | 1 | | | 0.125 | | |

Pulse edge(raising edge or falling edge) switching time should be less than 0.1 μ s.

7.2.3.5 Pulse Input Noise Filter

Using parameter P3-02 Pulse Input Noise Filter to filter the input pulse signal to prevent it from being interfered and cause inaccurate positioning and other problems. This noise filter is a low-pass filter, and the unit is 0.1µs.

Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|--------------------------|---------|---------|-------|----------------------------------|
| P3-02 | SZ | Pulse Input Noise Filter | 0~32000 | 2 | 0.1µs | Set the Pulse Input Noise Filter |


Instructions:

Ts: The set value of P3-02 pulse input noise filter

T1: The high voltage level width of input pulse

T2: The low voltage level width of input pulse

Then the relationship between the input pulse signal and the the filtered signal is as follows.




- ◆ Both T1 and T2 of a pulse are bigger than Ts, this input pulse is valid.
- ◆ One of T1 and T2 of a pulse is smaller than Ts, this input pulse will be filtered.

$$\text{Noise Filter time : } Ts \leq \frac{1}{A \times \text{Pulse Input Frequency (Hz)}}$$

Generally, when the duty cycle of the input frequency is 50%, the value of A is 4 or 5.

Example:

1) When the input pulse frequency is 200KHz, and the duty cycle is 50%.




$$T1 = \frac{1}{200000} \times 0.5 = 0.0000025s \quad T2 = \frac{1}{200000} \times 0.5 = 0.0000025s$$

$$Ts = \frac{1}{5 \times 200000} = 0.000001s \quad Ts < T1 \text{ and } T2$$

That is, the minimum filter time is 1µs. Since the unit of parameter P3-02 is 0.1µs, the value of P3-02 is 10.

2) When the input pulse frequency is 500KHz, and the duty cycle is 10%.



$$T1 = \frac{1}{500000} \times 0.1 = 0.0000002s \quad T2 = \frac{1}{500000} \times 0.9 = 0.0000018s$$

$$Ts = \frac{T1}{2} = 0.0000001s$$

Since the pulse widths T1 and T2 of the input pulse need to be both greater than P3-02, the pulse input is valid. In the case of 10% duty cycle, if the value is 5 according to formula, Ts is 0.4µs and greater than T1, the pulse input will be invalid at this time.

Set Ts=0.5 x T1=0.1µs. Since the unit of parameter P3-02 is 0.1µs, the value of P3-02 is 1.

7.2.4 Electronic Gear Ratio

M56S series servo drives have two electronic gearing systems, parameter P3-16 is used to switch this.

| Parameter P3-16 set value | Description | Instructions |
|---------------------------|--|---|
| 0 | Based on parameter P3-05 (Command Pulses per revolution) Setting | Set the required number of command pulses per revolution of motor. Note: ◆ When this setting is zero, electronic gear ratio P03-00 and P3-01 is invalid. ◆ The read value of feedback encoder position is also determined by this parameter. That is, the read value of feedback encoder position per motor revolution = the setting of parameter P3-05 |
| 1 | Electronic gear ratio is valid | ◆ Electronic gear ratio P03-00 and P3-01 become valid and P3-05 is invalid ◆ The read value of feedback encoder position is: Feedback encoder position per revolution = $\frac{1048576}{(\text{Encoder resolution})} \times \frac{\text{P3-01 (Electronic Gear Ratio-Numerator)}}{\text{P3-00 (Electronic Gear Ratio-Denominator)}}$ |

The electronic gear ratio is to multiply the pulse input command by the electronic gear ratio as the position command reference. By using this function, the motor rotation and movement amount corresponding to the input command pulse can be set.

$$\text{External Position Pulse Command (Communication Position Command)} \times \frac{\text{P3-00 (Electronic Gear Ratio-Denominator)}}{\text{P3-01 (Electronic Gear Ratio-Numerator)}} = \text{Reference Position Command}$$


- ◆ When parameter P3-16 = 0, the electronic gear ratio P03-00 and P03-01 is invalid. The number of pulses per revolution of the motor is determined by parameter P3-05.
- ◆ When parameter P3-16 = 1, the electronic gear ratio P03-00 and P03-01 become valid. The number of pulses for one rotation of the motor is fixed to the encoder resolution. Regardless of the encoder with 17-bit or 20-bit resolution, it takes 1,048,576 pulses to rotate the motor once.
For example: the number of pulses required for one revolution of the motor is 1048576 pulses. When the electronic gear ratio is equal to 1, the controller sends 1048576 pulses and the motor rotates one turn. When the electronic gear ratio is equal to 0.5, that is, every 2 pulses sent by the controller to the motor rotation is 1 pulse. The controller needs to send 2097152 pulses, multiplied by the electronic gear ratio, the position command reference is 1048576 pulses, and the motor rotates one turn.

Setting an appropriate electronic gear ratio will simplify the calculation of pulses sent by the host controller.

Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|-----------------------------------|----------------|---------|--------|--|
| P3-00 | EN | Electronic Gear Ratio-Numerator | 1 ~ 2147483647 | 1048576 | - | Set the numerator of electronic gear ratio |
| P3-01 | EU | Electronic Gear Ratio-Denominator | 1 ~ 2147483647 | 10000 | - | Set the denominator of electronic gear ratio |
| P3-05 | EG | Command Pulse per Revolution | 200 ~ 131072 | 10000 | pulses | Set the number of pulses required for one revolution |
| P3-16 | PU | Electronic Gearing Switch | 0 ~ 1 | 0 | - | Enable electronic gear ratio |

For example: The lead of the screw is 3mm, when you needs to move 4mm.



If the electronic gear ratio is not used, the number of pulses that need to be sent is:

Since the lead is 3mm, that is, for each turn of the motor, the mechanical moves 3mm. Moving 4mm requires a $\frac{4}{3}$ turns.

Calculate required pulses :

If the pulses required per motor revolution is 1048576 pulses, $1048576 \times \frac{4}{3} = 1398101.33333.....$ pulses.

Moving 4mm requires 1398101.3333 input pulses, and cumulative error will be generated . Using an electronic gear ratio will solve this problem.

7.2.4.1 Electronic Gear Ratio Calculations:

The total mechanical transmission ratio of the motor shaft and the load side is m:n (when the motor rotates m turns, the load moves n turns), the electronic gear ratio can be quickly calculated by the following formula.

$$\text{Electronic Gear Ratio } \frac{B}{A} = \frac{P3-00}{P3-01} = \frac{\text{Encoder Resolution}}{\text{Position commands for one rotation of the load shaft}} \times \frac{m}{n}$$

7.2.4.2 Calculation Example

Taking the lead screw as an example, the related parameters are:

| | |
|---|--|
| ◆ Ball screw lead: P_B , Unit: mm | |
| ◆ Load Position: L, Unit: mm | |
| ◆ Total mechanical transmission ratio: | |
| $R = \frac{\text{Output n Turns}}{\text{Input m Turns}}$ | |
| ◆ Encoder Resolution E_R , Unit :counts ER=1048576 counts | |
| ◆ Numerator of Electronic gear ratio: B | |
| ◆ Denominator of Electronic gear ratio: A | |
| ◆ Required Input Pulses: P, Unit: counts | |

1) Calculate the electronic gear ratio according to the external input pulse P(counts) and the corresponding load travel distance L(mm)

According to:

Motor shaft turns X Mechanical transmission ratio = Ball screw turns

When the load travel distance is L, the ball screw turns $\frac{L}{P_B}$, motor shaft turns $\frac{P \times \frac{B}{A}}{E_R}$,

That is

$$\frac{P \times \frac{B}{A}}{E_R} \times R = \frac{L}{P_B}$$

So the electronic gear ratio is:

$$\frac{B}{A} = \frac{L}{P_B} \times \frac{1}{R} \times E_R \times \frac{1}{P}$$

2) Calculate the electronic gear ratio according to the external input one pulse and the corresponding load travel distance ΔL (mm)

According to

Motor shaft turns X Mechanical transmission ratio = Ball screw turns

When the external input one pulse and the load travel distance is $\Delta L \frac{\Delta L}{P_B}$, motor shaft turns $\frac{1 \times \frac{B}{A}}{E_R}$

That is

$$\frac{1 \times \frac{B}{A}}{E_R} \times R = \frac{\Delta L}{P_B}$$

So the electronic gear ratio is:

$$\frac{B}{A} = \frac{\Delta L}{P_B} \times \frac{1}{R} \times E_R$$

3) Calculate the electronic gear ratio according to the external input pulse frequency F (Hz) and the corresponding load speed V_L (mm/s)

According to:

Motor shaft speed X Mechanical transmission ratio = Load speed

Load Speed: $\frac{V_L}{P_B}$ (rps), Motor shaft speed: $\frac{F \times \frac{B}{A}}{E_G}$.

That is

$$F \times \frac{B}{A} \times \frac{1}{E_G} \times R = \frac{V_L}{P_B}$$

So the electronic gear ratio is:

$$\frac{B}{A} = \frac{V_L}{P_B} \times \frac{1}{R} \times E_G \times \frac{1}{F}$$

7.2.4.3 Electronic Gear Ratio Calculation Example

Ball screw lead: 3mm

Mechanical transmission ratio: 10:1

Requirements: Every time the host controller sends one pulse, the workload travels 1 μ m.

$$\frac{B}{A} = \frac{1}{3000} \times 10 \times 1048576 = \frac{1048576}{300}$$

So

P3-00 Electronic gear ratio - Numerator: 1048576

P3-01 Electronic gear ratio - Denominator: 300

7.2.5 Command Smoothing Filter

When the position command or speed command to the servo system changes suddenly, it is easy to cause the whole system to vibrate, and the running noise will also increase. Command Smoothing Filter is used to filter and smooth the position command or speed command, which can reduce the running transient of the motor and mechanical system and make the operation smoother.

Command Smoothing Filter frequency, in Hz. The lower the frequency value the more pronounced the S-curve profile will be. Setting the value to 0 will disable the filter.

S-curve acceleration/deceleration ramps are beneficial in positioning systems where instantaneous changes in speed may cause the load to jerk excessively. One example is when the load is connected to the motion actuator via a long moment arm. If the arm is not sufficiently rigid, changes in speed at the actuator can result in undesirable oscillations and increased settling time at the load. Smoothed transitions in speed changes, can alleviate this unwanted motion and reduce settling time.

Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|----------------------|-----------|---------|------|--|
| P2-05 | JT | Jerk Time | 0 ~ 125 | 10 | ms | The FIR filter time of internal trajectory planning. |
| P2-28 | KJ | Low-pass Jerk Filter | 0 ~ 10000 | 10 | ms | Set the time constant of the low-pass filter of the position command or speed command. |
| P2-29 | FF | Interpolation Filter | 0 ~ 125 | 10 | ms | Time constant of smoothing filter in pulse position control command |


Note: The filter function will be disabled when the value is set to zero.

7.2.5.1 Interpolation Filter

Parameter P2-29 Interpolation Filter works in the pulse position control mode, applicable to the following application scenarios:

- ◆ Input pulse command does not perform acceleration or deceleration.
- ◆ The frequency of input pulse command changes suddenly.
- ◆ The frequency of input pulse command is extremely low.


The smoothing effect of the Interpolation Filter to the input command is shown in the figure below.



7.2.5.2 Jerk Time

Parameter P2-05 jerk time takes effect in internal trajectory modes (position, speed, torque), analog position, analog speed, analog torque, or communication command control(SCL or Modbus etc.).


The smoothing effect of the Jerk Time to the input command is shown in the figure below.



7.2.5.3 Low-pass Jerk Filter

Parameter P2-28 Low-pass Jerk Filter can take effect in all control modes, such as: external pulse control position mode, internal trajectory mode (position, speed, torque), analog position, analog speed, analog torque, Communication command control(SCL or Modbus), etc.


The smoothing effect of Low-pass Jerk Filter to the input command is shown in the figure below.



7.2.6 Pulse Input Prohibition Function

The pulse command input prohibition function means that in the pulse position mode, an external digital input is used to stop the input pulse command counting.

The drive will ignore the input pulses and will not rotate immediately.



To use this function, one of the digital input of the servo drive is configured as INHP function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|---|
| Input | INHP | 25 | Closed | INHP function is enabled, drive ignores input pulses. |
| | | | Open | INHP function is NOT enabled, motor works under the control of input pulse. |
| | | 26 | Open | INHP function is enabled, drive ignores input pulses. |
| | | | Closed | INHP function is NOT enabled, motor works under the control of input pulse. |

7.2.7 Clear the Position Following Error Counter Input

Position Following Error = Position Command Reference - Encoder Feedback

In pulse position mode, use an external input to clear the position following error counter. When input C-CLR is true, this counter is set to zero and no position compensation is performed.

To use this function, one of the digital input of the servo drive is configured as C-CLR function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|---|
| Input | C-CLR | 17 | Closed | C-CLR function is enabled, position error counter is set to zero. |
| | | | Open | C-CLR function is NOT enabled, the value of Position error counter = Position command-Encoder feedback. |
| | | 18 | Open | C-CLR function is enabled, position error counter is set to zero. |
| | | | Closed | C-CLR function is NOT enabled, the value of Position error counter = Position command-Encoder feedback. |

7.2.8 In-position Output Signal

The In-position output signal is used to indicate current positioning status of the servo system in the position mode. When the position following error, which is the difference between input position command and the motor actual position feedback by motor encoder, is less than the set value of P5-39, the In-position signal will output.

To use this function, one of the digital output of the servo drive is configured as IN-POS function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | IN-POS | 9 | Closed | When positioning finished condition is met, the IN-POS signal is output, and the output state is CLOSED. |
| | | | Open | When positioning finished condition is NOT met, the IN-POS signal will NOT output, and the output state is OPEN. |
| | | 10 | Open | When positioning finished condition is met, the IN-POS signal is output, and the output state is OPEN. |
| | | | Closed | When positioning finished condition is NOT met, the IN-POS signal will NOT output, and the output state is CLOSED. |



By default, the Servo Ready signal is set in the table below.

| Signal Symbol | Output NO. | CN2-Pin NO | Parameter | Command | Setup Value | Signal Logic | Description | Control Mode | | | |
|---------------|------------|------------|-----------|---------|-------------|--------------|--|--------------|---|---|---|
| IN-POS | Y4+ | 39 | P5-15 | MO4 | 9 | Closed | When positioning finished condition is met, the IN-POS signal is output, and the output state is CLOSED. | P | V | T | F |
| | Y4- | 38 | | | | Open | When positioning finished condition is NOT met, the IN-POS signal will NOT output, and the output state is OPEN. | | | | |

Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|--|-----------|---------|-------|--|
| P5-39 | PD | In-position Output Threshold | 0 ~ 32000 | 40 | pulse | The position following error judgment range that determines whether the In-position signal is output or not. |
| P5-40 | PE | Time Constant of Motion Output Condition | 0 ~ 32000 | 10 | ms | Counting time for positioning completion |
| P5-41 | TT | Pulse Complete Timer | 0 ~ 20000 | 2 | ms | Pulse input completion detection time |

The following figure shows the relationship of P5-39,P5-40 and P5-41.



7.2.9 Near Target Position Output

Near target position, which is also called Position Consistent, is to output a signal(P-COIN) when the actual position of motor is equal to the position set by parameter P5-46.

To use this function, one of the digital output of the servo drive is configured as P-COIN function.


| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|---|
| Output | P-COIN | 31 | Closed | When Position Consistent Output judgment condition is met, the P-COIN signal is output, and the output state is CLOSED. |
| | | | Open | When Position Consistent Output judgment condition is NOT met, the P-COIN signal will NOT output, and the output state is OPEN. |
| | | 32 | Open | When Position Consistent Output judgment condition is met, the P-COIN signal is output, and the output state is OPEN. |
| | | | Closed | When Position Consistent Output judgment condition is NOT met, the P-COIN signal will NOT output, and the output state is CLOSED. |

Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|----------------------|---------------------------|---------|-------|---|
| P5-46 | DG | Near Target Position | -2147483647 ~ +2147483647 | 10 | Pulse | Target position of the judgement of whether output the P-COIN signal. |

Near Target Position Output judgement condition

The P-COIN will out when the actual position of motor is equal to the position set by parameter P5-46. Detection is associated with ± 100 pulses hysteresis.



7.2.10 Gain Parameters in Position Mode

In position mode, reasonable gain parameters can make the servo system run more smoothly and accurately and excellent positioning performance.


The following gain parameters take effects in position mode and can be automatically adjusted using the Luna software, and can also be modified and fine-tuned through software or LED operation panel.

| Parameter | Command | Description | Type | Default | Unit |
|-----------|---------|---|--|---------|----------|
| P0-05 | KP | 1st Position Loop Gain | First Gain Parameters Group | 52 | 0.1Hz |
| P0-07 | KD | 1st Position Loop Derivative Time Constant | | 0 | ms |
| P0-08 | KE | 1st Position Loop Derivative Filter | | 20000 | 0.1Hz |
| P0-11 | KF | 1st Velocity Command Gain | | 10000 | 0.01% |
| P0-12 | VP | 1st Velocity Loop Gain | | 183 | 0.1Hz |
| P0-13 | VI | 1st Velocity Loop Integral Time Constant | | 189 | ms |
| P0-16 | KC | 1st Torque Command Filter | | 1099 | 0.1Hz |
| P0-17 | UP | 2nd Position Loop Gain | Second Gain Parameters Group | 52 | 0.1Hz |
| P0-19 | UD | 2nd Position Loop Derivative Time Constant | | 0 | ms |
| P0-20 | UE | 2nd Position Loop Derivative Filter | | 20000 | 0.1Hz |
| P0-21 | UF | 2nd Velocity Command Gain | | 10000 | 0.01% |
| P0-22 | UV | 2nd Velocity Loop Gain | | 183 | 0.1Hz |
| P0-23 | UG | 2nd Velocity Loop Integral Time Constant | | 189 | ms |
| P0-24 | UC | 2nd Torque Command Filter | | 1099 | 0.1Hz |
| P0-25 | XP | Full Closed-loop Position Loop Gain | Full Closed-loop Gain Parameters Group | 52 | 0.1Hz |
| P0-27 | XD | Full Closed-loop Position Loop Derivative Time Constant | | 0 | ms |
| P0-28 | XE | Full Closed-loop Position Loop Derivative Filter | | 20000 | 0.1Hz |
| P0-29 | XF | Full Closed-loop Velocity Command Gain | | 10000 | 0.01% |
| P0-30 | XV | Full Closed-loop Velocity Loop Gain | | 183 | 0.1Hz |
| P0-31 | XG | Full Closed-loop Velocity Loop Integral Time Constant | | 189 | ms |
| P0-32 | XC | Full Closed-loop Torque Command Filter | | 1099 | 0.1Hz |
| P0-33 | SD | Automatic Gain Switching Method | - | 0 | |
| P0-34 | PN | Gain Switch with Position Error Condition Change | - | 0 | counts |
| P0-35 | VN | Gain Switch with Actual Speed Condition Change | - | 0 | 0.025rps |
| P0-36 | TN | Gain Switch with Actual Torque Condition Change | - | 10 | 0.1% |
| P0-37 | SE1 | Second Gain Switching to First Gain Delay Time | - | 10 | ms |
| P0-38 | SE2 | First Gain Switching to Second Gain Delay Time | - | 0 | ms |


7.2.11 Using Luna Software to Configure Position Control Mode

The position control mode can be easily configured using the Luna software.


Step 1: Select Control Mode




Step 2: Set Electronic Gear Ratio




Step 3: Set Smoothing Filter



Step 4: Set Input and Output Function




Step 5: Gain Tuning



7.3 Velocity Mode

Velocity control mode is used for precise speed control.

◆ Function Block Diagram




◆ Velocity Control Mode Select

There are three velocity control mode in M56S series, Analog Speed Mode, Command Speed Mode and Internal Multi-speed Mode.

- 1) Analog Speed Mode: -10 ~ +10Vdc external analog voltage input to control the motor speed.
- 2) Command Speed Mode: Use Q program commands to control the motor speed, or use Modbus commands to control the motor speed.
- 3) Internal Multi-speed Mode: Use the digital input to select and control the motor speed, there up to 8 different speeds can be select.

| Control Mode | Control Signal | P1-00 | Instructions |
|---------------------------|---------------------------------------|-------|---|
| Analog Speed Mode | +10~-10V Analog input | 11 | ◆ Analog speed mode |
| Command Speed Mode | Q program commands or Modbus commands | 21 | ◆ Q program commands ◆ Modbus communications control |
| Internal Multi-speed Mode | Digital Inputs | 15 | When motor is enabled, the running speed is set by P2-10 to P2-17, and selected by the digital input states of SPD1, SPD2 and SPD3. |

7.3.1 Wiring Diagram of Speed Control Mode



7.3.2 Related Parameters to Analog Speed Control

There are two -10 ~ +10Vdc analog inputs with 12bit resolution, each can be set low-pass filter, Offset, Deadband, etc.

AIN1 is used as speed reference and AIN2 is used as torque reference,

| Parameters | Command | Description | Range | Default | Unit | Instructions |
|------------|---------|-------------------------------|----------------|---------|-------|--|
| P1-00 | CM | Main Control Mode | 1,2,7,11,15,21 | 7 | | The first control mode selection of the driver |
| P1-01 | CN | Secondary Control Mode | 1,2,7,11,15,21 | 21 | | The second control mode selection of the driver |
| P1-03 | JM | Speed Control Clamp Mode | 1-2 | 2 | | Select the control type for speed mode |
| P4-01 | AG | Analog Input Velocity Scale | 0 ~ 100 | 50 | Rps | Scale factor value for motor speed and analog input. (Set corresponding motor speed when the analog input voltage is 10VDC). |
| P4-02 | AN | Analog Input Torque Scale | 0 ~ 3000 | 1000 | 0.1% | Scale factor value for motor torque and analog input. (Set corresponding motor torque when the analog input voltage is 10VDC) |
| P4-03 | AV1 | Analog Input 1 Offset | -10000 ~ 10000 | 0 | mV | The offset of analog input 1. |
| P4-04 | AV2 | Analog Input 2 Offset | -10000 ~ 10000 | 0 | mV | The offset of analog input 2. |
| P4-05 | AD1 | Analog Input 1 Deadband | 0 ~ 255 | 0 | mV | The deadband of analog input 1. |
| P4-06 | AD2 | Analog Input 2 Deadband | 0 ~ 255 | 0 | mV | The deadband of analog input 2. |
| P4-07 | AF1 | Analog Input 1 Filter | 0 ~ 20000 | 1000 | 0.1Hz | Low-pass filter for analog input 1 |
| P4-08 | AF2 | Analog Input 2 Filter | 0 ~ 20000 | 1000 | 0.1Hz | Low-pass filter for analog input 2 |
| P4-11 | FA1 | Velocity Limit Source Setting | 0 ~ 2 | 0 | | The source of velocity limit command. |
| P2-03 | JA | Jog Acceleration | 0.167 ~ 5000 | 100 | rps/s | The acceleration in internal speed control mode and analog speed mode. |
| P2-04 | JL | Jog Deceleration | 0.167 ~ 5000 | 100 | rps/s | The deceleration in internal speed control mode and analog speed mode. |

Note:

1. The parameter unit is the unit shown in software, it will be different when the parameter is shown in LED display on the drive.

2. The default values of different drive are not same.

7.3.3 Analog Speed Mode Settings

7.3.3.1 Wiring Methods of Analog Input

| Signal Type | Signals | Pin No. | Description |
|-------------|---------|---------|----------------------|
| Input | AIN1 | 16 | Analog speed command |
| | DGND | 15 | GND of analog input |

7.3.3.2 Source of Analog Speed Command


The source of analog speed command is set by parameter P4-11.

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|-------------------------------|-------|---------|------|---|
| P4-11 | FA1 | Velocity Limit Source Setting | 0, 1 | 0 | - | The source of velocity limit command. 0: Internal speed command 1: Analog input 1 |

Note: When the control mode is set as Analog Speed Mode, P4-11 will be automatically set to 1.

7.3.3.3 Analog Speed Scale

The range of analog input is 10~+10VDC, P4-00 set the corresponding motor speed when analog input voltage is at 10VDC



| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|-----------------------------|---------|---------|------|---|
| P4-01 | AG | Analog Input Velocity Scale | 0 ~ 100 | 50 | rps | Set corresponding motor speed when the analog input voltage is 10VDC. |

Note: To check or to change this value from drive operation panel, please calculate according to the following formula.

$$\text{LED Display value} = \frac{V}{240}$$


Where V is the speed to be set in rps(revolution per second)

Set by Luna Software

7.3.3.4 Analog Input Offset

When using the analog speed mode, the servo motor may rotate slightly in some cases even if the input analog command is at 0 voltage. This is because there is a slight drift when analog signal is received by drive.

The parameter P4-03 and P4-04 are used to eliminate this situation. You can use the Luna software to automatically adjust the offset or manually modify these parameters.



| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|-----------------------|------|----------------|---------|------------------------------|
| P4-03 | AV1 | Analog Input 1 Offset | mV | -10000 ~ 10000 | 0 | The offset of analo input 1. |
| P4-04 | AV2 | Analog Input 2 Offset | mV | -10000 ~ 10000 | 0 | The offset of analo input 2. |


The M56Sseries provides two methods of automatically adjust the analog offset.

1) Automatic Adjust by Software

2) Adjust by LED Operation Panel

In the function mode, select the F06AZ function code to set the offset of analog input 1 and analog input 2 at the same time.

Related operations are as follows. For more details, refer to [Chapter 5.5 Function Mode](#).




Note: When performing automatic adjustment:

- ◆ The servo system should be disabled.
- ◆ The analog command of the host controller outputs 0 voltage.

7.3.3.5 Analog Input Deadband

In analog control mode, due to some disturbances and other reasons, even if the command voltage is 0V, the input voltage on the drive side may be not absolutely zero, which makes the motor rotate at a very low speed. In order to eliminate this situation, setting a reasonable deadband can ensure that when the input voltage is within the deadband, it is regarded as 0V.



The analog input deadband can be set P4-05 and P4-06.

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|-------------------------|------|---------|---------|---------------------------------|
| P4-05 | AD1 | Analog Input 1 Deadband | mV | 0 ~ 255 | 0 | The deadband of analog input 1. |
| P4-06 | AD2 | Analog Input 2 Deadband | mV | 0 ~ 255 | 0 | The deadband of analog input 2. |

Set by Luna Software

7.3.3.6 Analog Input Filter

In analog control mode, due to external interference, the analog voltage may fluctuate, which will cause the fluctuation of the motor speeds or the torque output, which will affect the control accuracy.

The analog input filter is a low-pass filter which is used to eliminate this fluctuation.


| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|-----------------------|-------|-----------|---------|------------------------------------|
| P4-07 | AF1 | Analog Input 1 Filter | 0.1Hz | 0 ~ 20000 | 1000 | Low-pass filter for analog input 1 |
| P4-08 | AF2 | Analog Input 2 Filter | 0.1Hz | 0 ~ 20000 | 1000 | Low-pass filter for analog input 2 |

Note:

If the set value is too small, the response to the speed command will be reduced.

7.3.3.7 Acceleration Smoothing For Analog Speed Control

Analog commands are generally step signals, for example, the analog input voltage changes from 1V to 5V, which can easily cause equipment vibration when motor speed changes. Acceleration smoothing filtering is to smooth the step speed command, that is, to control the acceleration and deceleration when target speed changes.



Parameters P2-03 and P2-04 set acceleration and deceleration in analog speed control mode.

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|------------------|-------|--------------|---------|--|
| P2-03 | JA | Jog Acceleration | rps/s | 0.167 ~ 5000 | 100 | The acceleration in internal speed control mode and analog speed mode. |
| P2-04 | JL | Jog Deceleration | rps/s | 0.167 ~ 5000 | 100 | The deceleration in internal speed control mode and analog speed mode. |

Note: To check or to change this value from drive operation panel, please calculate according to the following formula.


$$\text{LED Display value} = \underline{V} \times 6$$

Where \underline{V} is the acceleration or deceleration to be set in rps/s

7.3.4 Zero Speed Clamp

In the speed control mode, when the Zero Speed Clamp input signal (ZCLAMP) is valid and the speed command is less than the set value of P5-42 (zero-speed judgment width), the servo motor will decelerate to zero and enters the zero-position lock state. Meanwhile the drive becomes position controlled, even if the shaft rotates under external force, it will return to the position when the ZCLAMP was valid.

If the speed command is higher than the set value of P5-42, servo drive exits the zero speed clamping state and accelerates to the command speed with the acceleration set by P2-03.



If the servo motor vibrates when the zero speed clamp is in effect, the position loop gains need to be tuned.

It is necessary to set a reasonable zero-speed judgment width. If the set value is too higher, it will cause vibration when motor decelerates quickly.

◆ ZCLAMP--Zero speed clamp input signal

To use Zero Speed Clamp function, one of digital inputs needs to be assigned this function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Input | ZCLAMP | 21 | Closed | ZCLAMP will be in effect when the input is CLOSED. |
| | | | Open | ZCLAMP will be no effect when the input is OPEN. |
| | | 22 | Open | ZCLAMP will be in effect when the input is OPEN. |
| | | | Closed | ZCLAMP will be no effect when the input is CLOSED. |

Related Parameter

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|------------------|------|-------|---------|--|
| P5-42 | ZV | Zero Speed Width | rps | 0 ~ 2 | 0.5 | When the speed is less than or equal to this set value, it is in the zero speed state. |

Note: To check or to change this value from drive operation panel, please calculate according to the following formula.

$$\text{LED Display value} = \underline{V} \times 240$$


Where \underline{V} is the speed to be set in rps(revolution per second)

7.3.5 Start/Stop Control and Direction Changing in Analog Speed Mode

7.3.5.1 Start and Stop Control

The motor speed is determined by the actual analog input voltage in the analog speed mode. When the speed command is "zero", the motor keeps the speed at zero.

You can also use the "Torque and Velocity Control" of input function to start and stop the motor rotating.



Note:

When the digital input is configured as the "Torque and Velocity Control" function, if the input logic is OFF, the motor will stop even if the speed command is not zero.

7.3.5.2 Direction Control

In the speed mode, the motor rotation direction is usually determined by the sign of analog input voltage, or by the sign of speed command. If one of the digital inputs is set as Torque and Velocity Direction Switch (SPD-DIR) function, the motor rotates the absolute value of speed command, and the direction is controlled by the input logic of SPD-DIR.

For example, the analog input voltage is only 0 to 10V, the motor can only rotate positive, but the SPD-DIR input can be used to change the direction..

◆ SPD-DIR Configuration

To use torque and Velocity Direction Switch, one of digital inputs needs to be assigned this function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Input | SPD-DIR | 35 | Closed | SPD-DIR input is valid, the motor rotates direction will be changed. |
| | | | Open | SPD-DIR input is invalid, the motor rotates direction will NOT be changed. |
| | | 36 | Open | SPD-DIR input is valid, the motor rotates direction will be changed. |
| | | | Closed | SPD-DIR input is invalid, the motor rotates direction will NOT be changed. |
| | GP | 0 | - | None of digital inputs is configured as SPD-DIR function, the rotate direction is controlled by the sign of speed command. |

The actual rotation direction is determined by the parameters P1-11 (Rotational Direction Setup), Speed Command (such as analog or communication command), and the input logic of SPD-DIR. The detailed relationship is as follows.

◆ When none of digital inputs is configured as SPD-DIR function

| Value of P1-11 | Speed Command | Input logic of SPD-DIR | Actual motor rotation direction |
|----------------|---------------|------------------------|---------------------------------|
| 0 | Positive | NONE FUNCTION | CW |
| 0 | Negative | NONE FUNCTION | CCW |
| 1 | Positive | NONE FUNCTION | CCW |
| 1 | Negative | NONE FUNCTION | CW |


◆ One of digital inputs is configured as SPD-DIR function:

| Value of P1-11 | Speed Command | Input logic of SPD-DIR | Actual motor rotation direction |
|----------------|---------------|------------------------|---------------------------------|
| 0 | Positive | Invalid | CW |
| 0 | Negative | Invalid | |
| 0 | Positive | Valid | CCW |
| 0 | Negative | Valid | |
| 1 | Positive | Invalid | CCW |
| 1 | Negative | Invalid | |
| 1 | Positive | Valid | CW |
| 1 | Negative | Valid | |

7.3.6 Zero Speed Detected Output

When the absolute value of motor actual speed is less than the set value of P5-42(zero-speed judgment width), the servo drive outputs the Zero Speed Detected(Z-SPD) signal. On the contrary, if the absolute value of motor actual speed is less than P5-42, the Z-SPD signal will not output.

Z-SPD output is not affected by control mode and servo status, therefore, this signal can also be used as the motor moving signal.



◆ Z-SPD Configuration

To use Zero Speed Detected(Z-SPD), one of digital outputs needs to be assigned this function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | Z-SPD | 33 | Closed | When Zero Speed Detected output judgment condition is met, the Z-SPD signal will output, and the output state is CLOSED. |
| | | | Open | When Zero Speed Detected output judgment condition is NOT met, the Z-SPD signal will NOT output, and the output state is OPEN. |
| | | 34 | Open | When Zero Speed Detected output judgment condition is met, the Z-SPD signal will output, and the output state is OPEN |
| | | | Closed | When Zero Speed Detected output judgment condition is NOT met, the Z-SPD signal will NOT output, and the output state is CLOSED. |

Related Parameters

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|------------------|------|-------|---------|--|
| P5-42 | ZV | Zero Speed Width | rps | 0 ~ 2 | 0.5 | As the speed is less than or equal to this set value, it is in the zero speed state. |

Note: To check or to change this value from drive operation panel, please calculate according to the following formula.

$$\text{LED Display value} = \underline{V} \times 240$$

Where \underline{V} is the speed to be set in rps(revolution per second)

7.3.7 Velocity Reach Output


In speed control mode, the Velocity Reach Output, also know as At-speed(AT-SPD), which will be output when the filtered motor actual speed exceeds P5-44 (Target Value of AT-speed Output), and the time exceeds P5-40 (counting time for positioning completion) .

On the contrary, if the filtered motor actual speed is less than P5-44, the AT-SPD signal will not output.

◆ AT-SPD Configuration

To use Velocity Reach Output(AT-SPD), one of digital outputs needs to be assigned this function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | AT-SPD | 19 | Closed | When Velocity Reach Output judgment condition is met, the AT-SPD signal will output, and the output state is CLOSED. |
| | | | Open | When Velocity Reach Output judgment condition is NOT met, the AT-SPD signal will NOT output, and the output state is OPEN. |
| | | 20 | Open | When Velocity Reach Output judgment condition is met, the AT-SPD signal will output, and the output state is OPEN. |
| | | | Closed | When Velocity Reach Output judgment condition is NOT met, the AT-SPD signal will NOT output, and the output state is CLOSED. |



Related Parameters

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|--|------|-----------|---------|--|
| P5-44 | VV | Target Value of AT-speed Output | Rps | 0~100 | 10 | AT-SPD will be out when the filtered motor actual speed exceeds P5-44 (Target Value of AT-speed Output), and the time exceeds P5-40 (counting time for positioning completion) |
| P5-40 | PE | Time Constant of Motion Output Condition | ms | 0 ~ 32000 | 10 | |

Note: To check or to change this value of P5-44 from drive operation panel, please calculate according to the following formula.

$$\text{LED Display value} = \underline{V} \times 240$$

Where \underline{V} is the speed to be set in rps(revolution per second)

7.3.8 Velocity Coincidence Output


In speed mode, when the difference between the filtered motor actual speed and the speed command, that is, the speed error is within the range of P5-43 (Speed Coincidence Width), and the duration time meets the set value of P5-40 (Time Constant of Motion Output Condition), then the Velocity Coincidence signal V-COIN is output.

If the speed error exceeds the set value of P5-43, V-COIN will not output.

◆ V-COIN Configuration

To use Velocity Coincidence Output(V-COIN), one of digital outputs needs to be assigned this function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | V-COIN | 17 | Closed | When Velocity Coincidence output judgment condition is met, the V-COIN signal will output, and the output state is CLOSED. |
| | | | Open | When Velocity Coincidence output judgment condition is NOT met, the V-COIN signal will NOT output, and the output state is OPEN. |
| | | 18 | Open | When Velocity Coincidence output judgment condition is met, the V-COIN signal will output, and the output state is OPEN. |
| | | | Closed | When Velocity Coincidence output judgment condition is NOT met, the V-COIN signal will NOT output, and the output state is CLOSED. |



Related Parameters

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|--|------|-----------|---------|--|
| P5-43 | VR | Speed Coincidence Width | Rps | 0~100 | 0.1 | V-COIN will output when the speed error is within the range of P5-43 (Speed Coincidence Width), and the duration time meets the set value of P5-40 (Time Constant of Motion Output Condition). |
| P5-40 | PE | Time Constant of Motion Output Condition | ms | 0 ~ 32000 | 10 | |

Note: To check or to change this value of P5-43 from drive operation panel, please calculate according to the following formula.

$$\text{LED Display value} = \underline{V} \times 240$$

Where \underline{V} is the speed to be set in rps(revolution per second)

7.3.9 Gain parameters and Speed Control Type in Speed Mode

There are two speed control types in the speed mode.

1. Detect the position errors in real-time
2. Speed control only(default setting)

Related Parameters

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|--------------------------|------|-------|---------|--|
| P1-03 | JM | Speed Control Clamp Mode | - | 1, 2 | 2 | Set the control type in speed mode JM=1. Detect the position errors in real-time JM=2. Speed control only(default setting) |

A) P1-03 = 1-----Detect the position errors in real-time

In this control type, the position error will be detected in real time. When the position error exceeds the setting of P3-04 (Position Error Limit), the drive will get a position follow error fault.

Related gain parameters are as follows.

| Parameter | Command | Description | Type | Default | Unit |
|-----------|---------|--|------------------------------|---------|-------|
| P0-05 | KP | 1st Position Loop Gain | First Gain Parameters Group | 52 | 0.1Hz |
| P0-07 | KD | 1st Position Loop Derivative Time Constant | | 0 | ms |
| P0-08 | KE | 1st Position Loop Derivative Filter | | 20000 | 0.1Hz |
| P0-11 | KF | 1st Velocity Command Gain | | 10000 | 0.01% |
| P0-12 | VP | 1st Velocity Loop Gain | | 183 | 0.1Hz |
| P0-13 | VI | 1st Velocity Loop Integral Time Constant | | 189 | ms |
| P0-16 | KC | 1st Torque Command Filter | | 1099 | 0.1Hz |
| P0-17 | UP | 2nd Position Loop Gain | Second Gain Parameters Group | 52 | 0.1Hz |
| P0-19 | UD | 2nd Position Loop Derivative Time Constant | | 0 | ms |
| P0-20 | UE | 2nd Position Loop Derivative Filter | | 20000 | 0.1Hz |
| P0-21 | UF | 2nd Velocity Command Gain | | 10000 | 0.01% |
| P0-22 | UV | 2nd Velocity Loop Gain | | 183 | 0.1Hz |
| P0-23 | UG | 2nd Velocity Loop Integral Time Constant | | 189 | ms |
| P0-24 | UC | 2nd Torque Command Filter | | 1099 | 0.1Hz |

B) P1-03 = 2-----Speed control only

In this control type, position error will not be detected, and no alarm will be occurred even if the motor stalled.

The speed loop gain parameters are set by P0-12 and P0-13.

| Parameter | Command | Description | Unit | Range | Default |
|-----------|---------|--|-------|---------|---------|
| P0-12 | VP | 1st Velocity Loop Gain | 0.1Hz | 0~30000 | 515 |
| P0-13 | VI | 1st Velocity Loop Integral Time Constant | ms | 0~32767 | 79 |

7.3.10 Using Luna Software to Configure Speed Control Mode

The speed control mode can be easily configured using the Luna software.

Step 1: Select Control Mode

The screenshot shows the 'Control Mode [No Name (Offline)]' window. The 'Control Mode' dropdown is set to 'Analog Velocity'. Under 'Analog Velocity Mode', the 'Velocity Limit Settings' are configured as follows:

- Source: Analog Velocity Command
- Range: ± 10V
- Speed Scale(P4-01): 50 rev/sec at +10V
- Offset(P4-03): 10 mV (Auto Offset button is present)
- Deadband(P4-05): 20 mV

The 'Analog Input 1 Filter(P4-07)' is set to 1000 0.1Hz. A 'Torque Limit Settings' button is also visible. To the right, a graph plots 'Actual Velocity' against 'Voltage'. The voltage ranges from -10V to +10V. The graph shows a linear increase in velocity with voltage, with a deadband region around 0V and an offset region. Labels include 'Actual Velocity', 'Ain', 'Deadband', and 'Offset'.

Step 2: Set Smoothing Filter

The screenshot shows the 'Smoothing Filter [No Name (Offline)]' window. The 'Jerk Filter(P2-28)' is set to 20 ms (0 = not used) and is noted to 'Take effect in speed mode'. Below this is a graph of 'Speed' vs 'Time' showing a smooth S-curve transition between velocity levels V_c , $V_c \times 0.632$, and $V_c \times 0.368$. The 'S-Curve' section has 'Jerk Time(P2-05)' set to 10 ms (0 = not used) and 'Interpolation Filter(P2-29)' set to 10 ms (0 = not used), both noted to 'Take effect in speed mode'. A second graph shows a trapezoidal speed profile with 'T' indicating the transition time, labeled as 'T = S-Curve Filter'.

Step 3: Input and Output Configurations


The screenshot shows the 'Digital I/O' configuration window. It features a table for configuring digital inputs and outputs. The 'Digital Input' section is expanded, showing the following configuration:

| Status Name | Function | Input Filter | Pin |
|-------------|-------------------------------|---------------|--------|
| X1 | CCW Limit | FI [Not Used] | CN2-8 |
| X2 | CW Limit | FI [Not Used] | CN2-9 |
| X3 | Zero Speed Clamp | FI [Not Used] | CN2-26 |
| X4 | Emergency Stop | FI [Not Used] | CN2-27 |
| X5 | Internal Speed Select Input 1 | FI [Not Used] | CN2-28 |
| X6 | Servo Enable | FI [Not Used] | CN2-29 |
| X7 | Internal Speed Select Input 2 | FI [Not Used] | CN2-30 |
| X8 | Alarm Reset | FI [Not Used] | CN2-31 |
| X9 | Control Mode Select | FI [Not Used] | CN2-32 |
| X10 | Internal Speed Select Input 3 | FI [Not Used] | CN2-33 |


Legend: ● = Closed(C) ○ = Open(O)

Step 4: Position Limit and Torque Limit Configuration

The torque limit function can also be used in speed mode. If an absolute encoder is used, the soft limit function can be used.



Step 5: Gain Tuning



7.4 Torque Mode


7.4.1 Torque Control Mode Instructions

Torque control mode is used for precise torque control. There are two torque control mode in M56S series: Analog Torque Mode and Command Torque Mode.

- 1) Analog Torque Mode: -10 ~ +10Vdc external analog voltage input to control the motor torque.
- 2) Command Torque Mode: Use Q program commands to control the motor torque, or use Modbus commands to control the motor torque.

| Control Mode | Control Signal | P1-00 | Instructions |
|---------------------|---------------------------------------|-------|---|
| Analog Torque Mode | +10~-10V Analog input | 2 | ◆ Analog speed mode |
| Command Torque Mode | Q program commands or Modbus commands | 1 | ◆ Q program commands ◆ Modbus communications control |

7.4.2 Wiring Diagram of Torque Control Mode



7.4.3 Related Parameters to Analog Torque Control

There are two -10 ~ +10Vdc analog inputs with 12bit resolution, each can be set low-pass filter, Offset, Deadband, etc.

AIN1 is used as speed reference and AIN2 is used as torque reference,

| Parameters | Command | Description | Range | Default | Unit | Instructions |
|------------|---------|-------------------------------|----------------|---------|-------|--|
| P1-00 | CM | Main Control Mode | 1,2,7,11,15,21 | 7 | | The first control mode selection of the driver |
| P1-01 | CN | Secondary Control Mode | 1,2,7,11,15,21 | 21 | | The second control mode selection of the driver |
| P1-03 | JM | Speed Control Clamp Mode | 1-2 | 2 | | Select the control type for speed mode |
| P4-01 | AG | Analog Input Velocity Scale | 0 ~ 100 | 50 | Rps | Scale factor value for motor speed and analog input. (Set corresponding motor speed when the analog input voltage is 10VDC). |
| P4-02 | AN | Analog Input Torque Scale | 0 ~ 3000 | 1000 | 0.1% | Scale factor value for motor torque and analog input. (Set corresponding motor torque when the analog input voltage is 10VDC) |
| P4-03 | AV1 | Analog Input 1 Offset | -10000 ~ 10000 | 0 | mV | The offset of analog input 1. |
| P4-04 | AV2 | Analog Input 2 Offset | -10000 ~ 10000 | 0 | mV | The offset of analog input 2. |
| P4-05 | AD1 | Analog Input 1 Deadband | 0 ~ 255 | 0 | mV | The deadband of analog input 1. |
| P4-06 | AD2 | Analog Input 2 Deadband | 0 ~ 255 | 0 | mV | The deadband of analog input 2. |
| P4-07 | AF1 | Analog Input 1 Filter | 0 ~ 20000 | 1000 | 0.1Hz | Low-pass filter for analog input 1 |
| P4-08 | AF2 | Analog Input 2 Filter | 0 ~ 20000 | 1000 | 0.1Hz | Low-pass filter for analog input 2 |
| P4-11 | FA1 | Velocity Limit Source Setting | 0 ~ 2 | 0 | | The source of velocity limit command. |
| P2-03 | JA | Jog Acceleration | 0.167 ~ 5000 | 100 | rps/s | The acceleration in internal speed control mode and analog speed mode. |
| P2-04 | JL | Jog Deceleration | 0.167 ~ 5000 | 100 | rps/s | The deceleration in internal speed control mode and analog speed mode. |

Note:


1. The parameter unit is the unit shown in software, it will be different when the parameter is shown in LED display on the drive.
2. The default values of different drive are not same.

7.4.4 Analog Torque Mode Settings

When the control mode of torque mode is selected as analog control, i.e. P1-00=2. It is necessary to make relevant settings for analog input.


7.4.4.1 Wiring Methods of Analog Torque Command Input

| Signal Type | Signals | Pin No. | Description |
|-------------|---------|---------|-----------------------------|
| Input | AIN2 | 18 | Analog torque command input |
| | DGND | 15, 17 | GND of analog input |




7.4.4.2 Analog Torque Scale

The range of analog input is 10~-+10VDC, P4-02 set the corresponding motor output torque when analog input voltage is at 10VDC.



| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|---------------------------|----------|---------|------|--|
| P4-02 | AN | Analog Input Torque Scale | 0 ~ 3000 | 1000 | 0.1% | Set corresponding motor output torque when the voltage of analog input 2 is 10VDC. |

Software Settings



Torque Limit Settings

- Source: Analog Input 2
- Range: ± 10V
- Torque Scale(P4-02): 1000 (0.1% at +10V)**
- Offset(P4-04): 0 mV (Auto Offset)
- Deadband(P4-06): 0 mV

Analog Input 2 Filter(P4-08)


- 1000 0.1Hz

Velocity Limit Settings

- Source: General Purpose
- Range: ± 10V
- Speed Scale(P4-01): 50 rev/sec at +10V
- Offset(P4-03): 0 mV (Auto Offset)
- Deadband(P4-05): 0 mV
- Velocity Limit(P2-30): 80.000 rps

Analog Input 1 Filter(P4-07)


- 1000 0.1Hz



7.4.4.3 Analog Input Offset

When using the analog speed mode, the servo motor may rotate slightly in some cases even if the input analog command is at 0 voltage. This is because there is a slight drift when analog signal is received by drive.


The parameter P4-03 and P4-04 are used to eliminate this situation. You can use the Luna software to automatically adjust the offset or manually modify these parameters.



| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|-----------------------|------|----------------|---------|-------------------------------|
| P4-03 | AV1 | Analog Input 1 Offset | mV | -10000 ~ 10000 | 0 | The offset of analog input 1. |
| P4-04 | AV2 | Analog Input 2 Offset | mV | -10000 ~ 10000 | 0 | The offset of analog input 2. |

The M56Sseries provides two methods of automatically adjust the analog offset.


1) Automatic Adjust by Software



2) Adjust by LED Operation Panel

In the function mode, select the F06AZ function code to set the offset of analog input 1 and analog input 2 at the same time.

Related operations are as follows. For more details, refer to [Chapter 5.5 Function Mode](#).




Note: When performing automatic adjustment:

- ◆ The servo system should be disabled.
- ◆ The analog command of the host controller outputs 0 voltage.

7.4.4.4 Analog Input Deadband

In analog control mode, due to some disturbances and other reasons, even if the command voltage is 0V, the input voltage on the drive side may be not absolutely zero, which makes the motor rotate at a very low speed. In order to eliminate this situation, setting a reasonable deadband can ensure that when the input voltage is within the deadband, it is regarded as 0V.



The analog input deadband can be set P4-05 and P4-06.

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|-------------------------|------|---------|---------|---------------------------------|
| P4-05 | AD1 | Analog Input 1 Deadband | mV | 0 ~ 255 | 0 | The deadband of analog input 1. |
| P4-06 | AD2 | Analog Input 2 Deadband | mV | 0 ~ 255 | 0 | The deadband of analog input 2. |

Set by Luna Software

The screenshot shows the Luna Software interface for 'Control Mode [No Name (Offline)]'. The 'Control Mode' is set to 'Analog Velocity'. Under 'Analog Velocity Mode', the 'Velocity Limit Settings' are visible. The 'Source' is 'Analog Velocity Command', 'Range' is '± 10V', 'Speed Scale(P4-01)' is '50 rev/sec at +10V', and 'Offset(P4-03)' is '-100 mV'. The 'Deadband(P4-05)' is set to '40 mV' and is highlighted with a red box. Below this, the 'Analog Input 1 Filter(P4-07)' is set to '1000 0.1Hz'. To the right, a graph shows 'Actual Velocity' vs 'Voltage' from -10V to 10V. The graph shows a red line for the velocity command that is zero within a 'Deadband' region around 0V. The 'Actual Velocity' is shown as a dashed line that follows the command but is zero during the deadband.

7.4.4.5 Analog Input Filter

In analog control mode, due to external interference, the analog voltage may fluctuate, which will cause the fluctuation of the motor speed or the torque output, which will affect the control accuracy.

The analog input filter is a low-pass filter which is used to eliminate this fluctuation.


| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|-----------------------|-------|-----------|---------|------------------------------------|
| P4-07 | AF1 | Analog Input 1 Filter | 0.1Hz | 0 ~ 20000 | 1000 | Low-pass filter for analog input 1 |
| P4-08 | AF2 | Analog Input 2 Filter | 0.1Hz | 0 ~ 20000 | 1000 | Low-pass filter for analog input 2 |

Note:

If the set value is too small, the response to the speed command will be reduced.

7.4.4.6 Acceleration Smoothing For Analog Speed Control

Analog commands are generally step signals, for example, the analog input voltage changes from 1V to 5V, which can easily cause equipment vibration when motor speed changes. Acceleration smoothing filtering is to smooth the step speed command, that is, to control the acceleration and deceleration when target speed changes.



Parameters P2-03 and P2-04 set acceleration and deceleration in analog speed control mode.

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|------------------|-------|--------------|---------|--|
| P2-03 | JA | Jog Acceleration | rps/s | 0.167 ~ 5000 | 100 | The acceleration in internal speed control mode and analog speed mode. |
| P2-04 | JL | Jog Deceleration | rps/s | 0.167 ~ 5000 | 100 | The deceleration in internal speed control mode and analog speed mode. |

Note: To check or to change this value from drive operation panel, please calculate according to the following formula.

$$\text{LED Display value} = \underline{V} \times 6$$

Where \underline{V} is the acceleration or deceleration to be set in rps/s

7.4.5 Speed Limit in Torque Control Mode


In torque mode, when the load connected to the motor is small but the torque command is too large, the motor may accelerate to a very high speed if the motor output speed is not limited, which may cause unexpected situations. Therefore it is necessary to set a maximum motor speed in torque mode. The motor actual speed will be limited within the set value.

7.4.5.1 Speed Limit Source

There are three limit sources in torque control mode.

| Speed Limit Source | Description |
|-----------------------|---|
| Analog Input 1 | Use analog input 1 as the speed limit source, and the corresponding limit speed at 10Vdc is set by parameter P4-01(AG) |
| Internal Speed Limits | There are two internal speed limits: 1. Directly limited by parameter P2-30(VT) 2. If the digital input function is set as the Speed Limit Input (V-LMT), when the input logic is ON, the speed limit function takes effect, the speed is limited at the value set by P2-02 (JS). |

The mechanism of speed limit sources is shown in the figure below.



Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Description |
|---------------|---------|--|------------|---------|------|--|
| P4-11 | FA | Velocity Limit Setting of Torque Control | 0 ~ 1 | 0 | | Speed limit source: 0: Internal Speed command 1: Analog Input 1 |
| P4-01 | AG | Analog Input Velocity Scale | 0 ~ 100 | 50 | rps | Analog input speed scaling. In torque mode, when the analog input 1 is used as the speed limit source, this parameter corresponds to the speed limit value at 10Vdc |
| P2-30 | VT | Velocity Limit in Torque Control | 0 ~ 100 | 50 | rps | In torque mode, when the internal speed limit is used as the speed limit source, this parameter is used as the speed limit value |
| P2-02 | JS | Jog Velocity | -100 ~ 100 | 10 | rps | If the digital input function is set as the Speed Limit Input (V-LMT), when the input logic is ON, the speed limit function takes effect, the speed is limited at the value set by P2-02 (JS). |
| P5-00 至 P5-09 | MU1~MUA | Digital Input Function | 37 ~ 38 | | | Set the function of digital input X1 to X10 as "Speed Limit Input" |
| P5-12 至 P5-17 | MO1~MO6 | Digital Output Function | 21 ~ 22 | | | Set the function of digital output Y1 to Y6 as "Speed Limit Output" |


Note: To check or to change the value of P4-01\P2-30\P2-02 from drive operation panel, please calculate according to the following formula.

$$\text{LED Display value} = \frac{V}{240} \times 240$$

Where V is the speed to be set in rps(revolution per second)

1) Seed Limit Source----Analog Input 1(P4-11 = 1)


When the parameter P4-11 is set to 1, the analog input 1 is used as the speed limit source, the corresponding speed limit value at 10V is set by parameter P4-01 (AG).



2) Seed Limit Source----Internal Speed Command(P4-11 = 0)


A) Directly limited by P2-30

When P4-11 is set to 0, parameter P2-30 is used as the speed limit in torque mode.



B) Speed Limit Input(V-LMT)

If the digital input function is set as the Speed Limit Input (V-LMT), when the input logic is ON, the speed limit function takes effect, the speed is limited at the value set by P2-02 (JS)




◆ V-LMT configuration

To use Speed Limit Input function, one of digital inputs needs to be assigned this function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|---|
| Input | V-LMT | 37 | Closed | V-LMT will be in effect when the input is CLOSED. |
| | | | Open | V-LMT will be no effect when the input is OPEN. |
| | | 38 | Open | V-LMT will be in effect when the input is OPEN. |
| | | | Closed | V-LMT will be no effect when the input is CLOSED. |

7.4.5.2 How to Set by Luna Software



7.4.6 Speed Limited Output(V-LTD)

V-LTD, speed limited output signal, indicates that the motor speed is limited.

Related Parameter

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|---|
| Output | V-LMT | 21 | Closed | When the motor output speed is limited, the V-LTD signal will output, and the output state is CLOSED. |
| | | | Open | When the motor output speed is NOT limited, the V-LTD signal will NOT output, and the output state is OPEN. |
| | | 22 | Open | When the motor output speed is limited, the V-LTD signal will output, and the output state is OPEN. |
| | | | Closed | When the motor output speed is NOT limited, the V-LTD signal will NOT output, and the output state is CLOSED. |

7.4.7 Torque Reach Output

When the absolute value of the actual motor output torque exceeds the set value of P1-07(Target Torque Value when Torque Value Reached), and the torque fluctuation is within the range of P5-45, the torque reach signal TQ-REACH will be output.


If the actual motor output torque doesn't exceed or is lower than P1-07, the TQ-REACH signal will not output.

This function is applicable in all control modes, such as position mode, speed mode, torque mode, etc.

◆ TQ-REACH signal configuration

To use Torque Reach Output(TQ-REACH), one of digital outputs needs to be assigned this function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | TQ-REACH | 13 | Closed | When Torque Reach Output judgment condition is met, the TQ-REACH signal will output, and the output state is CLOSED. |
| | | | Open | When Torque Reach Output judgment condition is NOT met, the TQ-REACH signal will NOT output, and the output state is OPEN. |
| | | 14 | Open | When Torque Reach Output judgment condition is met, the TQ-REACH signal will output, and the output state is OPEN. |
| | | | Closed | When Torque Reach Output judgment condition is NOT met, the TQ-REACH signal will NOT output, and the output state is CLOSED. |



Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|---|--------|---------|------|--|
| P1-07 | CV | Target Torque Value when Torque Value Reached | 0~3000 | 0 | 0.1% | When the actual motor output torque exceeds the P1-07 and the torque fluctuation is within the range of P5-45, the TQ-REACH signal will be output. |
| P5-45 | TV | Torque Reach Width | 0~3000 | 10 | 0.1% | |

7.4.8 Torque Coincidence Output


In torque mode, when the difference between the filtered motor actual output torque and the torque command, that is, the torque error is within the range of P5-45 (Torque Reach Width), and the duration time meets the set value of P5-40 (Time Constant of Motion Output Condition), then the Torque Coincidence signal T-COIN is output.

If the torque error exceeds the set value of P5-45, T-COIN will not output.

◆ T-COIN signal configuration

To use Torque Coincidence Output(T-COIN), one of digital outputs needs to be assigned this function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | T-COIN | 35 | Closed | When Torque Coincidence output judgment condition is met, the T-COIN signal will output, and the output state is CLOSED. |
| | | | Open | When Torque Coincidence output judgment condition is NOT met, the T-COIN signal will NOT output, and the output state is OPEN. |
| | | 36 | Open | When Torque Coincidence output judgment condition is met, the T-COIN signal will output, and the output state is OPEN. |
| | | | Closed | When Torque Coincidence output judgment condition is NOT met, the T-COIN signal will NOT output, and the output state is CLOSED. |



Related Parameters

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|--|------|-----------|---------|---|
| P5-45 | TV | Torque Reach Width | 0.1% | 0 ~ 3000 | 10 | T-COIN will output when the torque error is within the range of P5-45 and the duration time meets the set value of P5-40. |
| P5-40 | PE | Time Constant of Motion Output Condition | ms | 0 ~ 32000 | 10 | |

7.4.9 Using Luna Software to Configure Torque Control Mode


The torque control mode can be easily configured using the Luna software.

Step 1: Select Control Mode


Select control mode and set related parameters.

Step 2: Set Smoothing Filter


Step 3: Input and Output Configurations



Step 4: Speed Limit Settings



Step 5: Gain Tuning



7.5 Torque Limit

Torque Limit Function is used to limit the motor output torque. This function is applicable in all control modes, such as Position Control, Speed Control and Torque Control, etc.

7.5.1 Torque Limit Methods

Parameter P1-10 defines 6 kinds of torque limit methods which are shown as follows.

| P1-10 Torque Limit Method | Positive Torque Limit Source | Negative Torque Limit Source |
|---------------------------|--------------------------------|--------------------------------|
| 0 | Register [Y] | Register [Z] |
| 1 (Default) | Parameter P1-06 | |
| 2 | Parameter P1-06 | Parameter P1-25 |
| 3 | TQ-LMT input is valid: P1-06 | |
| | TQ-LMT input is invalid: P1-25 | |
| 4 | Analog input 2(AIN2) | |
| 5 | TQ-LMT input is valid: P1-06 | TQ-LMT input is valid: P1-25 |
| | TQ-LMT input is invalid: P1-26 | TQ-LMT input is invalid: P1-27 |

Related Parameters

| Parameter | Command | Description | Unit | Range | Default | Instructions | |
|-----------|---------|---------------------------|------|--------------|---------|--------------|--|
| P1-10 | LD | Torque Limit Method | | 0 ~ 6 | 0 | - | Torque limit method. |
| P1-06 | CC | 1st Torque Limit | | 0~3000 | 3000 | 0.1% | Set up the first limit value of the motor output torque. |
| P1-25 | CX | 2nd Torque Limit | | 0~3000 | 3000 | 0.1% | Set up the second limit value of the motor output torque. |
| P1-26 | CY | 3rd Torque Limit | | 0~3000 | 3000 | 0.1% | Set up the third limit value of the motor output torque. |
| P1-27 | CZ | 4th Torque Limit | | 0~3000 | 3000 | 0.1% | Set up the fourth limit value of the motor output torque. |
| P4-02 | AN | Analog Input Torque Scale | | -3000 ~ 3000 | 1000 | 0.1% | Set the motor output torque when analog input voltage is at 10Vdc. |

7.5.2 Torque Limit Sources

7.5.2.1 Limited by Registers

There are some registers in M56S servo system.

When P1-10 = 0, the positive direction torque limit is set by register [Y], and the negative torque limit is set by register [Z]. The values of these two registers can be set by communication and take effect in real time.


| Torque limit is not enabled | Enable the torque limit |
|---|--|
| <p>Motor Max. Torque</p> <p>Time</p> <p>Motor Max. Torque</p> | <p>Motor Max. Torque</p> <p>Register [Y]</p> <p>- Register [Z]</p> <p>Motor Max. Torque</p> <p>Time</p> |
| Torque limit function is not enabled, the motor can output upto the motor maximum torque. | When P1-10 = 0, the positive direction torque limit is set by register [Y], and the negative torque limit is set by register [Z] |

7.5.2.2 Limited by Parameter P1-06 in both Direction

When P1-10 = 1, the positive direction torque and the negative torque is limited by P1-06.

Related Parameters

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|------------------|--------|-------|---------|---|
| P1-06 | CC | 1st Torque Limit | 0~3000 | 3000 | 0.1% | Set up the first limit value of the motor output torque |




7.5.2.3 Positive and Negative Direction are limited by different parameters

When P1-10 = 2, the positive direction torque is limited by P1-06, and the negative torque is limited by P1-25.

Related Parameters

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|------------------|--------|-------|---------|---|
| P1-06 | CC | 1st Torque Limit | 0~3000 | 3000 | 0.1% | Set up the first limit value of the motor output torque. |
| P1-25 | CX | 2nd Torque Limit | 0~3000 | 3000 | 0.1% | Set up the second limit value of the motor output torque. |




7.5.2.4 Limited by Digital Input---Method One

When P1-10 = 3, the positive and negative torque limit is determined by the input logic state of Torque Limit Input function(TQ-LMT).

- ◆ When the TQ-LMT input is VALID, the positive and negative direction torque is limited by the set value of P1-06.
- ◆ When the TQ-LMT input is INVALID, the positive and negative direction torque is limited by the set value of P1-25.

Related Parameters

| Parameter | Command | Description | Unit | Range | Default | Instructions |
|-----------|---------|------------------|--------|-------|---------|---|
| P1-06 | CC | 1st Torque Limit | 0~3000 | 3000 | 0.1% | Set up the first limit value of the motor output torque. |
| P1-25 | CX | 2nd Torque Limit | 0~3000 | 3000 | 0.1% | Set up the second limit value of the motor output torque. |



7.5.2.5 Limited by Analog Input 2


When P1-10 = 4, the positive and negative torque are limited by the voltage of analog input 2.

Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|---------------------------|----------|---------|------|--|
| P4-02 | AN | Analog Input Torque Scale | 0 ~ 3000 | 1000 | 0.1% | Set corresponding motor output torque when the voltage of analog input 2 is 10VDC. |

Note:

- ◆ When the analog input voltage is negative, take the absolute value as the torque limit.




7.5.2.6 Limited by Digital Input---Method Two

When P1-10 = 5, the positive and negative torque limit is determined by the input logic state of Torque Limit Input function(TQ-LMT).

- ◆ When the TQ-LMT input is VALID, the positive direction torque is limited by the set value of P1-06, and negative direction torque is limited by the set value of P1-25.
- ◆ When the TQ-LMT input is INVALID, the positive direction torque is limited by the set value of P1-26, and negative direction torque is limited by the set value of P1-27.

| Parameter | Command | Description | Unit | Range | Default | Instructions | |
|-----------|---------|------------------|------|--------|---------|--------------|---|
| P1-06 | CC | 1st Torque Limit | | 0~3000 | 3000 | 0.1% | Set up the first limit value of the motor output torque. |
| P1-25 | CX | 2nd Torque Limit | | 0~3000 | 3000 | 0.1% | Set up the second limit value of the motor output torque. |
| P1-26 | CY | 3rd Torque Limit | | 0~3000 | 3000 | 0.1% | Set up the third limit value of the motor output torque. |
| P1-27 | CZ | 4th Torque Limit | | 0~3000 | 3000 | 0.1% | Set up the fourth limit value of the motor output torque. |



7.5.3 Torque Limited Output(T-LMT)

The T-LMT output signal shows that the motor output torque is being limited.

To use Torque Limited Output(T-LMT), one of digital outputs needs to be assigned this function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Output | T-LMT | 15 | Closed | When the motor output torque is being limited, the T-LMT signal will output, and the output state is CLOSED. |
| | | | Open | When the motor output torque is NOT limited, the T-LMT signal will NOT output, and the output state is OPEN. |
| | | 16 | Open | When the motor output torque is being limited, the T-LMT signal will output, and the output state is OPEN. |
| | | | Closed | When the motor output torque is NOT limited, the T-LMT signal will NOT output, and the output state is CLOSED. |

7.6 Encoder/Pulse Divided Output

Encoder/Pulse Divided Output is a function that output the position information feedback by the encoder and the external position pulse command in a A/B quadrature line driver mode.


Related Parameters

| Parameter | Command | Description | Range | |
|-----------|---------|--|--------------|--|
| P3-12 | PO | Pulses Output Mode | 0 ~ 256 | Pulse output settings |
| P3-13 | ON | Pulses Output Gear Ratio - Numerator | 0 ~ 13107200 | Set the numerator of pulse output division ratio |
| P3-14 | OD | Pulses Output Gear Ratio - Denominator | 0 ~ 13107200 | Set the denominator of pulse output division ratio |

7.6.1 Pin Numbers of Pulse Output Function

| CN2-Pin No. | Signals | Description | Connecting Method |
|-------------------|---------|--|---------------------------------------|
| 21 | AOUT+ | The position feedback informations of the encoder are output differentially in A,B and Z signals. The number of pulses per revolution and frequency division ratio of pulse output can be set by parameters. | Refer to Chaper 4.9.8 |
| 22 | AOUT- | | |
| 48 | BOUT+ | | |
| 49 | BOUT- | | |
| 23 | ZOUT+ | | |
| 24 | ZOUT- | | |
| 19 | OCZ | | |
| 13,14 15,17,25 | DGND | Digital ground. | |

◆ Example of A/B/Z differential signal connection



Note:

1. The output circuits are line-driver output, the line-receiver circuits are recommended in the host controller. A differential to single-ended conversion board is needed is the host does not support differential signals. Do not connect directly the OUT+ to power+ or connect OUT- to ground.
2. Twisted shielded wires are recommended for well anti-interference. The shielding must be connected to PE, and the both digital ground of servo drive and host should be connected together.
3. The outputs are 5V differential signals, maximum output current is 20mA.

7.6.2 Pulse Divided Output Settings.

Parameter P3-12 is used to set the pulse output source, pulse output phase logic, Z pulse output polarity, and division ratio.

The corresponding functions to each bit are as follows.

| P3-12 Pulse output settings | | | | | | | |
|---|------|------|------|-------------------------|--------------------------|--|------|
| bit7 | bit6 | bit5 | bit4 | bit3 | bit2 | bit1 | bit0 |
| 0 | 0 | 0 | 0 | Z pulse output polarity | Pulse output phase logic | Pulse output source | |
| | | | | 0: Rasing edge | 0: Phase A leads Phase B | bit1=0,bit0=1: Main Encoder feedback | |
| | | | | 1: Falling edge | 1: Phase B leads Phase A | bit1=1,bit0=0: Second Encoder feedback | |
| bit1=1,bit0=1: External pulse command | | | | | | | |
| bit0 and bit1: Pulse output source bit2: Pulse output phase logic bit3: Z pulse output polarity | | | | | | | |

Note:

When set this parameter from the LED operation panel and software, it needs to be converted into decimal.

7.6.2.1 Pulse Output Source

The pulse divided output function supports the following three signal sources. The bit0 and bit1 of parameter P3-12 are used to select signal sources.

bit1=0,bit0=1: Main Encoder feedback

bit1=1,bit0=0: Second Encoder feedback, full closed-loop encoder feedback

bit1=1,bit0=1: External pulse position command(By pass)

Note:

When the signal source is external pulse command, the setting of parameter P3-13 and parameter P3-14 are invalid, and the external command pulse is directly output by-pass. The setting of bit2 and bit3 of P3-12 will also be invalid.

7.6.2.2 Pulse Output Settings

| Z pulse output polarity | Pulse output phase logic | Pulse output source | | Positive Direction | Negative Direction | P3-12 Set Value (Decimal) | |
|-------------------------|--------------------------|---------------------|------|----------------------|--------------------|---------------------------|------|
| | | bit3 | bit2 | | | | bit1 |
| 0 | 0 | 0 | 1 | Main encoder | | 1 | |
| 0 | 1 | 0 | 1 | Main encoder | | 5 | |
| 1 | 0 | 0 | 1 | Main encoder | | 9 | |
| 1 | 1 | 0 | 1 | Main encoder | | 13 | |
| 0 | 0 | 1 | 0 | Second encoder | | 2 | |
| 0 | 1 | 1 | 0 | Second encoder | | 6 | |
| 1 | 0 | 1 | 0 | Second encoder | | 10 | |
| 1 | 1 | 1 | 0 | Second encoder | | 14 | |
| Any set | Any set | 1 | 1 | External pulse input | By pass | By pass | 3 |

7.6.3 Pulse Output Gear Ratio

When the pulse output source is the motor encoder or second encoder, some applications where the number of output pulses per one motor revolution is not an integer, you can set the output gear ratio.

Output counts per motor revolution(A and B are converted into 4 times the frequency.)

$$\frac{\text{P3-13 Pulses Output Gear Ratio - Numerator}}{\text{P3-14 Pulses Output Gear Ratio - Denominator}} \times 131072$$

Related Parameters

| Parameter | Command | Description | Range | Default | |
|-----------|---------|--|--------------|---------|--|
| P3-13 | ON | Pulses Output Gear Ratio - Numerator | 0 ~ 13107200 | 10000 | Set the numerator of pulse output division ratio |
| P3-14 | OD | Pulses Output Gear Ratio - Denominator | 0 ~ 13107200 | 131072 | Set the denominator of pulse output division ratio |

Note:

- 1). **P3-13 should be smaller than P3-14.**
- 2). **When P3-13 is larger than P3-14, output pulse counts per motor revolution is set by P3-13.**

For example: If you need to output 1000 pulses per revolution.

- 1). If you count A/B at the same time, and the frequency is 4 times.

Then: P3-13 = 1000

$$\text{P3-14} = 131072 \text{ or } \text{P3-14} = 1$$

- 2). If you count A/B at the same time, and only count the rising edge or the falling edge when counting.

Then: P3-13 = 2000

$$\text{P3-14} = 131072 \text{ or } \text{P3-14} = 1$$

- 3). If you only count the output of phase A, and only count the rising edge or the falling edge when counting.

Then: P3-13 = 4000

$$\text{P3-14} = 131072 \text{ or } \text{P3-14} = 1$$

7.7 Analog Output

The data to be monitored can be output as a voltage signal through the analog output function. M56S series servo drive provides two analog output channels. Maximum output capacity is 7mA and the output voltage is -10 ~ +10V.

Related Parameters

| Parameter | Command | Description | Range | Default | Description |
|-----------|---------|--------------------------|-----------|---------|--|
| P4-16 | OS1 | Analog Output 1 Scale | 1 ~ 32000 | 1000 | Output scale for analog output 1. The values of speed, torque, position error, etc. corresponding to the analog output at 10V can be set. |
| P4-17 | OS2 | Analog Output 2 Scale | 1 ~ 32000 | 1000 | Output scale for analog output 2. The values of speed, torque, position error, etc. corresponding to the analog output at 10V can be set. |
| P4-18 | XA1 | Analog Output 1 Function | 0 ~ 5 | 0 | Function definition of analog output 1: 0: As a general-purpose voltage output. 1: As the motor actual output current, unit: 0.1% 2: As the motor command current, unit: 0.1% 3: As the motor actual output speed, unit: 0.25 rpm 4: As the motor command speed, unit: 0.25 rpm 5: As counts of position following error, unit: counts |
| P4-19 | XA2 | Analog Output 2 Function | 0 ~ 5 | 0 | Function definition of analog output 2: 0: As a general-purpose voltage output. 1: As the motor actual output current, unit: 0.1% 2: As the motor command current, unit: 0.1% 3: As the motor actual output speed, unit: 0.25 rpm 4: As the motor command speed, unit: 0.25 rpm 5: As counts of position following error, unit: counts |

Setting Example:

Use analog output 1 to monitor the motor actual speed, the speed range is -3000rpm to 3000rpm and the output voltage is -10 to 10V.

The parameters are set as follows:

P4-16 = 12000

P4-18 = 3

7.7.1 Analog Output Wiring Method

◆ M56S Series-RF Type


Output Specifications:

Voltage: -10 ~ +10V

Maximum output capacity: 8mA

The output impedance is 1 kOhm. Pay an attention to the input impedance of the measuring instrument or the external circuit to be connected.

Wiring Diagram:



7.8 Full Closed-loop Control

High precision positioning is possible with a full closed-loop position control, an external installed encoder is used to detect the position of the controlled machine and the machine's position information is fed back to the servo drive.




Note: Only A/B quadrature incremental encoder is supported in M56S-RT series.

7.8.1 Full Closed-loop Wiring Method

The CN4 connector of M56S-RF series AC servo drive is used to connect the external second encoder.

7.8.1.1 Wiring Diagram



7.8.2 Full Closed-loop Control Gain Tuning

7.8.2.1 Tuning Step of Full Closed-loop Control

Step 1: Complete the parameter settings without turning on the full closed-loop function. For detailed tuning method, please refer to [Chapter 10. Servo Gain Tuning](#).

Step 2: After first step, when the gain tuning is completed, proceed to Chapter 7.8.3 Full Closed-loop Control Setting Steps.

7.8.2.2 Related Gain Parameters in Full Closed-loop Control

In different gain tuning modes, the synergistic parameters to be tuned in full closed-loop control mode are different.

1) The Gain Tuning Mode P0-00 is 0.

P0-00 = 0, the gain Gain Tuning Mode is NO tuning, which means only needs to change the stiffness level of P0-03 or P0-04 in the full closed-loop mode.

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|--------------------------------|--------|---------|------|---|
| P0-03 | KG | 1st Mechanical Stiffness Level | 1 ~ 20 | 5 | - | The first stiffness value of the servo system. |
| P0-04 | KX | 2nd Mechanical Stiffness Level | 1 ~ 20 | 5 | - | The second stiffness value of the servo system. |

2) The Gain tuning Mode P0-00 is 1.

P0-00 = 1, the gain Gain Tuning Mode is Auto-tuning.

Step 1: Complete the load inertia ratio estimating and gain tuning without turning on the full closed-loop function.

Step 2: Enable the full closed-loop control and then only needs to change the stiffness level of P0-03 or P0-04.

Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|--------------------------------|--------|---------|------|---|
| P0-03 | Kg | 1st Mechanical Stiffness Level | 1 ~ 20 | 5 | - | The first stiffness value of the servo system. |
| P0-04 | KX | 2nd Mechanical Stiffness Level | 1 ~ 20 | 5 | - | The second stiffness value of the servo system. |

3) The Gain tuning Mode P0-00 is 2.

P0-00 = 2, the gain Gain Tuning Mode is Fine Tuning, there is a set of independent gain parameters shown as follows in full closed-loop control mode.

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|---|----------------|---------|-------|--|
| P0-25 | XP | Full Closed-loop Position Loop Gain | 0 ~ 20000 | 52 | 0.1Hz | Proportional gain in full closed-loop control mode. The proportional gain of the position loop in the PID control algorithm can improve the system's stiffness and reduce the system error. |
| P0-27 | XD | Full Closed-loop Position Loop Derivative Time Constant | 0 ~ 32767 | 0 | ms | Derivative time constant in full closed-loop control mode. The derivative time constant of position loop in the PID control algorithm. Setting to zero means that derivative function is not used. The smaller setting value will increase derivative gain effect. |
| P0-28 | XE | Full Closed-loop Position Loop Derivative Filter | 0 ~ 40000 | 20000 | 0.1Hz | A low-pass filter for derivative gain. This filter is a single-output low-pass filter, which is used to filter the derivative output of the PID controller. When setting this value, the cutoff frequency needs to be considered |
| P0-29 | XF | Full Closed-loop Velocity Command Gain | -30000 ~ 30000 | 10000 | 0.01% | The percentage of speed command gain of speed loop in full closed-loop control. |

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|---|-----------|---------|-------|---|
| P0-30 | XV | Full Closed-loop Velocity Loop Gain | 0 ~ 30000 | 183 | 0.1Hz | <p>Proportional gain of speed loop in full closed-loop control mode.</p> <p>This parameter determines the responsiveness of speed loop. Higher set value can increase the speed loop responds. If it's set too larger, it may cause vibrations and noise.</p> <p>In the position control mode, the speed loop proportional gain and the position loop proportional gain should be increased both.</p> |
| P0-31 | XG | Full Closed-loop Velocity Loop Integral Time Constant | 0 ~ 30000 | 189 | ms | <p>Integral time constant of speed loop in full closed-loop control mode.</p> <p>The smaller setting value will increase integral gain effect.</p> |
| P0-32 | XC | Full Closed-loop Torque Command Filter | 0 ~ 40000 | 1099 | 0.1Hz | <p>A low-pass filter for the output of PID controller. This filter is a single-output low-pass filter used to filter the output of PID controller, that is the reference current.</p> <p>It's necessary to consider the cutoff frequency required for the whole system.</p> <p>By performing low-pass filtering on the command current, the output current can be made to decelerate and vibrate more smoothly.</p> |

7.8.3 Full Closed-loop Control Setting Steps

After all the operations of Chapter 7.8.2, if the servo system can run normally without full closed-loop control function, the following setting steps can be applied to set the necessary parameters of full closed-loop control.

Step 1: Set the resolution of external second encoder/scale

The resolution of external encoder/scale must be input correctly, otherwise it will cause the full closed-loop following error alarm.

Related Parameter:

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|---------------------------|----------------|---------|--------------------------------|---|
| P3-11 | XR | Second Encoder Resolution | 200 ~ 13107200 | 10000 | pulses/rev pulses/user unit | The resolution of external encoder/scale. |

A) For rotary encoder, enter the resolution of one revolution of the encoder;

B) For linear scale, enter the number of pulses per moving user unit.

Note 1:

The maximum speed under the full closed-loop control is 128 user unit per second, the appropriate resolution and user unit must be set.

For example, the resolution of a linear scale is 0.5 μm .

◆ If the user unit is in mm, when P3-11 is set to 2000, the maximum speed is 128 mm/s

◆ If the user unit is in cm, when P3-11 is set to 20000, the maximum speed is 128 cm/s

Note 2:

In any case, as long as the setting value of P3-11 is changed, the mechanical transmission ratios P3-00 and P3-01 must be reset

Step 2: Set the feedback signal direction of external encoder

The positive rotation direction of the motor is defined as: viewed from the front of the motor when motor shaft rotates clockwise, the motor encoder counter is increased; when the motor shaft rotates counterclockwise, the motor encoder counter is decreased.

In full closed-loop mode, the feedback signal direction of the external second encoder needs to be the same as the direction of the motor encoder. That is, when the motor shaft rotates clockwise, the motor encoder counter is increased and the external second encoder counter must also be increased. Similarly, when the motor shaft rotates counterclockwise, the motor encoder counter is decreased and the external second encoder counter must be decreased.

If not, it needs to be modified with parameter P3-06 (Second Encoder Direction). Or directly swap the wiring of the second encoder's phase A and phase B.

Note: The direction must be set correctly, otherwise a position following error will be caused.

Related Parameter

| Parameter | Command | Description | Range | Default | Instructions |
|-----------|---------|--------------------------|-------|---------|---|
| P3-06 | PV | Second Encoder Direction | 0 ~ 1 | 0 | Define the direction of the second encoder in full closed loop mode:: 0: A Leads B 1: B Leads A |

Use the software or the operation panel on the driver (refer to [Chapter 6.3 JOG mode](#)) to enter the JOG mode. When the motor rotates, use the monitoring page of the Luna software to observe the change of the value of the motor encoder and the second encoder. Or when the motor is disabled, move the load and observe the change of the value through the Luna software.

Step 3: Set the pulses per user unit length (user unit)

In full closed-loop control mode, the electronic gear ratio (P3-00 and P3-01) will be invalid, P3-05(Command Pulses per revolution) will take effect.

Related Parameter

| Parameter | Command | Description | Range | Default | Instructions |
|-----------|---------|-------------------------------|--------------|---------|---|
| P3-05 | EG | Command Pulses per revolution | 200 ~ 131072 | 10000 | Set the number of required command pulses to move each user unit length |

Note:

- The set value of P3-05 must be less than or equal to P3-11 (Second Encoder Resolution).
- If the set value of P3-05 is higher than P3-11, the number of required command pulses to move each user unit length is set by P3-11.

In any case, as long as the setting value of P3-05 is changed, the mechanical transmission ratios P3-00 and P3-01 must be reset.

Setting Example 1:

Linear scale resolution is 1μm,if P3-11 is set to 10000.

- When P3-05 is set to 1000, the mechanical will move 1cm for every 1000 pulses sent by the host.
- When P3-05 is set to 10000, the mechanical will move 1cm for every 10000 pulses sent by the host.
- When P3-05 is set to 20000, the mechanical will move 1cm for every 10000 pulses sent by the host.

Setting Example 2:

Linear scale resolution is 0.5μm,if P3-11 is set to 20000.

- When P3-05 is set to 1000, the mechanical will move 1cm for every 1000 pulses sent by the host.
- When P3-05 is set to 10000, the mechanical will move 1cm for every 10000 pulses sent by the host.
- When P3-05 is set to 20000, the mechanical will move 1cm for every 20000 pulses sent by the host.

Step 4: Set the numerator and denominator of the mechanical transmission ratio

The electronic gear ratio (P3-00 and P3-01) of the system will become the mechanical transmission ratio in the fully closed-loop control mode. The appropriate mechanical transmission ratio must be set otherwise the system will not work normally, and a full closed-loop hybrid deviation excess error will occur.

If the mechanical transmission ratio cannot be determined, the following methods can be used.

$$\frac{P3-00}{P3-01} = \frac{\text{Numerator of transmission ratio in full closed-loop mode}}{\text{Denominator of transmission ratio in full closed-loop mode}}$$

$$= \frac{\text{The number of motor encoder feedback pulses per motor revolution}}{\text{The number of external encoder feedback pulses per motor revolution}}$$


◆ Use Luna software to confirm the mechanical transmission ratio

Method 1:

- 1) Disable the full-closed-loop control function, and make the motor rotate one revolution in Commissioning interface of the software.
- 2) Then check and record the number of Motor Encoder Position and the number of 2nd Encoder Position after the motor rotates once in Monitor interface of the software
- 3) Fill these two numbers into the above formula.

Method 2:

- 1) Disable the full-closed-loop control function and disable the drive
- 2) Make the load move a small distance
- 3) Then check and record the number of Motor Encoder Position and the number of 2nd Encoder Position after the motor rotates once in Monitor interface of the software
- 4) Fill these two numbers into the above formula.



Related Parameter:


| Parameter | Command | Description | Range | Default | Instructions |
|-----------|---------|-------------------------------------|----------------|---------|--|
| P3-00 | EN | Electronic Gear Ratio - Numerator | 1 ~ 2147483647 | 10000 | Numerator of transmission ratio in full closed-loop mode |
| P3-01 | EU | Electronic Gear Ratio - Denominator | 1 ~ 2147483647 | 10000 | Denominator of transmission ratio in full closed-loop mode |

Note:

- The appropriate mechanical transmission ratio must be set otherwise the system will not work normally, vibration and a full closed-loop hybrid deviation excess error will occur.
- If the numerator or denominator of mechanical transmission ratio is set to zero, the servo system will calculate the ratio as 1:1.
- The effective transmission ratio ranges from 1/8192 to 8192. If the actual transmission ratio is greater than 8192, the system automatically calculates the transmission ratio as 8192. If the actual transmission ratio is less than 1/8192, the system automatically calculates the transmission ratio as 1/8192.
- If the transmission ratio is set incorrectly, the deviation between the position value calculated from the motor encoder and the position value calculated from the second encoder will increase, and a full closed-loop hybrid deviation excess error will occur during long-distance motion.

Step 5: Full Closed-loop Hybrid Deviation Error

Set the allowable deviation between the current position of motor encoder and external second encoder, and automatically clear the hybrid deviation whenever the motor's revolutions reaches the set value.



Note:

- The servo motor rotates the number of revolutions set by P3-09, and the hybrid deviation is always less than the set value of P3-10. As the motor reaches the revolutions set by P3-09, the hybrid deviation is cleared to zero and counted again from zero.
- Once hybrid deviation is greater than the set value of P3-10, a full closed-loop hybrid deviation excess error will occur.
- As P3-10 is set to 0 which means the hybrid deviation is not detected.

A. Hybrid Deviation Fault Threshold in full closed-loop control mode

As the deviation between the current position of motor encoder and external second encoder is greater than the set value of P3-10, a full closed-loop hybrid deviation excess error will occur, **r28FP** will display on the drive's LED display panel.

Related Parameter

| Parameter | Command | Description | Range | Default | Instructions |
|-----------|---------|----------------------------------|----------------|---------|---|
| P3-10 | XO | Hybrid Deviation Fault Threshold | 0 ~ 2147483647 | 100000 | Hybrid Deviation Fault Threshold in full closed-loop control mode |

B. Hybrid Deviation Clear Setting

As the motor reaches the revolutions set by P3-09, the hybrid deviation is cleared to zero and counted again from zero.

Related Parameter

| Parameter | Command | Description | Range | Default | Instructions |
|-----------|---------|--------------------------------|----------------|---------|--------------|
| P3-09 | XT | Hybrid Deviation Clear Setting | 0 ~ 2147483647 | 100000 | - |

7.8.4 Enable Full Closed-loop Control Mode

After completing the setting of full closed-loop in Chapter 7.8.3, the full closed-loop control can be enable though parameter P1-04(Full Closed-loop Control Switch).

Related Parameter

| Parameter | Command | Description | Range | Default | Instructions |
|-----------|---------|---------------------------------|-------|---------|---|
| P01-04 | XM | Full Closed-loop Control Switch | 0 ~ 1 | 0 | Full Closed-loop Control 0 = Disable 1 = Enable |

7.8.5 Common Error and Trouble-shooting in Full Closed-loop Control Mode

Common alarms in full closed loop mode are as follows.


| LED Display | Description | Causes | Measures |
|-------------|--|---|---|
| | Full closed-loop hybrid deviation excess error | Full closed-loop hybrid deviation exceeds the threshold. | 1. Check whether the set value of P3-09 and P3-10 are too small. 2. Check whether the CN4 port, external encoder input is correct. Monitor the feedback value of second encoder changes even the motor stopped. |
| | External encoder error | External encoder input error. | Check whether the CN4 port, external encoder input is correct. Check whether the feedback cable connection is correct. |
| | Position following error | The value of position following error exceeds the set value of P3-04. | 1. Check whether the set value of P3-4(Position error limit) is too small. 2. Check whether the gain parameters are properly set. 3. Check whether the motor selection matches the actual load and whether the acceleration and deceleration are too large. 4. Check whether an unreasonable torque limit is used. 5. The electronic gear ratio sets incorrectly. 6. The mechanical part is stuck, the motor is stalled. 7. Check the motor power cable is connected correctly. If there are more than one motor, check whether the cable is connected to the correct servo drive.. |

7.8.5.1 Full Closed-loop Hybrid Deviation excess error

The error code displayed on the drive's LED is

Causes: Full closed-loop hybrid deviation exceeds the threshold which is set by P3-10.

Measures: The set value of P3-10 is too small, this alarm is likely to occur in some applications where the mechanical transmission ratio is relatively large.



Measure steps:

- 1) Click to reset the Encoder Position and 2nd Encoder Position to zero
- 2) Make the motor run the number of turns set by P3-09
- 3) Make sure that the set value of P3-10 is larger than the monitored data of 2nd Encoder Position

7.8.5.2 External Encoder Error

The error code displayed on the drive's LED is

Causes: External encoder input error.

Measures: Check whether the CN4 port, the external encoder input is correct. Check whether the feedback cable connection is correct.

7.8.5.3 Velocity is Limited or Position following error

Anomaly: In full closed-loop control mode, if the pulse command frequency is increased, the motor fails to reach the set speed or generates a position following error alarm. The error code displayed by the drive LED is


Causes: The value of position following error exceeds the set value of P3-04.

Measures: If the operation is normal in non-full-closed-loop mode, only in full closed-loop mode, there is this problem, please focus on confirming whether the resolution of the external second encoder P3-11 are correctly input.

7.9 Dynamic Brake

In the case of abnormal servo OFF, driver fault or sudden power off, etc., the driver can not control the motor normally, and the dynamic brake function can be used as the servo motor stop method. When the dynamic brake is working, the U/V/W three-phase of the motor is short-circuited to make the motor stop at the fastest speed, thereby protecting the safety of equipment and people.

There are build-in dynamic brake in the F type and X type of M56S series.



Note:

1. Dynamic brake is a stop function for servo abnormality. Do not use it to stop normal operation.
2. When the driver control power input is disconnected, the dynamic brake remains in action.
3. When the dynamic brake is activated, do not drive the motor to rotate by external force, otherwise it may damage the dynamic brake circuit and even cause the driver to smoke or catch fire.
4. Frequency and number of times of dynamic brake use

Frequency: more than 5 minutes/1

Time Number: stop from rated speed, 1000 times under the condition of applicable load inertia

7.9.1 Dynamic braking resistor wiring method

For models of 750W and below that support the dynamic braking function, the driver has a built-in dynamic braking resistor and does not need to be connected externally.


For models of 1kW and above that support the dynamic braking function, an external dynamic braking resistor is required.

7.9.1.1 The specifications of the external dynamic brake resistor are as follows:

| | |
|------------|-----------------------------------|
| Resistance | Minimum: 3 ohms, Maximum: 10 ohms |
| Power | >30W |

7.9.1.2 External dynamic brake resistor wiring method

Connect an external dynamic brake resistor to the R1 and R2 pins of the drive power connector.



Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|-----------|---------|---|----------|---------|------|---|
| P5-42 | ZV | Zero Speed Width | 0.1 ~ 2 | 0.5 | rps | As the speed is less than or equal to this set value, it is in the zero speed state. |
| P1-29 | YV | Dynamic Brake Sequence when Servo Off | 0 ~ 5 | 0 | - | Select the action mode of the dynamic brake when the drive state changes from servo-on to servo-off |
| P1-30 | YR | Dynamic Brake Sequence when Fault Occurs | 0 ~ 3 | 0 | - | Select the action mode of the dynamic brake when fault occurs |
| P1-31 | YM | Dynamic Brake Action Time during Deceleration of Servo Off | 0 ~30000 | 500 | ms | Set the maximum working time of the dynamic brake when the servo is OFF. |
| P1-32 | YN | Dynamic Brake Action Time during Deceleration when Fault Occurs | 0 ~30000 | 500 | ms | Set the maximum working time of the dynamic brake when fault occurs. |

7.9.2 Dynamic Brake when Servo-off

When the servo state changes from servo-on to servo-off, the action mode of dynamic brake is set by P1-29 and the maximum braking time is set by P1-31.

The braking time refers to the total time that the motor actual speed deceleates to the threshold speed set by P5-42 when the dynamic brake takes effect.

| P1-29 | Description | |
|-------|--|---------------|
| | Deceleration period | Stopped |
| 0 | Decelerate according to the setting of parameter P2-01 | Free Run |
| 1 | Decelerate according to the setting of parameter P2-01 | Dynamic Brake |
| 2 | Free Run | Free Run |
| 3 | Free Run | Dynamic Brake |
| 4 | Dynamic Brake | Free Run |
| 5 | Dynamic Brake | Dynamic Brake |

7.9.3 Dynamic Brake when Drive Fault Occurs

When the servo fault occurs, the action mode of dynamic brake is set by P1-30 and the maximum braking time is set by P1-31.

| P1-30 | Description | |
|-------|---------------------|---------------|
| | Deceleration period | Stopped |
| 0 | Free Run | Free Run |
| 1 | Free Run | Dynamic Brake |
| 2 | Dynamic Brake | Free Run |
| 3 | Dynamic Brake | Dynamic Brake |

7.10 Homing Mode

In Homing Control Mode, the servo drive generates a motion profile according to the parameters such as homing acceleration/deceleration, velocity, Home Offset etc. Homing mode and the Home sensor signal are set by the controller which also controls execution of the generated motion profile.

The M56S series of AC servo drives supports 39 homing methods.


There are three ways to start homing.

◆ Start with digital input (S-HOM)

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Input | S-HOM | 15 | Closed | When the input logic is ON(CLOSED), Homing starts. |
| | | | Open | When the input logic is OFF(OPEN), Homing dose not start. |
| | | 16 | Open | When the input logic is OFF(OPEN), Homing starts. |
| | | | Closed | When the input logic is ON(CLOSED), Homing dose not start. |

◆ Start with Q program

◆ Start with Modbus Command



Related Parameters

| Parameter | Command | Description | Range | Default | Unit | Instructions |
|---------------|-----------|----------------------------------|---------------------------|---------|--------|---|
| P5-49 | HE | Homing Method | -4 ~ 35 | 1 | - | Set homing method. |
| P2-18 | HA1 | Homing Acceleration/Deceleration | 0.167 ~ 5000 | 100 | rps/s | Set homing acceleration and deceleration. |
| P2-24 | HV1 | Homing Velocity 1 | 0.0042 ~ 100 | 10 | rps | Set the first velocity of seek home. |
| P2-25 | HV2 | Homing Velocity 2 | 0.0042 ~ 100 | 1 | rps | Set the second velocity of seek home. |
| P2-27 | HO | Homing Offset | -2147483647 ~ +2147483647 | 0 | pulses | Set the offset position when homing is finished. |
| P2-00 | VM | Max Velocity | 0 ~ 100 | 80 | rps | Set the maximum speed of motor. |
| P2-01 | AM | Max. Brake Deceleration | 0.167 ~ 5000 | 3000 | rps/s | Set the maximum deceleration for emergence stop. |
| P5-00 ~ P5-09 | MU1 ~ MUA | Digital Input Function | 39 ~ 40 | - | - | Set one of the digital inputs as the home sensor's input. |

7.10.1 Homing Function Instructions

Homing function is used to seek the mechanical home sensor and define the position relationship between the mechanical origin and mechanical zero.


Mechanical Origin: A fixed position on the machine that can be a switch sensor or the index signal of the motor encoder.

Mechanical Zero : The absolute zero position.

When finished the homing operation, the position where the motor stop is the Mechanical Origin. The relationship between Mechanical Origin and Mechanical Zero can be set by parameter P2-27(Homing Offset).

Mechanical Origin = Mechanical Zero + P2-27

When P2-27 is set to zero, the Mechanical Origin coincides with the Mechanical Zero.



H: Seek home sensor speed 1 is set by parameter P2-24.

L: Back to home sensor speed 2 is set by parameter P2-25.

Home Sensor: You can use one of the digital inputs as the home switch sensor.

Positive Limit Switch: You can use one of the digital inputs as the positive limit switch sensor.

Negative Limit Switch: You can use one of the digital inputs as the negative limit switch sensor.

7.10.2 Homing Methods Summary

| Homing Method | Motor Index Pulse | Home Sensor | Limit Switch |
|------------------|-------------------|-------------|--------------|
| Methods -4 & -3 | | | |
| Methods -2 & -1 | √ | | |
| Methods 1 & 2 | √ | | √ |
| Methods 3 to 6 | √ | √ | |
| Methods 7 to 14 | √ | √ | √ |
| Methods 15 & 16 | Reserved | | |
| Methods 17 & 18 | | | √ |
| Methods 19 to 22 | | √ | |
| Methods 23 to 30 | | √ | √ |
| Methods 31 & 32 | Reserved | | |
| Methods 33 & 34 | √ | | |
| Methods 35 | | | |

The homing methods 1~35 are defined in accordance with the CiA402 motion control protocol.


The homing methods -4 ~ -1, AKA Hard-stop Homing, are manufacturer customized methods that don't need external switch sensor. By detecting the torque of the motor during the homing process, when the position that the moving load is blocked by the mechanical hard limit, and the output torque of the motor is equal to the set current threshold, then the motor stops and set the encoder position to zero, this is the mechanical origin.

The current threshold is set by parameter P1-08(Torque Limit for Hard Stop Homing). Set the value of this object according to the actual needs. If the set value is too small, the homing process may fail. Too large value may cause damage to mechanical equipment.

Note:

- ◆ When using homing methods -4~-1, it is necessary to set a suitable homing offset, so that after reaches the mechanical origin, the load could move a small distance away from the mechanical hard limit. This new position is the mechanical zero.
- ◆ When using homing methods 1~35, the actual position after homing finished is the value set by P2-27.


7.10.2.1 Method -4: Start in the negative direction, seek for the negative mechanical hard limit



Start homing at the speed set by P2-24 in the negative direction, when the moving load is blocked by the negative mechanical hard limit, and the output torque of the motor is equal to the set current threshold(P1-08), then the motor stops and sets the encoder position to zero, the whole homing process has finished.

If the Homing Offset(P2-27) is not zero, the motor moves a offset distance set by P2-27.


7.10.2.2 Method -3: Start in the positive direction, seek for the positive mechanical hard limit



Start homing at the speed set by P2-24 in the positive direction, when the moving load is blocked by the positive mechanical hard limit, and the output torque of the motor is equal to the set current threshold(P1-08), then the motor stops and sets the encoder position to zero, the whole homing process has finished.

If the Homing Offset(P2-27) is not zero, the motor moves a offset distance set by P2-27.


7.10.2.3 Method -2: Start in the negative direction, seek for the negative mechanical hard limit and motor index



Start homing at the speed set by P2-24 in the negative direction, when the moving load is blocked by the negative mechanical hard limit, and the output torque of the motor is equal to the set current threshold(P1-08), then the motor stops and turns back at the speed set by P2-25 for seeking encoder's index signal. The motor will stop and set encoder position to zero till the first rising edge of index signal is detected, the whole homing process has finished after that.

If the Homing Offset(P2-27) is not zero, the motor moves a offset distance set by P2-27.


7.10.2.4 Method -1: Start in the positive direction, seek for the positive mechanical hard limit and motor index



Start homing at the speed set by P2-24 in the positive direction, when the moving load is blocked by the positive mechanical hard limit, and the output torque of the motor is equal to the set current threshold(P1-08), then the motor stops and turns back at the speed set by P2-25 for seeking encoder's index signal. The motor will stop and set encoder position to zero till the first rising edge of index signal is detected, the whole homing process has finished after that.

If the Homing Offset(P2-27) is not zero, the motor moves a offset distance set by P2-27.

7.10.2.5 Method 1: Start in the negative direction, seek for the negative limit switch and Motor Index




Position A: The motor moves in the negative direction with a homing speed set by P2-24 as long as the Negative Limit Switch(NLS) remains invalid. When the valid state of NLS is detected, the motor changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the first index pulse is detected after NLS attains the invalid state.

Position B: The valid state of NLS is detected when homing starts, the motor moves in the positive direction with a homing speed set by P2-25 until the first motor index pulse is detected after NLS attains the invalid state.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.6 Method 2: Start in the positive direction, seek for the positive limit switch and Motor Index




Position A: The motor moves in the positive direction with a homing speed set by P2-24 as long as the Positive Limit Switch(PLS) remains invalid. When the valid state of PLS is detected, the motor changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the first motor index pulse is detected after PLS attains the invalid state.

Position B: The valid state of PLS is detected when homing starts, the motor moves in the negative direction with a homing speed set by P2-25 until the first motor index pulse is detected after NLS attains the invalid state.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.7 Method 3: Start Positive Homing for the Falling-edge of Home Sensor and Motor Index




The initial direction of movement depends on the logic state of home sensor when start homing.

Position A: If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 as long as home sensor remains invalid. When the valid state of home switch is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid, where means the falling-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

Position B: If homing starts and the home sensor is valid, the motor moves in the negative direction with a speed set by P2-25 until the logic state of home sensor changes to invalid. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.8 Method 4: Start Positive Homing for the Raising-edge of Home Sensor and Motor Index




The initial direction of movement depends on the logic state of home sensor when start homing.

Position A: If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 as long as home sensor remains invalid. When the valid state of home switch is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid, then changes direction and speed, and moves again in the positive direction with a speed set by P2-25 as long as home sensor remains valid. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

Position B: If homing starts and the home sensor is valid, the motor moves in the negative direction with a speed set by P2-25 until the logic state of home sensor changes to invalid. then changes direction and speed, and moves again in the positive direction with a speed set by P2-25 as long as home sensor remains valid. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.9 Method 5: Start Negative Homing for the Falling-edge of Home Sensor and Motor Index




The initial direction of movement depends on the logic state of home sensor when start homing.

Position A: If homing starts and the home sensor is invalid, the motor moves in the negative direction with a homing speed set by P2-24 as long as home sensor remains invalid. When the valid state of home switch is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid, where means the falling-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

Position B: If homing starts and the home sensor is valid, the motor moves in the positive direction with a speed set by P2-25 until the logic state of home sensor changes to invalid. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.10 Start Negative Homing for the Raising-edge of Home Sensor and Motor Index




The initial direction of movement depends on the logic state of home sensor when start homing.

Position A: If homing starts and the home sensor is invalid, the motor moves in the negative direction with a homing speed set by P2-24 as long as home sensor remains invalid. When the valid state of home switch is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid, then changes direction and speed, and moves again in the negative direction with a speed set by P2-25 as long as home sensor remains valid. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

Position B: If homing starts and the home sensor is valid, the motor moves in the positive direction with a speed set by P2-25 until the logic state of home sensor changes to invalid, then changes direction and speed, and moves again in the negative direction with a speed set by P2-25 as long as home sensor remains valid. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.11 Method 7: Start Positive Homing, Seek for PLS, Falling-edge of Home Switch's Negative Side and Motor Index, Reverse on the PLS



When using homing method 7, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: When the valid state of home sensor is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid, where means the falling-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.
- Position B: When the valid state of PLS is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-24 until the logic state of home sensor changes to valid, then reverse to leave away the home sensor. After left the home sensor, the motor changes direction again and moves in the negative direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, and then from valid to invalid, where means the falling-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

If homing starts and the home sensor is valid (like Position C), the motor moves in the negative direction with a speed set by P2-25 until home switch changes logic state from valid to invalid. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.12 Method 8: Start Positive Homing, Seek for PLS, Raising-edge of Home Switch's Negative Side and Motor Index, Reverse on the PLS



When using homing method 8, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: When the valid state of home sensor is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid. After left the home sensor, the motor changes direction again and moves in the positive direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, where means the raising-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.
- Position B: When the valid state of PLS is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-24 until the valid state of home sensor is detected. In this case the motor continues to move in the negative direction as long as home sensor remain valid. After left the home sensor, the home sensor invalid state is detected, the motor reverses with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, where means the raising-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

If homing starts and the home sensor is valid (like Position C), the motor moves in the negative direction with a speed set by P2-25 until home switch changes logic state from valid to invalid. After left the home sensor, the motor reverses with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, where means the raising-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.13 Method 9: Start Positive Homing, Seek for PLS, Raising-edge of Home Switch's Positive Side and Motor index, Reverse on the PLS



When using homing method 9, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: The valid state of home sensor is detected. In this case the motor continues to move in the positive direction with the same speed as long as home sensor remains valid. When the home sensor invalid state is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the logic state of home sensor changes to valid, where means the raising-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.
- Position B: When the valid state of PLS is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-24 until the logic state of home sensor changes to valid, then reverse to leave away the home sensor. After left the home sensor, the motor changes direction again and moves in the negative direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, where means the raising-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

If homing starts and the home sensor is valid (like Position C), the motor moves in the positive direction with a speed set by P2-25 as long as home switch remains valid. When the invalid state is detected, the motor changes direction again and moves in the negative direction with a homing speed set by P2-25 until the home sensor attains the valid state. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.14 Method 10: Start Positive Homing, Seek for PLS, Falling-edge of Home Switch's Positive Side and Motor Index, Reverse on the PLS



When using homing method 10, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: When the valid state of home sensor is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid. After left the home sensor, the motor changes direction again and continues to moves in the positive direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, and then the change from valid to invalid state is detected, where means the falling-edge is detected. Then if the first motor motor index pulse is detected, the motor stops, Homing has been finished.
- Position B: When the valid state of PLS is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-24 until the valid state of home sensor is detected, then the motor reverses with a homing speed set by P2-25 until the home sensor changes logic state from valid to invalid, where means the falling-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

If homing starts and the home sensor is valid (like Position C), the motor moves in the positive direction with a speed set by P2-25 until home switch changes logic state from valid to invalid, where means the falling-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.15 Method 11: Start Negative Homing, Seek for NLS, Falling-edge of Home Switch's Positive Side and Motor Index, Reverse on the NLS



When using homing method 11, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the negative direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: When the valid state of home sensor is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid, where means the falling-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.
- Position B: When the valid state of NLS (Negative Limit Switch) is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-24 until the logic state of home sensor changes to valid, then reverse to leave away the home sensor. After left the home sensor, the motor changes direction again and moves in the negative direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, and then the change from valid to invalid state is detected, where means the falling-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

If homing starts and the home sensor is valid (like Position C), the motor moves in the positive direction with a speed set by P2-25 until home switch changes logic state from valid to invalid. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.17 Method 13: Start Negative Homing, Seek for NLS, Raising-edge of Home Switch's Negative Side and Motor Index, Reverse on the NLS



When using homing method 13, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the negative direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: The valid state of home sensor is detected. In this case the motor continues to move in the negative direction with the same speed as long as home sensor remains valid. When the home sensor invalid state is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the logic state of home sensor changes to valid, where means the raising-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.
- Position B: When the valid state of NLS (Negative Limit Switch) is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-24 until the logic state of home sensor changes to valid, then reverse to leave away from the home sensor. After left the home sensor, the motor changes direction again and moves in the positive direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, where means the raising-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

If homing starts and the home sensor is valid (like Position C), the motor moves in the negative direction with a speed set by P2-25 as long as home switch remains valid. When the invalid state is detected, the motor changes direction again and moves in the positive direction with a homing speed set by P2-25 until the home sensor attains the valid state. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.18 Method 14: Start Negative Homing, Seek for NLS, Falling-edge of Home Switch's Negative Side and Motor Index, Reverse on the NLS



When using homing method 14, the initial direction of movement depends on the logic state of home sensor when start homing.

If homing starts and the home sensor is invalid, the motor moves in the negative direction with a homing speed set by P2-24 until one of two possible event occur:


- Position A: When the valid state of home sensor is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid. After left the home sensor, the motor changes direction again and continues to moves in the negative direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, and then the change from valid to invalid state is detected, where means the falling-edge is detected. Then if the first motor motor index pulse is detected, the motor stops, Homing has been finished.
- Position B: When the valid state of NLS(Negative Limit Switch) is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-24 until the valid state of home sensor is detected, then the motor reverses with a homing speed set by P2-25 until the home sensor changes logic state from valid to invalid, where means the falling-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

If homing starts and the home sensor is valid(like Position C), the motor moves in the negative direction with a speed set by P2-25 until home switch changes logic state from valid to invalid, where means the falling-edge is detected. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.19 Methods 15 and 16: Reserved

7.10.2.20 Method 17: Start Negative Homing, Seek for Negative Home Switch




Method 17 is similar to method 1, except that the home position is not dependent on the motor index, it is dependent only on the NLS(Negative Limit Switch).

Position A: The motor moves in the negative direction with a homing speed set by P2-24 as long as the Negative Limit Signal(NLS) remains invalid. When the valid state of NLS is detected, the motor changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until NLS attains the invalid state.

Position B: The valid state of NLS is detected when homing starts, the motor moves in the positive direction with a homing speed set by P2-25 until NLS attains the invalid state.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.21 Method 18: Start Positive Homing, Seek for Positive Home Switch




Method 18 is similar to method 2, except that the home position is not dependent on the motor index, it is dependent only on the NLS(Negative Limit Switch).

Position A: The motor moves in the positive direction with a homing speed set by P2-24 as long as the Positive Limit Signal(PLS) remains invalid. When the valid state of PLS is detected, the motor changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until PLS attains the invalid state.

Position B: The valid state of PLS is detected when homing starts, the motor moves in the negative direction with a homing speed set by P2-25 until PLS attains the invalid state.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.22 Method 19: Start Positive Homing for the Falling-edge of Home Sensor



Method 19 is similar to method 3, except that the home position is not dependent on the motor index, it is dependent only on the home sensor.


The initial direction of movement depends on the logic state of home sensor when start homing.

Position A: If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 as long as home sensor remains invalid. When the valid state of home switch is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid, where means the falling-edge is detected, then the motor stops, Homing has been finished.

Position B: If homing starts and the home sensor is valid, the motor moves in the negative direction with a speed set by P2-25 until the logic state of home sensor changes to invalid, then the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.23 Method 20: Start Positive Homing for the Raising-edge of Home Sensor



Method 20 is similar to method 4, except that the home position is not dependent on the motor index, it is dependent only on the home sensor.

The initial direction of movement depends on the logic state of home sensor when start homing.


Position A: If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 as long as home sensor remains invalid. When the valid state of home switch is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid, then changes direction and speed, and moves again in the positive direction with a speed set by P2-25 as long as home sensor remains valid. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

Position B: If homing starts and the home sensor is valid, the motor moves in the negative direction with a speed set by P2-25 until the logic state of home sensor changes to invalid. then changes direction and speed, and moves again in the positive direction with a speed set by P2-25 as long as home sensor remains valid. Then if the first motor index pulse is detected, the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's

status.

7.10.2.24 Method 21: Start Negative Homing for the Falling-edge of Home Sensor



Method 21 is similar to method 5, except that the home position is not dependent on the motor index, it is dependent only on the home sensor.


The initial direction of movement depends on the logic state of home sensor when start homing.

Position A: If homing starts and the home sensor is invalid, the motor moves in the negative direction with a homing speed set by P2-24 as long as home sensor remains invalid. When the valid state of home switch is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid, where means the falling-edge is detected, then the motor stops, Homing has been finished.

Position B: If homing starts and the home sensor is valid, the motor moves in the positive direction with a speed set by P2-25 until the logic state of home sensor changes to invalid, then the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.25 Method 22: Start Negative Homing for the Raising-edge of Home Sensor



Method 22 is similar to method 6, except that the home position is not dependent on the motor index, it is dependent only on the home sensor.

The initial direction of movement depends on the logic state of home sensor when start homing.


Position A: If homing starts and the home sensor is invalid, the motor moves in the negative direction with a homing speed set by P2-24 as long as home sensor remains invalid. When the valid state of home switch is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid, then changes direction and speed, and moves again in the negative direction with a speed set by P2-25 until the home sensor state transition from invalid to valid is detected, then the motor stops, Homing has been finished.

Position B: If homing starts and the home sensor is valid, the motor moves in the positive direction with a speed set by P2-25 until the logic state of home sensor changes to invalid, then changes direction and speed, and moves again in the negative direction with a speed set by P2-25 until the home sensor state transition from invalid to valid is detected, then the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

status.

7.10.2.26 Method 23: Start Positive Homing, Seek for PLS, Falling-edge of Home Switch's Negative Side, Reverse on the PLS



Method 23 is similar to method 7, except that the home position is not dependent on the motor index, it is dependent only on the home sensor transitions and positive limit switch(PLS) transitions.

When using homing method 23, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: When the valid state of home sensor is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the home sensor state transition from valid to invalid, where means the falling-edge is detected, then the motor stops, Homing has been finished.
- Position B: When the valid state of PLS is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-24 until the logic state of home sensor changes to valid, then reverse to leave away the home sensor. After left the home sensor, the motor changes direction again and continues to moves in the negative direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, and then the change from valid to invalid state is detected, where means the falling-edge is detected, then the motor stops, Homing has been finished.

If homing starts and the home sensor is valid(like Position C), the motor moves in the negative direction with a speed set by P2-25 until home switch changes logic state from valid to invalid, then the motor stops,Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.27 Method 24: Start Positive Homing, Seek for PLS, Raising-edge of Home Switch's Negative Side, Reverse on the PLS



Method 24 is similar to method 8, except that the home position is not dependent on the motor index, it is dependent only on the home sensor transitions and positive limit switch(PLS) transitions.

When using homing method 24, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: When the valid state of home sensor is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid. After left the home sensor, the motor changes direction again and moves in the positive direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, where means the raising-edge is detected, then the motor stops, Homing has been finished.
- Position B: When the valid state of PLS is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-24 until the valid state of home sensor is detected. In this case the motor continues to move in the negative direction as long as home sensor remain valid. After left the home sensor, the home sensor invalid state is detected, the motor reverses with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, where means the raising-edge is detected, then the motor stops, Homing has been finished.

If homing starts and the home sensor is valid(like Position C), the motor moves in the negative direction with a speed set by P2-25 until home switch changes logic state from valid to invalid. After left the home sensor, the motor reverses with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, where means the raising-edge is detected, then the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.28 Method 25: Start Positive Homing, Seek for PLS, Raising-edge of Home Switch's Positive Side, Reverse on the PLS



Method 25 is similar to method 9, except that the home position is not dependent on the motor index, it is dependent only on the home sensor transitions and positive limit switch(PLS) transitions.

When using homing method 25, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: The valid state of home sensor is detected. In this case the motor continues to move in the positive direction with the same speed as long as home sensor remains valid. When the home sensor invalid state is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the home sensor state transition from invalid to valid is detected, where means the raising-edge is detected, then the motor stops, Homing has been finished.
- Position B: When the valid state of PLS is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-24 until the logic state of home sensor changes to valid, then reverse to leave away the home sensor. After left the home sensor, the motor changes direction again and moves in the negative direction with a homing speed set by P2-25 until the home sensor state transition from invalid to valid is detected, where means the raising-edge is detected, then the motor stops, Homing has been finished.

If homing starts and the home sensor is valid(like Position C), the motor moves in the positive direction with a speed set by P2-25 as long as home switch remains valid. When the invalid state is detected, the motor changes direction again and moves in the negative direction with a homing speed set by P2-25 until the home sensor state transition from invalid to valid is detected, where means the raising-edge is detected, then the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.29 Method 26: Start Positive Homing, Seek for PLS, Falling-edge of Home Switch's Positive Side, Reverse on the PLS



Method 26 is similar to method 10, except that the home position is not dependent on the motor index, it is dependent only on the home sensor transitions and positive limit switch(PLS) transitions.

When using homing method 26, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the positive direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: When the valid state of home sensor is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid. After left the home sensor, the motor changes direction again and continues to moves in the positive direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, and then the change from valid to invalid state is detected, where means the falling-edge is detected, then the motor stops, Homing has been finished.
- Position B: When the valid state of PLS is detected, the motor stops, changes direction and speed, and moves in the negative direction with a homing speed set by P2-24 until the valid state of home sensor is detected, then the motor reverses with a homing speed set by P2-25 until the home sensor changes logic state from valid to invalid, where means the falling-edge is detected, then the motor stops, Homing has been finished.

If homing starts and the home sensor is valid(like Position C), the motor moves in the positive direction with a speed set by P2-25 until home switch changes logic state from valid to invalid, where means the falling-edge is detected, then the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.30 Method 27: Start Negative Homing, Seek for NLS, Falling-edge of Home Switch's Positive Side, Reverse on the NLS



Method 27 is similar to method 11, except that the home position is not dependent on the motor index, it is dependent only on the home sensor transitions and negative limit switch(NLS) transitions.

When using homing method 27, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the negative direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: When the valid state of home sensor is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the home sensor state transition from valid to invalid, where means the falling-edge is detected, then the motor stops, Homing has been finished.
- Position B: When the valid state of NLS(Negative Limit Switch) is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-24 until the logic state of home sensor changes to valid, then reverse to leave away the home sensor. After left the home sensor, the motor changes direction again and moves in the negative direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, and then the change from valid to invalid state is detected, where means the falling-edge is detected, then the motor stops, Homing has been finished.

If homing starts and the home sensor is valid(like Position C), the motor moves in the positive direction with a speed set by P2-25 until home switch changes logic state from valid to invalid, then the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.31 Method 28: Start Negative Homing, Seek for NLS, Raising-edge of Home Switch's Positive Side, Reverse on the NLS



Method 28 is similar to method 12, except that the home position is not dependent on the motor index, it is dependent only on the home sensor transitions and negative limit switch(NLS) transitions.

When using homing method 28, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the negative direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: When the valid state of home sensor is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid. After left the home sensor, the motor changes direction again and moves in the negative direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, where means the raising-edge is detected, then the motor stops, Homing has been finished.
- Position B: When the valid state of NLS(Negative Limit Switch) is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-24 until the valid state of home sensor is detected. In this case the motor continues to move in the positive direction as long as home sensor remain valid. After left the home sensor, the home sensor invalid state is detected, the motor reverses with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, where means the raising-edge is detected, then the motor stops, Homing has been finished.

If homing starts and the home sensor is valid(like Position C), the motor moves in the positive direction with a speed set by P2-25 until home switch changes logic state from valid to invalid. After left the home sensor, the motor reverses with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, where means the raising-edge is detected, then the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.32 Method 29: Start Negative Homing, Seek for NLS, Raising-edge of Home Switch's Negative Side, Reverse on the NLS



Method 29 is similar to method 13, except that the home position is not dependent on the motor index, it is dependent only on the home sensor transitions and negative limit switch(NLS) transitions.

When using homing method 29, the initial direction of movement depends on the logic state of home sensor when start homing.


If homing starts and the home sensor is invalid, the motor moves in the negative direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: The valid state of home sensor is detected. In this case the motor continues to move in the negative direction with the same speed as long as home sensor remains valid. When the home sensor invalid state is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the home sensor state transition from invalid to valid is detected, where means the raising-edge is detected, then the motor stops, Homing has been finished.
- Position B: When the valid state of NLS(Negative Limit Switch) is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-24 until the valid state of home sensor is detected, then reverse to leave away from the home sensor. After left the home sensor, the motor changes direction again and moves in the positive direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid,where means the raising-edge is detected, then the motor stops, Homing has been finished.

If homing starts and the home sensor is valid(like Position C), the motor moves in the negative direction with a speed set by P2-25 as long as home switch remains valid. When the invalid state is detected, the motor changes direction again and moves in the positive direction with a homing speed set by P2-25 until the home sensor state transition from invalid to valid is detected, where means the raising-edge is detected, then the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.33 Method 30: Start Negative Homing, Seek for NLS, Falling-edge of Home Switch's Negative Side, Reverse on the NLS



Method 30 is similar to method 14, except that the home position is not dependent on the motor index, it is dependent only on the home sensor transitions and negative limit switch(NLS) transitions.

When using homing method 30, the initial direction of movement depends on the logic state of home sensor when start homing.

If homing starts and the home sensor is invalid, the motor moves in the negative direction with a homing speed set by P2-24 until one of two possible event occur:

- Position A: When the valid state of home sensor is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-25 until the logic state of home sensor changes to invalid. After left the home sensor, the motor changes direction again and continues to moves in the negative direction with a homing speed set by P2-25 until the home sensor changes logic state from invalid to valid, and then the change from valid to invalid state is detected, where means the falling-edge is detected, then the motor stops, Homing has been finished.
- Position B: When the valid state of NLS(Negative Limit Switch) is detected, the motor stops, changes direction and speed, and moves in the positive direction with a homing speed set by P2-24 until the valid state of home sensor is detected, then the motor reverses with a homing speed set by P2-25 until the home sensor changes logic state from valid to invalid, where means the falling-edge is detected, then the motor stops, Homing has been finished.


If homing starts and the home sensor is valid(like Position C), the motor moves in the negative direction with a speed set by P2-25 until home switch changes logic state from valid to invalid, where means the falling-edge is detected, then the motor stops, Homing has been finished.

When receiving this event and the motor completely stops, the drive sets Homing Finished bit of drive's status.

7.10.2.34 Methods 31 and 32: Reserved.


These two homing methods are reserved for future expansion of the homing mode.

7.10.2.35 Method 33: Start Negative Homing, Seek for First Motor Index



The motor moves in the negative direction with a homing speed set by P2-25 until the first motor index pulse is detected, the motor stops, Homing has been finished.

7.10.2.36 Method 34: Start Positive Homing, Seek for First Motor Index




The motor moves in the positive direction with a homing speed set by P2-25 until the first motor index pulse is detected, the motor stops, Homing has been finished.

7.10.2.37 Method 35: Homing on the Current Position


In this Method, the current position is taken to be the home position.

If Home Offset(parameter P2-27) is set, Mechanical Origin = Mechanical Zero + Home Offset



7.11 Internal Velocity Control

M56S series servo drive supports setting 8 groups of internal speeds, and selects the corresponding speed group through the external digital inputs. Since the parameters are stored in the driver, the speed mode can be controlled without analog input.



7.11.1 Set the Control Mode to Internal Velocity

Parameter P1-00 is used to set the main control mode.

| Set Value | Description |
|-----------|-------------------|
| 15 | Internal Velocity |

Software Setting Method

The control mode can also be set through the "Control Mode" interface of the Luna software.

7.11.2 Digital Inputs Settings

When using the internal velocity mode, it is necessary to set the corresponding function for the digital inputs. Parameters P5-00 ~ P5-09 are used to set the functions of digital inputs X1 ~ X10.


| Signals | Symbol | Setup value and corresponding input logic state of P5-00 ~ P5-09. | | Description |
|-------------------------------|---------|---|-----------------|-------------------------------|
| | | Valid when Closed | Valid when Open | |
| Internal speed select input 1 | SPD1 | 27 | 28 | Internal speed select input 1 |
| Internal speed select input 2 | SPD2 | 29 | 30 | Internal speed select input 2 |
| Internal speed select input 3 | SPD3 | 31 | 32 | Internal speed select input 3 |
| Velocity Start | SP-STA | 33 | 34 | Start velocity control |
| Velocity Direction Switch | SPD-DIR | 35 | 36 | Switch the rotation direction |

Note:

The valid logic of internal speed select input must be set to all CLOSED or all OPEN, which cannot be mixed set.

Software Setting Method

The control mode can also be set through the "Digital I/O" interface of the Luna software.



7.11.3 Internal Velocity Settings

Target Speed Setting

Parameters P2-10 to P-17 are used to set 8 different speeds of the internal velocity mode.

| Parameters | SCL Com. | Description | Default | Range | Unit |
|------------|----------|------------------------------------|---------|------------|------|
| P2-10 | JC1 | Internal Velocity Control: Speed 1 | 0 | -100 ~ 100 | rps |
| P2-11 | JC2 | Internal Velocity Control: Speed 2 | 10 | -100 ~ 100 | rps |
| P2-12 | JC3 | Internal Velocity Control: Speed 3 | 20 | -100 ~ 100 | rps |
| P2-13 | JC4 | Internal Velocity Control: Speed 4 | 25 | -100 ~ 100 | rps |
| P2-14 | JC5 | Internal Velocity Control: Speed 5 | 30 | -100 ~ 100 | rps |
| P2-15 | JC6 | Internal Velocity Control: Speed 6 | 35 | -100 ~ 100 | rps |
| P2-16 | JC7 | Internal Velocity Control: Speed 7 | 40 | -100 ~ 100 | rps |
| P2-17 | JC8 | Internal Velocity Control: Speed 8 | 50 | -100 ~ 100 | rps |


Acceleration and Deceleration Settings

The acceleration is set by parameter P2-03 and the deceleration is set by P2-04.

| Parameters | SCL Com. | Description | Default | Range | Unit |
|------------|----------|------------------|---------|--------------|-------|
| P2-03 | JA | Jog Acceleration | 100 | 0.167 ~ 5000 | rps/s |
| P2-04 | JL | Jog Deceleration | 100 | 0.167 ~ 5000 | rps/s |

7.11.4 Input Signal and 8-segment Internal Speed Selection

The correspondences between the logic state of the speed selection input signal and the internal speed segments are as shown in the figure below.



7.11.5 Rotation Direction Switching in Internal Velocity Mode

The rotation direction is usually determined by the positive and negative of speed command set by parameters P2-10 to P2-17 in internal velocity control mode.

Since one of the digital inputs set as the SPD-DIR (Velocity Direction Switch) function, the speed reference takes the absolute value of speed command and the rotation direction are controlled by the logic state of the SPD-DIR input.

SPD-DIR Configuration

To use torque and Velocity Direction Switch, one of digital inputs needs to be assigned this function.

| Signal Type | Signal Symbol | Setup Value | Signal Logic | Instructions |
|-------------|---------------|-------------|--------------|--|
| Input | SPD-DIR | 35 | Closed | SPD-DIR input is valid, the motor rotates direction will be changed. |
| | | | Open | SPD-DIR input is invalid, the motor rotates direction will NOT be changed. |
| | GP | 0 | Open | SPD-DIR input is valid, the motor rotates direction will be changed. |
| | | | Closed | SPD-DIR input is invalid, the motor rotates direction will NOT be changed. |
| | | | - | None of digital inputs is configured as SPD-DIR function, the rotate direction is controlled by the sign of speed command. |

The actual rotation direction is determined by the parameters P1-11 (Rotational Direction Setup), Speed Command, and the input logic of SPD-DIR. The detailed relationship is as follows.

◆ **None of digital inputs is configured as SPD-DIR function**

| Value of P1-11 | P2-10 to P2-17 Speed Command | Input logic of SPD-DIR | Actual motor rotation direction |
|----------------|---------------------------------|------------------------|---------------------------------|
| 0 | Positive | NONE FUNCTION | CW |
| 0 | Positive | NONE FUNCTION | CCW |
| 0 | Negative | NONE FUNCTION | CCW |
| 0 | Negative | NONE FUNCTION | CW |
| 1 | Positive | NONE FUNCTION | CCW |
| 1 | Positive | NONE FUNCTION | CW |
| 1 | Negative | NONE FUNCTION | CW |
| 1 | Negative | NONE FUNCTION | CCW |

◆ **One of digital inputs is configured as SPD-DIR function:**

| Value of P1-11 | P2-10 to P2-17 Speed Command | Input logic of SPD-DIR | Actual motor rotation direction |
|----------------|---------------------------------|------------------------|---------------------------------|
| 0 | Positive | Invalid | CW |
| 0 | Negative | Invalid | |
| 0 | Positive | Valid | CCW |
| 0 | Negative | Valid | |
| 1 | Positive | Invalid | CCW |
| 1 | Negative | Invalid | |
| 1 | Positive | Valid | CW |
| 1 | Negative | Valid | |

8 Parameter Settings

8.1 Parameter Definitions

The servo drive parameters are divided into six groups.

| Group | Type | Instruction |
|----------------|--------------------|--|
| Group 0: P0-XX | PID parameters | Set the gain parameters of the servo and related parameters |
| Group 1: P1-XX | Configuration | Set or configure various drive functions |
| Group 2: P2-XX | Trajectory | Set the parameters related to the internal motion trajectory |
| Group 3: P3-XX | Encoder & Step/Dir | Set parameters related to encoder and input/output pulses |
| Group 4: P4-XX | Analog | Set parameters related to analog input and output |
| Group 5: P5-XX | I/O | Set the parameters of digital input and output related functions |

8.2 Parameter List

Group 0: P0-XX: PID Parameters

| Parameter | Command | Description | Default | Range | Unit | Type |
|-----------|---------|--|---------|----------------|--------|------|
| P0-00 | UM | Parameter tuning mode | 0 | 0 ~ 2 | --- | |
| P0-01 | LY | Load type | 0 | 0 ~ 10 | --- | |
| P0-02 | NR | Load inertia ratio | 0 | 0 ~ 10000 | 0.01倍 | |
| P0-03 | Kg | First rigidity level | 5 | 0 ~ 20 | --- | |
| P0-04 | KX | Second rigidity level | 5 | 0 ~ 20 | --- | |
| P0-05 | KP | First position loop gain | 52 | 0 ~ 20000 | 0.1Hz | |
| P0-07 | KD | First position loop differential time constant | 2000 | 0 ~ 30000 | ms | |
| P0-08 | KE | First position loop differential filter frequency | 20000 | 0 ~ 40000 | 0.1Hz | |
| P0-09 | KL | Speed feedforward gain | 10000 | -30000 ~ 3000 | 0.01% | |
| P0-10 | KR | Speed feedforward filter frequency | 20000 | 0 ~ 40000 | 0.1Hz | |
| P0-11 | KF | First command speed gain | 10000 | -30000 ~ 3000 | 0.01% | |
| P0-12 | VP | First speed loop gain | 183 | 0 ~ 30000 | 0.1Hz | |
| P0-13 | VI | First speed loop integral time constant | 189 | 0 ~ 30000 | ms | |
| P0-14 | KK | Acceleration feedforward gain | 3000 | 0 ~ 10000 | 0.01% | |
| P0-15 | KT | Acceleration feedforward filter frequency | 20000 | 0 ~ 40000 | 0.1Hz | |
| P0-16 | KC | First command torque filter frequency | 1099 | 0 ~ 40000 | 01Hz | |
| P0-17 | UP | Second position loop gain | 52 | 0 ~ 20000 | 0.1Hz | |
| P0-19 | UD | Second position loop differential time constant | 2000 | 0 ~ 30000 | ms | |
| P0-20 | UE | Second position loop differential filter frequency | 15000 | 0 ~ 40000 | 0.1Hz | |
| P0-21 | UF | Second command speed gain | 10000 | -30000 ~ 3000 | 0.01% | |
| P0-22 | UV | Second speed loop gain | 183 | 0 ~ 30000 | 0.1Hz | |
| P0-23 | UG | Second speed loop integral time constant | 189 | 0 ~ 30000 | ms | |
| P0-24 | UC | Second command torque filter frequency | 1099 | 0 ~ 40000 | 01Hz | |
| P0-25 | XP | Full closed loop - position loop gain | 52 | 0 ~ 20000 | 0.1Hz | |
| P0-27 | XD | Full closed loop - position loop differential time constant | 2000 | 0 ~ 30000 | ms | |
| P0-28 | XE | Full closed loop - position loop differential filter frequency | 15000 | 0 ~ 40000 | 0.1Hz | |
| P0-29 | XF | Full closed loop - command speed gain | 10000 | -30000 ~ 3000 | 0.01% | |
| P0-30 | XV | Full closed loop - speed loop gain | 183 | 0 ~ 30000 | 0.1Hz | |
| P0-31 | XG | Full closed loop - speed loop integral time constant | 189 | 0 ~ 30000 | ms | |
| P0-32 | XC | Full closed loop - command torque filter frequency | 1099 | 0 ~ 40000 | 0.1Hz | |
| P0-33 | SD | Gain switching condition selection | 0 | 0 ~ 4 | --- | |
| P0-34 | PN | Gain switching condition - position | 0 | 0 ~ 2147483647 | Pulses | |
| P0-35 | VN | gain switching condition - speed | 0.000 | 0 ~ 100 | rps | |
| P0-36 | TN | gain switching condition - torque | 10 | 0 ~ 3000 | 0.1% | |
| P0-37 | SE1 | Second gain switches to first gain Delay time | 10 | 0 ~ 10000 | ms | |
| P0-38 | SE2 | First gain switches to second gain Delay time | 0 | 0 ~ 10000 | ms | |
| P0-39 | LR | Speed feedback filter | 0 | 0 ~ 3 | --- | |

Group 1: P1-XX: Configurations

| Parameter | Command | Description | Default | Range | Unit | Type |
|-----------|---------|---|------------|----------------|------|-----------------------|
| P1-00 | CM | Main Control Mode | 21 | 1,2,7,11,15,21 | - | Effective immediately |
| P1-01 | CN | Secondary Control Mode | 21 | 1,2,7,11,15,21 | - | Effective immediately |
| P1-02 | PM | Operation Mode When Power-up | 10 | 8 ~ 10 | - | |
| P1-03 | JM | Speed Control Clamp Mode | 2 | 1 ~ 2 | - | |
| P1-04 | XM | Full Closed-loop Control Switch | 0 | 0, 1 | - | |
| P1-05 | GC | Torque Command for Internal Torque Mode | 0 | -3000 ~ 3000 | 0.1% | |
| P1-06 | CC | 1st Torque Limit | 3000 | 0 ~ 3000 | 0.1% | |
| P1-07 | CV | Target Torque Value when Torque Value Reached | 0 | 0 ~ 3000 | 0.1% | |
| P1-08 | HC | Torque Limit for Hard Stop Homing | 200 | 0 ~ 3000 | 0.1% | |
| P1-09 | CL | Current Foldback Continuous Time | 2000 | 0 ~ 30000 | ms | |
| P1-10 | LD | Torque Limit Method | 1 | 1 ~ 5 | - | |
| P1-11 | RN | Rotational Direction Setup | 0 | 0, 1 | - | |
| P1-12 | - | Reserved | - | - | - | |
| P1-13 | PR | Communication Protocol | 5 | 1 ~ 511 | - | |
| P1-14 | TD | Transmit Delay | 2 | 0 ~ 20 | ms | |
| P1-15 | BR | RS-485 Baud Rate | 1 | 1 ~ 5 | - | |
| P1-16 | DA | RS-485 Address | 32 | 1 ~ 32 | - | |
| P1-19 | ZR | Regeneration Resistor Value | 200 | 10 ~ 32000 | Ω | |
| P1-20 | ZC | Regeneration Resistor Continuous Wattage | 40 | 1 ~ 32000 | W | |
| P1-21 | ZT | Regeneration Resistor Time Constant | 1000 | 0 ~ 8000 | ms | |
| P1-22 | PK | Key Setting Lock | 0 | 0, 1 | - | |
| P1-23 | DD | Default Display | 0 | 0 ~ 20 | - | |
| P1-24 | MA | Alarm Mask | 4294967295 | 0 ~ 4294967295 | - | |
| P1-25 | CX | 2nd Torque Limit | 3000 | 0 ~ 3000 | 0.1% | |
| P1-26 | CY | 3rd Torque Limit | 3000 | 0 ~ 3000 | 0.1% | |
| P1-27 | CZ | 4th Torque Limit | 3000 | 0 ~ 3000 | 0.1% | |
| P1-28 | HT | Motor Stall protection time | 0 | 0 ~ 30000 | ms | |
| P1-29 | YV | Dynamic Brake Sequence when Servo Off | 0 | 0 ~ 5 | | |
| P1-30 | YR | Dynamic Brake Sequence when Fault Occurs | 0 | 0 ~ 3 | | |
| P1-31 | YM | Dynamic Brake Action Time during Deceleration of Servo Off | 500 | 0 ~ 30000 | ms | |
| P1-32 | YN | Dynamic Brake Action Time during Deceleration when Fault Occurs | 0 | 0 ~ 30000 | ms | |
| P1-33 | OT | Missing phase detection switch | 0 | 0 ~ 1 | | |
| P1-34 | RT | Instantaneous change value of current | 1000 | 0 ~ 3000 | 0.1% | |

Group 2: P2-XX: Trajectory

| Parameter | Command | Description | Default | Range | Unit | Type |
|-----------|---------|------------------------------------|---------|------------------------------|--------|------|
| P2-00 | VM | Max Velocity | 80 | 0 ~ 100 | rps | |
| P2-01 | AM | Max Brake Deceleration | 3000 | 0.167 ~ 5000 | rps/s | |
| P2-02 | JS | Jog Velocity | 10 | -100 ~ 100 | rps | |
| P2-03 | JA | Jog Acceleration | 100 | 0.167 ~ 5000 | rps/s | |
| P2-04 | JL | Jog Deceleration | 100 | 0.167 ~ 5000 | rps/s | |
| P2-05 | JT | Jerk Time | 10 | 0 ~ 125 | ms | |
| P2-06 | VE | Point-to-Point Velocity | 10 | 0.0042 ~ 100 | rps | |
| P2-07 | AC | Point-to-Point Acceleration | 100 | 0.167 ~ 5000 | rps/s | |
| P2-08 | DE | Point-to-Point Deceleration | 100 | 0.167 ~ 5000 | rps/s | |
| P2-09 | VC | Point-to-Point Change Velocity | 2 | 0 ~ 100 | rps | |
| P2-10 | JC1 | Internal Velocity Control: Speed 1 | 2 | -100 ~ 100 | rps | |
| P2-11 | JC2 | Internal Velocity Control: Speed 2 | 10 | -100 ~ 100 | rps | |
| P2-12 | JC3 | Internal Velocity Control: Speed 3 | 20 | -100 ~ 100 | rps | |
| P2-13 | JC4 | Internal Velocity Control: Speed 4 | 25 | -100 ~ 100 | rps | |
| P2-14 | JC5 | Internal Velocity Control: Speed 5 | 30 | -100 ~ 100 | rps | |
| P2-15 | JC6 | Internal Velocity Control: Speed 6 | 35 | -100 ~ 100 | rps | |
| P2-16 | JC7 | Internal Velocity Control: Speed 7 | 40 | -100 ~ 100 | rps | |
| P2-17 | JC8 | Internal Velocity Control: Speed 8 | 50 | -100 ~ 100 | rps | |
| P2-18 | HA1 | Homing Acceleration/Deceleration | 100 | 0.167 ~ 5000 | rps/s | |
| P2-21 | - | Reserved- | - | - | - | |
| P2-24 | HV1 | Homing Velocity 1 | 10 | 0.0042 ~ 100 | rps | |
| P2-25 | HV2 | Homing Velocity 2 | 1 | 0.0042 ~ 100 | rps | |
| P2-27 | HO | Homing Offset | 0 | -2147483647 ~ +2147483647 | pulses | |
| P2-28 | KJ | Jerk Filter | 0 | 0 ~ 1000 | ms | |
| P2-29 | FF | Interpolation Filter | 10 | 0 ~ 125 | ms | |
| P2-30 | VT | Velocity Limit of Torque Control | 80 | 0 ~ 100 | rps | |

Group 3: P3-XX: Encoder & Step/Dir

| Parameter | Command | Description | Default | Range | Unit | Type |
|-----------|---------|--|---------|----------------|------------|------|
| P3-00 | EN | Electronic Gear Ratio - Numerator | 32000 | 1 ~ 2147483647 | - | |
| P3-01 | EU | Electronic Gear Ratio - Denominator | 32000 | 1 ~ 2147483647 | - | |
| P3-02 | SZ | Pulse Input Noise Filter | 2 | 0 ~ 32000 | 0.1µs | |
| P3-03 | PT | Pules Input Setting | 9 | 0 ~ 31 | | |
| P3-04 | PF | Position Error Limit | 100000 | 0 ~ 2147483647 | pulses | |
| P3-05 | EG | Command Pulses per revolution | 10000 | 200 ~ 131072 | pulses/rev | |
| P3-06 | PV | Second Encoder Direction | 0 | 0 ~ 1 | - | |
| P3-07 | -- | Reserved | - | - | - | |
| P3-08 | -- | Reserved | - | - | - | |
| P3-09 | XT | Hybrid Deviation Clear Setting | 10 | 1 ~ 100 | rev | |
| P3-10 | XO | Hybrid Deviation Fault Threshold | 100000 | 0 ~ 2147483647 | pulses | |
| P3-11 | XR | Second Encoder Resolution | 10000 | 200 ~ 100000 | pulses/rev | |
| P3-12 | PO | Pulses Output Mode | 1 | 0 ~ 256 | - | |
| P3-13 | ON | Pulses Output Gear Ratio - Numerator | 10000 | 0 ~ 13107200 | - | |
| P3-14 | OD | Pulses Output Gear Ratio - Denominator | 131072 | 0 ~ 13107200 | - | |
| P3-15 | ES | Absolute Encoder Usage | 1 | 0 ~ 3 | - | |
| P3-16 | PU | Electronic Gearing Switch | 0 | 0 ~ 1 | - | |

Group 4: P4-XX: Analog

| Parameter | Command | Description | Default | Range | Unit | Type |
|-----------|---------|--|---------|----------------|---------|------|
| P4-01 | AG | Analog Input Velocity Gain | 50 | 0 ~ 100 | rps/10V | |
| P4-02 | AN | Analog Input Torque Gain | 1000 | 0 ~ 3000 | 0.1% | |
| P4-03 | AV1 | Analog Input 1 Offset | 0 | -10000 ~ 10000 | mV | |
| P4-04 | AV2 | Analog Input 2 Offset | 0 | -10000 ~ 10000 | mV | |
| P4-05 | AD1 | Analog Input 1 Dead-band | 0 | 0 ~ 255 | mV | |
| P4-06 | AD2 | Analog Input 2 Dead-band | 0 | 0 ~ 255 | mV | |
| P4-07 | AF1 | Analog Input 1 Filter | 1000 | 0 ~ 2000 | 0.1Hz | |
| P4-08 | AF2 | Analog Input 2 Filter | 1000 | 0 ~ 2000 | 0.1Hz | |
| P4-09 | AT1 | Analog Input 2 Threshold | 5000 | -10000 ~ 10000 | mV | |
| P4-10 | AT2 | Analog Input 2 Threshold | 5000 | -10000 ~ 10000 | mV | |
| P4-11 | FA1 | Velocity Limit Setting of Torque Control | 1 | 0 ~ 1 | | |
| P4-16 | OS1 | Analog Output 1 Scale | 1000 | 1 ~ 32000 | | |
| P4-17 | OS2 | Analog Output 2 Scale | 1000 | 1 ~ 32000 | | |
| P4-18 | XA1 | Analog Output 1 Function | 0 | 0 ~ 5 | | |
| P4-19 | XA2 | Analog Output 2 Function | 0 | 0 ~ 5 | | |

Group 5: P5-XX: I/O Configuration

| Parameter | Command | Description | Default | Range | Unit | Type |
|-----------|---------|---|---------|---------------------------|--------|------|
| P5-00 | MU1 | Digital Input 1 Function | | 0 ~ 46 | - | |
| P5-01 | MU2 | Digital Input 2 Function | | 0 ~ 46 | - | |
| P5-02 | MU3 | Digital Input 3 Function | | 0 ~ 46 | - | |
| P5-03 | MU4 | Digital Input 4 Function | | 0 ~ 46 | - | |
| P5-04 | MU5 | Digital Input 5 Function | | 0 ~ 46 | - | |
| P5-05 | MU6 | Digital Input 6 Function | | 0 ~ 46 | - | |
| P5-06 | MU7 | Digital Input 7 Function | | 0 ~ 46 | - | |
| P5-07 | MU8 | Digital Input 8 Function | | 0 ~ 46 | - | |
| P5-08 | MU9 | Digital Input 9 Function | | 0 ~ 46 | - | |
| P5-09 | MUA | Digital Input 10 Function | | 0 ~ 46 | - | |
| P5-12 | MO1 | Digital Output 1 Function | | 0 ~ 34 | - | |
| P5-13 | MO2 | Digital Output 2 Function | | 0 ~ 34 | - | |
| P5-14 | MO3 | Digital Output 3 Function | | 0 ~ 34 | - | |
| P5-15 | MO4 | Digital Output 4 Function | | 0 ~ 34 | - | |
| P5-16 | MO5 | Digital Output 5 Function | | 0 ~ 34 | - | |
| P5-17 | MO6 | Digital Output 6 Function | | 0 ~ 34 | - | |
| P5-24 | BD | Move Command Delay Time after Brake Release | 200 | 0 ~ 32000 | ms | |
| P5-25 | BE | Servo-off Delay Time after Brake Engagement | 200 | 0 ~ 32000 | ms | |
| P5-27 | HX | Home Sensor | 5 | 1 ~ 10 | - | |
| P5-28 | FI1 | Digital Input 1 Filter | 1 | 0 ~ 8000 | ms | |
| P5-29 | FI2 | Digital Input 2 Filter | 1 | 0 ~ 8000 | ms | |
| P5-30 | FI3 | Digital Input 3 Filter | 1 | 0 ~ 8000 | ms | |
| P5-31 | FI4 | Digital Input 4 Filter | 1 | 0 ~ 8000 | ms | |
| P5-32 | FI5 | Digital Input 5 Filter | 1 | 0 ~ 8000 | ms | |
| P5-33 | FI6 | Digital Input 6 Filter | 1 | 0 ~ 8000 | ms | |
| P5-34 | FI7 | Digital Input 7 Filter | 1 | 0 ~ 8000 | ms | |
| P5-35 | FI8 | Digital Input 8 Filter | 1 | 0 ~ 8000 | ms | |
| P5-36 | FI9 | Digital Input 9 Filter | 1 | 0 ~ 8000 | ms | |
| P5-37 | FIA | Digital Input 10 Filter | 1 | 0 ~ 8000 | ms | |
| P5-38 | PL | Dynamic Follow Error Threshold | 10 | 0 ~ 2147483647 | pulses | |
| P5-39 | PD | In-position Output Threshold | 40 | 0 ~ 32000 | pulses | |
| P5-40 | PE | Time Constant of Motion Output Condition | 10 | 0 ~ 30000 | ms | |
| P5-41 | TT | Pulse Complete Timing | 2 | 0 ~ 20000 | ms | |
| P5-42 | ZV | Zero Speed Width | 0.5 | 0.1 ~ 2 | rps | |
| P5-43 | VR | Speed Coincidence Width | 0.1 | 0 ~ 100 | rps | |
| P5-44 | VV | Target Value of AT-speed Output | 10 | 0 ~ 100 | rps | |
| P5-45 | TV | Torque Reach Width | 10 | 0 ~ 3000 | 0.1% | |
| P5-46 | DG | Near Target Position | 10000 | -2147483647 ~ +2147483647 | pulses | |
| P5-47 | LP | Positive Software Limit | 0 | -2147483647 ~ +2147483647 | pulses | |
| P5-48 | LM | Negative Software Limit | 0 | -2147483647 ~ +2147483647 | pulses | |
| P5-49 | HE | Homing Method | 1 | -4 ~ 40 | - | |

8.3 Parameter Description

8.3.1 Group P0-XX: PID Parameters

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------|---------|-------|------|-------------|---|---|---|
| P0-00 | UM | Tuning Mode Selection | 0 | 0 ~ 2 | --- | P | V | T | F |

The servo drive provides three gain tuning modes for gain parameters tuning.

| Set value | Tuning Mode | Description | Note |
|-----------|-------------|--|--|
| 0 | No Tuning | Increase or decrease the mechanical stiffness level by setting P0-03. | The mechanical stiffness level is only set by P0-03. Modification other gain parameters is invalid. |
| 1 | Auto Tuning | Performing Auto-tuning, the servo system will estimate the load inertia ratio and set the best mechanical stiffness level automatically. | After Auto-tuning is finished, parameters P0-03 and P0-02 could be modified to optimize the system's performance. Modification other gain parameters is invalid. |
| 2 | Fine Tuning | Set the tuning mode to "Fine Tuning", all gain parameters can be modified to optimize the response of the system. | |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------|---------|--------|------|-------------|---|---|---|
| P0-01 | LY | Load Type | 0 | 0 ~ 10 | --- | P | V | T | F |

Set the current load type.

Setting the load type is conducive to accurate identification and optimization of system gain parameters.

| Set value | Load Type | Description |
|-----------|----------------|--|
| 0 | General Type | Horizontally placed ball-screw, Turntable, etc.. |
| 1 | Stiffness Type | Ball-screw load mounted horizontally on a marble base. Horizontally placed turntable, etc. |
| 2 | Flexible Type | Belt load, etc.. |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------|---------|-----------|-------|-------------|---|---|---|
| P0-02 | NR | Load Inertia Ratio | 0 | 0 ~ 10000 | 0.01倍 | P | V | T | F |

Set the ratio of load inertia to motor rotator inertia.

The load inertial ratio can be indentified in real time when auto-tuning is in progress, and it will be automatically saved after auto-tuning is completed.

If the load inertial ratio is set correctly, P0-05 can represent the system response accurately.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------------|---------|--------|------|-------------|---|---|---|
| P0-03 | Kg | 1st mechanical Stiffness Level | 5 | 1 ~ 20 | --- | P | V | T | F |

The first stiffness level. You can set this while the tuning mode is set to Auto-tuning.

Increase this value can enhance the velocity response and servo stiffness. If set the value too high, it may cause vibration and noise.


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------------|---------|--------|------|-------------|---|---|---|
| P0-04 | KX | 2nd mechanical Stiffness Level | 5 | 1 ~ 20 | --- | P | V | T | F |

The second stiffness level. Increase this value can enhance the velocity response and servo stiffness. If set the value too high, it may cause vibration and noise.

When gain switch function is activated, the second stiffness level will take effect due to conditions. Refer to [Chapter 7.1.6 Gain Select](#) for details.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | |
|-----------|---------|------------------------|---------|-----------|-------|-------------|---|---|
| P0-05 | KP | 1st Position Loop Gain | 52 | 0 ~ 20000 | 0.1Hz | P | V | T |

Set the rigidity gain of position control.
 0 means not used, and 20000 means the proportional action is maximized.
 Increasing this parameter can improve the responsiveness of the system, reduce the position error, and shorten the positioning time.
 When the position loop proportional gain is too small, the system will not respond fast enough and the position error will decrease slowly.
 However, if it is set too large, it may cause vibration.
 The algorithm control block diagram of the position loop is as follows:



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | |
|-----------|---------|--|---------|-----------|------|-------------|---|---|
| P0-07 | KD | 1st Position Loop Derivative Time Constant | 0 | 0 ~ 30000 | ms | P | V | T |

The derivative time constant of Position Loop in the PID control algorithm.
 Setting to zero means that derivative function is not used. The smaller the set value, the stronger the effect of derivative term.
 Running a motor with a pure PI controller the motor would overreact to small errors, creating ever large errors,ultimately becoming unstable. If know what the motor is going to do before it do it, you could prevent this.
 A motor drive can control a motor better if it examines the rate of change of the position error and includes that in its torque calculation. For example, if the motor has error, but the error is decreasing, back off on the torque.
 When the system's ability to suppress vibration is insufficient, there will be obvious vibrations during the acceleration/deceleration, cruising and stopped. This vibrations has a decreasing trend and eventually stabilizes.
 ♦ When the set value of the derivative time constant (KD) is reasonable, the system's ability to suppress vibration is significantly enhanced, and it tends to stabilize quickly.
 ♦ When the derivative time constant (KD) is set too small, the motion system will be too sensitive, easily vibrate and generate noise.


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | |
|-----------|---------|-------------------------------------|---------|-----------|-------|-------------|---|---|
| P0-08 | KE | 1st Position Loop Derivative Filter | 20000 | 0 ~ 40000 | 0.1Hz | P | V | T |

Set the low-pass filter for the first derivative time constant of position loop .
 Set to zero means the low-pass filter does not take effect.
 This filter is a single-output low-pass filter,which is used to filter the derivative output of the PID controller. When setting this value, the cutoff frequency needs to be considered. The default value of 20000 can be used in most applications.
 For a load with a large inertia ratio, it's necessary to increase the position loop gain(P0-05) and reduce the derivative time constant to obtain a good performance. However, excessive gain value may cause jitter, and it's necessary to reduce the derivative low-pass filter P0-08 to prevent jitter and suppress the noise caused by derivative gain.


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|---------------|-------|-------------|---|---|---|
| P0-09 | KL | Velocity Feedforward Gain | 10000 | -30000 ~ 3000 | 0.01% | P | V | T | F |

The value of the reference speed generated by the position loop calculation in the internal trajectory planning and the ratio of this parameter is added to the speed command generated by the position loop, which can reduce the position error and speed error and improve the response speed of the system.

As can be seen from the figure below, when the command speed and position loop gain remain unchanged, increasing the speed feedforward gain will reduce the following position deviation during the movement.



In the servo algorithm, speed feedforward is used in combination with speed feedback to increase the suppression capability. The feedforward value is generated by "trajectory calculation". If the speed feedforward gain is increased, if the servo motor runs well, the calculated speed value of the motor will match the actual speed value, and a shorter positioning time and smaller position following error can be obtained.




| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------------|---------|-----------|-------|-------------|---|---|---|
| P0-10 | KR | Velocity Feedforward Filter | 20000 | 0 ~ 40000 | 0.1Hz | P | V | T | F |

Sets the low pass filter for velocity feedforward.
0 means no filtering effect.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|---------------|-------|-------------|---|---|--|
| P0-11 | KF | 1st Velocity Command Gain | 10000 | -30000 ~ 3000 | 0.01% | P | V | T | |

As motor power per size has gone up so has the size of the loads. As more performance is asked of the servo motor we may need to add more damping. Velocity feedback has been added to the M56S servo drive to provide greater damping for the larger loads.

This term adds in the motor actual Velocity as negative feedback and usually works in conjunction with the Velocity Feedforward term (See above). If the velocity of the motor matches what is expected no feedback value is generated. If however the velocity's do not match the negative feedback helps to "damp" the differences in velocity. Typically both terms are set to the same value.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|-----------|-------|-------------|---|---|--|
| P0-12 | VP | 1st Velocity Loop Gain | 183 | 0 ~ 30000 | 0.1Hz | P | V | T | |

The stiffness gain of the Velocity Loop in the PID control algorithm.

The simplest part of the Velocity Loop is the proportional gain, or VP, term. The drive applies current to the motor in direct proportion to the error. For example, if a motor is not moving, and the shaft is turned by hand or some other force, the drive will increase the motor current until the motor returns to "0" speed. The faster the motor is moved from "0" speed, the more the opposing torque will increase. The VP term (also called VP gain) governs how much torque will be applied for a given amount of velocity error (Vn). In general, more load inertia or load friction, requires more torque and therefore a higher VP gain.

To improve the overall response of the servo system and to reduce position following error, it is necessary to increase the speed loop gain value. Setting the value too high will cause vibration. The response frequency of the speed loop must be 4-6 times higher than the response frequency of the position loop; otherwise, the machinery might vibrate or it might cause overshoot when positioning

When P0-02 (auto estimation or manually set value) is equal to the real inertia ratio (JL/ JM), the real speed loop frequency response is the value set by P0-12.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|-----------|------|-------------|---|---|--|
| P0-13 | VI | 1st Velocity Loop Integral Time Constant | 189 | 0 ~ 30000 | ms | P | V | T | |

Set the Integral Time Constant of the Velocity Loop. The Integral gain will not take effect when the value is set to zero.


If only proportional gain is working without integral gain, the error is hard to decrease to zero quickly, or it may take long time to get zero. The integral time constant accumulates all errors and takes effect together with the proportional gain. A smaller integral time constant (VI) setting can improve the response and responsiveness of the servo system and reduce the following error.

The smaller the set value, the stronger the integral gain. If the set value of the integral time constant (VI) is too small, the excessive rigidity of the system will cause vibration and noise of the entire servo system. This vibration and noise occurs during the entire movement process, and it is always in an oscillating state, which cannot be stabilized.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------------------------|---------|-----------|-------|-------------|---|---|---|
| P0-14 | KK | Acceleration Feedforward Gain | 3000 | 0 ~ 10000 | 0.01% | P | V | T | F |

Acceleration feedforward gain in servo control. The Acceleration Feedforward does not work when set the value to zero. Set to 10000 means that the feedforward effect is maximized.

A larger load usually comes larger load inertia ratio, and a larger inertia can be controlled more easily by estimating the torque required by the system. The acceleration feedforward gain obtains an acceleration value according to the required torque to perform feedforward control and eliminate the following error. The gain coefficient can significantly improve the dynamic response during acceleration and deceleration by giving the open-loop control current of a certain load under a certain acceleration.



The acceleration feedforward gain coefficient can significantly improve the dynamic response during acceleration and deceleration by giving an open-loop control current for a certain load under a certain acceleration.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------------|---------|-----------|-------|-------------|---|---|---|
| P0-15 | KT | Acceleration Feedforward Filter | 20000 | 0 ~ 40000 | 0.1Hz | P | V | T | F |

The low-pass filter of Acceleration Feedforward Gain(P0-14). The filter does not work when set the value to zero.

The filter is a single-output low-pass filter used to filter the output of the acceleration feedforward gain. The smaller the value, the lower the filtering frequency and the more obvious the filtering effect. The default value of 20000 can be used in most situations.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|-----------|-------|-------------|---|---|--|
| P0-16 | KC | 1st Torque Command Filter | 1099 | 0 ~ 40000 | 0.1Hz | P | V | T | |

Filter the command torque of Current Loop.

The filter is a single-output low-pass filter, which is used to filter the output of the PID controller (that is, the reference current). When setting this value, consider the cutoff frequency required for system operation. The default value of 1099 can be used in most applications.

Used in some particular applications, such as:

- 1) There are vibration with audible noise in the mechanical system. You can try reducing this value.
- 2) There is a mechanical resonance, the low-pass filter cutoff frequency can be set below the resonance frequency point so that the output of the control loop will not excite the resonance.
- 3) In a large inertia load system, increasing the position loop gain K_P can obtain a good system response. However, excessive gain will cause jitter, and this filter could be used to be reduced to prevent jitter and vibration.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|-----------|-------|-------------|---|---|---|
| P0-17 | UP | 2nd Position Loop Gain | 52 | 0 ~ 20000 | 0.1Hz | P | V | T | F |

The second group of Proportional Gain for the Position Loop in the PID control algorithm. Refer to parameter P0-05.

For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|-----------|------|-------------|---|---|---|
| P0-19 | UD | 2nd Position Loop Derivative Time Constant | 2000 | 0 ~ 30000 | ms | P | V | T | F |

The second group of Derivative time constant of Position Loop in the PID control algorithm. Refer to parameter P0-07.

For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------------------------------|---------|-----------|-------|-------------|---|---|---|
| P0-20 | UE | 2nd Position Loop Derivative Filter | 15000 | 0 ~ 40000 | 0.1Hz | P | V | T | F |

Set the low-pass filter for the second group of derivative time constant. Refer to parameter P0-08.

For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|---------------|-------|-------------|---|---|---|
| P0-21 | UF | 2nd Velocity Command Gain | 10000 | -30000 ~ 3000 | 0.01% | P | V | T | F |

Set the second group of Velocity Command Gain. Refer to parameter P0-11.

For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|-----------|-------|-------------|---|---|---|
| P0-22 | UV | 2nd Velocity Loop Gain | 183 | 0 ~ 30000 | 0.1Hz | P | V | T | F |

Set the second group of the Proportional Gain for the Velocity Loop in the PID control algorithm. Refer to parameter P0-12.

For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|-----------|------|-------------|---|---|---|
| P0-23 | UG | 2nd Velocity Loop Integral Time Constant | 189 | 0 ~ 30000 | ms | P | V | T | F |

Set the second group of the Integral Time Constant of the Velocity Loop. Refer to parameter P0-13.

For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|-----------|-------|-------------|---|---|---|
| P0-24 | UC | 2nd Torque Command Filter | 1099 | 0 ~ 40000 | 0.1Hz | P | V | T | F |

Set the second group of low-pass filter for the torque command of Current Loop. Refer to parameter P0-16.

For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------------------------------|---------|-----------|-------|-------------|---|---|---|
| P0-25 | XP | Full Closed-loop Position Loop Gain | 52 | 0 ~ 20000 | 0.1Hz | P | V | T | F |

Set the Position Loop Proportional Gain in Full Closed-loop control mode. Refer to parameter P0-05.

For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---|---------|-----------|------|-------------|---|---|---|
| P0-27 | XD | Full Closed-loop Position Loop Derivative Time Constant | 2000 | 0 ~ 30000 | ms | P | V | T | F |

Set the Derivative Time Constant of Position Loop in Full Closed-loop control mode. Refer to parameter P0-07.
For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|-----------|-------|-------------|---|---|---|
| P0-28 | XE | Full Closed-loop Position Loop Derivative Filter | 15000 | 0 ~ 40000 | 0.1Hz | P | V | T | F |

Set the low-pass filter of Derivative Time Constant in Full Closed-loop control mode. Refer to parameter P0-08.
For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|---------------|-------|-------------|---|---|---|
| P0-29 | XF | Full Closed-loop Velocity Command Gain | 10000 | -30000 ~ 3000 | 0.01% | P | V | T | F |

Set the Velocity Command Gain in Full Closed-loop control mode. Refer to parameter P0-11.
For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------------------------------|---------|-----------|-------|-------------|---|---|---|
| P0-30 | XV | Full Closed-loop Velocity Loop Gain | 183 | 0 ~ 30000 | 0.1Hz | P | V | T | F |

Set the Proportional Gain of the Velocity Loop in Full Closed-loop control mode. Refer to parameter P0-12.
For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---|---------|-----------|------|-------------|---|---|---|
| P0-31 | XG | Full Closed-loop Velocity Loop Integral Time Constant | 189 | 0 ~ 30000 | ms | P | V | T | F |

Set the Integral Time Constant of the Velocity Loop in Full Closed-loop control mode. Refer to parameter P0-13.
For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|-----------|-------|-------------|---|---|---|
| P0-32 | XC | Full Closed-loop Torque Command Filter | 1099 | 0 ~ 40000 | 0.1Hz | P | V | T | F |

Set the low-pass filter for the torque command of Current Loop in Full Closed-loop control mode. Refer to parameter P0-16.
For the first group/second group gain switching function, please refer to [Chapter 7.1.6 Gain Switching](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------------|---------|-------|------|-------------|---|---|---|
| P0-33 | SD | Automatic Gain Swiching Method | 0 | 0 ~ 4 | --- | P | V | T | F |

Parameter P0-33 is used to set the method of automatic gain switching.

| Setup Value | Conditions | Swithing Delay Time |
|-------------|---|---------------------|
| 0(Default) | Fix at 1st Gain Group | - |
| 1 | Condition for switching to 2nd Gain Group: Absolute Position following error \geq P0-34 | P0-38 |
| | Condition for switching to 1st Gain Group: Absolute Position following error $<$ P0-34 | P0-37 |
| 2 | Condition for switching to 2nd Gain Group: Absolute value of motor speed \geq P0-35 | P0-38 |
| | Condition for switching to 1st Gain Group: Absolute value of motor speed $<$ P0-35 | P0-37 |
| 3 | Condition for switching to 2nd Gain Group: Absolute value of motor torque \geq P0-36 | P0-38 |
| | Condition for switching to 1st Gain Group: Absolute value of motor torque $<$ P0-36 | P0-37 |
| 4 | Condition for switching to 2nd Gain Group: the positioning is not completed. | P0-38 |
| | Return to 1st Gain Group: the positioning is kept in completed. | P0-37 |



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|----------------|--------|-------------|---|---|---|
| P0-34 | PN | Gain Switch with Position Error Condition Change | 0 | 0 ~ 2147483647 | Pulses | P | V | T | F |

Gain switch condition: Absolute Position Following Error.
 When P0-33(Gain Swiching Method) is set to "1", this parameter is used to set the judgement condition for gain switch.
 If the absolute position following error is greater than the set value of P0-34, switch to 2nd Gain Group.
 If the absolute position following error is smaller than the set value of P0-34, switch to 1st Gain Group.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|---------|------|-------------|---|---|---|
| P0-35 | VN | Gain Switch with Actual Speed Condition Change | 0.000 | 0 ~ 100 | rps | P | V | T | F |

Gain switch condition: Absolute value of motor speed.
 When P0-33(Gain Swiching Method) is set to "2", this parameter is used to set the judgement condition for gain switch.
 If the absolute motor speed is greater than the set value of P0-35, switch to 2nd Gain Group.
 If the absolute motor speed is smaller than the set value of P0-35, switch to 1st Gain Group.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---|---------|----------|------|-------------|---|---|---|
| P0-36 | TN | Gain Switch with Actual Torque Condition Change | 10 | 0 ~ 3000 | 0.1% | P | V | T | F |

Gain switch condition: Absolute value of motor output torque.
 When P0-33(Gain Swiching Method) is set to "3", this parameter is used to set the judgement condition for gain switch.
 If the absolute motor torque is greater than the set value of P0-36, switch to 2nd Gain Group.
 If the absolute motor torque is smaller than the set value of P0-36, switch to 1st Gain Group.


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------------|---------|-----------|------|-------------|---|---|---|
| P0-37 | SE1 | Gain Switching Delay Time 1 | 10 | 0 ~ 10000 | ms | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------------|---------|-----------|------|-------------|---|---|---|
| P0-38 | SE2 | Gain Switching Delay Time 2 | 10 | 0 ~ 10000 | ms | P | V | T | F |

To avoid jitter caused by immediate gain switch, parameters P0-37 and P0-38 define the switch delay in the process of gain switching between the first gain group and the second gain group.

- ◆ When the switching conditions are not met, the first gain group will gradually switch to the second gain group after the rise time of P0-38 gain switching.
- ◆ When the switching conditions are met, the second gain group will gradually switch to the first gain group after the rise time of P0-37 gain switching.

As shown below.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|-------|------|-------------|---|---|---|
| P0-39 | LR | Velocity Feedback Filter | 0 | 0 ~ 3 | --- | P | V | T | F |

The low-pass filter for Speed Feedback in Velocity Loop.

| Setup Value | Low-pass Frequency |
|-------------|--------------------|
| 0 | Not used |
| 1 | 8KHz |
| 2 | 2KHz |
| 3 | 1KHz |

8.3.2 Group P1-XX: Configurations

| Parameter | Command | Description | Default | Range | Unit | Control mode | | | |
|-----------|---------|-------------------|---------|----------------|------|--------------|---|---|---|
| P1-00 | CM | Main Control Mode | 21 | 1,2,7,11,15,21 | - | P | V | T | F |

Parameter P1-00 is used to set the Main Control Mode of the drive.

| Setup Value | Control Mode | Control Signal | Instruction |
|-------------|--------------------------------|--|--|
| 1 | Command Torque Mode | Q program commands or Modbus commands | Use communication commands to control the motor output torque |
| 2 | Analog Torque Mode | +10~-10V Analog input | Use external analog input for torque control |
| 7 | Digital pulse position mode | Pulse & Direction CW/CCW Pulse A/B quard | Use digital pulse for position control |
| 11 | Analog Speed Mode | +10~-10V Analog input | Use external analog input for velocity control |
| 15 | Internal Multi-speed Mode | Digital Inputs | Internal 8-segment speed mode |
| 21 | Internal command position mode | Q program commands or Modbus commands | Use communication commands to control point-to-point position control. |

| Parameter | Command | Description | Default | Range | Unit | Control mode | | | |
|-----------|---------|------------------------|---------|----------------|------|--------------|---|---|---|
| P1-01 | CN | Secondary Control Mode | 21 | 1,2,7,11,15,21 | - | P | V | T | F |

Parameter P1-01 is used to set the Secondary Control Mode of the drive.

| Setup Value | Control Mode | Control Signal | Instruction |
|-------------|--------------------------------|--|--|
| 1 | Command Torque Mode | Q program commands or Modbus commands | Use communication commands to control the motor output torque |
| 2 | Analog Torque Mode | +10~-10V Analog input | Use external analog input for torque control |
| 7 | Digital pulse position mode | Pulse & Direction CW/CCW Pulse A/B quard | Use digital pulse for position control |
| 11 | Analog Speed Mode | +10~-10V Analog input | Use external analog input for velocity control |
| 15 | Internal Multi-speed Mode | Digital Inputs | Internal 8-segment speed mode |
| 21 | Internal command position mode | Q program commands or Modbus commands | Use communication commands to control point-to-point position control. |

For control mode switching, please refer to [Chapter: 7.1.7 Control Mode Select](#)

| Parameter | Command | Description | Default | Range | Unit | Control mode | | | |
|-----------|---------|------------------------------|---------|--------|------|--------------|---|---|---|
| P1-02 | PM | Operation Mode When Power-up | 10 | 8 ~ 10 | - | P | V | T | F |

Parameter P1-02 is used to set the communication mode and servo operation mode after power-up.

| Setup Value | Power-up Mode |
|-------------|---|
| 8 | Automatically enable the servo drive after power-up, and support Modbus communication, the Q program is not executed. |
| 9 | Automatically enable the servo drive and execute Q program after power-up. Modbus communication is supported. |
| 10 | After power-on, the servo is disabled and the Q program is not executed. Modbus communication is supported. |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|-------|------|-------------|---|---|---|
| P1-03 | JM | Speed Control Clamp Mode | 2 | 1 ~ 2 | - | P | V | T | F |

You can chose to use the position loop in speed control mode or torque control mode.

| Setup Value | Mode | Description |
|-------------|-----------------------|---|
| 1 | Use the Position-loop | The position-loop takes effect and the position error is detected in real time in speed control mode or torque control mode. When the position error exceeds the set value of parameter P3-04, a Position Following Error will occur. |
| 2 | Speed-loop Only | Only Speed-loop takes effect. |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------------|---------|-------|------|-------------|---|---|---|
| P1-04 | XM | Full Closed-loop Control Switch | 0 | 0, 1 | - | P | V | T | F |

Switch of full closed-loop control mode.

| Setup Value | Description |
|-------------|---------------------------------------|
| 0 | Full closed-loop control is disabled. |
| 1 | Full closed-loop control is enabled. |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---|---------|--------------|------|-------------|---|---|---|
| P1-05 | GC | Torque Command for Internal Torque Mode | 0 | -3000 ~ 3000 | 0.1% | P | V | T | F |

This parameter is used to set the target output torque of motor when using internal torque mode or Modbus communication control mode.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------|---------|----------|------|-------------|---|---|---|
| P1-06 | CC | 1st Torque Limit | 3000 | 0 ~ 3000 | 0.1% | P | V | T | F |

Set up the first limit value of the motor output torque.

Refer to [Chapter 7.5 Torque Limit](#) for more details.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------------------|---------|----------|------|-------------|---|---|---|
| P1-07 | CV | Target Torque when Torque Reached | 0 | 0 ~ 3000 | 0.1% | P | V | T | F |

Set the detecting value to output Torque Reach signal.

When the actual motor output torque exceeds the P1-07 and the torque fluctuation is within the range of P5-45, the TQ-REACH signal will be output.

Refer to [Chapter 7.4.7 Torque Reach Output](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------------------|---------|----------|------|-------------|---|---|---|
| P1-08 | HC | Torque Limit for Hard Stop Homing | 200 | 0 ~ 3000 | 0.1% | P | V | T | F |

The homing methods -4 ~ -1,AKA Hard-stop Homing, are manufacturer customized methods that don't need external switch sensor. By detecting the torque of the motor during the homing process, when the position that the moving load is blocked by the mechanical hard limit, and the output torque of the motor is equal to the set current threshold, than the motor stops and set the encoder position to zero, this is the mechanical origin.


The current threshold is set by parameter P1-08(Torque Limit for Hard Stop Homing).

Refer to [Chapter 7.10 Homing Mode](#) for more details.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|----------------------------------|---------|-----------|------|-------------|---|---|---|
| P1-09 | CL | Current Foldback Continuous Time | 0 | 0 ~ 30000 | ms | P | V | T | F |

The servo can provide overload torque for a short time, the maximum overload output torque is set by parameter P1-06, and the duration of overload torque output is by the parameter P1-09.

- When the duration of overload is greater than P1-09, alarm code **r16CL** (Current Limit) will occur.
- Too large set value and long-time overload will easily cause the the motor overheat and damage.
- This function doesn't take effect in Torque Contol Mode.
- Even if the value is set to "0", alarm code **r16CL** will not be generated, the servo motor still provides overload torque output for 2 seconds.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------|---------|-------|------|-------------|---|---|---|
| P1-10 | LD | Torque Limit Method | 1 | 1 ~ 5 | ms | P | V | T | F |



Parameter P1-10 defines 6 kinds of torque limit methods which are shown as follows.

| P1-10 Torque Limit Method | Positive Torque Limit Source | Negative Torque Limit Source |
|---------------------------|--------------------------------|--------------------------------|
| 0 | Register [Y] | Register [Z] |
| 1 (Default) | Parameter P1-06 | |
| 2 | Parameter P1-06 | Parameter P1-25 |
| 3 | TQ-LMT input is valid: P1-06 | |
| | TQ-LMT input is invalid: P1-25 | |
| 4 | Analog input 2(AIN2) | |
| 5 | TQ-LMT input is valid: P1-06 | TQ-LMT input is valid: P1-25 |
| | TQ-LMT input is invalid: P1-26 | TQ-LMT input is invalid: P1-27 |

Refer to [Chapter 7.5 Torque Limit](#) for more details.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|----------------------------|---------|-------|------|-------------|---|---|---|
| P1-11 | RN | Rotational Direction Setup | 0 | 0, 1 | - | P | V | T | F |

Setup the relationship between the direction of command and direction of motor rotation

| Setup Value | Rotation Direction | Description |
|-------------|---|--|
| 0 |  Rotates Positive Direction at Clockwise | Motor rotates CW in response to positive direction command (CW when viewed from load side shaft end) |
| 1 |  Rotates Positive Direction at Counterclockwise | Motor turns CCW in response to positive direction command (CCW when viewed from load side shaft end) |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------|---------|-------|------|-------------|---|---|---|
| P1-12 | IF | Immediate Format | H | D,H | - | P | V | T | F |

Data format when using SCL command.

| Setup Value | Data Format |
|-------------|-------------|
| D | Decimal |
| H | Hexadecimal |

For example the "IE" command is used to get the current position of the encoder. Suppose the current position value in decimal is "20000", if this parameter is set to "H", the return value of IP is 4E20 in hexadecimal.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|---------|------|-------------|---|---|---|
| P1-13 | PR | Communication Protocol | 5 | 1 ~ 511 | - | P | V | T | F |

The serial communication protocol settings. There are a number of settings that can be turned on or off in the PR command. Each setting is assigned a bit in a 8-bit binary word. The parameter of the PR command is the decimal equivalent of this word. If you send the PR command without a parameter the drive will respond with the decimal equivalent of the word as well. The different protocol settings and their bit assignments are shown below.

- Bit 0 = Default ("Standard SCL")
- bit 1 = Always use Address Character
- bit 2 = Ack/Nack
- bit 3 = Checksum (RESERVED)
- bit 4 = RS-485 Adaptor
- bit 5 = 3-digit numeric register addressing
- bit 6 = Checksum Type
- bit 7 = Little endian or big endian used in MODBUS type drive
- bit 8 = Full Duplex in RS-485

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|----------------|---------|--------|------|-------------|---|---|---|
| P1-14 | TD | Transmit Delay | 2 | 0 ~ 20 | ms | P | V | T | F |

The time delay used by the drive when responding to a command that requests a response. Typically this is needed when using the 2-wire RS-485 interface (Half-duplex). Because the same wires are used for both receive and transmit a time delay is usually needed to allow transition time.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------|---------|-------|------|-------------|---|---|---|
| P1-15 | BR | RS-485 Baud Rate | 1 | 1 ~ 5 | - | P | V | T | F |

The baud rate that takes effect after power-on in serial communication. This value will be saved immediately after being configured but will not take effect immediately until the next power-on, so the host can configure this value at any time.

| Setup Valuse | Baud Rate |
|--------------|-----------|
| 1 | 9600bps |
| 2 | 19200bps |
| 3 | 38400bps |
| 4 | 57600bps |
| 5 | 115200bps |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------|---------|--------|------|-------------|---|---|---|
| P1-16 | DA | RS485 Address | 32 | 1 ~ 32 | - | P | V | T | F |

The drive unique address character for multi-axis RS-485 or Modbus/RTU communications.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------------|---------|------------|------|-------------|---|---|---|
| P1-19 | ZR | Regeneration Resistor Value | 200 | 10 ~ 32000 | Ω | P | V | T | F |

This parameter sets the resistance of the regenerative energy absorption resistor, the drive calculates the discharge power of the resistor according to the current voltage and this resistance.

The default setup value is the resistance of build-in absorption resistor. When an external resistor is used, a correct value must be set.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|-----------|------|-------------|---|---|---|
| P1-20 | ZC | Regeneration Resistor Continuous Wattage | 40 | 1 ~ 32000 | W | P | V | T | F |

Set the heat dissipation power of the regenerative energy absorption resistor.

The drive calculates the power continuously according to the current absorption power and its dissipated power so as to avoid damage to the absorption resistor.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------------------------------|---------|----------|------|-------------|---|---|---|
| P1-21 | ZT | Regeneration Resistor Time Constant | 1000 | 0 ~ 8000 | ms | P | V | T | F |

The time of the regenerative resistor can continuously absorb the regenerative energy.

For more details about the regeneration energy, refer to [Chapter 4.7 Regenerative Resistor Settings](#).

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------|---------|-------|------|-------------|---|---|---|
| P1-22 | PK | Key Setting Lock | 0 | 0, 1 | - | P | V | T | F |

The buttons below the drive LED display panel can be used to modify or set parameters. To prevent misoperation by people who are not familiar with the servo drive, a key lock function is provided. When the keys are locked, parameters can not be changed by operation panel.

| Setpup Value | Description |
|--------------|---------------------------------------|
| 0 | Parameters can be changed by Keys |
| 1 | Parameters can not be changed by Keys |

Note:

When the Keys are blocked, all the parameters except P1-22 CANNOT be changed. This parameter must be set to "0" before changing other parameters.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------|---------|--------|------|-------------|---|---|---|
| P1-23 | DD | LED Default Display | 0 | 0 ~ 20 | - | P | V | T | F |

Set the content displayed on the LED panel after the drive is power-on.

| Status | Description | Unit |
|--------|--------------------------|----------|
| n00 | Motor Actual Speed | RPM |
| n01 | Position Error | Pulse |
| n02 | Pulses Input Counter | counts |
| n03 | Encoder Feedback Counter | counts |
| n04 | Position Command Counter | counts |
| n05 | Drive Temperature | x 0.1 °C |
| n06 | DC-Bus Voltage | x 0.1V |
| n07 | Communications Address | |
| n08 | Alarm History 1 | |
| n09 | Alarm History 2 | |
| n10 | Alarm History 3 | |
| n11 | Alarm History 4 | |
| n12 | Alarm History 5 | |
| n13 | Alarm History 6 | |
| n14 | Alarm History 7 | |
| n15 | Alarm History 8 | |
| n16 | Analog Input 1 | x 0.001V |
| n17 | Analog Input 2 | x 0.001V |
| n18 | Digital Inputs States | |
| n19 | Digital Outputs States | |
| n20 | Torque Output percent | 0.1% |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------|------------|----------------|------|-------------|---|---|---|
| P1-24 | MA | Alarm Mask | 4294967295 | 0 ~ 4294967295 | - | P | V | T | F |

When there are some non-serous warning, the corresponding bits of this parameter can shield these warnings displayed on drive's LED. When the shield warning is occurred, it will no longer be displayed on the LED.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------|---------|----------|------|-------------|---|---|---|
| P1-25 | CX | 2nd Torque Limit | 3000 | 0 ~ 3000 | 0.1% | P | V | T | F |

Set up the second limit value of the motor output torque. Refer to [Chapter 7.5 Torque Limit](#) for more details.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------|---------|----------|------|-------------|---|---|---|
| P1-26 | CY | 3rd Torque Limit | 3000 | 0 ~ 3000 | 0.1% | P | V | T | F |

Set up the third limit value of the motor output torque. Refer to [Chapter 7.5 Torque Limit](#) for more details.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------|---------|----------|------|-------------|---|---|---|
| P1-27 | CZ | 4th Torque Limit | 3000 | 0 ~ 3000 | 0.1% | P | V | T | F |

Set up the fourth limit value of the motor output torque.
Refer to [Chapter 7.5 Torque Limit](#) for more details.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------------|---------|-----------|------|-------------|---|---|---|
| P1-28 | HT | Motor Stall protection time | 0 | 0 ~ 30000 | ms | P | V | T | F |

In position control mode or in speed control mode with position loop(for example P1-03 = 1), the drive will keep outputing rated torque if the motor is stalled, which may cause the motor overheat.
This parameter is used to set the protection time in such situation. When the actual output current is equal to the rated current of the motor and the time exceeds the setting value of P1-28, an alarm which is Motor Stalled(alarm code r37) will be generated and the drive will be disabled.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------------------|---------|-------|------|-------------|---|---|---|
| P1-29 | YV | Dynamic Brake Sequence when Servo Off | 0 | 0 ~ 5 | --- | P | V | T | F |

If the servo state changes from servo-on to servo-off, the action mode of dynamic brake is set by P1-29 and the maximum braking time is set by P1-31.
The braking time refers to the total time for the motor actual speed to decelerate to the threshold speed set by P5-42 when the dynamic brake takes effect.
The deceleration period means that the actual speed of the motor decelerates from the speed when the dynamic brake takes effect to within the set value of parameter P5-42, or the deceleration time reaches the set time of P1-31.

| P1-29 | Description | |
|-------|--|---------------|
| | Deceleration period | Stopped |
| 0 | Decelerate according to the setting of parameter P2-01 | Free Run |
| 1 | Decelerate according to the setting of parameter P2-01 | Dynamic Brake |
| 2 | Free Run | Free Run |
| 3 | Free Run | Dynamic Brake |
| 4 | Dynamic Brake | Free Run |
| 5 | Dynamic Brake | Dynamic Brake |


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|-------|------|-------------|---|---|---|
| P1-30 | YR | Dynamic Brake Sequence when Fault Occurs | 0 | 0 ~ 3 | | P | V | T | F |

When the servo fault occurs, the action mode of dynamic brake is set by P1-30 and the maximum braking time is set by P1-31.

| P1-30 | Description | |
|-------|---------------------|---------------|
| | Deceleration period | Stopped |
| 0 | Free Run | Free Run |
| 1 | Free Run | Dynamic Brake |
| 2 | Dynamic Brake | Free Run |
| 3 | Dynamic Brake | Dynamic Brake |


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|-----------|------|-------------|---|---|---|
| P1-31 | YM | Dynamic Brake Action Time during Deceleration of Servo Off | 500 | 0 ~ 30000 | ms | P | V | T | F |

This parameter sets the maximum braking time of dynamic brake during deceleration period after the servo-off. When the deceleration time exceeds the setting of P1-31, even if the actual speed is still greater than the setting value of P5-42, the dynamic brake will stop working to protect the internal braking resistor. The following figure shows dynamic braking process when P1-29 = 4.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---|---------|-----------|------|-------------|---|---|---|
| P1-32 | YN | Dynamic Brake Action Time during Deceleration when Fault Occurs | 0 | 0 ~ 30000 | ms | P | V | T | F |

This parameter sets the maximum braking time of dynamic brake during deceleration period after the drive gets a fault. When the deceleration time exceeds the setting of P1-32, even if the actual speed is still greater than the setting value of P5-42, the dynamic brake will stop working to protect the internal braking resistor. The following figure shows dynamic braking process when P1-30 = 2.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|-------|------|-------------|---|---|---|
| P1-33 | OT | Phase Lost Detect Switch | 0 | 0 ~ 1 | | P | V | T | F |

Drive's power supply phase loss detection switch.

If this function is turned on, when it is detected that there is a phase loss in the power supply of the drive, an alarm of "Phase loss of main circuit"(Alarm code r19) will occur.

| Setup Value | Description |
|-------------|-------------|
| 0 | Disable |
| 1 | Enable |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------|---------|----------|------|-------------|---|---|---|
| P1-34 | RT | Current Ramp Limit | 1000 | 0 ~ 3000 | 0.1% | P | V | T | F |

This parameter sets the current ramp up limit value when the current change instantaneously.

When the servo system detects that the current ramp up exceeds this limit value, a "Motor Collision Alarm" (Alarm code r41)will occur.

8.3.3 Group P2-XX: Trajectory

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------|---------|---------|------|-------------|---|---|---|
| P2-00 | VM | Max Velocity | 80 | 0 ~ 100 | rps | P | V | T | F |

The maximum motor velocity in rev/sec. Used in all control mode to limit the maximum speed of the drive.
If the actual speed exceeds the set value of P2-00 for 400ms, an alarm of "Motor Over Speed" (Alarm code r12) will occur.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|--------------|-------|-------------|---|---|---|
| P2-01 | AM | Max Brake Deceleration | 3000 | 0.167 ~ 5000 | rps/s | P | V | T | F |

The maximum acceleration/deceleration allowed. When the targeted acceleration/deceleration exceeds the maximum value, the actual acceleration/deceleration will limit to the maximum value.
Also sets the deceleration rate used when an end-of-travel limit is activated during a move or an emergency stop command is executed.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------|---------|------------|------|-------------|---|---|--|
| P2-02 | JS | Jog Velocity | 10 | -100 ~ 100 | rps | P | V | T | |

The speed for Jog moves in internal speed control mode.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------|---------|--------------|-------|-------------|---|---|--|
| P2-03 | JA | Jog Acceleration | 100 | 0.167 ~ 5000 | rps/s | P | V | T | |


The acceleration rate for Jog moves and internal velocity control mode.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------|---------|--------------|-------|-------------|---|---|--|
| P2-04 | JL | Jog Deceleration | 100 | 0.167 ~ 5000 | rps/s | P | V | T | |

The deceleration rate for Jog moves and internal velocity control mode.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------|---------|---------|------|-------------|---|---|---|
| P2-05 | JT | Jerk Time | 10 | 0 ~ 125 | ms | P | V | T | F |

The FIR filter time of internal trajectory planning control command, for example: internal position/velocity/torque control mode, analog velocity control mode, analog torque control mode and communication command control mode.
The smoothing effect of Jerk Filter to the input command is shown in the figure below.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------------------|---------|--------------|------|-------------|---|---|---|
| P2-06 | VE | Point-to-Point Velocity | 10 | 0.0042 ~ 100 | rps | P | V | T | F |

The target motor speed for point-to-point move.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------------|---------|--------------|-------|-------------|---|---|---|
| P2-07 | AC | Point-to-Point Acceleration | 100 | 0.167 ~ 5000 | rps/s | P | V | T | F |

The acceleration rate used in point-to-point move commands in rev/sec/sec.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------------|---------|--------------|-------|-------------|---|---|---|
| P2-08 | DE | Point-to-Point Deceleration | 100 | 0.167 ~ 5000 | rps/s | P | V | T | F |

The deceleration rate used in point-to-point move commands in rev/sec/sec.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------------|---------|---------|------|-------------|---|---|---|
| P2-09 | VC | Point-to-Point Change Velocity | 2 | 0 ~ 100 | rps | P | V | T | F |

If the internal position control command which supports point-to-point move with variable speed control, this parameter is used to set the speed of second stage.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------------------|---------|------------|------|-------------|---|---|--|
| P2-10 | JC1 | Internal Velocity Control: Speed 1 | 2 | -100 ~ 100 | rps | P | V | T | |

The first speed setting value for Internal Velocity Control.

For more details about multi-speed control, refer to [Chapter 7.11 Internal Velocity Control](#)

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------------------|---------|------------|------|-------------|---|---|--|
| P2-11 | JC2 | Internal Velocity Control: Speed 2 | 10 | -100 ~ 100 | rps | P | V | T | |

The second speed setting value for Internal Velocity Control.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------------------|---------|------------|------|-------------|---|---|--|
| P2-12 | JC3 | Internal Velocity Control: Speed 3 | 20 | -100 ~ 100 | rps | P | V | T | |

The third speed setting value for Internal Velocity Control.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------------------|---------|------------|------|-------------|---|---|--|
| P2-13 | JC4 | Internal Velocity Control: Speed 4 | 25 | -100 ~ 100 | rps | P | V | T | |

The fourth speed setting value for Internal Velocity Control.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------------------|---------|------------|------|-------------|---|---|--|
| P2-14 | JC5 | Internal Velocity Control: Speed 5 | 30 | -100 ~ 100 | rps | P | V | T | |

The fifth speed setting value for Internal Velocity Control.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------------------|---------|------------|------|-------------|---|---|--|
| P2-15 | JC6 | Internal Velocity Control: Speed 6 | 35 | -100 ~ 100 | rps | P | V | T | |

The sixth speed setting value for Internal Velocity Control.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------------------|---------|------------|------|-------------|---|---|--|
| P2-16 | JC7 | Internal Velocity Control: Speed 7 | 40 | -100 ~ 100 | rps | P | V | T | |

The seventh speed setting value for Internal Velocity Control.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------------------|---------|------------|------|-------------|---|---|--|
| P2-17 | JC8 | Internal Velocity Control: Speed 8 | 50 | -100 ~ 100 | rps | P | V | T | |

The eighth speed setting value for Internal Velocity Control.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|----------------------------------|---------|--------------|-------|-------------|---|---|--|
| P2-18 | HA1 | Homing Acceleration/Deceleration | 100 | 0.167 ~ 5000 | rps/s | P | V | T | |

The acceleration and deceleration rate used in first stage of homing mode.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------------|---------|--------------|------|-------------|---|---|--|
| P2-24 | HV1 | Homing Velocity 1 | 10 | 0.0042 ~ 100 | rps | P | V | T | |


This parameter set the velocity used in first stage of homing mode.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------------|---------|--------------|------|-------------|---|---|--|
| P2-25 | HV2 | Homing Velocity 2 | 1 | 0.0042 ~ 100 | rps | P | V | T | |

This parameter set the velocity used in second stage of homing mode.

| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|---------------|---------|---------------------------|--------|-------------|
| P2-27 | HO | Homing Offset | 0 | -2147483647 ~ +2147483647 | pulses | P V T |


The offset distance after homing is completed.



P2-18, P2-24, P2-25 and P2-27 are the configuration parameters of the build-in homing function, refer to [Chapter 7.10 Homing](#) for more detailed.

| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|-------------|---------|----------|------|-------------|
| P2-28 | KJ | Jerk Filter | 0 | 0 ~ 1000 | ms | P V T F |

Parameter P2-28 Low-pass Jerk Filter can take effect in all control modes, such as: external pulse control position mode, internal trajectory mode (position, speed, torque), analog position, analog speed, analog torque, Communication command control(SCL or Modbus), etc. The smoothing effect of Low-pass Jerk Filter to the input command is shown in the figure below.



- ◆ The low-pass jerk filter will cause a certain delay to the input command pulse, but it will not affect the final positioning accuracy.
- ◆ The larger the time constant of P2-28 is, the more smoothing effect will be, and the command delay will also increase. A reasonable filter time constant should be set according to the actual application.


Refer to [Chapter 7.2.5 Command Smoothing Filter](#) for more detailed.

| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|----------------------|---------|---------|------|-------------|
| P2-29 | FF | Interpolation Filter | 10 | 0 ~ 125 | ms | P V T F |

Parameter P2-29 Interpolation Filter works in the pulse position control mode, applicable to the following application scenarios:

- ◆ Input pulse command does not perform acceleration or deceleration.
- ◆ The frequency of input pulse command changes suddenly.
- ◆ The frequency of input pulse command is extremely low.

The smoothing effect of the Interpolation Filter to the input command is shown in the figure below.



- ◆ Interpolation filter will cause a certain delay to the input command pulse, but it will not affect the final positioning accuracy.
- ◆ The larger the time constant of P2-29 is, the more smoothing effect will be, and the command delay will also increase. A reasonable filter time constant should be set according to the actual application.

| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|----------------------------------|---------|---------|------|-------------|
| P2-30 | VT | Velocity Limit of Torque Control | 80 | 0 ~ 100 | rps | P V T |

In torque mode, when the internal speed limit is used as the speed limit source, this parameter is used as the speed limit value.

Refer to [Chapter 7.4.5 Speed Limit in Torque Control Mode](#).

8.3.4 Group P3-XX: Encoder & Step/Dir Configuration

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------------------|---------|------------|------|-------------|---|---|---|
| P3-00 | EN | Electronic Gear Ratio - Numerator | 32000 | 0 ~ 131072 | - | P | V | T | F |

This parameter defines the numerator of Electronic Gear Ratio.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------------------------------|---------|------------|------|-------------|---|---|---|
| P3-01 | EU | Electronic Gear Ratio - Denominator | 32000 | 0 ~ 131072 | - | P | V | T | F |

This parameter defines the denominator of Electronic Gear Ratio.

The electronic gear ratio is to multiply the pulse input command by the electronic gear ratio as the position command reference. By using this function, the motor rotation and movement amount corresponding to the input command pulse can be set.

$$\text{External Position Pulse Command (Communication Position Command)} \times \frac{\text{P3-00 (Electronic Gear Ratio-Denominator)}}{\text{P3-01 (Electronic Gear Ratio-Numerator)}} = \text{Reference Position Command}$$

Refer to [Chapter 7.2.4 Electronic Gear Ratio](#) for more detailed settings.


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|-----------|-------|-------------|---|---|---|
| P3-02 | SZ | Pulse Input Noise Filter | 2 | 0 ~ 32000 | 0.1μs | P | V | T | F |

Using paratermer P3-02 Pulse Input Noise Filter to filte the input pulse signal to prevent it from being interfered and cause inaccurate positioning and other problems. This noise filter is a low-pass filter, and the unit is 0.1μs.

Instructions:

- Ts: The set value of P3-02 pulse input noise filter
- T1: The high voltage level width of input pulse
- T2: The low voltage level width of input pulse

Then the relationship between the input pulse signal and the the filtered signal is as follows.



- ◆ Both T1 and T2 of a pulse are bigger than Ts, this input pulse is valid.
- ◆ One of T1 and T2 of a pulse is smaller than Ts, this input pulse will be filtered.

$$\text{Noise Filter time :Ts} \leq \frac{1}{A \times \text{Pulse Input Frequency (Hz)}}$$

Generally, when the duty cycle of the input frequency is 50%, the value of A is 4 or 5.

Refer to [Chapter 7.2.3.5 Pulse Input Noise Filter](#) for more detailed settings.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------|---------|--------|------|-------------|---|---|---|
| P3-03 | PT | Pules Input Setting | 9 | 0 ~ 31 | | P | V | T | F |

Parameter P3-03 is used to set the input pulse command source, pulse type, rotation direction and pulse edge valid type.

| P3-03 Pulse input setting | | | | | | | |
|---------------------------|------|------|--|--|--|--|------|
| bit7 | bit6 | bit5 | bit4 | bit3 | bit2 | bit1 | bit0 |
| 0 | 0 | 0 | 0: Open-colector input 1: Line receiver input | 0: Valid on falling edge 1: Valid on raising edge | 0: Positive Direction 1: Negative Direction | bit1=0,bit0=1: Pulse & Direction bit1=1,bit0=0: CW/CCW bit1=1,bit0=1: A/B Quadrature | |

bit0 & bit1: Pulse command type
bit2: Rotation direction
bit3: Valid pulse setting
bit4: Pulse input source

◆ **Input Pulse Type:**

There are three types of input pulse: Pulse & Direction, CW/CCW pulse, A/B quadrature pulse that is set by bit 0 and bit 1 of parameter P3-03.

| bit 1 | bit 0 | Input pulse type |
|-------|-------|----------------------------|
| 0 | 1 | Pulse & Direction(Default) |
| 1 | 0 | CW/CCW pulse |
| 1 | 1 | A/B quadrature pulse |

◆ **Rotation Direction:**

Bit 2 of parameter P3-03 determines the relationship between the input pulse and the rotation direction of the motor, as shown in the figure below.

| Bit2 | Input pulse type | Positive Direction | | Negative Direction | |
|----------------|-------------------|---|--|---|--|
| 0 (Default) | Pulse & Direction | Positive rotation when the direction signal keeps CLOSED. | | Negative rotation when the direction signal keeps OPEN. | |
| | CW/CCW pulse | When the CW pulse input, and the CCW keeps Open, it is positive rotation. | | When the CCW pulse input, and the CW keeps Open, it is negative rotation. | |
| | A/B quadrature | When phase-A leads phase-B by 90 degree, it is positive rotation | | When phase-B leads phase-A by 90 degree, it is negative rotation | |

| | | | | | |
|---|-------------------|---|--|---|--|
| 1 | Pulse & Direction | Positive rotation when the direction signal keeps OPEN | | Negative rotation when the direction signal keeps CLOSED. | |
| | CW/CCW pulse | When the CCW pulse input, and the CW keeps Open, it is positive rotation. | | When the CW pulse input, and the CCW keeps Open, it is negative rotation. | |
| | A/B quadrature | When phase-B leads phase-A by 90 degree, it is positive rotation | | When phase-A leads phase-B by 90 degree, it is negative rotation | |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------|---------|--------|------|-------------|---|---|---|
| P3-03 | PT | Pules Input Setting | 9 | 0 ~ 31 | | P | V | T | F |

◆ **Valid Pulse Edge Setting:**

Bit 3 of parameter P3-03 determines the valid edge condition of input pulse.

| bit 3 | Valid edge |
|-------|--------------------------------|
| 0 | Valid on falling edge(Default) |
| 1 | Valid on raising edge |

◆ **Pulse input source**

Bit 4 of parameter P3-03 sets the input port for the position pulse command. There are variety input ports in M56S series, it is necessary to select the appropriate pulse input port according to the pulse type of the controller and the drive model.

| |
|-------------------------|
| 0: Open-collector input |
| 1: Line receiver input |

1) There are two pulse input sources in -F & -R Type (50-Pin CN2 Connector) of M56S series.

◆ **When bit4 = 0, Open-collector Pulse Inputs (or Low-speed pulse signal input) is selected.**

| bit4 | CN2-Pin NO. | Signals | Wiring Diagram |
|------|-------------|---------|----------------|
| 0 | 1 | OPC1 | |
| | 3 | STEP+ | |
| | 4 | STEP- | |
| | 2 | OPC2 | |
| | 5 | DIR+ | |
| | 6 | DIR- | |

◆ **When bit4 = 1, Line Driver pulse Inputs(or High-speed pulse signal input) is selected.**

| bit4 | CN2-Pin NO. | Signals | Wiring Diagram |
|------|-------------|---------|----------------|
| 1 | 44 | PULSH+ | |
| | 45 | PULSH- | |
| | 46 | SIGNH+ | |
| | 47 | SIGNH- | |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------|---------|--------|------|-------------|---|---|---|
| P3-03 | PT | Pules Input Setting | 9 | 0 ~ 31 | | P | V | T | F |

2) -X & -N Type (26-Pin CN2 Connector) of M56S series

◆ When bit4 = 0, Open-collector Pulse Inputs (or Low-speed pulse signal input) is selected.

| bit4 | CN2-Pin NO. | Signals | Wiring Diagram |
|------|-------------|-----------------------|----------------|
| 0 | 26 | STEP+ | |
| | 25 | STEP- | |
| | 24 | DIR+ | |
| | 23 | DIR- | |
| | | Pulse command input | |
| | | Pulse direction input | |

◆ When bit4 = 1, Line Driver pulse Inputs(or High-speed pulse signal input) is selected.








| bit4 | CN2-Pin NO. | Signals | Wiring Diagram |
|------|-------------|-----------------------|----------------|
| 1 | 10 | PULSH+ | |
| | 9 | PULSH- | |
| | 8 | SIGNH+ | |
| | 7 | SIGNH- | |
| | | Pulse command input | |
| | | Pulse direction input | |

Note:

The RS-485 type driver does not support the high-speed pulse input of the Line Driver, only supports the pulse signal of the open-collector. When using this type drive, please set bit4 of parameter P3-03 to "0".

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------|---------|--------|------|-------------|---|---|---|
| P3-03 | PT | Pules Input Setting | 9 | 0 ~ 31 | | P | V | T | F |

Quick setup for P3-03

| Valid pulse edge | Rotation direction | Pulse command type | | | | Positive | Negative | Parameter P3-03 Set value (Decimal) | |
|------------------|--------------------|--------------------|------|-----------------|---|---|----------|-------------------------------------|---------------|
| | | bit3 | bit2 | bit1 | bit0 | | | Open-collector | Line receiver |
| 0 | 0 | 0 | 1 | Pulse & Dircion | Pulse Input  Direction  Closed | Pulse Input  Direction  Open | 1 | 17 | |
| 0 | 0 | 1 | 0 | CW/CCW | CW  CCW  Open | CW  CCW  | 2 | 18 | |
| 0 | 0 | 1 | 1 | A/B | Phase-A  Phase-B  | Phase-A  Phase-B  | 3 | 19 | |
| 0 | 1 | 0 | 1 | Pulse & Dircion | Pulse Input  Direction  Open | Pulse Input  Direction  Closed | 5 | 21 | |
| 0 | 1 | 1 | 0 | CW/CCW | CW  CCW  | CW  CCW  Open | 6 | 22 | |
| 0 | 1 | 1 | 1 | A/B | Phase-A  Phase-B  | Phase-A  Phase-B  | 7 | 23 | |
| 1 | 0 | 0 | 1 | Pulse & Dircion | Pulse Input  Direction  Closed | Pulse Input  Direction  Open | 9 | 25 | |
| 1 | 0 | 1 | 0 | CW/CCW | CW  CCW  Open | CW  CCW  | 10 | 26 | |
| 1 | 1 | 0 | 1 | Pulse & Dircion | Pulse Input  Direction  Open | Pulse Input  Direction  Closed | 13 | 29 | |
| 1 | 1 | 1 | 0 | CW/CCW | CW  CCW  | CW  CCW  Open | 14 | 30 | |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|----------------------|---------|----------------|--------|-------------|---|---|---|
| P3-04 | PF | Position Error Limit | 100000 | 0 ~ 2147483647 | pulses | P | V | T | F |

During the movement, when the deviation between the target position and the actual position fed back by the encoder exceeds the set value of P3-04, an error "Position Following Error" will occur, and the LED display panel of the driver will display an error code **r 10PL**.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------------------------|---------|--------------|------------|-------------|---|---|---|
| P3-05 | EG | Command Pulses per revolution | 10000 | 200 ~ 131072 | pulses/rev | P | V | T | F |

Set the required number of pulses to make the motor rotates one revolution.
 When parameter P3-16 is set to zero, this parameter setting is invalid. The required number of pulse per revolution is set by electronic gear ratio, that is, by the parameter P3-00(Electronic Gear Ratio - Numerator) and P3-01(Electronic Gear Ratio - Denominator).


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|-------|------|-------------|---|---|---|
| P3-06 | PV | Second Encoder Direction | 0 | 0 ~ 1 | - | P | V | T | F |

Define the direction of the second encoder in full closed-loop control mode.

| Setup Value | Description |
|-------------|---|
| 0 | In positive direction, the second encoder's Phase-A leads Phase-B 90 degrees. |
| 1 | In positive direction, the second encoder's Phase-B leads Phase-A 90 degrees. |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------------|---------|---------|------|-------------|---|---|---|
| P3-09 | XT | Hybrid Deviation Clear Setting | 10 | 1 ~ 100 | rev | P | V | T | F |

Set the allowable deviation between the current position of motor encoder and external second encoder, and automatically clear the hybrid deviation whenever the motor's revolutions reaches the set value.



Note:


- ◆ The servo motor rotates the number of revolutions set by P3-09, and the hybrid deviation is always less than the set value of P3-10. As the motor reaches the revolutions set by P3-09, the hybrid deviation is cleared to zero and counted again from zero.
- ◆ Once hybrid deviation is greater than the set value of P3-10, a full closed-loop hybrid deviation excess error will occur.
- ◆ As P3-10 is set to 0 which means the hybrid deviation is not detected.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|----------------------------------|---------|----------------|--------|-------------|---|---|---|
| P3-10 | XO | Hybrid Deviation Fault Threshold | 100000 | 0 ~ 2147483647 | pulses | P | V | T | F |

Set the position following error alarm threshold in full closed-loop control mode.

As the deviation between the current position of motor encoder and external second encoder is greater than the set value of P3-10, a full closed-loop hybrid deviation excess error will occur, **r28FP** will display on the drive's LED display panel.

- Once hybrid deviation is greater than the set value of P3-10, a full closed-loop hybrid deviation excess error will occur.
- As P3-10 is set to 0 which means the hybrid deviation is not detected.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|--------------|----------------------|-------------|---|---|---|
| P3-11 | XR | Second Encoder Resolution | 10000 | 200 ~ 100000 | pulses/ user-unit | P | S | T | F |

The resolution of external second encoder or scale.
 A) For rotary encoder, enter the resolution of one revolution of the encoder;
 B) For linear scale, enter the number of pulses per moving user unit.
Note 1:
 The maximum speed under the full closed-loop control is 128 user unit per second, the appropriate resolution and user unit must be set. For example, the resolution of a linear scale is 0.5 μm.
 ◆ If the user unit is in mm, when P3-11 is set to 2000, the maximum speed is 128 mm/s
 ◆ If the user unit is in cm, when P3-11 is set to 20000, the maximum speed is 128 cm/s
Note 2:
 In any case, as long as the setting value of P3-11 is changed, the mechanical transmission ratios P3-00 and P3-01 must be reset
Note 3:
 The resolution of the external second encoder must be input correctly, otherwise, it will cause the full-closed loop position following error alarm when running.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------|---------|---------|------|-------------|---|---|---|
| P3-12 | PO | Pulses Output Mode | 1 | 0 ~ 256 | - | P | S | T | F |

Parameter P3-12 is used to set the pulse output source, pulse output phase logic, Z pulse output polarity, and division ratio. The corresponding functions to each bit are as follows.

| P3-12 Pulse output settings | | | | | | | |
|-----------------------------|------|------|------|-------------------------|--------------------------|--|------|
| bit7 | bit6 | bit5 | bit4 | bit3 | bit2 | bit1 | bit0 |
| 0 | 0 | 0 | 0 | Z pulse output polarity | Pulse output phase logic | Pulse output source | |
| | | | | 0: Rasing edge | 0: Phase A leads Phase B | bit1=0,bit0=1: Main Encoder feedback | |
| | | | | 1: Falling edge | 1: Phase B leads Phase A | bit1=1,bit0=0: Second Encoder feedback | |
| | | | | | | bit1=1,bit0=1: External pulse command | |

bit0 and bit1: Pulse output source
 bit2: Pulse output phase logic
 bit3: Z pulse output polarity

Note:
 When set this parameter from the LED operation panel and software, it needs to be converted into decimal.
◆ Pulse Output Source
 The pulse divided output function supports the following three signal sources. The bit0 and bit1 of parameter P3-12 are used to select signal sources.

| Setup Value | Description |
|---------------|--|
| bit1=0,bit0=1 | Main Encoder feedback |
| bit1=1,bit0=0 | Second Encoder feedback, full closed-loop encoder feedback |
| bit1=1,bit0=1 | External pulse position command(By pass) |

Note:
 When the signal source is external pulse command, the setting of parameter P3-13 and parameter P3-14 are invalid, and the external command pulse is directly output by-pass. The setting of bit2 and bit3 of P3-12 will also be invalid.

◆ Pulse output phase logic
 Set the relationship between Phase-A and Phase-B of pulse output when motor rotates at positive direction.

| Setup Value | Description |
|-------------|-----------------------------------|
| 0 | Phase-A leads Phase-B 90 degrees |
| 1 | Phase-B leads Phase-A 90 degrees. |

◆ Z pulse output polarity
 Set the output polarity of Z pulse.

| Setup Value | Description |
|-------------|-------------|
| 0 | Rasing edge |
| 1 | Rasing edge |

Refer to [Chapter 7.6 Encoder/Pulse Divided Output](#) for more detaled.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------------------|---------|--------------|------|-------------|---|---|---|
| P3-13 | ON | Pulses Output Gear Ratio - Numerator | 10000 | 0 ~ 13107200 | - | P | V | T | F |

Set the numerator of pulse output division ratio

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|--------------|------|-------------|---|---|---|
| P3-14 | OD | Pulses Output Gear Ratio - Denominator | 131072 | 0 ~ 13107200 | - | P | V | T | F |

Set the denominator of pulse output division ratio
 When the pulse output source is the motor encoder or second encoder, some applications where the number of output pulses per one motor revolution is not an integer, you can set the output gear ratio.

Output counts per motor revolution(A and B are converted into 4 times the frequency.)

$$\frac{\text{P3-13 Pulses Output Gear Ratio - Numerator}}{\text{P3-14 Pulses Output Gear Ratio - Denominator}} \times 131072$$

Note:

- 1). P3-13 should be smaller than P3-14.
- 2). When P3-13 is larger than P3-14, output pulse counts per motor revolution is set by P3-13.
- 3). The output pulse unit is CPR, which means counts per revolution, and refers to the number of quadrature decoded states that exist between the two outputs A and B. With both outputs A and B switching between high and low, there exists 2 bits of information represented as 4 distinct states. The term quadrature decoding describes the method of using both outputs A and B together to count each state change. This results in 4 times the amount of counts that exist for each pulse or period. Therefore, the CPR of an encoder is the encoder's PPR multiplied by 4.

Refer to [Chapter 7.6 Encoder/Pulse Divided Output](#) for more detailed.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|-------|------|-------------|---|---|---|
| P3-15 | ES | Absolute Encoder Usage | 1 | 0 ~ 3 | - | P | V | T | F |

Define the usage of Absolute Encoder:

| Setup Value | Description | Instructions |
|-------------|--|--|
| 0 | Incremental Encoder | It is used as an incremental encoder, the encoder feedback position will be reset to zero when power-on. Even if no external battery is connected, the alarm of multi-turn loss will not be generated. |
| 1 | Single Turn Absolute Encoder | Same as an incremental encoder, but the absolute position information of the motor within one revolution can be get. |
| 2 | Multi-Turn Absolute Encoder | Use as a multi-turn absolute encoder, records the absolute position of the motor. |
| 3 | Multi-Turn Absolute Encoder without Overflow | Use as a multi-turn absolute encoder. Even if the multi-turn value exceeds the range, the multi-turn overflow alarm will not be generated |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|-------|------|-------------|---|---|---|
| P3-16 | PU | Electronic Gearing Switch | 1 | 0 ~ 1 | - | P | V | T | F |

M56S series servo drives have two electronic gearing systems, parameter P3-16 is used to switch this.

| Parameter P3-16 set value | Description | Instructions |
|---------------------------|--|--|
| 0 | Based on parameter P3-05 (Command Pulses per revolution) Setting | Set the required number of command pulses per revolution of motor. Note: ◆ When this setting is zero, electronic gear ratio P03-00 and P3-01 is invalid. ◆ The read value of feedback encoder position is also determined by this parameter. That is, the read value of feedback encoder position per motor revolution = the setting of parameter P3-05 |
| 1 | Electronic gear ratio is valid | ◆ Electronic gear ratio P03-00 and P3-01 become valid and P3-05 is invalid ◆ The read value of feedback encoder position is: $\text{Feedback encoder position per revolution} = \frac{1048576}{(\text{Encoder resolution})} \times \frac{P3-01 (\text{Electronic Gear Ratio-Numerator})}{P3-00 (\text{Electronic Gear Ratio-Denominator})}$ |

The electronic gear ratio is to multiply the pulse input command by the electronic gear ratio as the position command reference. By using this function, the motor rotation and movement amount corresponding to the input command pulse can be set.

$$\text{External Position Pulse Command (Communication Position Command)} \times \frac{P3-00 (\text{Electronic Gear Ratio-Denominator})}{P3-01 (\text{Electronic Gear Ratio-Numerator})} = \text{Reference Position Command}$$

- ◆ When parameter P3-16 = 0, the electronic gear ratio P03-00 and P03-01 is invalid. The number of pulses per revolution of the motor is determined by parameter P3-05.
- ◆ When parameter P3-16 = 1, the electronic gear ratio P03-00 and P03-01 become valid. The number of pulses for one rotation of the motor is fixed to the encoder resolution. Regardless of the encoder with 17-bit or 20-bit resolution, it takes 1,048,576 pulses to rotate the motor once.


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|------------------------|------|-------------|---|---|---|
| P3-18 | FV | Absolute Encoder Multi-turn Counter Overflow Value | 1 | 0 ~ 2147483647/[P3-05] | - | P | V | T | F |

Define the absolute encoder Multi-turn counter overflow value

8.3.5 Group P4-XX: Analog


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|----------------------------|---------|---------|---------|-------------|---|---|---|
| P4-01 | AG | Analog Input Velocity Gain | 50 | 0 ~ 100 | rps/10V | P | V | T | F |

Scale factor value for motor speed and analog input.
Set corresponding motor speed when the analog input voltage is 10VDC.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|----------|----------|-------------|---|---|---|
| P4-02 | AN | Analog Input Torque Gain | 1000 | 0 ~ 3000 | 0.1%/10V | P | V | T | F |


Scale factor value for motor output torque and analog input.
Set corresponding motor output torque when the analog input voltage is 10VDC.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------|---------|----------------|------|-------------|---|---|---|
| P4-03 | AV1 | Analog Input 1 Offset | 0 | -10000 ~ 10000 | mV | P | V | T | F |


When using the analog mode, the servo motor may rotate slightly in some cases even if the input analog command is at 0 voltage. This is because there is a slight drift when analog signal is received by drive.

The parameter P4-03 and P4-04 are used to eliminate this situation. You can use the Luna software to automatically adjust the offset or manually modify these parameters




| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------|---------|----------------|------|-------------|---|---|---|
| P4-04 | AV2 | Analog Input 2 Offset | 0 | -10000 ~ 10000 | mV | P | V | T | F |

Set the offset of analog input 2




| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|--------------------------|---------|---------|------|-------------|
| P4-05 | AD1 | Analog Input 1 Dead-band | 0 | 0 ~ 255 | mV | P S T F |

The analog input deadband value of the analog input 1.
 The deadband value is the zone around the "zeroed" value of the analog input. This deadband defines the area of the analog input range that the drive should interpret as "zero". The deadband is an absolute value that in usage is applied to either side of the zero point.



| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|--------------------------|---------|---------|------|-------------|
| P4-06 | AD2 | Analog Input 1 Dead-band | 0 | 0 ~ 255 | mV | P S T F |

The analog input deadband value of the analog input 2.



| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|-----------------------|---------|----------|-------|-------------|
| P4-07 | AF1 | Analog Input 1 Filter | 1000 | 0 ~ 2000 | 0.1Hz | P S T F |

This parameter sets the low-pass filter for analog input 1.

| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|-----------------------|---------|----------|-------|-------------|
| P4-08 | AF2 | Analog Input 2 Filter | 1000 | 0 ~ 2000 | 0.1Hz | P S T F |

This parameter sets the low-pass filter for analog input 2.
 In analog control mode, due to external interference, the analog voltage may fluctuate, which will cause the fluctuation of the motor speed or the torque output, which will affect the control accuracy.
 The analog input filter is a low-pass filter which is used to eliminate this fluctuation.

Note:
 If the set value is too small, the response to the speed command will be reduced.

| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|--------------------------|---------|----------------|------|-------------|
| P4-09 | AT1 | Analog Input 1 Threshold | 5000 | -10000 ~ 10000 | mV | P S T F |

Sets the trigger threshold for analog input 1.

| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|--------------------------|---------|----------------|------|-------------|
| P4-10 | AT2 | Analog Input 1 Threshold | 5000 | -10000 ~ 10000 | mV | P S T F |

Sets the trigger threshold for analog input 2.
 The analog input can be set as the motor speed and torque commands, and can also be used as a general analog input to feedback the actual voltage of analog input.
 In Q program or SCL communication command, the AT1 and AT2 command can be used to set the voltage trigger threshold of analog input. Hence the analog voltage is used as a trigger switch. When the input voltage is equal to or greater than the parameter setting value, the input is activated.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|-------|------|-------------|---|---|---|
| P4-11 | AF1 | Velocity Limit Setting of Torque Control | 1 | 0 ~ 1 | --- | P | V | T | F |

In torque mode, when the load connected to the motor is small but the torque command is too large, the motor may accelerate to a very high speed if the motor output speed is not limited, which may cause unexpected situations. Therefore it is necessary to set a maximum motor speed in torque mode. The motor actual speed will be limited within the set value.

This parameter sets the source of the motor speed limit command.

| Setup Value | Description |
|-------------|----------------------|
| 0 | Internal Speed Limit |
| 1 | Analog Input 1 |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------|---------|-----------|------|-------------|---|---|---|
| P4-16 | OS1 | Analog Output 1 Scale | 1000 | 1 ~ 32000 | /10V | P | V | T | F |

Output scale for analog output 1. The values of speed, torque, position error, etc. corresponding to the analog output at 10V can be set.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------|---------|-----------|------|-------------|---|---|---|
| P4-17 | OS2 | Analog Output 2 Scale | 1000 | 1 ~ 32000 | /10V | P | V | T | F |

Output scale for analog output 2. The values of speed, torque, position error, etc. corresponding to the analog output at 10V can be set.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|-------|------|-------------|---|---|---|
| P4-18 | XA1 | Analog Output 1 Function | 0 | 0 ~ 5 | | P | V | T | F |

Function definition of analog output 1.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|-------|------|-------------|---|---|---|
| P4-19 | XA2 | Analog Output 2 Function | 0 | 0 ~ 5 | | P | V | T | F |

Function definition of analog output 2.

| Setup Value | Description |
|-------------|---|
| 0 | As a general-purpose voltage output. |
| 1 | As the motor actual output current, unit: 0.1% |
| 2 | As the motor command current, unit: 0.1% |
| 3 | As the motor actual output speed, unit: 0.25 rpm |
| 4 | As the motor command speed, unit: 0.25 rpm |
| 5 | As counts of position following error, unit: counts |

8.3.6 Group P5-XX: IO Configuration

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|--------|------|-------------|---|---|---|
| P5-00 | MU1 | Digital Input 1 Function | | 0 ~ 46 | | P | S | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|--------|------|-------------|---|---|---|
| P5-01 | MU2 | Digital Input 2 Function | | 0 ~ 46 | | P | S | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|--------|------|-------------|---|---|---|
| P5-02 | MU3 | Digital Input 3 Function | | 0 ~ 46 | | P | S | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|--------|------|-------------|---|---|---|
| P5-03 | MU4 | Digital Input 4 Function | | 0 ~ 46 | | P | S | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|--------|------|-------------|---|---|---|
| P5-04 | MU5 | Digital Input 5 Function | | 0 ~ 46 | | P | S | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|--------|------|-------------|---|---|---|
| P5-05 | MU6 | Digital Input 6 Function | | 0 ~ 46 | | P | S | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|--------|------|-------------|---|---|---|
| P5-06 | MU7 | Digital Input 7 Function | | 0 ~ 46 | | P | S | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|--------|------|-------------|---|---|---|
| P5-07 | MU8 | Digital Input 8 Function | | 0 ~ 46 | | P | S | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------|---------|--------|------|-------------|---|---|---|
| P5-08 | MU9 | Digital Input 9 Function | | 0 ~ 46 | | P | S | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|--------|------|-------------|---|---|---|
| P5-09 | MUA | Digital Input 10 Function | | 0 ~ 46 | | P | S | T | F |

Assignable functions and input logic state list as follows. Parameters P5-00 to P5-09 define the functions of digital inputs X1 to X10. The function of digital input can be set by writing the corresponding Function Code in the table below into the parameters.

| Signal Functions | Symbol | Setup value and corresponding input logic state | |
|--------------------------------------|----------|---|-----------------|
| | | Valid when Closed | Valid when Open |
| General Purpose Input | GPIN | 0 | |
| Servo On | S-ON | 1 | 2 |
| Alarm Reset | A-CLR | 3 | 4 |
| CW Limit | CW-LMT | 5 | 6 |
| CCW Limit | CCW-LMT | 7 | 8 |
| Control Mode Select | CM-SEL | 9 | 10 |
| Gain Select | GAIN-SEL | 11 | 12 |
| Emergency Stop | E-STOP | 13 | 14 |
| Start Homing | S-HOM | 15 | 16 |
| Position Error Clear | C-CLR | 17 | 18 |
| Torque Limit | TQ-LMT | 19 | 20 |
| Zero Speed Clamp | ZCLAMP | 21 | 22 |
| Pulse Input Inhibit | INHP | 25 | 26 |
| Internal Speed Select 1 | SPD1 | 27 | 28 |
| Internal Speed Select 2 | SPD2 | 29 | 30 |
| Internal Speed Select 3 | SPD3 | 31 | 32 |
| Torque and Velocity Control | SP-STA | 33 | 34 |
| Torque and Velocity Direction Switch | SPD-DIR | 35 | 36 |
| Speed Limit Select | V-LMT | 37 | 38 |
| Home Switch | HOM-SW | 39 | 40 |
| Start Q Program | START-Q | 45 | 46 |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|--------|------|-------------|---|---|---|
| P5-12 | MO1 | Digital Output 1 Function | | 0 ~ 34 | | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|--------|------|-------------|---|---|---|
| P5-13 | MO2 | Digital Output 2 Function | | 0 ~ 34 | | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|--------|------|-------------|---|---|---|
| P5-14 | MO3 | Digital Output 3 Function | | 0 ~ 34 | | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|--------|------|-------------|---|---|---|
| P5-15 | MO4 | Digital Output 4 Function | | 0 ~ 34 | | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|--------|------|-------------|---|---|---|
| P5-16 | MO5 | Digital Output 5 Function | | 0 ~ 34 | | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---------------------------|---------|--------|------|-------------|---|---|---|
| P5-17 | MO6 | Digital Output 6 Function | | 0 ~ 34 | | P | V | T | F |

Assignable functions and output logic state list is as follows. Parameters P5-12 ~ P5-17 define the functions of digital outputs Y1 to Y6. The function of digital output can be set by writing the corresponding Function Code in the table below into above parameters.

| Signal Functions | Symbol | Output logic state and set value when the output signal is valid | |
|-----------------------------|----------|--|------|
| | | Closed | Open |
| General Purpose Output | GPOUT | 0 | |
| Fault Output | ALM | 1 | 2 |
| Warning Output | WARN | 3 | 4 |
| Brake Release Output | BRK | 5 | NONE |
| Servo-on Status Output | SON-ST | 7 | 8 |
| In-position Output | IN-POS | 9 | 10 |
| Dynamic Postion Output | DYM-LMT | 11 | 12 |
| Torque Reach Output | TQ-REACH | 13 | 14 |
| Torque Limit Output | T-LMT | 15 | 16 |
| Velocity Coincidence Output | V-COIN | 17 | 18 |
| Velocity Reach Output | AT-SPD | 19 | 20 |
| Velocity Limit Outout | V-LTD | 21 | 22 |
| Servo Ready Output | S-RDY | 23 | 24 |
| Homing Finished Output | HOMED | 25 | 26 |
| Soft Limit CW | SLCW | 27 | 28 |
| Soft Limit CCW | SLCCW | 29 | 30 |
| Near Target Position Output | P-COIN | 31 | 32 |
| Zero Speed Detected | Z-SPD | 33 | 34 |
| Torque Coincidence Output | T-COIN | 35 | 36 |

The output logic state of the pin is as follows:

CLOSED: If current is flowing into or out of an output, the logic state of that output is low or closed.

OPEN: If no current is flowing, or the output is not connected, the logic state is high or open.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---|---------|-----------|------|-------------|---|---|---|
| P5-24 | BD | Move Command Delay Time after Brake Release | 200 | 0 ~ 32000 | ms | P | V | T | F |


The parameter P5-24 sets the delay time for the first movement after the drive is enabled. The brake must be released before a movements starts, since there is action time when the brake is released or braked, this parameter is set to ensure that the brake has been released successfully.

Note:

As mentioned above, it will cause a delay to the actual movement even if the motion command has been received. If the application is sensitvie to this delay and doesn't need to use the motor brake, you can set P5-24 to zero, or don't configure the "Brake Release Output" function for the digital outputs.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|---|---------|-----------|------|-------------|---|---|---|
| P5-25 | BE | Servo-off Delay Time after Brake Engagement | 200 | 0 ~ 32000 | ms | P | V | T | F |

The parameter P5-25 sets the delay time to actually disable the drive after the drive receives the disable command, to ensure that the brake has been braked successfully.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------|---------|--------|------|-------------|---|---|---|
| P5-27 | HX | Home Sensor | 5 | 1 ~ 10 | - | P | V | T | F |

This parameter P5-27 shows which digital input is configured as the Home Switch input. The function of digital input needs to be configured as "Home Switch Input" through parameters P5-00 to P5-09.

| Display Value | Digital Inputs |
|---------------|----------------|
| 1 | X1 |
| 2 | X2 |
| ... | ... |
| 10 | X10 |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|----------|------|-------------|---|---|---|
| P5-28 | FI1 | Digital Input 1 Filter | 2 | 0 ~ 8000 | ms | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|----------|------|-------------|---|---|---|
| P5-29 | FI2 | Digital Input 2 Filter | 2 | 0 ~ 8000 | ms | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|----------|------|-------------|---|---|---|
| P5-30 | FI3 | Digital Input 3 Filter | 2 | 0 ~ 8000 | ms | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|----------|------|-------------|---|---|---|
| P5-31 | FI4 | Digital Input 4 Filter | 2 | 0 ~ 8000 | ms | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|----------|------|-------------|---|---|---|
| P5-32 | F15 | Digital Input 5 Filter | 2 | 0 ~ 8000 | ms | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|----------|------|-------------|---|---|---|
| P5-33 | F16 | Digital Input 6 Filter | 2 | 0 ~ 8000 | ms | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|----------|------|-------------|---|---|---|
| P5-34 | F17 | Digital Input 7 Filter | 2 | 0 ~ 8000 | ms | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|----------|------|-------------|---|---|---|
| P5-35 | F18 | Digital Input 8 Filter | 2 | 0 ~ 8000 | ms | P | V | T | F |


| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------|---------|----------|------|-------------|---|---|---|
| P5-36 | F19 | Digital Input 9 Filter | 2 | 0 ~ 8000 | ms | P | V | T | F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-------------------------|---------|----------|------|-------------|---|---|---|
| P5-37 | F1A | Digital Input 10 Filter | 2 | 0 ~ 8000 | ms | P | V | T | F |

Parameters P5-28 to P5-37 set the input filter of digital input X1 to X10.
 When the width of input signal is greater than the set filter time, the input signal is valid.
 If there are lot of electromagnetic interferences, setting a reasonable input filter can improve the reliability of digital inputs, but too large filtering time will affect the input response.

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--------------------------------|---------|----------------|--------|-------------|---|---|---|
| P5-38 | PL | Dynamic Follow Error Threshold | 10 | 0 ~ 2147483647 | pulses | P | S | T | F |



This parameter P5-38 sets the judgement condition of outputting Dynamic Position Following Error over limit.
 Dynamic Position Following Error output refers to the output of this signal when the difference between the motor actual position and the command position is greater than P5-38 Dynamic Follow Error Threshold during the motor is rotating.
 The following figure shows that the dynamic following error exceeds the setting of P5-38, the DYM-LMT signal outputs.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|------------------------------|---------|-----------|--------|-------------|---|---|---|
| P5-39 | PD | In-position Output Threshold | 40 | 0 ~ 32000 | pulses | P | V | T | F |

This parameter P5-39 sets the judgement condition of the In-position signal output.

The In-position output signal is used to indicate current positioning status of the servo system in the position mode. When the position following error, which is the difference between input position command and the motor actual position feedback by motor encoder, is less than the set value of P5-39, the In-position signal will output.



| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|--|---------|-----------|------|-------------|---|---|---|
| P5-40 | PE | Time Constant of Motion Output Condition | 10 | 0 ~ 30000 | ms | P | V | T | F |

One of the conditions for judging whether to output the following signals: Time Constant.


For more detailed,please refer to following chapters:

- [Chapter 7.2.8 In-position output Signal](#)
- [Chapter 7.3.7 Velocity Reach Output](#)
- [Chapter 7.3.8 Velocity Coincidence Output](#)

| Parameter | Command | Description | Default | Range | Unit | Contol mode | | | |
|-----------|---------|-----------------------|---------|-----------|------|-------------|---|---|---|
| P5-41 | TT | Pulse Complete Timing | 2 | 0 ~ 20000 | ms | P | V | T | F |


The parameter P5-41 sets the detection time width for judging whether the input position pulses ends.

When the drive dose not receive a new pulse input within the detection time set by P5-41, it is deemed that the pulse input has completed.



| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|------------------|---------|---------|------|-------------|
| P5-42 | ZV | Zero Speed Width | 0.5 | 0.1 ~ 2 | rps | P V T |

The paramter P5-42 sets the judgment condition whether the actual motor speed is zero.
 When the absolute value of motor actual speed is less than the set value of P5-42(zero-speed judgment width), the servo drive outputs the Zero Speed Detected(Z-SPD) signal. On the contrary, if the absolute value of motor actual speed is less than P5-42, the Z-SPD signal will not output.
 The detection of Zero Speed is not affected by control mode and servo status, therefore, this signal can also be used as the motor moving signal.




Note: To check or to change this value from drive operation panel, please calculate according to the following formula.

$$\text{LED Display value} = \underline{V} \times 240$$

Where \underline{V} is the speed to be set in rps(revolution per second)

| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|-------------------------|---------|---------|------|-------------|
| P5-43 | VR | Speed Coincidence Width | 0.1 | 0 ~ 100 | rps | P V T |

In speed mode, when the difference between the filtered motor actual speed and the speed command, that is, the speed error is within the range of P5-43 (Speed Coincidence Width), and the duration time meets the set value of P5-40 (Time Constant of Motion Output Condition), then the Velocity Coincidence signal V-COIN is output.
 If the filtered speed error exceeds the set value of P5-43, V-COIN will not output.




Note: To check or to change this value from drive operation panel, please calculate according to the following formula.

$$\text{LED Display value} = \underline{V} \times 240$$

Where \underline{V} is the speed to be set in rps(revolution per second)

| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|---------------------------------|---------|---------|------|-------------|
| P5-44 | VV | Target Value of AT-speed Output | 10 | 0 ~ 100 | rps | P V T |

In speed control mode, the Velocity Reach Output, also know as At-speed(AT-SPD), which will be output when the filtered motor actual speed exceeds P5-44 (Target Value of AT-speed Output), and the time exceeds P5-40 (counting time for positioning completion) .
 On the contrary, if the filtered motor actual speed is less than P5-44, the AT-SPD signal will not output.




Note: To check or to change this value from drive operation panel, please calculate according to the following formula.

$$\text{LED Display value} = \underline{V} \times 240$$

Where \underline{V} is the speed to be set in rps(revolution per second)


| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|----------------------|---------|----------|------|-------------|
| P5-45 | TV | Torque Arrival Width | 10 | 0 ~ 3000 | 0.1% | P V T |

When the absolute value of the actual motor output torque exceeds the set value of P1-07(Target Torque Value when Torque Value Reached), and the torque fluctuation is within the range of P5-45, the torque reach signal TQ-REACH will be output. If the actual motor output torque doesn't exceed or is lower than P1-07, the TQ-REACH signal will not output. This function is applicable in all control modes, such as position mode, speed mode, torque mode, etc. To use Torque Reach Output(TQ-REACH), one of digital outputs needs to be assigned this function.



| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|----------------------|---------|---------------------------|--------|-------------|
| P5-46 | DG | Near Target Position | 10000 | -2147483647 ~ +2147483647 | pulses | P V T |

Near target position, which is also called Position Consistent, is to output a signal(P-COIN) when the actual position of motor is equal to the position set by parameter P5-46. The fluctuation range is ± 100 pulses.



| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|-------------------------|---------|---------------------------|--------|-------------|
| P5-47 | LP | Positive Software Limit | 0 | -2147483647 ~ +2147483647 | pulses | P V T F |

| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|-------------------------|---------|---------------------------|--------|-------------|
| P5-48 | LM | Negative Software Limit | 0 | -2147483647 ~ +2147483647 | pulses | P V T F |

Parameters P5-47 and P5-48 set the software position limit for the drive.

- ◆ If the actual motor position is equal to or exceeds the set value of P5-47 while motor is rotating at positive direction, a Positive Limit Alarm (Alarm Code **r 15LL**) will occur, hence the motor can not continue to rotate in positive direction.
- ◆ If the actual motor position is equal to or exceeds the set value of P5-48 while motor is rotating in negative direction, a Negative Limit Alarm (Alarm Code **r 14LL**) will occur, hence the motor can not continue to rotate at negative direction.

Note:

- ◆ When the motor encoder type is incremental encoder, after the drive is powered on, parameters P5-47 and P5-48 can be set and the software limit can work normally, but cannot be saved after power off. After power on again, the parameter returns to the default value "0".
- ◆ If using the motor with absolute encoder, parameters P5-47 and P5-48 can be saved.

| Parameter | Command | Description | Default | Range | Unit | Contol mode |
|-----------|---------|---------------|---------|---------|------|-------------|
| P5-49 | HE | Homing Method | 1 | -4 ~ 40 | - | P V T F |

The parameter P5-49 sets the homing method in Homing Mode. Refer to [Chapter 7.10 Homing Mode](#) for more detailed.

9 Troubleshooting

9.1 Alarm List

| Alarm Code | Description | Error Type | | Drive status after the alarm occurs | Resettable |
|------------|--|------------|---------|---|------------|
| | | Fault | Warning | | |
| r01ot | Drive over temperature | Fault | | Servo off | YES |
| r02ur | Internal voltage error | Fault | | Servo off | NO |
| r03uH | Over-voltage | Fault | | Servo off | YES |
| r04HC | Over current | Fault | | Servo off | YES |
| r05LC | | Fault | | Servo off | YES |
| r06rC | | Fault | | Servo off | YES |
| r09Eb | Encoder feedback error | Fault | | Servo off | 否 |
| r10PL | Position following error | Fault | | Servo off | YES |
| r11Lu | Low voltage | Fault | | Servo off | YES |
| r12ou | Over speed | Fault | | Servo off | YES |
| r13Lt | Limit switch trigger alarm | | Warning | Current state does not change. | YES |
| r14LL | Negative limit alarm | | Warning | Current state does not change. Motor cannot rotate in negative direction. | YES |
| r15JL | Positive limit alarm | | Warning | Current state does not change. Motor cannot rotate in positive direction | YES |
| r16CL | Current limit | | Warning | Current state does not change. | YES |
| r17CE | Communication error | | Warning | Current state does not change. | YES |
| r18EF | Parameter save failed | | Warning | Current state does not change. | YES |
| r19LP | Phase loss of main circuit | Fault | | Servo off | YES |
| r20to | STO is triggered | | Warning | Servo off | YES |
| r21rF | Regeneration failed | Fault | | Servo off | YES |
| r22uH | Under-voltage warning | | Warning | Current state does not change. | YES |
| r239E | No Q program warning | | Warning | Current state does not change. | YES |
| r24dd | Motion command received while motor disable | | Warning | Current state does not change. | YES |
| r25ur | Internal voltage error | Fault | | Servo off | NO |
| r26ur | | | | Servo off | NO |
| r27E3 | Emergency Stopped | | Warning | Motor decelerates and stops. | YES |
| r28FP | Full-closed loop hybrid deviation excess error | Fault | | Servo off | YES |

| | | | | | |
|-------|---|-------|---------|--------------------------------|-----|
| r29FE | External encoder error | Fault | | Servo off | NO |
| r30nE | Memory error | Fault | | Servo off | YES |
| r31bt | Absolute encoder battery undervoltage | | Warning | Current state does not change. | YES |
| r32AP | Absolute position lost | | Warning | Current state does not change. | NO |
| r33oP | Absolute position overflow | | Warning | Current state does not change. | NO |
| r34nE | Motor over temperature | Fault | | Servo off | YES |
| r35CE | Drive MCU over temperature | Fault | | Servo off | NO |
| r36nr | Absolute encoder multi-turn error | Fault | | Servo off | NO |
| r37Et | Motor stalled | Fault | | Servo off | YES |
| r38CE | Homing parameters configuration error | Fault | | Servo off | YES |
| r39Hr | Motor collision alarm | | Warning | Current state does not change. | YES |
| r40Hr | Motor Collision Alarm | Fault | | Servo off | YES |
| r41Er | Encoder Communication error | Fault | | Servo off | NO |
| r42io | Wrong configuration of I/O function in Q mode | | Warning | Current state does not change. | YES |

9.2 Driver Alarm Causes and Measures

| Alarm Code | Description | Causes | Measures | Reset Method |
|-------------------------|--------------------------|--|---|--------------|
| r01ot | Drive over temperature | Temperature of the heat sink and power component of the drive exceeds the specified value. 1. Ambient temperature is too high; 2. Drive operating temperature exceeds the specified value; 3. Overload, continue to use while the drive has exceed the rated load; 4. Drive cooling fan failure. | 1. Reduce the drive operating temperature and improve the cooling conditions; 2. Increase the capacity of the drive and motor, set up longer acceleration/deceleration time, and lower the load; 3. Replace the fan or return the servo drive for repairing. | Alarm reset |
| r02ur | Internal voltage error | The internal voltage is lower than the normal value. | Check the voltage of the power supply and replace the drive if still problems. | Re-power up |
| r03uH | Drive over voltage | Drive DC bus voltage is too high (220 series: higher than 420VDC, MBDV drive series: higher than 80VDC) 1. Power supply voltage exceeds the allowable input voltage range; 2. Disconnection of the regenerative absorbing resistor; 3. The built-in regenerative absorption resistor is too small to absorb the regenerative energy; 4. The external regenerative absorbing resistor does not match, resulting in the inability to absorb the regenerative energy; 5. Drive failure (circuit failure). | 1. Check and input correct voltage; 2. Measure the resistance of the internal regeneration resistor; 3. Detect the resistance of the external resistor. Replace the external resistor if the value is ∞; 4. If the problem is not resolved as described above, contact MOONS or replace the drive with a new one. | Alarm reset |
| r04HC r05LC r06rC | Over-current | 1. Failure of drive; 2. Short of the motor wire U, V, W; 3. Burned out of the motor; 4. Poor contact of the motor wire; 5. Input pulse frequency is too high; 6. Motor is over load, command output torque is larger than maximum torque, for a long operating time; 7. Poor gain adjustment cause motor vibration, and abnormal noise; 8. Machine has stalled or the load has gotten heavy suddenly. Machine has been distorted; 9. The motor electromagnetic brake is not released; 10. In the multiple mechanical wiring, the motor wire is mistakenly connected to other axes, and the wiring is incorrect. | 1. Turn to Servo-ON, while disconnecting the motor. If error occurs immediately, replace with a new driver; 2. Check that the motor wire (U, V and W) is not shorted, and check the branched out wire out of the connector. Make a correct wiring connection; 3. Check if the motor wires U, V, W are in the correct order. U-red, V-yellow, W-blue; 4. Measure the insulation resistance between motor wires, U, V and W and PE. In case of poor insulation, replace the motor; 5. Increase the power of the drive and motor. Extend the acceleration and deceleration time and reduce the load; 6. Check if the connector plug of the motor connection part U, V, W is off. If loose or falling off, fix them securely; 7. Adjust gain value settings; 8. Measure the voltage at the brake terminals; 9. Check drive and motor encoder and power wires correctly. | Alarm reset |
| r09Eb | Encoder feedback error | Motor encoder error | 1. Verify encoder lines properly connected to the motor; 2. Verify encoder lines connected with the drive correctly; 3. Replace the encoder wires; 4. Re-power on, if still problems, replace the motor. | Re-power up |
| r10PL | Position following error | Position following error value exceeds the position error range set by parameter P3-04(PF). | 1. Check if the position error range set by parameter P3-04 is too small 2. Check drive's gain parameters have been set properly; 3. Check if the selected motor model matches with the actual load, or if the acceleration/ deceleration is too large; 4. Check if any unreasonable torque limits; 5. Inappropriate electronic gear ratio setting; 6. Mechanical part of the motor drive is stuck and the motor is blocked; 7. Check if the motor power wire is connected correctly, when more than one motor, check if the power wire is connected to the correct drive. | Alarm reset |

| Alarm Code | Description | Causes | Measures | Reset Method |
|------------|-----------------------------|--|---|---|
| r11Lu | Low voltage | DC bus voltage is too low (220V series: below 90VDC) 1. Power supply voltage is low. Instantaneous power failure has occurred; 2. Lack of power capacity. Power supply voltage has fallen down due to inrush current at the main power-on; 3. Failure of servo drive (failure of the circuit). | Measure input voltage 1. Increase the power capacity. Change the power supply; 2. Check power input connections. Please refer to Chapter 4.3 3. If the problem is not resolved as described above, contact MOONS or replace the drive with a new one | Alarm reset |
| r12ou | Over speed | Motor rotary velocity exceeds parameter P2-00(VM) setting value. | Check if the motor speed command is within a reasonable range 1. Avoid high velocity command; 2. Check the command pulse input frequency and division/multiplication ratio; 3. Make a gain adjustment when an overshoot has occurred due to a poor gain adjustment; 4. Connect the encoder cable correctly according to the wiring diagram. 5. Check if the motor wires U, V, W are in the correct order. U-red, V-yellow, W-blue; | Alarm reset |
| r13Lt | Limit switch trigger alarm | 1. CW or CCW limit switch is triggered; 2. In the absolute value system, the actual position of the motor is equal the soft limit. | 1. External limit switch is triggered; 2. The limit input function is not set correctly, please refer to Chapter 7.1.5 CW and CCW Limit ; 3. In the absolute value system, the software limit setting is unreasonable. | Auto-clear after detachment |
| r14Ll | Negative limit alarm | 1. CCW limit is triggered; 2. In the absolute value system, the actual position of the motor is equal to the negative soft limit. | | |
| r15JL | Positive limit alarm | 1. CW limit is triggered; 2. In the absolute value system, the actual position of the motor is equal to the positive soft limit | | |
| r16CL | Current limit | Driver's output current exceeds setting value P1-06(CC),and the duration exceeds the set value of P1-09 1. Acceleration is too large; 2. Load was heavy and actual torque has exceeded the rated torque and kept running for a long time; 3. Poor gain adjustment causes oscillation, vibration, and abnormal sound; 4. Mechanical movement is restricted, a collision occurs, or the load suddenly becomes heavier. | 1. Make a gain re-adjustment; 2. Check if the selected motor model matches with the actual load, or if the acceleration/ deceleration is too large; 3. Check motor wirings for U/V/W as red/ yellow/blue; 4. Increase the power capacity of the driver and motor. Set up longer acceleration/deceleration time. Lower the load requirement. | Auto-clear when less than the rated current |
| r17CE | Communication error | Detected communication error when the host controller communicate with the drive. | 1. Luna software is trying to establish communication with the drive (this is a normal alarm); 2. Check wiring connection, and drive's communication address and baud rate setting. | Auto-clear when communication is normal |
| r18EF | Parameter save failed | Saving parameter failure. | 1. Please try to save again; 2. If problems is not solved, please contact MOONS. | Auto-clear |
| r19LP | Main power input phase lost | When the power is 3-phase, the drive detected one of the power inputs is lost | 1. Check power input connections. Please refer to Chapter 4.3 P1 drive power connection ; 2. Check the Power Lost Detect function is set correctly. | Auto-clear |
| r20to | STO is triggered | Safety torque off function is activated. Either or both safety input 1 or 2 is activated. | 1. Check the safety input 1 and 2 wiring configuration; 2. Check Safety sensor setting. | Auto-clear after STO input is normal |

| Alarm Code | Description | Causes | Measures | Reset Method |
|----------------|--|---|---|---|
| r21rF | Regeneration failed | Regenerative energy has exceeded the capacity of regenerative resistor, 1. Due to the large load inertia, the regenerative energy during deceleration is generated, causing the bus voltage to rise and the regenerative resistor is insufficient to this energy; 2. Regenerative energy has not been absorbed in the specified time due to a high motor rotational speed. | 1. Internal resistor value is smaller than required, cannot absorb the regeneration energy; 2. Check external regeneration resistor connections; 3. Reduce rotary velocity and decrease acceleration and deceleration value; 4. Refer to Chapter 4.7 | Alarm reset |
| r22uB | Under-voltage warning | Drive voltage lower than 200VDC 1. Power supply voltage is low. Instantaneous power failure has occurred; 2. Lack of power capacity. Power supply voltage has fallen down due to inrush current at the main power-on; 3. Failure of servo driver (failure of the circuit); 4. Drive main power is not powered. | Check input voltage 1. Increase the power capacity. Change the power supply; 2. Please check power connections, please refer to Chapter 4.3 ; 3. Check drive L1/L2/L3 terminals and voltage input; 4. Replace a new drive if still problems. | Alarm reset Auto-clear when the voltage is normal |
| r239E | No Q program warning | Drive in Q mode, but Q program is empty. | 1. Check Q program; 2. Check operation mode correction; 3. Check Q program coding, make sure no faults to stop the program running. | Alarm reset |
| r24dd | Motion-command received while motor disable | Motion command is received while motor is disabled. | Please enable the motor, and send the command again. | Alarm reset |
| r25ur r26ur | Internal voltage error | The internal voltage is lower than the normal value. | Check the voltage of the power supply and replace the drive if still problems. | Re-power up |
| r27E | Emergency stop | Digital input emergency stop function is triggered. | 1. Check emergency stop input switch; 2. Confirm if the emergency stop input logic setting is reasonable. | Alarm reset |
| r28FP | Full-closed loop hybrid deviation excess error | Full closed loop control position deviation exceeds the set value. | 1. Check if the CN4 external encoder input is correct. 1. Check whether the set value of parameters P3-10 and P3-11 | Alarm reset |
| r29FE | External encoder error | CN4-Second encoder input is not connected correctly. | Check if the CN4 external encoder input is correct. | Alarm reset |
| r30nE | Memory error | Drive internal memory unit is in exceptional situation. | Repower on, if still problems, contact MOONS. | Re-power up |
| r31bt | Absolute encoder battery under-voltage | The battery voltage of the absolute encoder is lower than the specified value of 3.2V. | Replace the battery. To prevent loss of absolute position, replace the battery while the drive is powered on. | Alarm reset |
| r32AP | Absolute position lost | The absolute encoder loses its multi-turn absolute positions due to low battery voltage or power interruption. 1. The encoder is configured as absolute type, but no battery is installed; 2. The absolute encoder is used for the first time without any configuration. 3. The battery voltage is too low and the it's not replaced in time. 4. Replacing the battery when the drive is not power-on. 5. The battery circuit is in poor contact or disconnected. 6. The current position exceeds -2147483647 ~ +2147483648 | 1. Check whether the battery voltage is lower than 2.8V, replace the battery in time; 2. Replace the battery when the drive is power-on; 3. Check and repair the wiring so that the battery can power the encoder normally. 1) Check the encoder wiring; 2) Check the wiring between the inside of the battery box, the outside and the driver. | After replacing the battery, it is necessary to perform the multi-turn zero clearing operation of the absolute encoder. |
| r33oP | Absolute position overflow | Absolute encoder multi-turn number exceeds the maximum range: -32768 ~ +32767 | 1. Check whether motor actual position exceeds the maximum range; 2. Out of range, please perform absolute encoder multi-turn clear; 3. For unidirectional operation, set parameter P3-15 to 2 (multi-turn encoder does not count overflow) | Perform the multi-turn zero clearing operation of the absolute encoder. |


| Alarm Code | Description | Causes | Measures | Reset Method |
|------------|---------------------------------------|--|---|---|
| r340t | Motor over temperature | The drive detects that the motor temperature exceeds the allowable value | <ol style="list-style-type: none"> 1. Check if the ambient temperature where the motor is installed is too high; 2. Reduce the ambient temperature of the motor and improve the cooling conditions; 3. Increase the capacity of the driver and motor, prolong the acceleration and deceleration time, and reduce the load; 4. Whether the motor is rubbed by the load; 5. When using a motor with an oil seal, please derate it. The output torque of the motor should be 70% of the rated torque of the motor; 6. The temperature rise and the motor torque are measured when the motor is mounted on a standard heat sink. When the motor mounting plate is small, in order to prevent the motor from overheating, please use it with derating; 7. The temperature of the motor is normal and cannot be cleared by powering on again, please replace the motor | Re-power up |
| r350t | Drive MCU over temperature | Drive processor temperature is too high | <ol style="list-style-type: none"> 1. Check if the ambient temperature of the drive installation is too high 2. Reduce the ambient temperature of the drive and improve the cooling conditions 3. The drive needs to be installed on a metal backplane with good heat dissipation 4. Increase the capacity of the driver and motor, prolong the acceleration and deceleration time, and reduce the load. 5. Replace the fan or send the servo drive for repair 6. The temperature of the drive heatsink is normal and the alarm still exists after powering on again, please replace the drive | Alarm reset |
| r360r | Absolute encoder multi-turn error | The absolute encoder loses its multi-turn absolute positions <ol style="list-style-type: none"> 1. The encoder is configured as absolute type, but no battery is installed; 2. The absolute encoder is used for the first time without any configuration. | Need to perform absolute encoder multi-turn clear operation. | Perform the multi-turn zero clearing operation of the absolute encoder. |
| r373t | Motor stalled | Working in non-torque mode, the duration time that motor has been stalled exceeds the value set by P1-28. | <ol style="list-style-type: none"> 1. Check whether the mechanical part driven by the motor is stuck 2. Check if the electromagnetic brake is open | Alarm reset |
| r380E | EtherCAT communication error | EtherCAT communication error <ol style="list-style-type: none"> 1. EtherCAT communication parameter configuration error 2. EtherCAT communication interruption | <ol style="list-style-type: none"> 1. Check the configuration parameters of EtherCAT communication 2. Check whether the communication line is connected well. | Auto-clear when communication is normal |
| r39Hr | Homing parameters configuration error | Check if the Homing Parameter is configured entirely. <ol style="list-style-type: none"> 1. Use the homing method with limit signal, the limit switch is not configured 2. Using the homing method with home switch, the home switch is not configured | Check if the Homing Parameter is configured entirely. | Alarm reset |
| r40H i | Motor Collision Alarm | <ol style="list-style-type: none"> 1. The instantaneous change of current exceeded the value of P1-34. 2. The motor-driven load collides with other fixed loads; 3. The servo gain setting is unreasonable and the stiffness gain is too large; 3. The motor is losing control caused by wrong UUV phase sequence. | <ol style="list-style-type: none"> 1. Check the motor UVW phase sequence 2. Check whether the servo gain parameters are reasonable 3. Check the load condition | Alarm reset |

| Alarm Code | Description | Causes | Measures | Reset Method |
|------------|---|---|---|--------------|
| r41Er | Encoder Communication error | <p>The servo drive detected abnormality in the communication with the encoder.</p> <ol style="list-style-type: none"> 1. Encoder cable is not wired according to the correct definition 2. Encoder cable is not connected well. 3. Interference causes abnormal encoder communications 4. The encoder is damaged. | <ol style="list-style-type: none"> 1. Check whether the encoder wiring is in accordance with the correct definition 2. Check the connection between the encoder cable and the driver and motor 3. Make sure the motor and driver are well grounded 4. Use twisted pair shielded wire with good anti-interference ability for encoder wire 5. Swap the motor and encoder wiring harness respectively to confirm whether the motor is abnormal | Re-power up |
| r42 io | Wrong configuration of I/O function in Q mode | <ol style="list-style-type: none"> 1. The function of I/O signal in Q program is not General Purpose. 2. The function of I/O signal in SCL command is not General Purpose. | Configure the function of I/O as General Purpose. | Alarm reset |

10 Servo Gain Tuning

Servo Gain Tuning is used to optimize the response of the servo system.


It is required for the servo drive to control the motor in least time delay and as accurately as possible to follow the command of controller. In order to make the motor action closer to the command and maximize the mechanical performance, it is necessary to adjust the gain.



10.1 Instructions for Gain Tuning Mode and Procedures

10.1.1 Servo Tuning Procedures

The servo tuning flowchart is as follows. Make sure that the servo system can run normally before starting the servo tuning. Reter to Chapter 6 for trial operation.



10.1.2 What is the Gain Tuning Mode

The servo drive provides three gain tuning modes for gain parameters tuning, which are set by parameter P0-00.

| Setup Value | Tuning Mode | Valid parameters | Instructions |
|-------------|-------------|---|---|
| 0 | No tuning | P0-03 1st mechanical Stiffness Level P0-04 2nd mechanical Stiffness Level | The mechanical stiffness level are only set by P0-03 or P0-04. Modification other gain parameters is invalid. |
| 1 | Auto Tuning | P0-03 1st mechanical Stiffness Level P0-04 2nd mechanical Stiffness Level P0-02 Load Inertia Ratio | The mechanical stiffness level is only set by P0-03. Modification other gain parameters is invalid. |
| 2 | Fine Tuning | P0-05, P0-07 P0-08, P0-11 P0-12, P0-13 P0-16 P0-17, P0-19 P0-20, P0-21 P0-22, P0-23 P0-24 P0-25, P0-27 P0-28, P0-29 P0-30, P0-31 P0-32 | In the "Fine Tuning" mode, you can manually set all gain parameters of each control loop of the servo control to get well stiffness, quick response and performance." |

10.2 Auto Tuning Mode

In the "Auto Tuning" mode, the servo system can automatically identify the external load inertia ratio, select an appropriate mechanical stiffness level and optimize the following gains:

- Gains(Position loop and Velocity loop)
- Filters (Torque filter of current loop)

The parameters in the table below will be changed automatically when the auto-tuning in progress and be stored after the tuning is completed.

| Parameter | Description | Valid to manually modify parameters in auto-tuning mode |
|-----------|--|---|
| P0-02 | Load Inertia Ratio | YES |
| P0-03 | 1st mechanical Stiffness Level | YES |
| P0-05 | 1st Position Loop Gain | NO |
| P0-07 | 1st Position Loop Derivative Time Constant | NO |
| P0-08 | 1st Position Loop Derivative Filter | NO |
| P0-09 | Velocity Feedforward Gain | NO |
| P0-10 | Velocity Feedforward Filter | NO |
| P0-11 | 1st Velocity Command Gain | NO |
| P0-12 | 1st Velocity Loop Gain | NO |
| P0-13 | 1st Velocity Loop Integral Time Constant | NO |
| P0-14 | Acceleration Feedforward Gain | NO |
| P0-15 | Acceleration Feedforward Filter | NO |
| P0-16 | 1st Torque Command Filter | NO |

10.2.1 Required Motion Profile in Auto Tuning Mode


In order to accurately complete the auto tuning, it's necessary to set reasonable motion trajectory including moving distance, travel speed, travel time, acceleration and deceleration and Interval time between two movements.

Travel Time: > 0.5 seconds

Travel Speed: > 180 rpm

Acc./Dec.: > 30rps/s


Interval Time: > 1.5 seconds




Before starting auto tuning, it is recommended to set P0-03(mechanical stiffness level) to "5".

10.2.2 Auto Tuning Flowchart

You can perform the Auto Tuning through Luna software or operation panel of the drive.



After completing the auto tuning, you can continue to modify the parameters P0-03 and P0-04 to optimize the response and stiffness of the servo system.




10.2.3 Start Auto Tuning-- By Operation Panel

Use the operation panel to start Auto Tuning:

- (1) Long press "MODE" key to switch to "Function Select Mode", which will display "F00FL".
- (2) Short press "UP" or "DOWN" key to select "F10AT"
- (3) Long press "SET" key to start auto tuning, the LED will display "At-in".
- (4) Control the motor to start moving according to the planned motion trajectory.
- (5) If error occurs when the auto-tuning in progress, alarm code "AtErr" will be displayed and the tuning process will be stopped and quited. Short press "SET" to exit the error.
- (6) After Auto Tuning is finished, "At-ok" is displayed.
- (7) Short press "SET" key to quite the Auto Tuning process.

Note:

Before starting Auto Tuning, the servo drive must be enabled, otherwise alarm code "AtErr" will be displayed.




10.2.4 Start Auto Tuning-- By Luna software


It's recommended to use Luna software to start Auto tuning. The operation steps are as follows.

Step 1: Connection Wizard


Select the drive that needs to be connented----Click "Next" button to establish communication with the drive.




Step 2: Set the Control mode to Position Control



Step 3: Select "Tuning" funtion



Step 4: Select the tuning mode to "Auto Tuning"



1) 1st Mechanical Stiffness Level:

Set the appropriate stiffness level. It's recommended to set to "5" when running for the first time.

2) Load Type

Select the load type according to the current mechanical structure.

| Load Type | Description |
|----------------|--|
| General Type | Horizontally placed ball-screw, Turntable, etc.. |
| Stiffness Type | Ball-screw load mounted horizontally on a marble base. Horizontally placed turntable, etc. |
| Flexible Type | Belt load, etc.. |

3) Load Inertia Ratio

If already know the current load inertai ratio, input it into "Load Inertai Ratio(P0-02)", which can improve the servo system stiffness and speed up the auto tuning process. It doesn't need to be set if don't know the inertia ratio, the system will indentify the load inertia ratio automatically.

4) Motion Control Source

自定义轨迹规划: 使用软件的“自定义轨迹规划”生成轨迹

外部运动指令: 当使用上位机发送运动轨迹时选择此项

5) Judgment Conditions for Auto Tuning

Vibration Level: The maximun torque vibration value that the servo system needs to be met when in auto tuning process. The larger the set value, the higher the system stiffness after auto tuning is finished.

Positioning Error: The maximum position following error that the servo system needs to be met. The smaller the set value, the higher the system stiffness after auto tuning is finished.

Setting Time: The longest positioning setting time that the servo system needs to be met. The smaller the set value, the higher the system stiffness after auto tuning is finished.

The default value of those parameters above can be used for most applications, they don't need to be set unless excellent stiffness and system response are needed. Note that too extreme conditions may cause servo system vibration easily and unstable.

Step 5: Start the Auto Tuning

After the above configurations are set, set the motion profile that meets the following conditions, and then click the "Start Auto Tuning" button to start the tuning process. The source of motion command can be choose by "My own profile" or "Outer motion profile".

Required Motion Profile:

Travel Time: > 0.5 seconds

Travel Speed: > 180 rpm

Acc./Dec.: > 30rps/s

Interval Time: > 1.5 seconds

1) 使用外部运动指令

点击“开始自动整定”按钮，使用上位机直接发送运动指令。

2) 自定义轨迹规划


用户也可以使用自定义轨迹规划。

按上述运动条件设定合理的运动轨迹，点击“开始自动整定”按钮。



3) The Auto Tuning is completed.


Since the Auto Tuning is completed successfully, the gain parameters will also be saved in the drive automatically, and the following message box will be showed to notice that whether upload parameters from the drive to the software or not. After confirming the upload, you can see that the first mechanical stiffness level and load inertia ratio have been updated.



4) Error Message

If the Auto Tuning process cannot be completed, the following error message box may be displayed, which means:

| Error Code | Cause | Measure |
|------------|--|---|
| 01 | Positioning time out. | Increase the initial stiffness and the value of Setting Time. |
| 02 | The Interval time of two motion profile is too short. | Increase the Interval Time. |
| 03 | The stiffness is reduce to the smallest value during the tuning process. | Increase the Vibration Level. |
| 04 | Error control mode. | Set the control mode to Position Control. |
| 05 | Servo is not enabled. | Enable the servo before starting the auto tuning. |
| 06 | Error tuning mode. | Set the Tuning Mode(P0-00) to "Auto Tuning" |



10.3 Fine Tuning Mode

Fine Tuning mode is suitable for the following situations:

- 1) Errors always occur in the auto tuning and cannot finish the tuning.
- 2) After auto tuning, even if optimize the stiffness level(P0-03) and the load inertia ratio(P0-02), the servo system response still cannot meet the requirements.

Using the Fine Tuning can optimize the system gains to meet the requirements of high servo stiffness, quick response time and minimum setting time.

10.3.1 Introduction of Fine Tuning Mode

Servo system gains are set by several parameters, such as: Load Inertia Ratio, Stiffness Level, Position Loop Gain, Position Loop Derivative Time Constant, Derivative Filter, Velocity Feedforward Gain, Velocity Feedforward Filter, Velocity Command Gain, Velocity Loop Gain, Velocity Loop Integral Time constant, Acceleration Feedforward Gain, Acceleration Filter and Torque Command Filter.

The PID tuning optimizes all the parameters above to meet the performance requirements of the motion system. In generally, for machines with high stiffness mechanical, the servo system response can be improved by increasing the servo gain parameters. However, for the machine with low stiffness mechanical, such as Bell Load, when increase the servo gain parameters, vibration may occur and servo system response cannot be improved.

After fine tuning, gain parameters need to be saved manually.

10.3.2 Parameters in Fine Tuning Mode

| Parameter | Command | Description | Type |
|-----------|---------|---|--|
| P0-01 | LY | Load Type | |
| P0-02 | NR | Load Inertia Ratio | |
| P0-03 | KG | 1st mechanical Stiffness Level | Gain Group 1 |
| P0-04 | KX | 2nd mechanical Stiffness Level | |
| P0-05 | KP | 1st Position Loop Gain | |
| P0-07 | KD | 1st Position Loop Derivative Time Constant | |
| P0-08 | KE | 1st Position Loop Derivative Filter | |
| P0-09 | KL | Velocity Feedforward Gain | |
| P0-10 | KR | Velocity Feedforward Filter | |
| P0-11 | KF | 1st Velocity Command Gain | Gain Group 1 |
| P0-12 | VP | 1st Velocity Loop Gain | |
| P0-13 | VI | 1st Velocity Loop Integral Time Constant | |
| P0-14 | KK | Acceleration Feedforward Gain | |
| P0-15 | KT | Acceleration Feedforward Filter | |
| P0-16 | KC | 1st Torque Command Filter | Gain Group 1 |
| P0-17 | UP | 2nd Position Loop Gain | Gain Group 2 when using Gain Switch function |
| P0-19 | UD | 2nd Position Loop Derivative Time Constant | |
| P0-20 | UE | 2nd Position Loop Derivative Filter | |
| P0-21 | UF | 2nd Velocity Command Gain | |
| P0-22 | UV | 2nd Velocity Loop Gain | |
| P0-23 | UG | 2nd Velocity Loop Integral Time Constant | |
| P0-24 | UC | 2nd Torque Command Filter | |
| P0-25 | XP | Full Closed-loop Position Loop Gain | When using Gain Switch, the first gain group in full closed-loop control |
| P0-27 | XD | Full Closed-loop Position Loop Derivative Time Constant | |
| P0-28 | XE | Full Closed-loop Position Loop Derivative Filter | |
| P0-29 | XF | Full Closed-loop Velocity Command Gain | |
| P0-30 | XV | Full Closed-loop Velocity Loop Gain | |
| P0-31 | XG | Full Closed-loop Velocity Loop Integral Time Constant | |
| P0-32 | XC | Full Closed-loop Torque Command Filter | |
| P0-39 | LR | Velocity Feedback Filter | |

Note:

- 1) When using gain switch function, the gain group 1 and group 2 are used.
- 2) Parameters P0-25 to P0-32 are the first gain group in full closed-loop control mode.

10.3.3 Description for Gain Parameters

The servo system consists of current loop, velocity loop and position loop. The more the inner control loop, the more it needs to improve its responsiveness. Failure to observe this principle can result in poor response or vibration.

If need to improve the response

- 1) Increase Mechanical Stiffness Level
- 2) Increase Position Loop Gain
- 3) Increase Velocity Loop Gain
- 4) Decease the Velocity Loop Integral Time Constant.

If overshoot and vibration occur

- 1) Decease mechanical stiffness level
- 2) Decease Position Loop Gain
- 3) Decease Velocity Loop Gain
- 4) Incease the Velocity Loop Integral Time Constant
- 5) Decease the Torque Command Filter
- 6) Appropriately adjust the Derivative Time Constant

If one parameter is changed, other parameters also need to be modified. Do not make huge changes to just one parameter, 5% changes each time is recommended.

10.3.3.1 Gain Parameters for Position Loop:

◆ Position Loop Gain

| Parameter | Comand | Description | Default | Range | Unit | Control mode | | | |
|-----------|--------|------------------------|---------|-----------|-------|--------------|---|---|--|
| P0-05 | KP | 1st Position Loop Gain | 52 | 0 ~ 20000 | 0.1Hz | P | V | T | |

The stiffness gain of the Position Loop in the PID control algorithm. It determines the response of position loop. Increase this value can improve the system's stiffness and get higher response frequency of position loop, and reduce the system position error. If set the value too high, it may cause vibration and overshoot.

Too small of this gain may cause the response of the system not fast enough, and decreasing trend of position following error will be slow.

Set to 0 means not used, value 20000 means the proportional effect is maximized.

The position loop gain must be smaller than the velocity loop gain.

◆ Position Loop Derivative Time Constant

| Parameter | Comand | Description | Default | Range | Unit | Control mode | | | |
|-----------|--------|--|---------|-----------|------|--------------|---|---|--|
| P0-07 | KD | 1st Position Loop Derivative Time Constant | 0 | 0 ~ 30000 | ms | P | V | T | |

The derivative time constant of Position Loop in the PID control algorithm.

Setting to zero means that derivative function is not used. The smaller the set value, the stronger the effect of derivative term.

Running a motor with a pure PI controller the motor would overreact to small errors, creating ever large errors, ultimately becoming unstable. If know what the motor is going to do before it do it, you could prevent this.

A motor drive can control a motor better if it examines the rate of change of the position error and includes that in its torque calculation. For example, if the motor has error, but the error is decreasing, back off on the torque.

When the system's ability to suppress vibration is insufficient, there will be obvious vibrations during the acceleration/deceleration, cruising and stopped. This vibrations has a decreasing trend and eventually stabilizes. If the system vibrates, the differential time constant can be adjusted appropriately, and the

recommended starting value is 2000.

When the set value of the derivative time constant (KD) is reasonable, the system's ability to suppress vibration is significantly enhanced, and it tends to stabilize quickly.

When the derivative time constant (KD) is set too small, the motion system will be too sensitive, easily vibrate and generate noise.

10.3.4 Gain Parameters for Velocity Loop

◆ Velocity Loop Gain

| Parameter | Comand | Description | Default | Range | Unit | Control mode | | | |
|-----------|--------|------------------------|---------|-----------|-------|--------------|---|---|--|
| P0-12 | VP | 1st Velocity Loop Gain | 183 | 0 ~ 30000 | 0.1Hz | P | V | T | |

The stiffness gain of the Velocity Loop in the PID control algorithm.

The simplest part of the Velocity Loop is the proportional gain, or VP, term. The drive applies current to the motor in direct proportion to the error. For example, if a motor is not moving, and the shaft is turned by hand or some other force, the drive will increase the motor current until the motor returns to "0" speed. The faster the motor is moved from "0" speed, the more the opposing torque will increase. The VP term (also called VP gain) governs how much torque will be applied for a given amount of velocity error (Vn). In general, more load inertia or load friction, requires more torque and therefore a higher VP gain.

In generally, applications or machines that require high speed and high precision, higher frequency response bandwidth is required. To improve the overall response of the servo system and to reduce position following error, it is necessary to increase the speed loop gain value. Setting the value too high will cause vibration. The response frequency of the speed loop must be 4–6 times higher than the response frequency of the position loop; otherwise, the machinery might vibrate or it might cause overshoot when positioning

When P0-02 (auto estimation or manually set value) is equal to the real inertia ratio (JL/ JM), the real speed loop frequency response is the value set by P0-12.

◆ Velocity Loop Integral Time Constant

| Parameter | Comand | Description | Default | Range | Unit | Control mode | | | |
|-----------|--------|--|---------|-----------|------|--------------|---|---|--|
| P0-13 | VI | 1st Velocity Loop Integral Time Constant | 189 | 0 ~ 30000 | ms | P | V | T | |

Set the Integral Time Constant of the Velocity Loop. The Integral gain will not take effect when the value is set to zero.

If only proportional gain is working without integral gain, the error is hard to decrease to zero quickly, or it may take long time to get zero. The integral time constant accumulates all errors and takes effect together with the proportional gain. A smaller integral time constant (VI) setting can improve the response and responsiveness of the servo system and reduce the following error.

The smaller the set value, the stronger the integral gain. If the set value of the integral time constant (VI) is too small, the excessive rigidity of the system will cause vibration and noise of the entire servo system. This vibration and noise occurs during the entire movement process, and it is always in an oscillating state, which cannot be stabilized.

10.4 Resonance Suppression

The mechanical system has an inherent resonance frequency. If the whole system runs at this mechanical resonance frequency point, vibration and noise may be caused.

M56S series provide 4 methods to suppress mechanical resonance.

- 1) Torque Command Filter
- 2) Notch Filters
- 3) End Effector Suppress
- 4) Load Disturbance Suppress

10.4.1 Torque Command Filter

| Parameter | Command | Description | Default | Range | Unit | Control mode | | |
|-----------|---------|---------------------------|---------|-----------|-------|--------------|---|---|
| P0-16 | KC | 1st Torque Command Filter | 1099 | 0 ~ 40000 | 0.1Hz | P | V | T |

对指令转矩进行滤波。数值越小，代表滤波频率越低，滤波效果越明显。

默认值1099可应用于大部分场合。转矩滤波频率(P0-16)必须是速度环增益(P0-12)的3倍以上。

该滤波器是一个单输出的低通滤波器，用来对PID控制器的输出(也就是参考电流)进行低通滤波。设定该值时需要考虑系统运行所需要的截止频率。


在一些特定场合使用，比如电机出现振动或是明显可听见的噪声。可以尝试减小此值，该滤波器对控制环路的输出进行低通滤波。

当一个系统容易出现机构共振，该低通滤波器截止频率可设置到共振频率点以下，这样控制环路的输出就不会激励共振。

10.4.2 Notch Filter

Reducing the Torque Command Filter could solve the resonance, but it also reduce the system response bandwidth and phase margin, and thus the system becomes unstable. In some case, it may cause a counter-action that the resonance may not be suppressed.

If you know the resonance frequency, the notch filter can be used to suppress the resonance. The notch filter suppresses mechanical resonance by reducing the gain at a specific frequency for high-frequency mechanical resonance.



This resonance frequency can be detected through open-loop mechanical analysis. If the resonance frequency drifts significantly with time or due to other cause, using notch filter is not suggested.

There are 4 notch filters in M56S series and each notch filter has three parameters, which are:

- Center frequency of Notch Filter
- Notch Bandwidth
- Notch Depth Level(Notch Filter Attenuation Level)

The first group and the second group are user-defined notch filters, and all parameters need to be set by user. The third group and the fourth group can be set manually or be set as an adaptive notch filter which all parameters are detected by the drive in real-time and automatically set.

Note: The center point frequency of the Notch Filter must be greater than 2 times of the Torque. Command Filter(P0-16).

10.4.2.1 Adaptive Notch Filter

When the servo system resonates and needs to use the notch filter, it's recommended to use the Adaptive Notch Filter.

◆ Scope of application and precautions:

Applicable to all control mode except Torque Mode

◆ Conditions may affect normal operation of the Adaptive Notch Filter:

- The resonance frequency is lower than 3 times the Velocity Loop Gain
- The frequency between two resonance points is less than 100Hz

◆ Steps for usage

1).In the "Anti-resonance" interface of Luna software, change the usage mode of "Notch Filter 3" to "Adaptive", and then click the "Download" button to enable a self-adaptive notch filter.

2).When the servo system is running, it will automatically detect resonance frequency and take effect to suppress.

3).If there is a new resonance, enable the "Notch Filter 4" with same operation.


4).When the system is running, the third and fourth groups of notch filter parameters are automatically updated, but will not be displayed in the software interface.

5) Although these parameters are updated automatically, they will not be saved automatically. After the servo system is powered on again, the system will automatically update these parameters when the servo is enabled and running.

This setting can prevent abnormal movement of the servo system during operation, resulting in the notch filter parameters being updated to wrong values, which may increase vibration.

◆ Software settings for Adaptive Notch Filter

Step 1: Open the "Anti-resonance" window, and then click "Upload" button.



Step 2: Change the usage mode of "Notch Filter 3" to "Adaptive", and then click the "Download" button.



Step 3: When the servo system is running, it will automatically detect resonance frequency and take effect to suppress.

10.4.3 Mechanical Analysis and Manual Setting of Notch Filtes

Analyze Resonance Frequency

To manually set the notch filter, it is necessary to detect the actual frequency when resonance occurs. You can use the "Mechanical Analysis" function in the Luna software.

Test Type for Mechanical Analysis

| Test Type: | Applicable load | Principle | Note |
|----------------------|--------------------------|--|---|
| Mechanical Open-loop | Horizontal Load | Analyze the resonance of a servo system in torque mode. Because it does not include the loop of the servo controller, it can be used to analyze the real resonance frequency of the whole system, and even detect vibration caused by unreasonable parameter settings. | For mechanical open-loop analysis, the drive needs to be disabled, so it cannot be used for vertical loads |
| Velocity Closed-loop | Horizontal Vertical Load | Analyze the resonance of a mechanical system in Command Velocity Mode. At this point the servo control loop is engaged. When using, it is necessary to ensure that the control parameters of the servo are set reasonably. | <ul style="list-style-type: none"> ◆ The control mode of the drive needs to be in the Command Velocity Mode, that is, the set value of P1-00 is 10. ◆ The drive needs to be enabled when starting the Velocity Closed-loop Analysis. ◆ For vertical loads, ensure that there are mechanical protection measures against falling. |

10.4.3.1 How to Analyze Resonance Frequency using Mechanical Open-loop


Step 1

Before starting the Mechanical Open-loop analysis, ensure that:

- Servo system works well.
- The gain parameters tuning is completed.
- Make sure the drive is disabled.

Step 2

Set an appropriate amplitude to start, be aware that an excessively large value may cause mechanical movement.




Smooth Factor:

The curve will be displayed smoothly, which is helpful for analyzing the frequency points of resonance. The larger the value, the smoother the curve.

Step 3


Click the "Start" button, the servo system starts the Mechanical Open-loop analysis and displays the result curve.

Click the icon in the upper right corner of the drawing area to optimize the displayed curve.



Step 4


Move the reference line in the "Magnitude_Phase Curve" to the place where the Magnitude curve (Blue curve in the figure below) has abnormal protrusion.



The Notch Filter in red area will display the resonance frequency of the current reference line(The picture above is around 1200Hz). Click "Set to Notch Filter 1" or "Set to Notch Filter 2" button will set this frequency as the resonance suppression frequency.


Step 5

Open the "Anti-Resonance" window, select "Use" and set appropriate Bandwidth Level and Depth Level, and then click "Download" button to enable the notch filter.



Note:

- 1) The mechanical open-loop analysis not include the servo control loop, even if the Notch Filter is set, the resonance frequency still can be detected when the open-loop analysis is performed again. You can use the Velocity Closed-loop Analysis to check the suppression result after the Notch Filter is set.
- 2) The center point frequency of the Notch Filter must be greater than 2 times of the Torque



10.4.3.2 How to Analyze Resonance Frequency using Velocity Closed-loop


Step 1

Before performing the Velocity Closed-loop Analysis, make sure that:

- Servo system works well.
- The gain parameters tuning is completed.
- The Control Mode is set to Command Velocity Mode
- Make sure the drive is enabled.
- It's recommended to use a motor with brake for vertical load to avoid accidental load drop.

Step 2


- 1) Set an appropriate amplitude to start, be aware that an excessively large value may cause mechanical movement.
- 2) Open "SCL Terminal" from the "Tools" menu.
- 3) Enter "CM10" in the SCL terminal to set the control mode to Command Velocity Mode.
- 4) Enable the drive



Step 3


- 1) Click the "Start" button, the servo system starts the Velocity Closed-loop analysis and displays the result curve.
- 2) Click the icon in the upper right corner of the drawing area to optimize the displayed curve.
- 3) Move the reference line in the "Magnitude_Phase Curve" to the place where the Magnitude curve (Blue curve in the figure below) has abnormal protrusion.

The Notch Filter in red area will display the resonance frequency of the current reference line(The picture below shows there is an obvious vibration around 1200Hz.). Click "Set to Notch Filter 1" or "Set to Notch Filter 2" button will set this frequency as the resonance suppression frequency.




Step 4

Open the "Anti-Resonance" window, select "Use" and set appropriate Bandwidth Level and Depth Level, and then click "Download" button to enable the notch filter.




Step 5

Perform Velocity Closed-loop analysis again to check the suppressed result.



10.5 End Effector Suppress

As shown in the figure below, the mechanical transmission part has a certain elasticity. For example, due to the long length of the end of the mechanical load and the hysteresis of the position control loop, it is easy to generate low-frequency vibration during running and stopping. This vibration tends to have a low frequency, generally within 30Hz, but it will affect the positioning accuracy and settling time.




After the position command has finished, the end of the mechanical part is still wobble even if the motor has stopped moving. This kind of vibration can be suppressed well by using the End Effector Suppress function, so as to improve the position accuracy and shorten the positioning and settling time.


How to Use:

Step 1: Detect the wobble frequency

Use the oscilloscope function of Luna software to observe the curves of "Target Speed" and "Actual Speed" and "Position Error" when motor stops.




As shown in the figure below, when the Target Speed is zero, the Position Error still has a relatively fluctuation, but the amplitude decrease gradually under the damping effect of servo system. The fluctuation frequency of Position Error can be measured.



Step 2: Set the Frequency and Enable the End Effector Suppress function

Open the "Anti-resonance" window and click the tab of "End Effector & Load Disturbance Suppress", and then enter the fluctuation frequency measured in the first step and check "Use", and then click "Download" button. After downloading to the driver, the end vibration suppression will take effect.

**Note:**

- ◆ Wrong Fluctuation Frequency will cause the end vibration suppression effect to become worse or even increase the vibration.
- ◆ Only the Fluctuation Frequency within 1-30Hz can be well suppressed.
- ◆ This function is not suitable for vibration caused by non-mechanical end causes.


10.6 Load Disturbance Suppress

The servo system is disturbed by external factors, such as sudden changes in load or sudden changes in external forces or friction, which may cause servo system vibration easily and become unstable.

The Load Disturbance Suppress function can eliminate such disturbances and improves system response.

How to Use:

Open the "Anti-resonance" window and click the tab of "End Effector & Load Disturbance Suppress", and then check "Use" of "Load Disturbance Suppress", and then click "Download" button. After downloading to the driver, the Load Disturbance Suppress function will take effect.



11 Modbus/RTU Commucation

There are two types of communication methods for ModBUS, ASCII(American Standard Code for information interchange) mode and RTU(Remote Terminal Unit)mode, this is defined based on different bus modulation and demodulation methods. For M56S series AC servo drives, only ModBUS RTU is supported.

11.1 Modbus/RTU Configurations

11.1.1 Data Encode

The drive uses "Big-Endian" or "Little-Endian" for 32-bit data storage. In M5, each register is a word in 16-bit, so when storing a 32-bit data, it needs to occupy 2 registers.

Big-Endian: The Most Significant Byte (MSB) value is stored at the memory location with the lowest address; the next byte value in significance is stored at the following memory location and so on. This is akin to Left-to-Right reading in hexadecimal order.

For example: To store a 32bit data 0x12345678 into register address 40011 and 40012. 0x1234 will be defined as MSB, and 0x5678 as LSB. With big-endian system:

Register 40031 = 0x1234

Register 40032 = 0x5678

When transfer 0x12345678, the first word will be 0x1234, and the second word will be 0x5678

Little-Endian: The Least Significant Byte (LSB) value is stored at the memory location with the lowest address, and the MSB value is stored at the following memory location and so on.

For example: To store a 32bit data 0x12345678 into register address 40031 and 40032. 0x5678 will be defined as LSB, and 0x1234 as MSB. With little-endian system:

Register 40031 = 0x5678

Register 40032 = 0x1234

When transfer 0x12345678, the first word will be 0x5678, and the second word will be 0x1234. M56S drive parameter P1-13 (PR) defines data transfer type:

P1-13(PR) = 5 represents Big-Endian.

P1-13(PR) = 133 represents Little-Endian.

11.1.2 Communication Address

In the network system, each drive requires a unique drive address. Only the drive with the matching address will responded to the host command. In ModBUS network, address "0" is the broadcast address.

It cannot be used for individual drive' s address. ModBUS RTU/ASCII can set drive address from 1 to 31. Parameter P1-16(DA) is used to set the communication address(Node ID) in RS-485 network.

11.1.3 Communication Protocol and Baud Rate

The supported data protocol in M56S series is :

- 8, N, 1. That is: 8 data bits, 1 stop bit, no parity bit.

The communication baud rate is set by parameter P1-15(BR).

The baud rate that takes effect after power-on in serial communication. This value will be saved immediately after being configured but will not take effect immediately until the next power-on, so the host software can configure this value at any time.

1 = 9600bps

2 = 19200bps

3 = 38400bps

4 = 57600bps

5 = 115200bps

11.1.4 Power-on Mode

Configure the operating mode of the drive after power on. Parameter P1-02(PM) is used to set it. The corresponding relationship between PM command parameter value and working mode in Modbus RTU communication mode is as follows:

- 8: After power on, the driver is in enable working mode.
- 9: After power on, the drive is in the working mode that conduct the Q programming automatically.
- 10: After power on, the drive is in non-enable working mode.

11.2 Modbus/RTU Message Frame

Modbus RTU protocol establishes the query message by putting the slave device address (or broadcast), the function code defining the requested operation, the data to be sent as well as CRC verification into the host query. The response message in slave device also uses Modbus RTU message structure, including the slave device address, the function code requesting operation, the data to be sent as well as CRC check. If there is fault when receiving the information or the slave device cannot operate the requested action, the slave device will send an abnormal information as a response. Modbus RTU data frame structure is as follows:

| Address Domain | Function Code | Data Domain | CRC Check |
|----------------|---------------|-------------|-----------|
| 1 BYTE | 1 BYTE | n BYTES | 2 BYTES |

11.3 Supported Function Codes for Modbus

The Modbus function codes supported by the MOONS' driver are as follows:

- ◆ 0x03: Read hold register
- ◆ 0x06: Write a single register
- ◆ 0x10: Write multiple registers

11.3.1 Function Code :0x03: Read Hold Register

Read single or multiple holding registers, up to 50 registers are allowed to be read, broadcast are not supported.

E.g. Read the drive status with slave address 1 and the register address is 40002, assuming the register value is 0x0009

| Host sends: Command Message(Master) | | | Slave response: Response Message(Slave) | | |
|--|-----------------------|-----------------|---|-----------------------|-----------------|
| Function | Data | Number of Bytes | Function | Data | Number of Bytes |
| Slave Address | 01H | 1 | Slave Address | 01H | 1 |
| Function Code | 03H | 1 | Function Code | 03H | 1 |
| Starting Data Address (Register 40002) | 00H(High) 01H(Low) | 2 | Number of Data (In Byte) | 04H | 1 |
| Number of Data (In word) | 00(High) 01(Low) | 2 | Content of Starting Data Address 40002 | 00H(High) 09H(Low) | 2 |
| CRC Check Low | D5H | 1 | CRC Check Low | 78H | 1 |
| CRC Check High | CAH | 1 | CRC Check High | 42H | 1 |

Host Sends: 01 03 00 01 00 01 D5 CA

Slave Responses: 01 03 02 00 09 78 42

If communication error occurs, the data format returned by the exception is:

01 83 XX CRC_L CRC_H

Where XX is,

- ◆ XX = 01H means does not support to read the function code 03H;
- ◆ XX = 02H means illegal register;
- ◆ XX = 03H means illegal data area;
- ◆ XX = 11H means register does not support read or write

The Modbus RTU/TCP message sent by the host is as follows:

| Modbus Protocol Type | MBAP Message Header | Address Code | Function Code | Register Address | Register Amount | CRC Check |
|----------------------|----------------------|--------------|---------------|------------------|-----------------|-----------|
| Modbus RTU | None | 01 | 03 | 00 01 | 00 01 | D5 CA |
| Modbus TCP | 00 00 00 00 00 06 01 | None | 03 | 00 01 | 00 01 | None |

The Modbus RTU/TCP message returned by the slave station equipment is as follows:

| Modbus Protocol Type | MBAP Message Header | Address Code | Function Code | Register Address | Register Amount | CRC Check |
|----------------------|----------------------|--------------|---------------|------------------|-----------------|-----------|
| Modbus RTU | None | 01 | 03 | 02 | 00 09 | 78 42 |
| Modbus TCP | 00 00 00 00 00 05 01 | None | 03 | 02 | 00 09 | None |

11.3.2 Function Code 0x06: Write a Single Register

Writes to a single holding register. When using a broadcast instruction, all slave devices on the bus perform the write operation to the same register.

For example, write the motor running speed to the drive whose slave device address is 11. The register address is 40030. Assuming that the motor speed is set to 12.5 rps, write the data bit $12.5 \times 240 = 3000$, which is converted to hexadecimal 12CH.

| Host sends: Command Message(Master) | | | Slave response: Response Message(Slave) | | |
|--|-----------------------|-----------------|---|-----------------------|-----------------|
| Function | Data | Number of Bytes | Function | Data | Number of Bytes |
| Slave Address | 0BH | 1 | Slave Address | 0BH | 1 |
| Function Code | 06H | 1 | Function Code | 06H | 1 |
| Starting Data Address (Register 40030) | 00H(High) 1DH(Low) | 2 | Starting Data Address (Register 40030) | 00H(High) 1DH(Low) | 2 |
| Content of Data | 01(High) 2C(Low) | 2 | Content of Data | 01(High) 2C(Low) | 2 |
| CRC Check Low | 19H | 1 | CRC Check Low | 19H | 1 |
| CRC Check High | 2BH | 1 | CRC Check High | 2BH | 1 |

Host Sends: 0B 06 00 1D 01 2C 19 2B

Slave Responses: 0B 06 00 1D 01 2C 19 2B

If communication error occurs, the data format returned by the exception is:

0B 86 XX CRC_L CRC_H

Where XX is

- ◆ XX = 01H, does not support to write in function code 06H
- ◆ XX = 02H, illegal register
- ◆ XX = 03H, illegal data area
- ◆ XX = 12H, register does not support read or write
- ◆ XX = 13H, set value exceeds the scope

The Modbus RTU/TCP message sent by the host is as follows:

| Modbus Protocol Type | MBAP Message Header | Address Code | Function Code | Register Address | Register Amount | CRC Check |
|----------------------|----------------------|--------------|---------------|------------------|-----------------|-----------|
| Modbus RTU | None | 0B | 06 | 00 1D | 01 2C | 19 2B |
| Modbus TCP | 00 00 00 00 00 06 0B | None | 06 | 00 1D | 01 2C | None |

The Modbus RTU/TCP message returned by the slave station equipment is as follows:

| Modbus协议类型 | MBAP Message Header | Address Code | Function Code | Register Address | Register Amount | CRC Check |
|------------|----------------------|--------------|---------------|------------------|-----------------|-----------|
| Modbus RTU | None | 0B | 06 | 00 1D | 01 2C | 19 2B |
| Modbus TCP | 00 00 00 00 00 06 0B | None | 06 | 00 1D | 01 2C | None |

11.3.3 Function Code 0x10: Write Multiple Register

Write single or multiple holding registers, with a maximum of 50 registers allowed. When a broadcast command is used, the same registers of all slave devices on the bus perform to write operations.

E.g. Write the target distance to the drive which the slave address is 10. The register addresses are 40031 and 40032. Assuming that the target distance is 30000, it is converted into hexadecimal 7530H and transmits in Big Endian encoding.

| Host sends: Command Message(Master) | | | Slave response: Response Message(slave) | | |
|--|-----------------------|-----------------|---|-----------------------|-----------------|
| Function | Data | Number of Bytes | Function | Data | Number of Bytes |
| Slave Address | 0AH | 1 | Slave Address | 0AH | 1 |
| Function Code | 10H | 1 | Function Code | 10H | 1 |
| Starting Data Address (Register 40031) | 00H(High) 1EH(Low) | 2 | Starting Data Address (Register 40031) | 00H(High) 1EH(Low) | 2 |
| Number of Data (In word) | 00H(High) 02H(Low) | 2 | Number of Data (In word) | 00(High) 02(Low) | 2 |
| Number of Data (In byte) | 04H | 1 | CRC Check Low | 20H | 1 |
| Content of First Data Address | 00H(High) 00H(Low) | 2 | CRC Check High | B5H | 1 |
| Content of Second Data Address | 75H(High) 30H(Low) | 2 | | | |
| CRC Check Low | 70H | 1 | | | |
| CRC Check High | 8FH | 1 | | | |

Host Sends: 0A 10 00 1E 00 02 04 00 00 75 30 70 8F

Slave Responses: 0A 10 00 1E 00 02 20 B5

If communication error occurs, the data format returned by the exception is:

0A 90 XX CRC_L CRC_H

Where XX is:

- ◆ XX = 01H: Function code 10H is not supported
- ◆ XX = 02H: Illegal register
- ◆ XX = 03H: Illegal data area
- ◆ XX = 12H: Register does not support writing in
- ◆ XX = 13H: Set value is out of range

The Modbus RTU/TCP message sent by the host is as follows:

| Modbus Protocol Type | MBAP Message Header | Address Code | Function Code | Register Address | Register Amount | Number of Bytes | Data Content | CRC Check |
|----------------------|----------------------|--------------|---------------|------------------|-----------------|-----------------|--------------|-----------|
| Modbus RTU | None | 0A | 10 | 00 1E | 00 02 | 04 | 00 00 75 30 | 70 8F |
| Modbus TCP | 00 00 00 00 00 0B 0A | None | 10 | 00 1E | 00 02 | 04 | 00 00 75 30 | None |

The Modbus RTU/TCP message returned by the slave station equipment is as follows:

| Modbus Protocol Type | MBAP Message Header | Address Code | Function Code | Register Address | Register Amount | CRC Check |
|----------------------|----------------------|--------------|---------------|------------------|-----------------|-----------|
| Modbus RTU | None | 0A | 10 | 00 1E | 00 02 | 20 B5 |
| Modbus TCP | 00 00 00 00 00 06 0A | None | 10 | 00 1E | 00 02 | None |

11.4 SCL Command Code

11.4.1 Command Code

Register 40125 is defined as the operation code register. If write corresponding operation code to register 40125, then it operates the corresponding function of operation code. The operation code that supports is listed as below.

| SCL Command Encoding Table | | | | | | | |
|---------------------------------------|-----|--------|-------------|-------------|-------------|-------------|-------------|
| Function | SCL | Opcode | Parameter 1 | Parameter 2 | Parameter 3 | Parameter 4 | Parameter 5 |
| Alarm Reset | AX | 0xBA | × | × | × | × | × |
| Start Jogging | CJ | 0x96 | × | × | × | × | × |
| Stop Jogging | SJ | 0xD8 | × | × | × | × | × |
| Encoder Position | EP | 0x98 | Position | Position | × | × | × |
| Feed to Length with Speed Change | FC | 0x6D | I/O Point | Condition | × | × | × |
| Feed to Length | FL | 0x66 | × | × | × | × | × |
| Feed to Sensor with Mask Distance | FM | 0x6A | I/O Point | Condition | × | × | × |
| Feed and Set Output | FO | 0x68 | I/O Point | Condition | × | × | × |
| Feed to Position | FP | 0x67 | × | × | × | × | × |
| Feed to Sensor | FS | 0x6B | I/O Point | Condition | × | × | × |
| Feed to Sensor with Safety Distance | FY | 0x6C | I/O Point | Condition | × | × | × |
| Motor Disable | MD | 0x9E | × | × | × | × | × |
| Motor Enable | ME | 0x9F | × | × | × | × | × |
| Seek Home | SH | 0x6E | I/O Point | Condition | × | × | × |
| Set Position | SP | 0xA5 | Position | Position | × | × | × |
| Full Closed-loop Control Switch | XM | 0x54 | 0..1 | × | × | × | × |
| Set Output | SO | 0x8B | I/O Point | Condition | × | × | × |
| Wait for Input | WI | 0x70 | × | × | × | × | × |
| Queue Load & Execute | QX | 0x78 | 1..12 | × | × | × | × |
| Wait Time | WT | 0x6F | 0.01 sec | × | × | × | × |
| Find Home | FH | 0xDB | -4..35 | × | × | × | × |
| Stop Move & Kill Buffer, Max Decel | SK | 0xE1 | × | × | × | × | × |
| Stop Move & Kill Buffer, Normal Decel | SKD | 0xE2 | × | × | × | × | × |

Notes: "x" in the table means do not use

E.g. SCL command "FL" means executing relative position control. In Modbus, writing "0x66" into register 40125 (that is FL's Opcode in register table) can execute relative position control.

For detailed operation code function, please refer to HOST COMMAND REFERENCE brochure.

For detailed usage routines of the motor brake, please refer to the Modbus user manual.

11.4.2 I/O Code

The coding of digital input/output port and status is shown in the table below.

| Character | Hex | Description |
|-----------|------|------------------------------|
| '0' | 0x30 | Z-phase signal for encoder |
| '1' | 0x31 | Digital Input/Output 1 |
| '2' | 0x32 | Digital Input/Output 2 |
| '3' | 0x33 | Digital Input/Output 3 |
| '4' | 0x34 | Digital Input/Output 4 |
| '5' | 0x35 | Digital Input/Output 5 |
| '6' | 0x36 | Digital Input/Output 6 |
| '7' | 0x37 | Digital Input/Output 7 |
| '8' | 0x38 | Digital Input/Output 8 |
| '9' | 0x39 | Digital Input/Output 9 |
| ':' | 0x3A | Digital Input/Output 10 |
| ',' | 0x3B | Digital Input/Output 11 |
| '<' | 0x3C | Digital Input/Output 12 |
| 'L' | 0x4C | Low-level (Optocoupler on) |
| 'H' | 0x48 | High-level (Optocoupler off) |
| 'R' | 0x52 | Rising edge of the signal |
| 'F' | 0x46 | Falling edge of the signal |

E.g. SCL command "FS1F". In Modbus control, when write "0x6B" in register 40125, "0x31" in register 40126 and "0x46" in register 40127, they execute the same control.

11.5 Modbus Register Table of M56S Series

11.5.1 M56S Series General Purpose Registers

| 11.5.1 M56S Series General Purpose Registers | | | | | |
|--|-----------|-----------|----------|-------------------------------------|--------------|
| Register | Access | Data Type | Units | Description | SCL Register |
| 40001..002 | Read Only | LONG | --- | Alarm Code (AL) | f |
| 40003..004 | Read Only | LONG | --- | Status Code (SC) | s |
| 40005 | Read Only | SHORT | --- | Digital Output Status (IO) | y |
| 40006 | Read Only | SHORT | --- | Digital Input Status (IS) | i |
| 40007..008 | Read Only | LONG | pulses | Immediate Absolute Position (IP) | l |
| 40009..010 | Read Only | LONG | pulses | Secondary Encoder Position (EQ) | |
| 40011..012 | Read Only | LONG | pulses | Encoder Position (EP) | e |
| 40013..014 | Read Only | LONG | pulses | Internal Use | |
| 40015 | R/W | SHORT | | Reserved | |
| 40016 | Read Only | SHORT | rev | Encoder Multi-turn Data | |
| 40017 | Read Only | SHORT | 1/240rps | Immediate Actual Velocity (IV) | v |
| 40018 | Read Only | SHORT | 1/240rps | Immediate Target Velocity (IV1) | w |
| 40019 | Read Only | SHORT | 0.1°C | Immediate Drive Temperature (IT) | t |
| 40020 | Read Only | SHORT | 0.1°C | Immediate DSP Temperature (IT1) | |
| 40021 | Read Only | SHORT | 0.1°C | Immediate Encoder Temperature (IT2) | |
| 40022 | Read Only | SHORT | 0.1V | Immediate DC_Bus Voltage (IU) | u |
| 40023..024 | Read Only | LONG | pulses | Immediate Position Error (IX) | x |
| 40025 | R/W | SHORT | | Reserved | |
| 40026 | Read Only | SHORT | mv | Analog Input 1 (IA1) | j |
| 40027 | Read Only | SHORT | mv | Analog Input 2 (IA2) | k |
| 40028 | R/W | SHORT | mv | Analog Output 1 (OA1) | T |
| 40029 | R/W | SHORT | mv | Analog Output 2 (OA2) | W (Capital) |

11.5.1 M56S Series General Purpose Registers

| Register | Access | Data Type | Units | Description | SCL Register |
|------------|-----------|-----------|--------|--------------------------------|--------------|
| 40030 | Read Only | SHORT | --- | Q Program Line Number | b |
| 40031 | Read Only | SHORT | 0.1% | Immediate Current Command (IC) | c |
| 40032 | Read Only | SHORT | 0.1% | Q Current (IQ) | q |
| 40033..034 | Read Only | LONG | pulses | Relative Distance (ID) | d |
| 40035..036 | Read Only | LONG | pulses | Sensor Position | g |
| 40037 | Read Only | SHORT | --- | Condition Code | h |
| 40038 | Read Only | SHORT | --- | Control Mode | m |
| 40039 | Read Only | SHORT | --- | Velocity Move State | n |
| 40040 | Read Only | SHORT | --- | Point-to-Point Move State | o |
| 40041 | Read Only | SHORT | --- | Q Segment Number | p |
| 40042 | Read Only | SHORT | --- | Model Number | |
| 40043 | Read Only | SHORT | --- | Sub Model | |
| 40044 | Read Only | SHORT | --- | DSP Firmware Version | |
| 40045 | Read Only | SHORT | --- | FPGA Firmware Version NO | |
| 40046 | Read Only | SHORT | --- | FPGA Firmware Version LA | |
| 40047..048 | R/W | LONG | pulses | Input Counter | I (Capital) |
| 40049..050 | R/W | LONG | pulses | Pulse Counter | S (Capital) |
| 40051 | R/W | SHORT | --- | Internal Use | |
| 40052..053 | Read Only | LONG | s | Power Up Seconds | |
| 40054..055 | Read Only | LONG | times | Power On Times | |
| 40056 | Read Only | SHORT | --- | Encoder Firmware Version | |
| 40057 | R/W | SHORT | --- | Internal Use | |
| 40058 | Read Only | SHORT | --- | Internal Use | |
| 40059 | Read | SHORT | --- | Internal Use | |

| 11.5.1 M56S Series General Purpose Registers | | | | | |
|--|-----------|-----------|----------|-----------------------------------|--------------|
| Register | Access | Data Type | Units | Description | SCL Register |
| 40060 | R/W | SHORT | 1% | Internal Use | |
| 40061 | R/W | SHORT | pulses | Internal Use | |
| 40062 | R/W | SHORT | ms | Internal Use | |
| 40063 | R/W | SHORT | --- | Internal Use | |
| 40064 | R/W | SHORT | --- | Internal Use | |
| 40065 | R/W | SHORT | 0 ~ 3000 | Torque Limit Dynamic CW | Y |
| 40066 | R/W | SHORT | 0 ~ 3000 | Torque Limit Dynamic CCW | Z (Capital) |
| 40067..68 | Read Only | LONG | --- | Alarm Code | r |
| 40069 | Read Only | SHORT | --- | Alarm Buffer 0 驱动器报错代码记录8 | |
| 40070 | Read Only | SHORT | --- | Alarm Buffer 1 驱动器报错代码记录1 | |
| 40071 | Read Only | SHORT | --- | Alarm Buffer 2 驱动器报错代码记录2 | |
| 40072 | Read Only | SHORT | --- | Alarm Buffer 3 驱动器报错代码记录3 | |
| 40073 | Read Only | SHORT | --- | Alarm Buffer 4 驱动器报错代码记录4 | |
| 40074 | Read Only | SHORT | --- | Alarm Buffer 5 驱动器报错代码记录5 | |
| 40075 | Read Only | SHORT | --- | Alarm Buffer 6 驱动器报错代码记录6 | |
| 40076 | Read Only | SHORT | --- | Alarm Buffer 7 驱动器报错代码记录7 | |
| 40077..78 | Read Only | LONG | s | Alarm Buffer 8 驱动器报错代码记录8产生时间 | |
| 40079..80 | Read Only | LONG | s | Alarm Buffer 9 驱动器报错代码记录1产生时间 | |
| 40081..82 | Read Only | LONG | s | Alarm Buffer 10 驱动器报错代码记录2产生时间 | |
| 40083..84 | Read Only | LONG | s | Alarm Buffer 11 驱动器报错代码记录3产生时间 | |
| 40085..86 | Read Only | LONG | s | Alarm Buffer 12 驱动器报错代码记录4产生时间 | |
| 40087..88 | Read Only | LONG | s | Alarm Buffer 13 驱动器报错代码记录5产生时间 | |
| 40089..90 | Read Only | LONG | s | Alarm Buffer 14 驱动器报错代码记录6产生时间 | |
| 40091..92 | Read Only | LONG | s | Alarm Buffer 15 驱动器报错代码记录7产生时间 | |

11.5.1 M56S Series General Purpose Registers

| Register | Access | Data Type | Units | Description | SCL Register |
|------------|-----------|-----------|-------|--------------------------------------|--------------|
| 40093..94 | Read Only | LONG | --- | Alarm Buffer 16 | |
| 40095..96 | Read Only | LONG | --- | Alarm Buffer 17 | |
| 40097..98 | Read Only | LONG | --- | Alarm Buffer 18 | |
| 40099..100 | Read | LONG | --- | Alarm Buffer 19 | |
| 40101..102 | Read Only | LONG | --- | Alarm Buffer 20 | |
| 40103..104 | Read Only | LONG | --- | Alarm Buffer 21 | |
| 40105..106 | Read Only | LONG | --- | Alarm Buffer 22 | |
| 40107..108 | Read Only | LONG | --- | Alarm Buffer 23 | |
| 40109..110 | Read Only | LONG | --- | Alarm Buffer 24 驱动器报错代码记录8产生时刻错误值 | |
| 40111..112 | Read Only | LONG | --- | Alarm Buffer 25 驱动器报错代码记录1产生时刻错误值 | |
| 40113..114 | Read Only | LONG | --- | Alarm Buffer 26 驱动器报错代码记录2产生时刻错误值 | |
| 40115..116 | Read Only | LONG | --- | Alarm Buffer 27 驱动器报错代码记录3产生时刻错误值 | |
| 40117..118 | Read Only | LONG | --- | Alarm Buffer 28 驱动器报错代码记录4产生时刻错误值 | |
| 40119..120 | Read Only | LONG | --- | Alarm Buffer 29 驱动器报错代码记录5产生时刻错误值 | |
| 40121..122 | Read Only | LONG | --- | Alarm Buffer 30 驱动器报错代码记录6产生时刻错误值 | |
| 40123..124 | Read Only | LONG | --- | Alarm Buffer 31 驱动器报错代码记录7产生时刻错误值 | |
| 40125 | R/W | SHORT | --- | Command Opcode | |
| 40126 | R/W | SHORT | --- | Parameter 1 | |
| 40127 | R/W | SHORT | --- | Parameter 2 | |
| 40128 | R/W | SHORT | --- | Parameter 3 | |
| 40129 | R/W | SHORT | --- | Parameter 4 | |
| 40130 | R/W | SHORT | --- | Parameter 5 | |
| 40131..132 | Read Only | LONG | --- | Accumulator | 0 |
| 40133..134 | R/W | LONG | --- | User Register 1 | 1 |
| 40135..136 | R/W | LONG | --- | User Register 2 | 2 |
| 40137..138 | R/W | LONG | --- | User Register 3 | 3 |

| 11.5.1 M56S Series General Purpose Registers | | | | | |
|--|--------|-----------|-------|------------------|--------------|
| Register | Access | Data Type | Units | Description | SCL Register |
| 40139..140 | R/W | LONG | --- | User Register 4 | 4 |
| 40141..142 | R/W | LONG | --- | User Register 5 | 5 |
| 40143..144 | R/W | LONG | --- | User Register 6 | 6 |
| 40145..146 | R/W | LONG | --- | User Register 7 | 7 |
| 40147..148 | R/W | LONG | --- | User Register 8 | 8 |
| 40149..150 | R/W | LONG | --- | User Register 9 | 9 |
| 40151..152 | R/W | LONG | --- | User Register 10 | : |
| 40153..154 | R/W | LONG | --- | User Register 11 | ; |
| 40155..156 | R/W | LONG | --- | User Register 12 | < |
| 40157..158 | R/W | LONG | --- | User Register 13 | = |
| 40159..160 | R/W | LONG | --- | User Register 14 | > |
| 40161..162 | R/W | LONG | --- | User Register 15 | ? |
| 40163..164 | R/W | LONG | --- | User Register 16 | @ |
| 40165..166 | R/W | LONG | --- | User Register 17 | [|
| 40167..168 | R/W | LONG | --- | User Register 18 | \ |
| 40169..170 | R/W | LONG | --- | User Register 19 |] |
| 40171..172 | R/W | LONG | --- | User Register 20 | ^ |
| 40173..174 | R/W | LONG | --- | User Register 21 | _ |
| 40175..176 | R/W | LONG | --- | User Register 22 | ` |

11.5.2 M56S Series—P0 Group (PID)

| 11.5.2 M56S Series—P0 Group (PID) | | | | | | |
|-----------------------------------|--------|-----------|-------|----------------|---|--------------|
| Register | Access | Data Type | Units | Range | Description | SCL Register |
| 40177..178 | R/W | LONG | --- | 0 ~ 2 | Tuning Mode Selection (UM) | |
| 40179..180 | R/W | LONG | --- | 0 ~ 10 | Load Type (LY) | |
| 40181..182 | R/W | LONG | --- | 0 ~ 100 | Inertia Ratio (NR) | |
| 40183..184 | R/W | LONG | --- | 1 ~ 20 | 1st Mechanical Stiffness Level (Kg) | |
| 40185..186 | R/W | LONG | --- | 1 ~ 20 | 2nd Mechanical Stiffness Level (KX) | |
| 40187..188 | R/W | LONG | 0.1Hz | 0 ~ 20000 | 1st Position Loop Gain (KP) | |
| 40189..190 | R/W | LONG | ms | 0 ~ 30000 | 1st Position Loop Integral Time Constant (KI) | |
| 40191..192 | R/W | LONG | ms | 0 ~ 30000 | 1st Position Loop Derivative Time Constant (KD) | |
| 40193..194 | R/W | LONG | 0.1Hz | 0 ~ 40000 | 1st Position Loop Derivative Filter (KE) | |
| 40195..196 | R/W | LONG | 0.01% | -30000 ~ 30000 | Velocity Feedforward Gain (KL) | |
| 40197..198 | R/W | LONG | 0.1Hz | 0 ~ 40000 | Velocity Feedforward Filter (KR) | |
| 40199..200 | R/W | LONG | 0.01% | -30000 ~ 30000 | 1st Velocity Command Gain (KF) | |
| 40201..202 | R/W | LONG | 0.1Hz | 0 ~ 30000 | 1st Velocity Loop Gain (VP) | |
| 40203..204 | R/W | LONG | ms | 0 ~ 30000 | 1st Velocity Loop Integral Time Constant (VI) | |
| 40205..206 | R/W | LONG | 0.01% | 0 ~ 20000 | Acceleration Feedforward Gain (KK) | |
| 40207..208 | R/W | LONG | 0.1Hz | 0 ~ 40000 | Acceleration Feedforward Filter (KT) | |
| 40209..210 | R/W | LONG | 0.1Hz | 0 ~ 40000 | 1st Torque Command Filter (KC) | |
| 40211..212 | R/W | LONG | 0.1Hz | 0 ~ 20000 | 2nd Position Loop Gain (UP) | |
| 40213..214 | R/W | LONG | ms | 0 ~ 30000 | 2nd Position Loop Integral Time Constant (UI) | |

11.5.2 M56S Series—P0 Group (PID)

| Register | Access | Data Type | Units | Range | Description | SCL Register |
|------------|--------|-----------|--------|----------------|--|--------------|
| 40215..216 | R/W | LONG | ms | 0 ~ 30000 | 2nd Position Loop Derivative Time Constant (UD) | |
| 40217..218 | R/W | LONG | 0.1Hz | 0 ~ 40000 | 2nd Position Loop Derivative Filter (UE) | |
| 40219..220 | R/W | LONG | 0.01% | -30000 ~ 30000 | 2nd Velocity Command Gain (UF) | |
| 40221..222 | R/W | LONG | 0.1Hz | 0 ~ 30000 | 2nd Velocity Loop Gain (UV) | |
| 40223..224 | R/W | LONG | ms | 0 ~ 30000 | 2nd Velocity Loop Integral Time Constant (UG) | |
| 40225..226 | R/W | LONG | 0.1Hz | 0 ~ 40000 | 2nd Torque Command Filter (UC) | |
| 40227..228 | R/W | LONG | 0.1Hz | 0 ~ 20000 | Full Closed-loop Position Loop Gain (XP) | |
| 40229..230 | R/W | LONG | ms | 0 ~ 30000 | Full Closed-loop Position Loop Integral Time Constant (XI) | |
| 40231..232 | R/W | LONG | ms | 0 ~ 32767 | Full Closed-loop Position Loop Derivative Time Constant (XD) | |
| 40233..234 | R/W | LONG | 0.1Hz | 0 ~ 40000 | Full Closed-loop Position Loop Derivative Filter (XE) | |
| 40235..236 | R/W | LONG | 0.01% | -30000 ~ 30000 | Full Closed-loop Velocity Command Gain (XF) | |
| 40237..238 | R/W | LONG | 0.1Hz | 0 ~ 30000 | Full Closed-loop Velocity Loop Gain (XV) | |
| 40239..240 | R/W | LONG | ms | 0 ~ 30000 | Full Closed-loop Velocity Loop Integral Time Constant (XG) | |
| 40241..242 | R/W | LONG | 0.1Hz | 0 ~ 40000 | Full Closed-loop Torque Command Filter (XC) | |
| 40243..244 | R/W | LONG | --- | 0 ~ 4 | Automatic Gain Switching Method (SD) | O (Capital) |
| 40245..246 | R/W | LONG | pulses | 0 ~ 2147483647 | Use Position Error as the Condition (PN) | |

11.5.2 M56S Series—P0 Group (PID)

| Register | Access | Data Type | Units | Range | Description | SCL Register |
|------------|--------|-----------|----------|-----------|---|--------------|
| 40247..248 | R/W | LONG | 1/240rps | 0 ~ 24000 | Use Actual Speed as the Condition (VN) | |
| 40249..250 | R/W | LONG | 0.1% | 0 ~ 3000 | Use Actual Torque as the Condition (TN) | |
| 40251..252 | R/W | LONG | ms | 0 ~ 10000 | Gain Switching Waiting Time 1 (SE1) | |
| 40253..254 | R/W | LONG | ms | 0 ~ 10000 | Gain Switching Waiting Time 2 (SE2) | |
| 40255..256 | R/W | LONG | --- | 0 ~ 3 | Velocity Feedback Filter (LR) | |
| 40257..258 | R/W | LONG | --- | 0 ~ 1 | Self-adapting Filter Switch (AE) | |
| 40259..260 | R/W | LONG | | | Reserved | |

11.5.3 M56S Series—P1 Group (Configuration)

| 11.5.3 M56S Series—P1 Group (Configuration) | | | | | | |
|---|--------|-----------|----------|----------------|---|--------------|
| Register | Access | Data Type | Units | Range | Description | SCL Register |
| 40261..262 | R/W | LONG | | | Reserved | |
| 40263..264 | R/W | LONG | --- | 1,2,7,11,15,21 | Main Control Mode (CM) | |
| 40265..266 | R/W | LONG | --- | 1,2,7,11,15,21 | Secondary Control Mode (CN) | |
| 40267..268 | R/W | LONG | --- | 8 ~ 10 | Operation Mode When Power-up (PM) | |
| 40269..270 | R/W | LONG | --- | 1 ~ 2 | Speed Control Clamp Mode (JM) | |
| 40271..272 | R/W | LONG | --- | 0 ~ 1 | Full Closed-loop Control Switch (XM) | |
| 40273..274 | R/W | LONG | 0.1% | -3000 ~ 3000 | Torque Command of Internal Torque Mode (GC) | G |
| 40275..276 | R/W | LONG | 0.1% | 0 ~ 3000 | 1st Torque Limit (CC) | |
| 40277..278 | R/W | LONG | 0.1% | 0 ~ 3000 | Target Value of Torque Arrival (CV) | |
| 40279..280 | R/W | LONG | 0.1% | 0 ~ 3000 | Torque Limit of Hardstop Homing (HC) | |
| 40281..282 | R/W | LONG | ms | 0 ~ 30000 | Current Foldback Continuous Time (CL) | |
| 40283..284 | R/W | LONG | --- | 0 ~ 5 | Torque Limit Method (LD) | |
| 40285..286 | R/W | LONG | --- | 0 ~ 1 | Rotational Direction Setup (RN) | |
| 40287..288 | R/W | LONG | | | Reserved | |
| 40289..290 | R/W | LONG | --- | 1 ~ 511 | Communication Protocol (PR) | |
| 40291..292 | R/W | LONG | ms | 0 ~ 20 | Transmit Delay (TD) | |
| 40293..294 | R/W | LONG | --- | 1 ~ 5 | RS-485 Baud Rate (BR) | |
| 40295..296 | R/W | LONG | --- | 0 ~ 32 | RS-485 Address (DA) | |
| 40297..298 | R/W | LONG | --- | 1 ~ 127 | Node ID (CO) | |
| 40299..300 | R/W | LONG | --- | 0 ~ 7 | CANopen Baud Rate | |
| 40301..302 | R/W | LONG | Ω | 10 ~ 32000 | Regeneration Resistor Value (ZR) | |

11.5.3 M56S Series—P1 Group (Configuration)

| Register | Access | Data Type | Units | Range | Description | SCL Register |
|------------|--------|-----------|-------|----------------|--|--------------|
| 40303..304 | R/W | LONG | W | 1 ~ 32000 | Regeneration Resistor Wattage (ZW) | |
| 40305..306 | R/W | LONG | ms | 0 ~ 8000 | Regeneration Resistor Time Constant (ZT) | |
| 40307..308 | R/W | LONG | --- | 0 ~ 1 | Keypad Setting Lock (PK) | |
| 40309..310 | R/W | LONG | --- | 0 ~ 20 | LED Default Display (DD) | |
| 40311..312 | R/W | LONG | --- | 0 ~ 4294967295 | Alarm Mask (MA) | |
| 40313..314 | R/W | LONG | 0.1% | 0 ~ 3000 | 2nd Torque Limit (CX) | |
| 40315..316 | R/W | LONG | 0.1% | 0 ~ 3000 | 3rd Torque Limit (CY) | |
| 40317..318 | R/W | LONG | 0.1% | 0 ~ 3000 | 4th Torque Limit (CZ) | |
| 40319..320 | R/W | LONG | ms | 0 ~ 30000 | Motor Stall Protection Time (HT) | |
| 40321..322 | R/W | LONG | --- | 0 ~ 5 | Dynamic Brake Sequence when Servo Off (YV) | |
| 40323..324 | R/W | LONG | --- | 0 ~ 3 | Dynamic Brake Sequence when Fault Occurs (YR) | |
| 40325..326 | R/W | LONG | ms | 0 ~ 30000 | Dynamic Brake Action Time during Deceleration of Servo Off (YM) | |
| 40327..328 | R/W | LONG | ms | 0 ~ 30000 | Dynamic Brake Action Time during Deceleration when Fault Occurs (YN) | |
| 40329..330 | R/W | LONG | --- | 0 ~ 1 | Main Power Phase Lost Detecting (OT) | |
| 40331..332 | R/W | LONG | 0.1% | 0 ~ 3000 | Current Ramp Limit (RT) | |
| 40333 | R/W | SHORT | | | Reserved | |
| 40334 | R/W | SHORT | | | Reserved | |

11.5.4 M56S Series—P2 Group (Trajectory)

| 11.5.4 M56S Series—P2 Group (Trajectory) | | | | | | |
|--|--------|-----------|------------|-----------------------------|--|--------------|
| Register | Access | Data Type | Units | Range | Description | SCL Register |
| 40335..336 | R/W | LONG | 1/6(rps/s) | 1 ~ 30000 | Max Brake Deceleration (AM) | |
| 40337..338 | R/W | LONG | 1/240rps | 0 ~ 24000 | Max Velocity (VM) | M |
| 40339..340 | R/W | LONG | 1/6(rps/s) | 1 ~ 30000 | Jog Accel (JA) | K (Capital) |
| 40341..342 | R/W | LONG | 1/6(rps/s) | 1 ~ 30000 | Jog Decel (JL) | L |
| 40343..344 | R/W | LONG | 1/240rps | -24000 ~ 24000 | Jog Velocity (JS) | J |
| 40345..346 | R/W | LONG | 1/6(rps/s) | 1 ~ 30000 | Point-to-Point Accel (AC) | A |
| 40347..348 | R/W | LONG | 1/6(rps/s) | 1 ~ 30000 | Point-to-Point Decel (DE) | B |
| 40349..350 | R/W | LONG | 1/240rps | 0 ~ 24000 | Point-to-Point Velocity (VE) | V (Capital) |
| 40351..352 | R/W | LONG | pulses | -2147483647 ~ 2147483647 | Point-to-Point Distance (DI) | D |
| 40353..354 | R/W | LONG | pulses | -2147483647 ~ 2147483647 | Point-to-Point Change Distance (DC) | C (Capital) |
| 40355..356 | R/W | LONG | 1/240rps | 0 ~ 24000 | Point-to-Point Change Velocity (VC) | U (Capital) |
| 40357..358 | R/W | LONG | 1/6(rps/s) | 1 ~ 30000 | Homing Accel /Decel (HA1) | |
| 40359..360 | R/W | LONG | | | Reserved | |
| 40361..362 | R/W | LONG | 1/240rps | 0 ~ 24000 | Homing Velocity 1 (HV1) | |
| 40363..364 | R/W | LONG | 1/240rps | 0 ~ 24000 | Homing Velocity 2 (HV2) | |
| 40365..366 | R/W | LONG | pulses | -2147483647 ~ 2147483647 | Homing Offset (HO) | |
| 40367..368 | R/W | LONG | 1/240rps | -24000 ~ 24000 | Internal Velocity Control: Speed 1 (JC1) | |
| 40369..370 | R/W | LONG | 1/240rps | -24000 ~ 24000 | Internal Velocity Control: Speed 2 (JC2) | |
| 40371..372 | R/W | LONG | 1/240rps | -24000 ~ 24000 | Internal Velocity Control: Speed 3 (JC3) | |

11.5.4 M56S Series—P2 Group (Trajectory)

| Register | Access | Data Type | Units | Range | Description | SCL Register |
|------------|--------|-----------|----------|----------------|--|--------------|
| 40373..374 | R/W | LONG | 1/240rps | -24000 ~ 24000 | Internal Velocity Control: Speed 4 (JC4) | |
| 40375..376 | R/W | LONG | 1/240rps | -24000 ~ 24000 | Internal Velocity Control: Speed 5 (JC5) | |
| 40377..378 | R/W | LONG | 1/240rps | -24000 ~ 24000 | Internal Velocity Control: Speed 6 (JC6) | |
| 40379..380 | R/W | LONG | 1/240rps | -24000 ~ 24000 | Internal Velocity Control: Speed 7 (JC7) | |
| 40381..382 | R/W | LONG | 1/240rps | -24000 ~ 24000 | Internal Velocity Control: Speed 8 (JC8) | |
| 40383..384 | R/W | LONG | ms | 0 ~ 125 | Jerk Time (JT) | |
| 40385..386 | R/W | LONG | ms | 0 ~ 1000 | Jerk Filter (KJ) | |
| 40387..388 | R/W | LONG | ms | 0 ~ 125 | Interpolation Filter (FF) | |
| 40389..390 | R/W | LONG | 1/240rps | 0 ~ 24000 | Velocity Limit of Torque Mode (VT) | |
| 40391 | R/W | SHORT | | | Reserved | |
| 40392 | R/W | SHORT | | | Reserved | |
| 40393 | R/W | SHORT | | | Reserved | |
| 40394 | R/W | SHORT | | | Reserved | |
| 40395 | R/W | SHORT | | | Reserved | |
| 40396 | R/W | SHORT | | | Reserved | |
| 40397 | R/W | SHORT | | | Reserved | |
| 40398 | R/W | SHORT | | | Reserved | |

11.5.5 M56S Series—P3 Group(Encoder & Step/Dir)

| 11.5.5 M56S Series—P3 Group(Encoder & Step/Dir) | | | | | | |
|---|--------|-----------|-------------|----------------|--|--------------|
| Register | Access | Data Type | Units | Range | Description | SCL Register |
| 40399..400 | R/W | LONG | --- | 1 ~ 2147483647 | Electronic Gear Ratio – Numerator (EN) | |
| 40401..402 | R/W | LONG | --- | 1 ~ 2147483647 | Electronic Gear Ratio - Denominator (EU) | |
| 40403..404 | R/W | LONG | 0.1 μ s | 0 ~ 32000 | Pulse Input Noise Filter (SZ) | |
| 40405..406 | R/W | LONG | --- | 0 ~ 31 | Pulse Input Setting (PT) | |
| 40407..408 | R/W | LONG | pulses | 0 ~ 2147483647 | Position Error Limit (PF) | |
| 40409..410 | R/W | LONG | pulses/rev | 200 ~ 131072 | Command Pulses per Revolution (EG) | R |
| 40411..412 | R/W | LONG | --- | 0 ~ 1 | Second Encoder Direction (PV) | |
| 40413..414 | R/W | LONG | | | Reserved | |
| 40415..416 | R/W | LONG | | | Reserved | |
| 40417..418 | R/W | LONG | rev | 1 ~ 100 | Hybrid Deviation Clear Setting (XT) | |
| 40419..420 | R/W | LONG | pulses | 0 ~ 2147483647 | Hybrid Deviation Fault Threshold (XO) | |
| 40421..422 | R/W | LONG | pulses/rev | 200 ~ 100000 | Second Encoder Resolution (XR) | |
| 40423..424 | R/W | LONG | --- | 0 ~ 256 | Pulses Output Mode (PO) | |
| 40425..426 | R/W | LONG | --- | 0 ~ 13107200 | Pulse Output Gear Ratio - Numerator (ON) | |
| 40427..428 | R/W | LONG | --- | 0 ~ 13107200 | Pulse Output Gear Ratio - Denominator (OD) | |
| 40429..430 | R/W | LONG | --- | 0 ~ 3 | Absolute Encoder Usage (ES) | |
| 40431..432 | R/W | LONG | --- | 0 ~ 1 | Electronic Gearing Switch (PU) | |
| 40433 | R/W | SHORT | | | Reserved | |
| 40434 | R/W | SHORT | | | Reserved | |
| 40435 | R/W | SHORT | | | Reserved | |
| 40436 | R/W | SHORT | | | Reserved | |
| 40437 | R/W | SHORT | | | Reserved | |
| 40438 | R/W | SHORT | | | Reserved | |
| 40439 | R/W | SHORT | | | Reserved | |
| 40440 | R/W | SHORT | | | Reserved | |

11.5.6 M56S Series—P4 Group(Analog)

| 11.5.6 M56S Series—P4 Group(Analog) | | | | | | |
|-------------------------------------|--------|-----------|----------|----------------|--|--------------|
| Register | Access | Data Type | Units | Range | Description | SCL Register |
| 40441..442 | R/W | LONG | | | Reserved | |
| 40443..444 | R/W | LONG | 1/240rps | 0 ~ 24000 | Analog Input Velocity Gain (AG) | |
| 40445..446 | R/W | LONG | 0.1% | 0 ~ 3000 | Analog Input Torque Gain (AN) | |
| 40447..448 | R/W | LONG | mv | -10000 ~ 10000 | Analog Input 1 Offset (AV1) | |
| 40449..450 | R/W | LONG | mv | -10000 ~ 10000 | Analog Input 2 Offset (AV2) | |
| 40451..452 | R/W | LONG | mv | 0 ~ 255 | Analog Input 1 Deadband (AD1) | |
| 40453..454 | R/W | LONG | mv | 0 ~ 255 | Analog Input 2 Deadband (AD2) | |
| 40455..456 | R/W | LONG | 0.1Hz | 1 ~ 20000 | Analog Input 1 Filter (AF1) | |
| 40457..458 | R/W | LONG | 0.1Hz | 1 ~ 20000 | Analog Input 2 Filter (AF2) | |
| 40459..460 | R/W | LONG | mv | -10000 ~ 10000 | Analog Input 1 Threshold (AT1) | |
| 40461..462 | R/W | LONG | mv | -10000 ~ 10000 | Analog Input 2 Threshold (AT2) | |
| 40463..464 | R/W | LONG | --- | 0 ~ 1 | Velocity Limit Setting of Torque Control (FA1) | |
| 40465..466 | R/W | LONG | | | Reserved | |
| 40467..468 | R/W | LONG | | | Reserved | |
| 40469..470 | R/W | LONG | | | Reserved | |
| 40471..472 | R/W | LONG | | | Reserved | |
| 40473..474 | R/W | LONG | --- | 1 ~ 32000 | Analog Output 1 Scale (OS1) | |
| 40475..476 | R/W | LONG | --- | 1 ~ 32000 | Analog Output 2 Scale (OS2) | |
| 40477..478 | R/W | LONG | --- | 0 ~ 5 | Analog Output 1 Function (XA1) | |
| 40479..480 | R/W | LONG | --- | 0 ~ 5 | Analog Output 2 Function (XA2) | |
| 40481 | R/W | SHORT | | | Reserved | |
| 40482 | R/W | SHORT | | | Reserved | |
| 40483 | R/W | SHORT | | | Reserved | |
| 40484 | R/W | SHORT | | | Reserved | |
| 40485 | R/W | SHORT | | | Reserved | |

11.5.6 M56S Series—P4 Group(Analog)

| Register | Access | Data Type | Units | Range | Description | SCL Register |
|----------|--------|-----------|-------|-------|-------------|--------------|
| 40486 | R/W | SHORT | | | Reserved | |
| 40487 | R/W | SHORT | | | Reserved | |
| 40488 | R/W | SHORT | | | Reserved | |
| 40489 | R/W | SHORT | | | Reserved | |
| 40490 | R/W | SHORT | | | Reserved | |

11.5.7 M56S Series—P5 Group(I/O)

11.5.7 M56S Series—P5 Group(I/O)

| Register | Access | Data Type | Units | Range | Description | SCL Register |
|------------|--------|-----------|-------|--------|---------------------------------|--------------|
| 40491..492 | R/W | LONG | --- | 0 ~ 46 | Digital Input 1 Function (MU1) | |
| 40493..494 | R/W | LONG | --- | 0 ~ 46 | Digital Input 2 Function (MU2) | |
| 40495..496 | R/W | LONG | --- | 0 ~ 46 | Digital Input 3 Function (MU3) | |
| 40497..498 | R/W | LONG | --- | 0 ~ 46 | Digital Input 4 Function (MU4) | |
| 40499..500 | R/W | LONG | --- | 0 ~ 46 | Digital Input 5 Function (MU5) | |
| 40501..502 | R/W | LONG | --- | 0 ~ 46 | Digital Input 6 Function (MU6) | |
| 40503..504 | R/W | LONG | --- | 0 ~ 46 | Digital Input 7 Function (MU7) | |
| 40505..506 | R/W | LONG | --- | 0 ~ 46 | Digital Input 8 Function (MU8) | |
| 40507..508 | R/W | LONG | --- | 0 ~ 46 | Digital Input 9 Function (MU9) | |
| 40509..510 | R/W | LONG | --- | 0 ~ 46 | Digital Input 10 Function (MUA) | |
| 40511 | R/W | SHORT | | | Reserved | |
| 40512 | R/W | SHORT | | | Reserved | |
| 40513 | R/W | SHORT | | | Reserved | |
| 40514 | R/W | SHORT | | | Reserved | |
| 40515 | R/W | SHORT | | | Reserved | |
| 40516 | R/W | SHORT | | | Reserved | |
| 40517 | R/W | SHORT | | | Reserved | |

11.5.7 M56S Series—P5 Group(I/O)

| Register | Access | Data Type | Units | Range | Description | SCL Register |
|------------|--------|-----------|-------|-----------|---|--------------|
| 40518 | R/W | SHORT | | | Reserved | |
| 40519..520 | R/W | LONG | --- | 0 ~ 36 | Digital Output 1 Function (MO1) | |
| 40521..522 | R/W | LONG | --- | 0 ~ 36 | Digital Output 2 Function (MO2) | |
| 40523..524 | R/W | LONG | --- | 0 ~ 36 | Digital Output 3 Function (MO3) | |
| 40525..526 | R/W | LONG | --- | 0 ~ 36 | Digital Output 4 Function (MO4) | |
| 40527..528 | R/W | LONG | --- | 0 ~ 36 | Digital Output 5 Function (MO5) | |
| 40529..530 | R/W | LONG | --- | 0 ~ 36 | Digital Output 6 Function (MO6) | |
| 40531 | R/W | SHORT | | | Reserved | |
| 40532 | R/W | SHORT | | | Reserved | |
| 40533 | R/W | SHORT | | | Reserved | |
| 40534 | R/W | SHORT | | | Reserved | |
| 40535 | R/W | SHORT | | | Reserved | |
| 40536 | R/W | SHORT | | | Reserved | |
| 40537 | R/W | SHORT | | | Reserved | |
| 40538 | R/W | SHORT | | | Reserved | |
| 40539..540 | R/W | LONG | ms | 0 ~ 32000 | Move Command Waiting Time When Brake Release (BD) | |
| 40541..542 | R/W | LONG | ms | 0 ~ 32000 | Servo-off Brake Engage Waiting Time (BE) | |
| 40543..544 | R/W | LONG | | | Reserved | |
| 40545..546 | R/W | LONG | --- | 0 ~ 10 | Home Sensor (HX) | |
| 40547..548 | R/W | LONG | ms | 0 ~ 8000 | Digital Input 1 Filter (FI1) | |
| 40549..550 | R/W | LONG | ms | 0 ~ 8000 | Digital Input 2 Filter (FI2) | |
| 40551..552 | R/W | LONG | ms | 0 ~ 8000 | Digital Input 3 Filter (FI3) | |
| 40553..554 | R/W | LONG | ms | 0 ~ 8000 | Digital Input 4 Filter (FI4) | |
| 40555..556 | R/W | LONG | ms | 0 ~ 8000 | Digital Input 5 Filter (FI5) | |
| 40557..558 | R/W | LONG | ms | 0 ~ 8000 | Digital Input 6 Filter(FI6) | |

| 11.5.7 M56S Series—P5 Group(I/O) | | | | | | |
|----------------------------------|--------|-----------|----------|--------------------------|---|--------------|
| Register | Access | Data Type | Units | Range | Description | SCL Register |
| 40559..560 | R/W | LONG | ms | 0 ~ 8000 | Digital Input 7 Filter (FI7) | |
| 40561..562 | R/W | LONG | ms | 0 ~ 8000 | Digital Input 8 Filter (FI8) | |
| 40563..564 | R/W | LONG | ms | 0 ~ 8000 | Digital Input 9 Filter (FI9) | |
| 40565..566 | R/W | LONG | ms | 0 ~ 8000 | Digital Input 10 Filter (FIA) | |
| 40567..568 | R/W | LONG | pulses | 0 ~ 2147483647 | Dynamic Follow Error Threshold (PL) | |
| 40569..570 | R/W | LONG | pulses | 0 ~ 32000 | In-position Output Threshold (PD) | |
| 40571..572 | R/W | LONG | ms | 0 ~ 32000 | Time Constant of Motion Output Condition (PE) | |
| 40573..574 | R/W | LONG | ms | 0 ~ 20000 | Pulse Complete Timing (TT) | |
| 40575..576 | R/W | LONG | 1/240rps | 24 ~ 480 | Zero Speed Width (ZV) | |
| 40577..578 | R/W | LONG | 1/240rps | 24 ~ 24000 | Speed Coincidence Width (VR) | |
| 40579..580 | R/W | LONG | 1/240rps | 0 ~ 24000 | Target Value of AT-speed (VV) | |
| 40581..582 | R/W | LONG | 0.1% | 0 ~ 3000 | Torque Arrival Width (TV) | |
| 40583..584 | R/W | LONG | pulses | -2147483647 ~ 2147483647 | Near Target Position (DG) | |
| 40585..586 | R/W | LONG | pulses | -2147483647 ~ 2147483647 | Positive Software Limit (LP) | |
| 40587..588 | R/W | LONG | pulses | -2147483647 ~ 2147483647 | Negative Software Limit (LM) | |
| 40589..590 | R/W | LONG | --- | -4 ~ 35 | Homing Method (HE) | |

11.6 Alarm Code and Status Code of M56S:

11.6.1 Servo M56S Drive Alarming Code (Main Code) Table

| Register | Bit | Explanation | Bit | Explanation |
|----------------|-----|------------------------------------|-----|---|
| 40001 40002 | 0 | Position Error out of Limit | 16 | Drive main Circuit Power Input Phase Loss |
| | 1 | CCW Direction Limit Prohibited | 17 | STO Prohibited |
| | 2 | CW Direction Limit Prohibited | 18 | Reserve |
| | 3 | Overtemperature | 19 | Motor Velocity exceeds Limit |
| | 4 | Internal Error | 20 | Drive under Voltage |
| | 5 | Power Voltage over Range | 21 | Emergency Stop |
| | 6 | Reserve | 22 | Second Encoder not connected |
| | 7 | Drive over Current | 23 | Full closed-loop Hybrid Deviation Over Limit |
| | 8 | Reserve | 24 | Absolute Encoder Battery under Voltage |
| | 9 | Motor Encoder not connected | 25 | Absolute Position Loss |
| | 10 | Abnormal Communication | 26 | Absolute Position Overflow |
| | 11 | Reserve | 27 | Reserve |
| | 12 | Release Failure | 28 | Absolute Encoder Multi-turn Error |
| | 13 | Motor heavy Load Protection | 29 | Abnormal Motor Action Protection |
| | 14 | Reserve | 30 | EtherCAT Communication Error |
| | 15 | Abnormal Start Alarm | 31 | Homing Parameter Configuration Error |

11.6.2 M56S Drive Alarming Code (auxiliary code) Table

| Register (40001..02) Bit | Explanation | Register (40067..68) Bit | Explanation |
|-----------------------------|---|-----------------------------|--|
| 3 | Overtemperature | 5 | Drive Processor over Temperature |
| | | 6 | Drive Power Module over Temperature |
| | | 7 | Motor over Temperature |
| 4 | Internal Error | 8 | Parameter read Failure |
| | | 9 | Inside Voltage Error |
| | | 10 | Reserve function and keep "0" |
| | | 11 | Reserve function and keep "0" |
| | | 12 | FPGA Error |
| | | 13 | Parameter Save Failure |
| | | 14 | Motor Encode Communication Error |
| 5 | Power Voltage over Scope | 15 | Drive over Voltage |
| | | 16 | Drive Low Voltage |
| 7 | Over-current | 2 | Low-end over Current |
| | | 3 | High-end over Current |
| | | 4 | Reading over Current |
| 15 | Abnormal Start Warning | 17 | The motor commands its operation when it is not enabled. |
| | | 18 | The motor commands its operation when it is not enabled. |
| | | 19 | I/O Signal Function Multiplex |
| 29 | Motor Movement Abnormal Protection | 24 | Motor Locked-rotor Protection |
| | | 25 | Motor Anti-collision Protection |

12 Appendix 1: LED Display character comparison table

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| A | b | C | d | E | F | G | H | · | J |
| A | B | C | D | E | F | G | H | I | J |
| K | L | M | N | O | P | Q | R | S | T |
| K | L | M | N | O | P | Q | R | S | T |
| U | v | W | X | Y | Z | | | | |
| U | V | W | X | Y | Z | | | | |

13 Contact Us



Customer Service Center

+86-400-820-9661

MOONS' Headquarter

168 Mingjia Road, Minhang District, Shanghai 201107, P.R. China

MOONS' Taicang

No. 18 Yingang Rd, Fuqiao Town, Taicang City Jiangsu Province, 215434, P.R. China

Domestic Office

Beijing

Room 1206, Jing Liang Mansion, No.16 Middle Road of East,3rd Ring, Chaoyang District, Beijing 100022, P.R. China

Qingdao

Room1913,Scientific and Technological Innovation Building,Floor19, No.171, ShanDong Road,Shibei District,QingDao, Shangdong Province, 266033, P.R. China

Xi'an

Room 1006, Tower D, Wangzuo International City, No.1 Tangyan Road, Xi'an, Shanxi Province, 710065, P.R. China

Wuhan

Room 3001, World Trade Tower, No.686 Jiefang Avenue, Jianghan District, Wuhan, Hubei Province, 430022, P.R. China

Hefei

Room 1521, Building B, CBC Tuoji Plaza, Jinggang Road, Shushan District, Hefei, Anhui Province, 230088, P.R. China

Nanjing

Room 1101-1102, Building 2, New Town Development Center, No.126 Tianyuan Road, Moling Street, Jiangning District, Jiangsu Province, China, 211106, P.R. China

Suzhou

Room 1103-1105, North Building 4, Huizu Plaza, 758 Nahuan East Rd, Gusu District, Suzhou, Jiangsu Province, 215007, P.R. China

Ningbo

Room 309, Tower B, Taifu Plaza, 565 Jiangjia Road, Jiangdong District, Ningbo, Zhejiang Province, 315040, P.R. China

Chengdu

Room 3907, Maoye Plaza, No.19, Dongyu Street, Jinjiang Distrit, Chengdu Sichuan Province, 610066, P.R. China

Chongqing

Room 2108, South yuanzhu Building 20, No.18 Fuquan Rd., Jiangbei District, Chongqing, 400000, P.R. China

Guangzhou

Room 4006, Tower B, China Shine Plaza, 9 Linhe Xi Road, Tianhe District, Guangzhou, Guangdong Province, 510610, P.R. China

Dongguan

Room 1106-1207, Building 5, Linrunzhigu, No.1 RD 5th Rd, Songshan Lake, Dongguan, Guangdong Province, 523000, P.R. China

Shenzhen

Room 3901, Building A, Zhongguan Times Square, No 4168 Liuxian Avenue, Nanshan District, Shenzhen, Guangdong Province, 518000, P.R. China

North America

USA

MOONS' INDUSTRIES (AMERICA), INC. (Chicago)
1113 North Prospect Avenue, Itasca, IL 60143, USA

MOONS' INDUSTRIES (AMERICA), INC. (Boston)
36 Cordage Park Circle, Suite 310 Plymouth, MA 02360, USA

APPLIED MOTION PRODUCTS, INC. (Morgan Hill)
18645 Madrone Parkway, Morgan Hill, CA 95037, USA

LIN ENGINEERING, Inc. (Morgan Hill)
16245 Vineyard Blvd., Morgan Hill, CA 95037, USA

Europe

Italy

MOONS' INDUSTRIES (EUROPE) HEAD QUARTER S.R.L.
Via Torri Bianche n.1 20871 Vimercate(MB) Italy

Germany

AMP & MOONS' AUTOMATION (GERMANY) GMBH
Kaiserhofstr. 15
60313 Frankfurt am Main Germany

Switzerland

TECHNOSOFT SA
Avenue des Alpes 20
CH 2000 Neuchâtel Switzerland

U.K

MOONS' INDUSTRIES (UK), LIMITED
Reading, Berkshire, UK

Asia

Singapore

MOONS' INDUSTRIES (SOUTH-EAST ASIA) PTE. LTD.
33 Ubi Avenue 3 #08-23 Vertex Singapore 408868

Japan

MOONS' INDUSTRIES JAPAN CO., LTD.
Room 602, 6F, Shin Yokohama Koushin Building,
2-12-1, Shin-Yokohama, Kohoku-ku, Yokohama, Kanagawa,
Japan 222-0033

India

MOONS' INTELLIGENT MOTION SYSTEM INDIA PVT. LTD.
Room. 908, 9th Floor, Amar Business Park,
Tal. Havelli, Baner, Pune, India 411045

Vietnam

MOONS' VIETNAM MANUFACTURING SITE
Factory C1&D1, Lot IN3-11*A, VSIP Hai Phong Industrial Park in Dinh Vu – Cat Hai Economic Zone, Lap Le Commune, Thuy Nguyen District, Hai Phong City, Vietnam



<https://www.moonsindustries.com/>

E-mail: ama-info@moons.com.cn

MOONS'
moving in better ways

- All the specifications, technical parameters of the products provided in this catalog are for reference only, subject to change without notice. For the latest details, please contact our sales department.