



### Lubrificazione

### Lubrication




CM	Quantità di olio (litri) / Oil quantity (litres)					
	B3	B8	B6	B7	V5	V6
026	0.015					
030	0.03					
040	0.07					
050	0.1					
063	0.25					
075	0.4					
090	0.85					
110	1.5					
130	4.5	3.3	3.5	3.5	4.5	3.3

Lubrificati a vita  
Life lubrication




CMP	Quantità di olio (litri) / Oil quantity (litres)					
	B3	B8	B6	B7	V5	V6
056/030	0.03					
056/040 - 063/040	0.07					
063/050 - 071/050	0.1					
063/063 - 071/063 - 080/063	0.25					
071/075 - 080/075 - 090/075	0.4					
071/090 - 080/090 - 090/090	0.85					
080/110 - 090/110	1.5					
080/130 - 090/130	4.5	3.3	3.5	3.5	4.5	3.3

Lubrificati a vita  
Life lubrication




CMP				
056/030 056/040	063/040 063/050 063/063	071/050 071/063 071/075 071/090	080/063 080/075 080/090 080/110 080/130	090/075 090/090 090/110 090/130
Lubrificazione a vita Life lubricated				


### Posizioni di montaggio / Mounting positions




**B3**  
(standard)




**B8**




**B6**



**B7**



**V5**



**V6**