



\* ALL DIGITAL INPUTS CAN BE SET AS PNP/NPN INPUTS BY SOFTWARE  
 \* FOR ALL AVAILABLE OPTIONS CHECK THE USER MANUAL OF THE DRIVE

<b>iPOS4808 BX-CAT</b>		<b>P/N: P027.214.E221</b>	
Copyright © Technosoft 2015. All rights reserved.			
<b>iPOS4808 BX-EtherCAT - Electrical Connection Diagram</b>			
Title			
Size <b>A4</b>	Document Number: P091.027.BX-ECAT.CDG.0815	Author: EP	Rev <b>C</b>