

Contents

| 1 | Intro | duction | 3 |
|---|-------|--|----|
| | 1.1 | Features | 3 |
| | 1.2 | Block diagram | 4 |
| 2 | Mou | Inting the Drive | 4 |
| 3 | Con | nections | 5 |
| | 3.1 | Connecting to Power | 6 |
| | 3.3 | Connecting the Inputs and Outputs | 8 |
| | | 3.3.1 Step & Direction Inputs | 8 |
| | | 3.3.2 EN input | 9 |
| | | 3.3.3 Fault Output | 10 |
| 4 | Swit | ch Selection | 11 |
| | 4.1 | Microstep Resolution | 11 |
| | 4.2 | Running Current | 12 |
| | 4.3 | Idle Current | 12 |
| | 4.4 | Step Input Signal Filter | 12 |
| | 4.5 | Anti Resonance | 12 |
| | 4.6 | Step Smoothing Filter | 13 |
| | 4.7 | Self Test | 13 |
| | 4.8 | Step/Direction Mode and CW/CCW Mode Jumper | 13 |
| 5 | Moto | or selection | 14 |
| | 5.1 | Recommended motors | 15 |
| | 5.2 | Torque-Speed Curves | 15 |
| 6 | Erro | r Codes | 16 |
| 7 | Refe | erence Materials | 17 |
| | 7.1 | Mechanical Outline | 17 |
| | 7.2 | Specifications | 18 |
| | | 7.2.1 Electrical Specifications | 18 |
| | | 7.2.2 Environmental Specifications | 18 |
| 8 | Con | tacting MOONS' | 19 |

1 Introduction

Thank you for selecting the MOONS' SRAC2 Step Motor Drive. The SRAC2 series AC input drives are based on advanced digital current control technology and provide high torque, low noise and low vibration. Many of the operational paramteres are switch selectable. We hope our dedication to performance, quality and economy will make your motion control project successful.

1.1 Features

- · Advanced digital current control provides excellent high speed torque
- Auto Setup measures motor parameters and configures motor current control and antiresonance gain settings
- Uses universal AC input 80 to 265 VAC, AC Input Voltage must be selected by switch
- Speed Range up to 50 rps
- Microstep Resolution switch selectable, 16 settings: 200, 400, 800, 1600, 3200, 6400, 12800, 25600, 1000, 2000, 4000, 5000, 8000, 10000, 20000, 25000 steps/rev
- Running Current peak setting, switch selectable, 8 settings: 0.6A, 0.8A, 1.0A, 1.2A, 1.6A, 1.8A, 2.0A, 2.5A.
- Idle Current automatic reduction of running current 1 second after the motor stops, switch selectable, 2 settings: 50%, 90% of running current
- Anti Resonance raises the system-damping ratio to eliminate midrange instability and allow stable operation throughout the speed range of the motor, switch selectable, 2 settings for low to high inertia loads
- Control Modes Step/Direction pulse input or CW/CCW pulse input, internal jumper switch selectable
- Input Signal Filter filters out unwanted noise that can cause extra steps, switch selectable, 2MHz or 150KHz
- Step Smoothing Filter (Microstep Emulation) performs high resolution stepping by synthesizing coarse steps into fine micro-steps, switch selectable, ON or OFF
- · Self Test performs a1 rev, 0.5RPS, CW/CCW move test, switch selectable, ON or OFF
- Motor Selection a 16 bit rotary switch is used to select the desired motor database which is pre-loaded at the Factory



1.2 Block diagram



2 Mounting the Drive

The SRAC2 drive can be mounted only on the narrow side of the chassis. M4 screws should be used in the two holes at the back of the drive.

The amplifiers in the drive generate heat. To operate the drive continuously at maximum power forced air cooling, as from a fan, should be provided.

Never use the drive in a space where there is no air flow or where other devices can cause the surrounding air to be more than 40 °C. Never put the drive where it can get wet or where metal particles can fall into it.



Never use the drive in a space where there is no air flow or where other devices can cause the surrounding air to be more than 40 °C Never put the drive where it can get wet or where metal particles can fall into it

3 Connections

To use the SRAC2 Step Drive, the following items are needed:

- Universal AC input of 80 to 265 VAC
- Pulse & Direction signal
- A compatible step motor
- · AC input voltage must be selected by switch



SRAC2 Wiring Diagram

B-

Blue

3.1 Connecting to Power

Use the supplied connector to connect to the AC supply according to the diagram below. Use 16 AWG wire for Line (L) and Neutral (N). Use 14 AWG for Earth Ground (G).



AC input voltage must be **selected by switch.Check** input voltage avoiding damage **before power on!**



80Vac<Input AC Voltage<135Vac: set the switch on 115V Status 135Vac<Input AC Voltage<265Vac: set the switch on 230V Status

The SRAC2 contains an internal 5A fast acting fuse.



Care should always be taken when working with high voltages.

3.2 Connecting to a Motor



Motor connections should be made according to the following diagrams.



MOONS'





3.3 Connecting the Inputs and Outputs

3.3.1 Step & Direction Inputs

The SRAC2 Step Drive has two high speed optically isolated inputs called STEP and DIR. They accept 5 to 24 volt single-ended or differential signals, up to 2MHz. The maximum voltage that can be applied to the input is 28V.

The motor executes one step when the STEP input closes.

The direction of rotation is controlled by the DIR input state. A closed input (logic "0") will result in clockwise rotation, and an open input (logic "1") will result in counterclockwise rotation.



Connecting to Indexer with Sinking Outputs



Connecting to Indexer with Sourcing Outputs



Connecting to Indexer with Differential Outputs Many high-speed indexers have differential outputs

3.3.2 EN input

The EN input enables or disables the drive amplifier. It is an optically isolated input that accepts a 5 to 24 volt single-ended or differential signal. The maximum voltage that can be applied to the input is 28V.

When EN input is closed, the driver amplifier is deactivated, all the MOSFETs will shut down, and the motor will be free. When EN input is open, the drive is activated.

When the drive has encountered an error and the fault is removed from the system, a falling signal into the EN input will reset the error status and activate the drive amplifier again.



Connecting the Input to a Switch or Relay



Connecting the Input to Sinking Outputs



Connecting the Input to Sourcing Outputs

3.3.3 Fault Output

The FAULT Output is optically isolated. The maximum collector current is 100mA, and the maximum collector to emitter voltage is 30 volts. The output can be wired to sink or source current.

When drive is working normally, the output is open. When the drive encounters an error, the output closes.



4 Switch Selection

Many of the operational parameters of the SRAC2 can be set or changed by position switches - either by a single switch or a combination of ON/OFF settings of 2 or more switches.



4.1 Microstep Resolution

The microstep resolution is set by the SW1, SW2, SW3 and SW4 switches. There are 16 settings.

| Microstep(steps/rev) | SW1 | SW2 | SW3 | SW4 |
|----------------------|-----|-----|-----|-----|
| 200 | ON | ON | ON | ON |
| 400 | OFF | ON | ON | ON |
| 800 | ON | OFF | ON | ON |
| 1600 | OFF | OFF | ON | ON |
| 3200 | ON | ON | OFF | ON |
| 6400 | OFF | ON | OFF | ON |
| 12800 | ON | OFF | OFF | ON |
| 25600 | OFF | OFF | OFF | ON |
| 1000 | ON | ON | ON | OFF |
| 2000 | OFF | ON | ON | OFF |
| 4000 | ON | OFF | ON | OFF |
| 5000 | OFF | OFF | ON | OFF |
| 8000 | ON | ON | OFF | OFF |
| 10000 | OFF | ON | OFF | OFF |
| 20000 | ON | OFF | OFF | OFF |
| 25000 | OFF | OFF | OFF | OFF |



4.2 Running Current

The output current is set by the SW5, SW6 and SW7 switches. There are 8 settings.

| Current (Peak) | SW5 | SW6 | SW7 |
|----------------|-----|-----|-----|
| 0.6A | ON | ON | ON |
| 0.8A | OFF | ON | ON |
| 1.0A | ON | OFF | ON |
| 1.2A | OFF | OFF | ON |
| 1.6A | ON | ON | OFF |
| 1.8A | OFF | ON | OFF |
| 2.0A | ON | OFF | OFF |
| 2.5A | OFF | OFF | OFF |



4.3 Idle Current

The running current of the SRAC2 drive is automatically reduced whenever the motor isn't moving. The **SW8** switches control the percentage of the running current the idle current is reduced to. The 90% setting is useful when a high holding torque is required. To

| Idle | SW8 |
|------|-----|
| 50% | ON |
| 90% | OFF |

minimize motor and drive heating it is highly recommended that the idle current reduction feature be set as low as the application can tolerate.

4.4 Step Input Signal Filter

SRAC2 Drive selects the digital signal filter frequency by **SW9**. Setting switch to "OFF" will select high frequency 2MHz, and setting switch to "ON" will select low frequency 150 KHz.

Note: The power must be cycled each time the position of SW9 is changed.

4.5 Anti Resonance

The **SW10** switches select the load inertia. There are 2 settings. The inertia selection can help the SRAC2 drive to calculate the current control parameter. If the load inertia is close to that of the

motor rotor, the low setting should be selected. If the load inertia is higher than that of the rotor, a proportionally higher setting should be selected.

| Option | SW10 | Inertia |
|--------|------|---------|
| 0 | ON | Low |
| 1 | OFF | High |

4.6 Step Smoothing Filter

Command signal smoothing can soften the effect of immediate changes in velocity and direction, making the motion of the motor less jerky. An added advantage is that it can reduce the wear on mechanical components. **SW11** selects this function - ON enables it, OFF disables it.

This function can cause a small delay in following the control signal, and it should be used with that in mind.

Note: The power must be cycled each time the position of SW11 is changed.

4.7 Self Test

Setting **SW12** to ON after the drive is powered up, will cause the drive to perform a Self Test move of 2 revolutions both CW and CCW at .5 rps. Setting SW16 to OFF will disable this feature.

4.8 Step/Direction Mode and CW/CCW Mode Jumper

Most indexers and motion controllers provide motion commands in the "Step and Direction" format. The Step signal pulses once for each motor step and the direction signal commands direction. However, a few PLCs use a different type of command signal: one signal pulses once for each desired step in the clockwise direction (called STEP CW), while a second signal pulses for counterclockwise motion (STE[CCW). The SRAC2 drives can accept this type of signal if you remove the drive cover and move jumper J10 from the "1-2" position to the "2-3" position CCW mode, the CW signal should be connected to the STEP input an DIR input.



1-2: Step & Direcion

2-3: Step CW & Step CCW

5 Motor selection

Each position of the 16-bit rotary switch selects a different motor, and automatically sets the configuration parameters in the drive. The SRAC2 drive comes programmed with up to 16 typical motors as factory defaults. Drives can be customized with specially selected motors when required.



When the motor selection is changed, the drive power supply will need to be cycled.

| BDC Position | Motor | Wiring | Up-limit current setting(A) |
|--------------|-------------|------------------|--------------------------------|
| 0 | Reserved | | None |
| 1 | Reserved | | None |
| 2 | Reserved | | None |
| 3 | Reserved | | None |
| 4 | Reserved | | None |
| 5 | Reserved | | None |
| 6 | Reserved | | None |
| 7 | AM23HS2459 | | 1.5 |
| 8 | AM23HS3466 | | 1.5 |
| 9 | AM24HS5411 | | 1.5 |
| A | AM34HD0802 | Series Connected | 2.5 |
| В | AM34HD1802 | Series Connected | 2.5 |
| С | AM34HD2805 | Series Connected | 2.5 |
| D | AM34HD4802 | Series Connected | 2.5 |
| E | AM34HD6801 | Series Connected | 2.5 |
| F | Motor_SRAC2 | | 2.5 |

| Model | Shaft | Wiring | Length"L" | Holding Torque | Current | Resistance | Rotor Inertia | Motor Mass | Dielectric |
|----------------|---|-----------|-----------|-------------------|---------|------------|------------------|---------------|----------------------|
| | | | mm | N∙m | A/Phase | Ω/Phase | g·cm² | Kg | Suengui |
| AM23HS2459-01 | Single Shaft | | 54 | 1.1 | | 16.6 | 260 | 0.6 | |
| AM23HS3466-01 | - Single Shalt | 4 Leads | 76 | 1.8 | 1 | 25.4 | 460 | 1.0 | |
| AM24HS5411-01N | Single Shaft | | 85 | 2.5 | | 15.4 | 900 | 1.4 | |
| AM34HD0802-01 | 134HD0802-01 Single Shaft 134HD0802-02 Double Shaft | | 66 F | 2 | | 2.4 | 1100 | 1.6 | |
| AM34HD0802-02 | | | 00.5 | 5 | | 3.4 | 1100 | 1.0 | |
| AM34HD4802-01 | Single Shaft | | 75 | 3.5 | 1 | 3.6 | 1350 | 1.9 | 1500V AC 1 minute |
| AM34HD1802-01 | Single Shaft | 8 Leads | 06 | F | 1.0 | 2.6 | 1050 | 0.7 | |
| AM34HD1802-03 | Double Shaft | Connected | 90 | 5 | 1.0 | 3.0 | 1650 | 2.7 | |
| AM34HD6801-01 | Single Shaft | | 115 | 6.5 | | 4 | 2400 | 3.5 | |
| AM34HD2805-01 | Single Shaft | 1 | 105.5 | 7.4 | 1 | 4.2 | 0750 | 2.0 | |
| AM34HD2805-03 | Double Shaft |] | 125.5 | | | 4.2 | 2750 | 3.0 | |

5.1 Recommended motors

Note: The "Drive Current Setting" shown here differs from the rated current of each motor because the rated current is RMS and the drive current setting is peak sine. If you are using a motor not listed here, for best results set the drive current at the motor's rated current x 1.2.

5.2 Torque-Speed Curves



6 Error Codes

The SRAC2 Drive has two LEDs to indicate status. When the motor is enabled the green LED flashes slowly, when the green LED is solid the motor is disabled. If the red LED flashes, an error has occurred. Errors are indicated by combinations of red and green flashes as shown below:

| Cod | Error | |
|-----|----------------|----------------------|
| | Solid green | Motor Disabled |
| | Flashing green | Motor Enabled |
| | 3 red, 1 green | Over Temperature |
| | 3 red, 2 green | Bad Internal Voltage |
| | 4 red, 1 green | Supply Voltage High |
| | 4 red, 2 green | Supply Voltage Low |
| | 5 red, 1 green | Over Current |
| | 5 red, 2 green | Excess Regen |
| | 6 red, 1 green | Open Motor Phase |

7 Reference Materials

7.1 Mechanical Outline



7.2 Specifications

7.2.1 Electrical Specifications

| Electrical Specifications | | | | | |
|---|------|-----------|------|------|--|
| Parameter | Min. | Тур. | Max. | Unit | |
| Power Supply | 80 | - | 265 | VAC | |
| Output Current (Peak) | 0.6 | - | 2.5 | А | |
| Step Frequency | 2 | - | 2M | Hz | |
| STEP Minimum Pulse Width Hi and Low | 250 | - | - | ns | |
| DIR Minimum Pulse Width | 62.5 | - | - | us | |
| Under Voltage Protection | - | 75*/135* | - | VAC | |
| Over Voltage Protection | - | 145*/295* | - | VAC | |
| STEP/DIR Input Signal Voltage | 4.0 | - | 28 | V | |
| OUT mxinmum output current | - | - | 100 | mA | |
| OUT maximum voltage | - | - | 30 | V | |
| * Note: when the input switch is on 115V status, under voltage protection point is 75VAC, over voltage protection point is 145VAC. when the input switch is on 230V status, under voltage protection point is 135VAC, over voltage protection point is 295VAC. | | | | | |

7.2.2 Environmental Specifications

| Environmental Specifications | | | | |
|------------------------------|---|--|--|--|
| Heat Sinking Method | Natural cooling or fan-forced cooling | | | |
| Surrounding Air Conditions | Avoid dust, oily mist and corrosive air | | | |
| Operating Temperature | 0 - 40°C (32 - 104°F) | | | |
| Maximum Ambient Humidity | 90% non-condensing | | | |
| Shock | 5.9m/s² maximum | | | |
| Storage Temperature | -10 - 70°C (14 - 158°F) | | | |

MOONS'

8 Contacting MOONS'



 Headquarters
 No. 168 Mingjia Road Industrial Park North Minhang District Shanghai 201107, P.R. China Tel: +86(0)21-52634688
 Fax: +86(0)21-62968682
 E-mail: info@moons.com.cn

MOONS' Industries (America), Inc.
 1113 North Prospect Avenue, Itasca, IL 60143 U.S.A.
 Tel: 001-630-833-5940
 Fax: 001-630-833-5946

MOONS' Industries (Europe) S.r.I. Via Torri Bianche n.1 20059 Vimercate(MB) Italy Tel: +39 039 62 60 521 Fax: +39 039 96 31 409

 MOONS' Industries (South-East Asia) Pte Ltd. 33 Ubi Avenue 3 #08-23 Vertex Singapore 408868 Tel: +65 6634 1198 Fax: +65 6634 1138

Shenzhen Branch Office
 Room 2209, 22/F, Kerry Center,No. 2008 Renminnan Road Shenzhen 518001 P. R.China
 Tel: +86 (0)755 25472080
 Fax: +86 (0)755 25472081

Beijing Branch Office
 Room 202, Unit 2, 7th Building, Huilongsen International Science & Technology Industry Park, No.99, Kechuang 14th Street, Beijing 101111 P. R.China
 Tel: +86 (0)10 59755578
 Fax: +86 (0)10 59755579

Qingdao Branch Office Room 10E, No.73 Wangjiao Mansion, mid. Hongkong Road Qingdao 266071 P. R.China Tel: +86 (0)532 85879625 Fax: +86 (0)532 85879512

Wuhan Branch Office

Room 3001, World Trade Tower, No.686 Jiefang Avenue, Jianghan District, Wuhan 430022 P.R.China Tel: +86 (0)27-85448742 Fax: +86 (0)27-85448355

Nanjing Branch Office

Room 302, Building A, Tengfei Creation Center,55 Jiangjun Avenue, Jiangning District, Nanjing 211100 P. R.China Tel: +86 (0)25 52785841 Fax: +86 (0)25 52785485

Chengdu Branch Office
 Room 1917, Western Tower, No.19,4th Section of South People Road,Wuhou District,Chengdu 610041
 P.R.China
 Tel: +86 (0)28-85268102
 Four +86 (0)28-85268102

Fax: +86 (0)28-85268103

Xi'an Branch Office

Room 1006, Block D, Wangzuo International City, No.1 Tangyan Road, Xi'an 710065 P.R. China Tel: +86 (0)29 81870400 Fax: +86 (0)29 81870340